

ARM DS-5

Version 5.13

EB RTSM Reference Guide



ARM DS-5

EB RTSM Reference Guide

Copyright © 2008-2010, 2012 ARM. All rights reserved.

Release Information

Change History

Description	Issue	Confidentiality	Change
August 2008	A	Non-Confidential	Release for RealView Development Suite v4.0 Professional, System Generator v4.0 SP1.
December 2008	B	Non-Confidential	Release for Fast Models 4.1. Added changes related to ARM_RTSM_PATH.
March 2009	C	Non-Confidential	Release for Fast Models 4.2. Minor changes to text. Added description for device-accurate-tlb parameter.
November 2009	D	Non-Confidential	Release for models provided by RealView Development Suite v4.0 Professional edition.
May 2010	E	Non-Confidential	Release for models provided by RealView Development Suite v4.1 Professional edition.
September 2010	F	Non-Confidential	Release for models provided by RealView Development Suite v4.1 SP1 Professional edition.
October 2012	G	Non-Confidential	Release for DS-5 version 5.12.
December 2012	H	Non-Confidential	Release for DS-5 version 5.13.

Proprietary Notice

Words and logos marked with or are registered trademarks or trademarks of ARM in the EU and other countries, except as otherwise stated below in this proprietary notice. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Where the term ARM is used it means “ARM or any of its subsidiaries as appropriate”.

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Product Status

The information in this document is final, that is for a developed product.

Web Address

<http://www.arm.com>

Contents

ARM DS-5 EB RTSM Reference Guide

	Preface	
	About this book	v
	Feedback	viii
Chapter 1	Introduction	
	1.1 Introduction to system models	1-2
	1.2 Introduction to the EB RTSM	1-3
Chapter 2	Getting Started with EB RTSMs	
	2.1 Starting an RTSM	2-2
	2.2 Configuring an RTSM	2-3
	2.3 Using the CLCD window	2-5
	2.4 Using Ethernet with an EB RTSM	2-8
	2.5 Using a terminal with a system model	2-10
	2.6 Virtual filesystem	2-12
	2.7 Using the VFS with a pre-built RTSM	2-14
Chapter 3	Programmer's Reference for the EB RTSMs	
	3.1 EB model memory map	3-2
	3.2 EB model configuration parameters	3-5
	3.3 EB RTSM baseboard parameters	3-6
	3.4 Ethernet parameters	3-9
	3.5 System controller parameters	3-10
	3.6 UART parameters	3-11
	3.7 Terminal parameters	3-12
	3.8 Visualization parameters	3-13
	3.9 RTSM_EB_Cortex-A8 CoreTile parameters	3-14
	3.10 Differences between the EB and CoreTile hardware and the models	3-15

Preface

This preface introduces the *EB RTSM Reference Guide*. It contains the following sections:

- *About this book* on page v
- *Feedback* on page viii.

About this book

This book describes how to configure and use the *Real-Time System Models* (RTSMs). The models let you run software applications on a virtual implementation of an *Emulation Baseboard* (EB) and an attached CoreTile.

The EB RTSMs are models of ARM® application processors.

Intended audience

This book has been written for experienced hardware and software developers to:

- understand how the RTSM examples are constructed
- use the RTSMs as part of a development environment to aid the development of products that use ARM architecture-based processors or peripherals.

Using this book

This book is organized into the following chapters:

Chapter 1 *Introduction*

Read this for an introduction to the general description of software models.

Chapter 2 *Getting Started with EB RTSMs*

Read this for a description of how to start using the EB RTSMs. It also contains information on the terminal and Ethernet features provided with the EB RTSMs.

Chapter 3 *Programmer's Reference for the EB RTSMs*

Read this for a description of the EB memory map and registers, in addition to information on model parameters and component configuration. It also describes differences between the EB RTSMs and their hardware equivalents.

Conventions

Conventions that this book can use are described in:

- *Conventions*
- *Signals* on page vi.

Typographical

The typographical conventions are:

<i>italic</i>	Highlights important notes, introduces special terminology, denotes internal cross-references, and citations.
bold	Highlights interface elements, such as menu names. Denotes signal names. Also used for terms in descriptive lists, where appropriate.
monospace	Denotes text that you can enter at the keyboard, such as commands, file and program names, and source code.
<u>monospace</u>	Denotes a permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.
<i>monospace italic</i>	Denotes arguments to monospace text where the argument is to be replaced by a specific value.

monospace bold	Denotes language keywords when used outside example code.
< and >	Enclose replaceable terms for assembler syntax where they appear in code or code fragments. For example: MRC p15, 0 <Rd>, <CRn>, <CRm>, <Opcode_2>

Signals

The signal conventions are:

Signal level	The level of an asserted signal depends on whether the signal is active-HIGH or active-LOW. Asserted means: <ul style="list-style-type: none"> HIGH for active-HIGH signals LOW for active-LOW signals.
Lower-case n	At the start or end of a signal name denotes an active-LOW signal.

Additional reading

This section lists publications by ARM and by third parties.

See Infocenter, <http://infocenter.arm.com> for access to ARM documentation.

ARM publications

This book contains information that is specific to this product. The following publications provide reference information about the ARM architecture:

- *AMBA® Specification* (ARM IHI 0011)
- *ARM Architecture Reference Manual* (ARM DDI 0100).

The following publications provide information about related ARM products and toolkits:

- *Component Architecture Debug Interface Developer Guide* (ARM DUI 0444)
- *Fast Models Reference Manual* (ARM DUI 0423)
- *Fast Models User Guide* (ARM DUI 0370)
- *Model Shell for Fast Models Reference Manual* (ARM DUI 0457).

The following publications provide information about ARM PrimeCell® and other peripheral or controller devices:

- *ARM® PrimeCell® UART (PL011) Technical Reference Manual* (ARM DDI 0183)
- *ARM® PrimeCell® Synchronous Serial Port Controller (PL022) Technical Reference Manual* (ARM DDI 0194)
- *ARM® PrimeCell® Real-Time Clock Controller (PL031) Technical Reference Manual* (ARM DDI 0224)
- *ARM® PrimeCell® Advanced Audio CODEC Interface (PL041) Technical Reference Manual* (ARM DDI 0173)
- *ARM® PrimeCell® GPIO (PL061) Technical Reference Manual* (ARM DDI 0190)
- *ARM® PrimeCell® DMA (PL081) Technical Reference Manual* (ARM DDI 0196)
- *ARM® PrimeCell® Synchronous Static Memory Controller (PL093) Technical Reference Manual* (ARM DDI 236)

- *ARM® PrimeCell® Color LCD Controller (PL111) Technical Reference Manual* (ARM DDI 0161)
- *ARM® PrimeCell® Smart Card Interface (PL131) Technical Reference Manual* (ARM DDI 0228)
- *ARM® PrimeCell® Multimedia Card Interface (PL180) Technical Reference Manual* (ARM DDI 0172)
- *ARM® PrimeCell® External Bus Interface (PL220) Technical Reference Manual* (ARM DDI 0249)
- *PrimeCell® Level 2 Cache Controller (PL310) Technical Reference Manual* (ARM DDI 0246)
- *ARM® Dynamic Memory Controller (PL340) Technical Reference Manual* (ARM DDI 0331)
- *PrimeCell® Generic Interrupt Controller (PL390) Technical Reference Manual* (ARM DDI 0416)
- *ARM® Dual-Timer Module (SP804) Technical Reference Manual* (ARM DDI 0271)
- *ARM® PrimeCell® Watchdog Controller (SP805) Technical Reference Manual* (ARM DDI 0270)
- *ARM® PrimeCell® System Controller (SP810) Technical Reference Manual* (ARM DDI 0254).

Other publications

This section lists relevant documents published by third parties. The following data sheets describe some of the integrated circuits or modules used on the EB:

- *CODEC with Sample Rate Conversion and 3D Sound (LM4549)* National Semiconductor, Santa Clara, CA.
- *MultiMedia Card Product Manual* SanDisk, Sunnyvale, CA.
- *Serially Programmable Clock Source (ICS307)*, ICS, San Jose, CA.
- *1.8 Volt Intel StrataFlash Wireless Memory with 3.0 Volt I/O (28F256L30B90)* Intel Corporation, Santa Clara, CA.
- *Three-In-One Fast Ethernet Controller (LAN91C111)* SMSC, Hauppauge, NY.

Feedback

ARM welcomes feedback on this product and its documentation.

Feedback on this product

If you have any comments or suggestions about this product, contact your supplier and give:

- The product name.
- The product revision or version.
- An explanation with as much information as you can provide. Include symptoms if appropriate.

Feedback on content

If you have any comments on content, send an e-mail to errata@arm.com. Give:

- the title
- the number, ARM DUI 0424H
- the page numbers to which your comments apply
- a concise explanation of your comments.

ARM also welcomes general suggestions for additions and improvements.

Chapter 1

Introduction

This chapter introduces the Real-Time System Models. It contains the following sections:

- *Introduction to system models* on page 1-2
- *Introduction to the EB RTSM* on page 1-3.

1.1 Introduction to system models

The *Real-Time System Models* (RTSM) enable development of software without the requirement for actual hardware.

The software models provide *Programmer's View* (PV) models of processors and devices. The functional behavior of a model is equivalent to real hardware.

Absolute timing accuracy is sacrificed to achieve fast simulated execution speed. This means that you can use the PV models for confirming software functionality, but you must not rely on the accuracy of cycle counts, low-level component interactions, or other hardware-specific behavior.

1.2 Introduction to the EB RTSM

The EB and CoreTiles are hardware development platforms produced by ARM.

The EB RTSMs are system models implemented in software. They are developed using the ARM® Fast Models™ library product.

————— **Note** —————

The EB RTSMs are provided as example platform implementations and are not intended to be accurate representations of a specific EB hardware revision. The RTSMs support selected peripherals as described in this book. The supplied RTSMs are sufficiently complete and accurate to boot the same operating system images as for EB hardware.

See also:

- *About the EB and CoreTile hardware*
- *About the EB Real-Time System Models* on page 1-4.

1.2.1 About the EB and CoreTile hardware

The major components on the hardware version of the baseboard are:

- two tile sites (supports ARM CoreTiles and LogicTiles)
- *Field Programmable Gate-Array* (FPGA) that implements a bus matrix, configuration interface, peripheral controllers, and interface logic
- 8MB configuration flash that holds FPGA images
- 256MB of 32-bit wide DDR SDRAM
- 4MB of 32-bit wide Cellular (Pseudo-static) RAM
- 64MB of 32-bit wide NOR flash
- up to 320MB (5x64MB) of static memory (flash or RAM) in an optional PISMO expansion board
- PCI expansion connector
- USB interface controller IC and connector
- Ethernet interface controller IC and connector
- connectors for VGA, color LCD display interface board, four UARTs, GPIO, keyboard, mouse, Smart Card, audio, MMC, and SSP
- electronic switches that select between the controllers located in the FPGA or on one of the tile sites
- debug and test connectors for JTAG, Integrated Logic Analyzer, and Trace port
- general purpose DIP switches and LEDs
- 2 row by 16 character LCD display
- power supply circuitry
- *Real-Time Clock* (RTC)
- time of year clock with backup battery

- programmable clock generators.

1.2.2 About the EB Real-Time System Models

The Real-Time System Model components for the EB Reference System are:

- Processor CoreTile:
 - Cortex™-A8.
- EB model with:
 - 64MB Flash memory
 - 256MB RAM
 - Ethernet interface
 - UART interface
 - debug DIP switches and LEDs
 - *Real-Time Clock* (RTC)
 - time of year clock
 - programmable clock generators
 - *Synchronous Serial Port Interface* (SSPI)
 - DMA controller configuration registers
 - *Static Memory Controller* (SMC).

The EB RTSM also includes virtual components:

- visualization for *Color LCD* (CLCD) display, keyboard and mouse
- touch screen controller
- four telnet terminals.

The Real-Time System Models for the EB Reference System are hierarchical models that consist of:

- the top-level view of the model
- the EB model
- the CoreTile model that is used by the system model.

The EB RTSMs provide a functionally-accurate model for software execution. However, the model sacrifices timing accuracy to increase simulation speed. Key deviations from actual hardware are:

- timing is approximate
- buses are simplified.

Many components can be configured at instantiation time. See *EB model configuration parameters* on page 3-5.

For more detail on the differences, see *Differences between the EB and CoreTile hardware and the models* on page 3-15.

Top-level view of an EB model

A block diagram of the top-level model for an EB with a Cortex-A8 CoreTile is shown in Figure 1-1 on page 1-5.




Figure 1-1 Block diagram of top-level EB model

CoreTile component

The CoreTile component provides the processor version and the associated ports that enable interconnection with other top-level components. The block diagram of the model for the Cortex-A8 CoreTile is shown in Figure 1-2.




Figure 1-2 Cortex-A8 Block diagram of CoreTile model

EB component

The block diagram of the EB Baseboard model is shown in Figure 1-3. The figure shows the components in block form, the ports, and the interconnections between them.




Figure 1-3 Block diagram of the EB Baseboard model

Chapter 2

Getting Started with EB RTSMs

This chapter describes the procedures for starting and configuring an EB RTSM, and running a software application on the model. The procedures differ depending on the ARM software tools you are using. Read the sections that apply to the software you have. This chapter contains the following sections:

- *Starting an RTSM* on page 2-2
- *Configuring an RTSM* on page 2-3
- *Using the CLCD window* on page 2-5
- *Using Ethernet with an EB RTSM* on page 2-8
- *Using a terminal with a system model* on page 2-10
- *Virtual filesystem* on page 2-12
- *Using the VFS with a pre-built RTSM* on page 2-14.

2.1 Starting an RTSM

This section describes how to start an EB RTSM. An example of loading and executing an application is documented separately.

The model can optionally start a CADI debug server allowing a CADI-enabled debugger, such as ARM DS-5™ Debugger, to be connected to the running model. It can also be configured to wait for a debugger connection before starting.

To start the RTSM, change to the directory where your model file is and enter the following at the command prompt:

```
model_name [--cadi-server] [--config-file filename] [-C instance.parameter=value]
[--application app_filename]
```

where:

model_name is the name of the model file. By default this file name is typically `RTSM_EB_processor`.

filename is the name of your optional plain-text configuration file. Configuration files simplify managing multiple parameters. See *Using a configuration file* on page 2-3.

instance.parameter=value

is the optional direct setting of a configuration parameter. See *Using the command line* on page 2-3.

app_filename is the file name of an image to load to your model at startup.

For more information on model options, see the *Model Shell for Fast Models Reference Manual*.

Starting the model opens the RTSM CLCD display. See *Using the CLCD window* on page 2-5.

After the RTSM starts, you can use ARM DS-5 Debugger to connect to it.

2.2 Configuring an RTSM

This section describes how to configure EB RTSMs.

Valid user settings for the EB RTSM parameters and their effects are described in *EB model configuration parameters* on page 3-5.

2.2.1 Setting model configuration options

The initial state of the RTSM can be controlled by configuration settings provided on the command line or in the CADI properties for the model.

Using a configuration file

To configure a model that you start from the command line, include a reference to an optional plain text configuration file as described in *Starting an RTSM* on page 2-2.

Comment lines in the configuration file must begin with a # character.

Each non-comment line of the configuration file contains:

- the name of the component instance
 - the parameter to be modified and its value.
- Boolean values can be set using either true/false or 1/0. Strings must be enclosed in double quotes if they contain whitespace.

A typical configuration file is listed in Example 2-1:

Example 2-1 Configuration file

```
# Disable semihosting using true/false syntax
coretile.core.semihosting-enable=false
#
# Enable the boot switch using 1/0 syntax
baseboard.sp810_sysctrl.use_s8=1
#
# Set the boot switch position
baseboard.eb_sysregs_0.boot_switch_value=1
```

Using the command line

You can use the -C switch to define model parameters when you invoke the model. You can also use --parameter as a synonym for the -C switch. See *Starting an RTSM* on page 2-2. Use the same syntax as for a configuration file, but each parameter must be preceded by the -C switch.

Examples

This section contains an example for configuring an EB RTSM.

Example 2-2 shows how to set the boot options.

Example 2-2 Booting a model from a flash image

```
# Boot from a flash image
RTSM_EB_Cortex-A8 \
  --parameter "coretile.core.semihosting-cmd_line="\
```

```
--parameter "baseboard.flashldr_0.fname=flash.bin" \  
--parameter "baseboard.eb_sysregs_0.user_switches_value=4" \  
--parameter "visualisation.disable_visualisation=false" \  
--parameter "visualisation.rate_limit-enable=0" \  

```

2.3 Using the CLCD window

When an RTSM starts, the RTSM CLCD window opens.

This window represents the contents of the simulated color LCD framebuffer. It automatically resizes to match the horizontal and vertical resolution set in the CLCD peripheral registers.

For more information on the CLCD model components and other peripherals, see the *Fast Models Reference Manual*.

This section describes the CLCD window for EB RTSMs.

2.3.1 Using the EB CLCD window

Figure 2-1 shows the EB RTSM CLCD in its default state, immediately after being started.




Figure 2-1 CLCD window at startup

The top section of the CLCD window displays the following status information:

USERSW Eight white boxes show the state of the EB User DIP switches:
These represent switch S6 on the EB hardware, USERSW[8:1], which is mapped to bits [7:0] of the SYS_SW register at address 0x10000004.
The switches are in the off position by default. Click in the area above or below a white box to change its state. See *Switch S6* on page 3-6.

BOOTSW Eight white boxes showing the state of the EB Boot DIP switches.
These represent switch S8 on the EB hardware, BOOTSEL[8:1], which is mapped to bits [15:8] of the SYS_SW register at address 0x10000004.
The switches are in the off position by default. See *Switch S8* on page 3-7.

———— **Note** ————

ARM recommends you configure the Boot DIP switches using the boot_switch model parameter rather than by using the CLCD interface.

Changing Boot DIP switch positions while the model is running can result in unpredictable behavior.

S6LED Eight colored boxes indicate the state of the EB User LEDs.
These represent LEDs D[21:14] on the EB hardware, which are mapped to bits [7:0] of the SYS_LED register at address 0x10000008. The boxes correspond to the red/yellow/green LEDs on the EB hardware.

Total Instr A counter showing the total number of instructions executed.
Because the RTSM models provide a programmer's view of the system, the CLCD displays total instructions rather than total core cycles. Timing might differ substantially from the hardware because:

- the bus fabric is simplified
- memory latencies are minimized
- programmer's view core and peripheral models are used.

In general, the timing of operations within a model is not accurate.

Total Time A counter showing the total elapsed time, in seconds.
This is wall clock time, not simulated time.

Rate Limit A feature that prevents the simulation from running faster than wall clock time.
Because the system model is highly optimized, your code might run faster than it would on real hardware. This might cause timing issues.
Rate Limit is enabled by default. Simulation time is restricted so that it more closely matches real time. See *Timing considerations* on page 3-18.
Click on the square button to disable or enable Rate Limit. The text changes from ON to OFF and the colored box becomes darker when Rate Limit is disabled.
Figure 2-2 shows the CLCD with Rate Limit disabled.

———— Note ————

You can control whether Rate Limit is enabled by using the `rate_limit-enable` parameter when instantiating the model. See on page 3-13 *Visualization parameters* on page 3-13.

If you click on the **Total Instr** or **Total Time** items in the CLCD, the display changes to show **Inst/sec** (instructions per second) and **Perf Index** (performance index) as shown in Figure 2-2. You can click on the items again to toggle between the original and alternative displays.




Figure 2-2 CLCD window with Rate Limit off

Instr/sec Shows the number of instructions executed per second of wall clock time.

Perf Index The ratio of real time to simulation time. The larger the ratio, the faster the simulation runs. If you enable the Rate Limit feature, the Perf Index approaches unity.

You can reset the simulation counters by resetting the model.

If the CLCD window has focus:

- any keyboard input is translated to PS/2 keyboard data.
- Any mouse activity over the window is translated into PS/2 relative mouse motion data. This is then streamed to the KMI peripheral model FIFOs.

———— Note ————

The simulator only sends relative mouse motion events to the model. As a result, the host mouse pointer does not necessarily align with the target OS mouse pointer.

You can hide the host mouse pointer by pressing the **Left Ctrl+Left Alt** keys. Press the keys again to redisplay the host mouse pointer. Only the **Left Ctrl** key is operational. The **Right Ctrl** key on the right of the keyboard does not have the same effect.

If you prefer to use a different key, use the `trap_key` configuration option.

2.3.2 See also

Reference

- *Visualization parameters* on page 3-13.

2.4 Using Ethernet with an EB RTSM

The EB RTSMs provide you with a virtual Ethernet component. This is a model of the SMSC91C111 Ethernet controller, and uses a TAP device to communicate with the network. By default, the Ethernet component is disabled.

2.4.1 Host requirements

Before you can use the Ethernet capability of the EB RTSM, you must first set up your host computer. See the *Fast Models User Guide* for more information.

2.4.2 Target requirements

The EB RTSMs include a software implementation of the SMSC91C111 device. Your target OS must therefore include a driver for this specific device, and you must configure the kernel to use the SMSC chip. Linux is the operating system that supports the SMSC91C111.

There are three Ethernet component parameters you can configure for the Ethernet component:

- enabled
- MAC address
- promiscuous.

Configure these before starting the EB RTSM.

enabled

The default state is false. When the device is disabled, the kernel cannot detect the device. For more information, see the SMSC_91C111 component section in the *Fast Models Reference Manual*. The following figure shows a block diagram of the model networking structure:




Figure 2-3 Model networking structure block diagram

You must configure a HostBridge component to perform read and write operations on the TAP device. The HostBridge component is a virtual programmer's view model, acting as a networking gateway to exchange Ethernet packets with the TAP device on the host, and to forward packets to NIC models.

mac_address

There are two options for the `mac_address` parameter.

If you do not specify a MAC address, then when the simulator runs it takes the default MAC address. The address is randomly-generated to increase the chance of it being unique when running models on multiple hosts on a local network.

promiscuous

The default state is `true`. This means that it receives all network traffic, even any not specifically addressed to the device. You must use the default if you are using a single network device for multiple MAC addresses. Use it if, for example, you are sharing the same network card between your host OS and the EB RTSM Ethernet component.

By default, the Ethernet device on the EB RTSM has a randomly-generated MAC address.

2.4.3 Configuring Ethernet

For information on configuring a connection to the Ethernet interface on the RTSM from Microsoft Windows or Linux, see the *Fast Models User Guide*.

2.4.4 See also**Reference**

- *Fast Models Reference Manual*,
<http://infocenter.arm.com/help/topic/com.arm.doc.dui0423-/index.html>
- *Fast Models User Guide*,
<http://infocenter.arm.com/help/topic/com.arm.doc.dui0370-/index.html>.

2.5 Using a terminal with a system model

The Terminal component is a virtual component that enables UART data to be transferred between a TCP/IP socket on the host and a serial port on the target.

———— Note ————

To use the Terminal component with a Microsoft Windows 7 client, you must first install Telnet. The Telnet application is not installed on Microsoft Windows Vista by default.

Download the application by following the instructions on the Microsoft web site. Search for “Windows 7 Telnet” to find the Telnet FAQ page. To install Telnet:

1. Select **Start** → **Control Panel** → **Programs and Features**. This opens a window that enables you to uninstall or change programs.
2. Select **Turn Windows features on or off** on the left side of the bar. This opens the Microsoft Windows Features dialog. Select the **Telnet Client** check box.
3. Click **OK**. The installation of Telnet might take several minutes to complete.

Figure 2-4 shows a block diagram of one possible relationship between the target and host through the Terminal component. The TelnetTerminal block is what you configure when you define Terminal component parameters. The Virtual Machine is your EB RTSM.




Figure 2-4 Terminal block diagram

On the target side, the console process invoked by your target OS relies on a suitable driver being present. Such drivers are normally part of the OS kernel. The driver passes serial data through a UART. The data is forwarded to the TelnetTerminal component, that exposes a TCP/IP port to the world outside of the RTSM. This port can be connected to by, for example, a telnet process on the host.

By default, the EB RTSM starts four telnet Terminals when the model is initialized. You can change the startup behavior for each of the four Terminals by modifying the corresponding component parameters.

If the Terminal connection is broken, for example by closing a client telnet session, the port is re-opened on the host. This might have a different port number if the original one is no longer available. Before the first data access, you can connect a client of your choice to the network socket. If there is no existing connection when the first data access is made, and the `start_telnet` parameter is true, a host telnet session is started automatically.

The port number of a particular Terminal instance can be defined when the RTSM starts. The actual value of the port used by each Terminal is declared when it starts or restarts, and might not be the value you specified if the port is already in use. The port numbers are displayed in the host window in which you started the model.

You can start the Terminal component in either telnet mode or raw mode.

2.5.1 Telnet mode

In telnet mode, the Terminal component supports a subset of the RFC 854 protocol. This means that the Terminal participates in negotiations between the host and client concerning what is and is not supported, but flow control is not implemented.

2.5.2 Raw mode

Raw mode enables the byte stream to pass unmodified between the host and the target. This means that the Terminal component does not participate in initial capability negotiations between the host and client. It acts as a TCP/IP port. You can use this feature to directly connect to your target through the Terminal component.

2.6 Virtual filesystem

The *Virtual FileSystem* (VFS) allows your target to access parts of a host filesystem. This access is achieved through a target OS-specific driver and a memory mapped device called the *MessageBox*. When using the VFS, access to the host filesystem is analogous to access to a shared network drive, and can be expected to behave in the same way.

If you want to build your own system that includes the VFS, see the *Fast Models Reference Manual*. See also the `WritingADriver.txt` file in `%PVLIB_HOME%\VFS\docs\`.

The VFS supports the following filesystem operations:

getattr	retrieves metadata for the file, directory or symbolic link
mkdir	creates a new directory
remove	removes a file, directory or symbolic link
rename	renames a file, directory or symbolic link
rmdir	removes an empty directory
setattr	sets metadata for the file, directory or symbolic link.

———— **Note** —————
 setattr is not implemented.

Symbolic links are not supported. Hard links cannot be created by the model but hard links created by the host operating system function correctly.

The VFS supports the following mount points:

closemounts	freed the iterator handle returned from openmounts
openmounts	retrieves an iterator handle for the list of available mounts
readmounts	reads one entry from the mount iterator ID.

The VFS supports the following directory iterators:

closedir	freed a directory iterator handle retrieved by opendir
opendir	retrieves an iterator handle for the directory specified
readdir	reads the next entry from the directory iterator.

———— **Note** —————

Datestamps returned are in milliseconds elapsed since the VFS epoch of January 01 1970 00:00 UTC and are host datestamps. The host datestamp might be in the future relative to the simulated OS datestamp.

The VFS supports the following file operations:

closefile	freed a handle opened with openfile
filesync	forces the host OS to flush all file data to persistent storage
getfilesize	returns the size of a file, in bytes
openfile	returns a handle to the file specified
readfile	reads a block of data from a file
setfilesize	sets the size of a file in bytes, either by truncating, or extending the file with zeroes

writefile writes a block of data to a file.

2.6.1 See also

Reference

- *Using the VFS with a pre-built RTSM* on page 2-14
- *Fast Models Reference Manual*,
<http://infocenter.arm.com/help/topic/com.arm.doc.dui0423-/index.html>.

2.7 Using the VFS with a pre-built RTSM

The supplied EB RTSMs include the necessary VFS components. This permits you to run a Linux image, for example, on the EB RTSM and access the filesystem running on your computer.

To use the VFS functionality of the EB RTSM, use the `motherboard.vfs2.mount` configuration parameter when you start the model. The value of the parameter is the path to the host filesystem directory that is to be made accessible within the model.

2.7.1 Mount names

When the target OS is running, create a mount point, such as `/mnt/host`. For example, on a Linux target, use the `mount` command as follows:

```
mount -t vmfs A /mnt/host
```

You can then access the host filesystem from the target OS through a supported filesystem operation. See the `ReadMe.txt` file in the `%PVLIB_HOME%\VFS2\linux\` directory.

2.7.2 Path names

All path names must be fully qualified paths of the form:

```
mountpoint:/path/to/object
```

2.7.3 See also

Reference

- *Virtual filesystem* on page 2-12
- *Fast Models Reference Manual*,
<http://infocenter.arm.com/help/topic/com.arm.doc.dui0423-/index.html>.

Chapter 3

Programmer's Reference for the EB RTSMs

The following topics describe the memory map and the configuration registers for the peripheral and system component models:

- *EB model memory map* on page 3-2
- *EB model configuration parameters* on page 3-5
- *EB RTSM baseboard parameters* on page 3-6
- *Ethernet parameters* on page 3-9
- *UART parameters* on page 3-11
- *Terminal parameters* on page 3-12
- *Visualization parameters* on page 3-13
- *RTSM_EB_Cortex-A8 CoreTile parameters* on page 3-14
- *Differences between the EB and CoreTile hardware and the models* on page 3-15.

Note

For detailed information on the programming interface for ARM PrimeCell® peripherals and controllers, see the appropriate technical reference manual.

3.1 EB model memory map

Table 3-1 lists the locations and interrupts for memory, peripherals, and controllers used in the EB Real-Time System Models. See the *Emulation Baseboard User Guide* for more details on the controllers and peripherals.

Table 3-1 Memory map and interrupts for standard peripherals

Peripheral	Modeled	Address range	Bus	Size	GIC Int ^a	DCCI Int ^b
Dynamic memory	Yes	0x00000000-0xFFFFFFFF	AHB	256MB	-	-
System registers (see <i>Status and system control registers</i> on page 3-17)	Yes	0x10000000-0x10000FFF	APB	4KB	-	-
SP810 System Controller	Yes	0x10001000-0x10001FFF	APB	4KB	-	-
Two-Wire Serial Bus Interface	No	0x10002000-0x10002FFF	APB	4KB	-	-
Reserved	-	0x10003000-0x10003FFF	APB	4KB	-	-
PL041 <i>Advanced Audio CODEC Interface</i> (AACI)	Partial ^c	0x10004000-0x10004FFF	APB	4KB	51	51
PL180 <i>MultiMedia Card Interface</i> (MCI)	Partial ^d	0x10005000-0x10005FFF	APB	4KB	49, 50	49, 50
Keyboard/Mouse Interface 0	Yes	0x10006000-0x10006FFF	APB	4KB	52	7
Keyboard/Mouse Interface 1	Yes	0x10007000-0x10007FFF	APB	4KB	53	8
Character LCD Interface	No	0x10008000-0x10008FFF	APB	4KB	55	55
UART 0 Interface	Yes	0x10009000-0x10009FFF	APB	4KB	44	4
UART 1 Interface	Yes	0x1000A000-0x1000AFFF	APB	4KB	45	5
UART 2 Interface	Yes	0x1000B000-0x1000BFFF	APB	4KB	46	46
UART 3 Interface	Yes	0x1000C000-0x1000CFFF	APB	4KB	47	47
Synchronous Serial Port Interface	Yes	0x1000D000-0x1000DFFF	APB	4KB	43	43
Smart Card Interface	No	0x1000E000-0x1000EFFF	APB	4KB	62	62
Reserved	-	0x1000F000-0x1000FFFF	APB	4KB	-	-
SP805 Watchdog Interface	Yes	0x10010000-0x10010FFF	APB	4KB	32	32
SP804 Timer modules 0 and 1 interface (Timer 1 starts at 0x10011020)	Yes	0x10011000-0x10011FFF	APB	4KB	36	1
SP804 Timer modules 2 and 3 interface (Timer 3 starts at 0x10020020)	Yes	0x10012000-0x10012FFF	APB	4KB	37	2
PL061 GPIO Interface 0	Yes	0x10013000-0x10013FFF	APB	4KB	38	38
PL061 GPIO Interface 1	Yes	0x10014000-0x10014FFF	APB	4KB	39	39
PL061 GPIO Interface 2 (miscellaneous onboard I/O)	Yes	0x10015000-0x10015FFF	APB	4KB	40	40
Reserved	-	0x10016000-0x10016FFF	APB	4KB	-	-
PL030 Real-Time Clock Interface	Yes	0x10017000-0x10017FFF	APB	4KB	-	-

Table 3-1 Memory map and interrupts for standard peripherals (continued)

Peripheral	Modeled	Address range	Bus	Size	GIC Int ^a	DCCI Int ^b
Dynamic Memory Controller configuration	Partial ^e	0x10018000–0x10018FFF	APB	4KB	-	-
PCI controller configuration registers	No	0x10019000–0x10019FFF	AHB	4KB	-	-
Reserved	-	0x1001A000–0x1001FFFF	APB	24KB	-	-
PL111 Color LCD Controller	Yes	0x10020000–0x1002FFFF	AHB	64KB	55	55
DMA Controller configuration registers	Yes	0x10030000–0x1003FFFF	AHB	64KB	-	-
Generic Interrupt Controller 1 CPU interface	Yes ^b	0x10040000–0x10040FFF	AHB	4KB	-	-
Generic Interrupt Controller 1 Distributor interface	Yes	0x10041000–0x10041FFF	AHB	4KB	-	-
Generic Interrupt Controller 2 CPU interface (nFIQ for tile 1)	No ^f	0x10050000–0x10050FFF	AHB	4KB	-	-
Generic Interrupt Controller 2 Distributor interface	Yes	0x10051000–0x10051FFF	AHB	4KB	-	-
Generic Interrupt Controller 3 CPU interface (nIRQ for tile 2)	No ^f	0x10060000–0x10060FFF	AHB	4KB	-	-
Generic Interrupt Controller 3 Distributor interface	No	0x10061000–0x10061FFF	AHB	4KB	-	-
Generic Interrupt Controller 4 CPU interface (nFIQ for tile 2)	No ^f	0x10070000–0x10070FFF	AHB	4KB	-	-
Generic Interrupt Controller 4 Distributor interface	No	0x10071000–0x10071FFF	AHB	4KB	-	-
PL350 Static Memory Controller configuration ^g	Yes	0x10080000–0x1008FFFF	AHB	64KB	-	-
Reserved	-	0x10090000–0x100EFFFF	AHB	448MB	-	-
<i>Debug Access Port</i> (DAP) ROM table. Some debuggers read information on the target processor and the debug chain from the DAP table.	No	0x100F0000–0x100FFFFF	AHB	64KB	-	-
Reserved	-	0x10100000–0x1FFFFFFF	-	255MB	-	-
Reserved	-	0x20000000–0x3FFFFFFF	-	512MB	-	-
NOR Flash	Yes ^h	0x40000000–0x43FFFFFF	AXI	64MB	-	-
Disk on Chip	No	0x44000000–0x47FFFFFF	AXI	64MB	41	41
SRAM	Yes	0x48000000–0x4BFFFFFF	AXI	64MB	-	-
Configuration flash	No	0x4C000000–0x4DFFFFFF	AXI	32MB	-	-
Ethernet	Yes ⁱ	0x4E000000–0x4EFFFFFF	AXI	16MB	60	60
USB	No	0x4F000000–0x4FFFFFFF	AXI	16MB	-	-

Table 3-1 Memory map and interrupts for standard peripherals (continued)

Peripheral	Modeled	Address range	Bus	Size	GIC Int ^a	DCCI Int ^b
PISMO expansion memory	No	0x50000000-0x5FFFFFFF	AXI	256MB	58	58
PCI interface bus windows	No	0x60000000-0x6FFFFFFF	AXI	256MB	-	-
Dynamic memory (mirror)	Yes	0x70000000-0x7FFFFFFF	AXI	256MB	-	-
Memory tile (Second CoreTile)	Yes	0x70000000-0x7FFFFFFF	AXI	0 to 1GB	-	-

- a. The Interrupt signal column lists the value to use to program your interrupt controller. The values shown are after mapping the SPI number by adding 32. The interrupt numbers from the peripherals are modified by adding 32 to form the interrupt number seen by the GIC. GIC interrupts 0-31 are for internal use.
- b. The numbers in this column are the interrupt numbers used by the DCCI system.
- c. See *Sound* on page 3-15.
- d. The implementation of the PL180 is limited, so not all features are present.
- e. See *Differences between the EB and CoreTile hardware and the models* on page 3-15.
- f. The EB RTSM GICs are not the same as those implemented on the EB hardware as the register map is different. See *Generic Interrupt Controller* on page 3-18.
- g. Although the EB hardware uses the PL093 static memory controller, the model implements PL350. These are functionally equivalent.
- h. This peripheral is implemented in the IntelStrataFlashJ3 component in the EB RTSM.
- i. This peripheral is implemented in the SC91C111 component in the EB RTSM.

———— **Note** ————

The EB RTSM implementation of memory does not require programming the memory controller with the correct values.

This means you must ensure that the memory controller is set up properly if you run an application on actual hardware. If this is not done, applications that run on an RTSM might fail on actual hardware.

3.2 EB model configuration parameters

The Real-Time System Models for the EB reference system have parameters that you can define at run time:

- *EB RTSM baseboard parameters* on page 3-6
- *Ethernet parameters* on page 3-9
- *UART parameters* on page 3-11
- *Terminal parameters* on page 3-12
- *Visualization parameters* on page 3-13
- *RTSM_EB_Cortex-A8 CoreTile parameters* on page 3-14.

Note

Parameters that you can modify only at model build time, or that you would not normally modify in the equivalent hardware system, are not described.

3.2.1 See also

Reference

- *EB model memory map* on page 3-2
- *Differences between the EB and CoreTile hardware and the models* on page 3-15.

3.3 EB RTSM baseboard parameters

Table 3-2 lists the baseboard instantiation time parameters that you can change when you start the model.

The syntax to use in a configuration file is:

`baseboard.component_name.parameter=value`

Table 3-2 EB Baseboard Model instantiation parameters

Component name	Parameter	Description	Type	Values	Default
eb_sysregs_0	user_switches_value	switch S6 setting	integer	see <i>Switch S6</i>	0
eb_sysregs_0	boot_switch_value	switch S8 setting	integer	see <i>Switch S8</i> on page 3-7	0
flashldr_0	fname	path to flash image file	string	valid path	""
	fnameWrite	name of flash image file	string	valid filename	""
flashldr_1	fname	path to flash image file	string	valid filename	""
	fnameWrite	name of flash image file	string	valid filename	""
mmc	p_mmc_file	multimedia card filename	string	valid filename	mmc.dat
pl111_clcd_0	pixel_double_limit	sets threshold in horizontal pixels below which pixels sent to framebuffer are doubled in size in both dimensions	integer	-	0x12c
sdram_size	sdram_size	sets the size of the SDRAM on the second installed CoreTile	integer	0 to 0x40000000	0
sp805_watchdog_0	simhalt	enables or disables the ARM Watchdog Module (SP805)	boolean	true or false	false
sp810_sysctrl	use_s8	indicates whether to read boot_switches_value	boolean	true or false	false
vfs2	mount	name of mount directory	string	valid filename	""

3.3.1 Switch S6

Switch S6 is equivalent to the Boot Monitor configuration switch on the EB hardware. Default settings are listed in Table 3-3 on page 3-7.

If you have the standard ARM Boot Monitor flash image loaded, the setting of switch S6-1 changes what happens on model reset. Otherwise, the function of switch S6 is implementation dependent.

To write the switch position directly to the S6 parameter in the model, you must convert the switch settings to an integer value from the equivalent binary, where 1 is on and 0 is off.

Table 3-3 Default positions for EB System Model switch S6

Switch	Default Position	Function in default position
S6-1	OFF	Displays prompt allowing Boot Monitor command entry after system start.
S6-2	OFF	See Table 3-4.
S6-3	OFF	See Table 3-4.
S6-4 to S6-8	OFF	Reserved for application use.

If S6-1 is in the ON position, the Boot Monitor executes the boot script that was loaded into flash. If there is no script, the Boot Monitor prompt is displayed.

The settings of S6-2 and S6-3 affect STDIO source and destination on model reset as defined in Table 3-4.

Table 3-4 STDIO redirection

S6-2	S6-3	Output	Input	Description
OFF	OFF	UART0	UART0	STDIO autodetects whether to use semihosting I/O or a UART. If a debugger is connected, STDIO is redirected to the debugger output window, otherwise STDIO goes to UART0.
OFF	ON	UART0	UART0	STDIO is redirected to UART0, regardless of semihosting settings.
ON	OFF	CLCD	Keyboard	STDIO is redirected to the CLCD and keyboard, regardless of semihosting settings.
ON	ON	CLCD	UART0	STDIO output is redirected to the LCD and input is redirected to the keyboard, regardless of semihosting settings.

For more information on Boot Monitor configuration and commands, see the *Emulation Baseboard User Guide (Lead Free)*.

3.3.2 Switch S8

Switch S8 is disabled by default. To enable it, you must change the state of the parameter `baseboard.sp810_sysctrl.use_s8` to true before you start the model. See *EB RTSM baseboard parameters* on page 3-6.

If you have a Boot Monitor flash image loaded, switch S8 enables you to remap boot memory.

On reset, the EB hardware starts to execute code at 0x0, which is typically volatile DRAM. You can put the contents of non-volatile RAM at this location by setting the S8 switch in the EB RTSM CLCD as shown in Table 3-5. The settings take effect on model reset.

Table 3-5 EB System Model switch S8 settings

Switch S8[4:1]	Memory Range	Description
0000	0x40000000–0x4FEFFFFF	NOR flash remapped to 0x0
0001	0x44000000–0x47FFFFFF	NOR flash remapped to 0x0
0010	0x48000000–0x4BFFFFFF	SRAM remapped to 0x0

3.4 Ethernet parameters

Table 3-6 lists the Ethernet instantiation-time parameters that you can change.

The syntax to use in a configuration file or on the command line is:

```
motherboard.smc_91c111_0.parameter=value
```

Table 3-6 Ethernet configuration parameters

Parameter	Description	Type	Values	Default
enabled	Host interface connection enabled	boolean	true or false	false
mac_address	Host/model MAC address	string	See <i>mac_address parameter</i>	00:02:f7:ef:31:11
promiscuous	Put host into promiscuous mode, for example when sharing the Ethernet controller with the host OS.	boolean	true or false	true

3.4.1 mac_address parameter

There are two options for the `mac_address` parameter:

- If you do not specify a MAC address, then when the simulator is run it takes the default MAC address and changes its bottom two bytes from 00:02 to the bottom two bytes of the MAC address of one of the adaptors on the host PC. This increases the chance of the MAC address being unique when running models on multiple hosts on a local network.
- If you specify the MAC address as auto, the local MAC address is randomly generated each time the simulator runs. The address has bit 1 set and bit 0 clear in the first byte to indicate a locally-administered unicast MAC address.

Note

DHCP servers allocate IP addresses, but because they sometimes do this based on the MAC address provided to them, then using random MAC addresses might conflict with some DHCP servers.

3.5 System controller parameters

Table 3-7 lists the system controller instantiation-time parameters that you can change when the model is started.

The syntax to use in a configuration file or on the command line is:

`motherboard.sp810_sysctrl.parameter=value`

Table 3-7 System controller configuration parameters

Parameter	Description	Type	Values	Default
sysid	Value for system identification register	Integer	0, 1, 2 ^a	0x00000000
use_s8	Select whether switch S8 is enabled	Boolean	true or false	false

a. The sysid parameter takes values 0, 1, or 2. These correspond to SYS_ID register read values of:
 sysid parameter value = 0 => SYS_ID register value = 0x0225f500, corresponding to REV_A
 sysid parameter value = 1 => SYS_ID register value = 0x12257500, corresponding to REV_B
 sysid parameter value = 2 => SYS_ID register value = 0x22252500, corresponding to REV_C.
 Any other value for parameter sysid results in a SYS_ID register value of 0x0.

3.6 UART parameters

Table 3-8 lists the UART instantiation-time parameters that you can change.

The syntax to use in a configuration file or on the command line is:

`motherboard.pl011_uartx.parameter=value`

where *x* is the UART identifier 0, 1, 2 or 3.

Table 3-8 UART configuration parameters

Parameter	Description	Type	Values	Default
baud_rate	Baud rate	Integer	-	0x9600
clock_rate	Clock rate for PL011	Integer	-	0xE10000
in_file	Input file	String		[empty string]
out_file	Output file (use “-” to send all output to stdout)	String		[empty string]
in_file_escape_sequence	Input file escape sequence	String		##
shutdown_on_eot	Shutdown simulation when an EOT (ASCII 4) char is transmitted	Boolean	true or false	false
unbuffered_output	Unbuffered output	Boolean	true or false	false
untimed_fifos	Ignore the clock rate and transmit/receive serial data immediately	Boolean	true or false	false
uart_enable	Enable the UART when the system starts	Boolean	true or false	false

3.7 Terminal parameters

Table 3-9 lists the terminal instantiation-time parameters that you can change when you start the model.

The syntax to use in a configuration file or on the command line is:

`motherboard.terminal_x.parameter=value`

where *x* is the terminal ID 0, 1, 2 or 3.

Table 3-9 Terminal instantiation parameters

Parameter	Description	Type	Values	Default
mode	Terminal operation mode.	String	telnet, raw	telnet
start_telnet	Enable terminal when the system starts.	Boolean	true or false	true
start_port	Port used for the terminal when the system starts. If the specified port is not free, the port value is incremented by 1 until a free port is found.	Integer	Valid port number	5000

3.8 Visualization parameters

Table 3-10 lists the Visualization instantiation-time parameters that you can change when you start the model. For more information on the Visualization component, see the *Fast Models Reference Manual*. The syntax to use in a configuration file is:

`visualisation.parameter=value.`

Table 3-10 Visualization instantiation parameters

Parameter	Description	Type	Values	Default
<code>disable_visualisation</code>	disable the EBVisualisation component on model startup	boolean	true or false	false
<code>rate_limit-enable^a</code>	restrict simulation speed so that simulation time more closely matches real time rather than running as fast as possible	boolean	true or false	true
<code>trap_key</code>	trap key that works with Left Ctrl key to toggle mouse pointer display	integer	valid ATKeyCode key value ^b	74 ^c

- a. You can click the Rate Limit button in the CLCD instead of setting the parameter at instantiation time. See *Using the CLCD window* on page 2-5.
- b. If you have Fast Models installed, see the header file, %PVLIB_HOME%\components\KeyCode.h, for a list of ATKeyCode values. On Linux, see the file \$PVLIB_HOME/components/KeyCode.h.
- c. This is equivalent to the **Left Alt** key.

3.9 RTSM_EB_Cortex-A8 CoreTile parameters

Table 3-11 lists the Cortex-A8 CoreTile RTSM parameters that you can change when you start the model. All listed parameters are instantiation-time parameters. This CoreTile RTSM is based on r2p1 of the Cortex-A8 processor.

The syntax to use in a configuration file is:

```
coretile.core.parameter=value
```

Table 3-11 RTSM_EB_Cortex-A8 CoreTile parameters

Parameter	Description	Type	Values	Default
semihosting-cmd_line	Command line available to semihosting SVC calls.	string	no limit except memory	[empty string]
semihosting-debug ^a	Enable debug output of semihosting SVC calls.	boolean	true or false	false
semihosting-enable	Enable semihosting SVC traps.	boolean	true or false	true
semihosting-ARM_SVC	ARM SVC number for semihosting.	integer	24 bit integer	0x123456
semihosting-Thumb_SVC	Thumb SVC number for semihosting.	integer	8 bit integer	0xAB
semihosting-heap_base	Virtual address of heap base.	integer	0x00000000 - 0xFFFFFFFF	0x0
semihosting-heap_limit	Virtual address of top of heap.	integer	0x00000000 - 0xFFFFFFFF	0x0F000000
semihosting-stack_base	Virtual address of base of descending stack.	integer	0x00000000 - 0xFFFFFFFF	0x10000000
semihosting-stack_limit	Virtual address of stack limit.	integer	0x00000000 - 0xFFFFFFFF	0x0F000000

a. Ignored.

The Cortex-A8 CoreTile RTSM also includes a GIC but this cannot be configured at instantiation time.

3.10 Differences between the EB and CoreTile hardware and the models

The following sections describe features of the Emulation Baseboard and CoreTile hardware that are not implemented in the models or have significant differences in implementation:

- *Features not present in the baseboard model*
- *Restrictions on the processor models* on page 3-16
- *Remapping and DRAM aliasing* on page 3-17
- *Dynamic memory characteristics* on page 3-17
- *Status and system control registers* on page 3-17
- *Generic Interrupt Controller* on page 3-18
- *GPIO2* on page 3-18
- *Timing considerations* on page 3-18.

3.10.1 Features not present in the baseboard model

The following features present on the hardware version of the Emulation Baseboard are not implemented in the system models:

- two wire serial bus interface
- character LCD interface
- smart card interface
- PCI controller configuration registers
- debug access port
- disk on chip
- configuration flash
- USB
- PISMO expansion memory
- PCI interface bus windows
- UART Modem handshake signals
- VGA support.

Note

For more information on memory-mapped peripherals, see *EB model memory map* on page 3-2.

The following features present on the hardware version of the Emulation Baseboard are only partially implemented in the Real-Time System Models:

- *Sound*
- *Dynamic memory controller* on page 3-16.

Partial implementation means that some of the components are present but the functionality has not been fully modeled. If you use these features, they might not work as you expect. See the model release notes for the latest information.

Sound

The EB RTSMs implement the PL041 AACI PrimeCell and the audio codec as in the EB hardware, but with a limited number of sample rates.

Dynamic memory controller

The dynamic memory controller, though modeled in the EB RTSMs, does not provide direct memory access to all peripherals. Only the audio and synchronous serial port interface components can be accessed through the DMC.

3.10.2 Restrictions on the processor models

For detailed information concerning what features are not fully implemented in the processor models included with the EB RTSMs, see the *Fast Models Reference Manual*. The following general restrictions apply to the Real-Time System Model implementations of ARM processors:

- Fast Models does not model accurate instruction timing. A processor issues a set of instructions (a “quantum”) at a point in simulation time, and then waits before executing the next quantum. The processor averages one instruction per clock tick.

Consequently:

- The perceived performance of software running on the model differs from real-world software. In particular, memory accesses and arithmetic operations all take the same amount of time.
- A program might be able to detect the quantized execution behavior of a processor, for example by polling a high-resolution timer.
- All instructions in a quantum are effectively atomic.

———— **Note** —————

This might mask some race-condition bugs in software.

- Although cache control registers are included, in most cases they only enable you to check register access permissions. Cache flush operations are supported, but they have no effect. As a consequence, code that might fail on real hardware because of cache aliasing problems might run without problems on the EB RTSM.
- VFP and NEON™ instruction set execution on the model is not high performance.
- Write buffers are not modeled.
- Most aspects of TLB behavior are implemented in the models. In Architecture v7 models, the TLB memory attribute settings are used when stateful cache is enabled.
- No MicroTLB is implemented.
- A single memory access port is implemented. The port combines accesses for instruction, data, DMA and peripherals. Configuration of the peripheral port memory map register is ignored.
- All memory accesses are atomic and are performed in programmer’s view order. All memory transactions are a maximum of 32 bits wide. Unaligned accesses are always performed as byte transfers.
- Interrupts are not taken at every instruction boundary.
- The semihosting-debug configuration parameter is ignored.
- Integration and test registers are not implemented.
- On some processor models, only one CP14 debug coprocessor register is included, CP14 DSCR. The register reads 0 and ignores writes. Access to other CP14 registers causes an undefined instruction exception. To debug an RTSM you must use an external debugger.

- Breakpoint types supported directly by the model are:
 - single address unconditional instruction breakpoints
 - single address unconditional data breakpoints
 - unconditional instruction address range breakpoints.
- Processor exception breakpoints are supported by pseudoregisters in the debugger. Setting an exception register to a nonzero value stops execution on entry to the associated exception vector.
- The *Performance Management Unit* (PMU) is not implemented except for the instruction counter.

RTSM_EB_Cortex-A8 CoreTile

The following additional restrictions apply to the Real-Time System Model implementation of the Cortex-A8 processor:

- Two 4GB address spaces are seen by the model core, one as seen from secure mode and one as seen from normal mode. The address spaces contain zero-wait state memory and peripherals, but a lot of the space is unmapped.
- The PLE model is purely register-based and has no implemented behavior.
- Unaligned accesses with the MMU disabled do not cause data aborts.

3.10.3 Remapping and DRAM aliasing

The EB hardware provides considerable memory remap functionality. During this boot remapping, the bottom 64MB of the physical address map can be:

- NOR flash
- Static expansion memory.

In addition to providing remap functionality, the hardware aliases all 256MB of system DRAM at 0x70000000.

Remapping does not typically apply to the system models. However, NOR flash is modeled and can be remapped. See *Switch S8* on page 3-7.

In the memory map, memory regions that are not explicitly occupied by a peripheral or by memory are unmapped. This includes regions otherwise occupied by a peripheral that is not implemented, and those areas that are documented as reserved. Accessing these regions from the host processor results in the model presenting a warning.

3.10.4 Dynamic memory characteristics

The Emulation Baseboard hardware contains a PL340 DMC. This presents a configuration interface at address 0x10030000 in the memory map.

The system models configure a generic area of DRAM and do not model the PL340. This simplification helps speed the simulation.

3.10.5 Status and system control registers

For the hardware version of the Emulation Baseboard, the status and system control registers enable the processor to determine its environment and to control some on-board operations.

Note

Most of the EB RTSM functionality is determined by its configuration on startup. See *Configuring an RTSM* on page 2-3.

All EB system registers have been implemented in the system model, except for SYS_TEST_OSC[4:0], the oscillator test registers. Registers that are not implemented function as memory and the values written to them do not alter the behavior of the model.

3.10.6 Generic Interrupt Controller

The *Generic Interrupt Controller* (GIC) provided with the EB RTSMs differs substantially from that in the Emulation Board firmware. The programmer's model of the newer device is largely backwards compatible. The model GIC is an implementation of the PL390 PrimeCell, for which comprehensive documentation is provided elsewhere. See *PrimeCell® Generic Interrupt Controller (PL390) Technical Reference Manual*.

3.10.7 GPIO2

On the EB hardware, GPIO2 is dedicated to USB, a push button, and MCI status signals. USB and MCI are not implemented in the EB RTSMs, and no push button is modeled. The GPIO is therefore provided as another generic IO device.

3.10.8 Timing considerations

The Real-Time System Models provide you with an environment that enables running software applications in a functionally-accurate simulation. However, because of the relative balance of fast simulation speed over timing accuracy, there are situations where the models might behave unexpectedly.

When your code interacts with real world devices like timers and keyboards, data arrives in the modeled device in real world (or wall clock) time, but simulation time can be running much faster than the wall clock. This means that a single keypress might be interpreted as several repeated key presses, or a single mouse click incorrectly becomes a double click.

The EB RTSMs provide the Rate Limit feature to match simulation time to match wall-clock time. Enabling Rate Limit, either by using the Rate Limit button in the CLCD display, or the `rate_limit-enable` model instantiation parameter, forces the model to run at wall clock time. This avoids issues with two clocks running at significantly different rates. For interactive applications, ARM recommends enabling Rate Limit.