



Upgrading from RVDS to DS-5

Version 1.0

Non-Confidential

Copyright © 2022 Arm Limited (or its affiliates).
All rights reserved.

Issue 01

102722_0100_01_en



Upgrading from RVDS to DS-5

Copyright © 2022 Arm Limited (or its affiliates). All rights reserved.

Release information

Document history

Issue	Date	Confidentiality	Change
0100-01	16 September 2022	Non-Confidential	Initial release

Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly

or indirectly, in violation of such export laws. Use of the word “partner” in reference to Arm’s customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its affiliates) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm’s trademark usage guidelines at <https://www.arm.com/company/policies/trademarks>.

Copyright © 2022 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

(LES-PRE-20349|version 21.0)

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Feedback

Arm® welcomes feedback on this product and its documentation. To provide feedback on the product, create a ticket on <https://support.developer.arm.com>

To provide feedback on the document, fill the following survey: <https://developer.arm.com/documentation-feedback-survey>.

Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used language that can be offensive. Arm strives to lead the industry and create change.

We believe that this document contains no offensive language. To report offensive language in this document, email terms@arm.com.

Contents

1. Overview.....	6
2. Upgrading from RealView Development Suite RVDS to DS-5.....	7
3. What about backwards compatibility?.....	8
4. Upgrading your product.....	9
5. Arranging an upgrade.....	10
6. Installing node-locked licenses for DS-5.....	11
7. Installing floating licenses for DS-5.....	12

1. Overview

In this tutorial, you will learn how to upgrade an existing RVDS installation to DS-5.

2. Upgrading from RealView Development Suite RVDS to DS-5

This guide explains how to upgrade the RealView Development suite RVDS to DS-5.

What is DS-5

DS-5 is the successor to RVDS and our recommended tool suite for all new projects. DS-5 brings compiler improvements, support for the latest Arm processors as well as a much more powerful debugger. The DS-5 Debugger offers support for multi-core and multi-cluster devices, in addition to awareness for Linux, Android and a range of RTOS.

For safety-related software development, we now also package the TÜV SÜD certified Arm Compiler 5, Compiler Qualification Kit and Extended Maintenance as part of DS-5 Ultimate Edition.

RVDS customers can even get 35% off when upgrading to DS-5 Professional Edition.

3. What about backwards compatibility?

DS-5 enables all previous versions of the Arm Compiler, so you don't need to worry if you're using the Arm Compiler 3 or 4. It also supports target connection via the legacy RealView ICE unit. If you still require use of RVDS beyond compilation tools, we even offer a discounted DS-5 and RVDS combination.

4. Upgrading your product

To upgrade to DS-5, contact an Arm representative or your Arm approved distributor to request an upgrade. Delete your RVDS license once you have been given your DS-5 serial number or activation code and then use this to collect your DS-5 license.

5. Arranging an upgrade

To arrange an upgrade:

1. Contact your original supplier of the license(s) in the first instance. However, you can also contact Arm through the [pricing information request page](#). You will need to provide your existing RVDS serial number.
2. A representative from Arm, or one of our approved distributors, will contact you to discuss your request.

6. Installing node-locked licenses for DS-5

Node-locked licenses are for single workstation installations and are locked to the host ID of your workstation. The license file for a node-locked license is generated using the Arm License Manager.

[Read this tutorial on how to install node-locked licenses for DS-5.](#)

7. Installing floating licenses for DS-5

DS-5 floating licenses enable you to share a single license with multiple users as long as it is used at different times. When a license is released, it immediately becomes part of a common license pool, available to the next user who needs it. Floating licenses can be made available to anyone on the same network up to the limit specified in the license file.

[Read this tutorial on how to install floating licenses for DS-5.](#)