

# IrisSupportLib

Version 1.0

## Reference Guide



<b>1 IrisSupportLib Reference Guide</b>	<b>1</b>
<b>2 IrisSupportLib NAMESPACE macros</b>	<b>5</b>
<b>3 Module Index</b>	<b>7</b>
3.1 Modules . . . . .	7
<b>4 Hierarchical Index</b>	<b>9</b>
4.1 Class Hierarchy . . . . .	9
<b>5 Class Index</b>	<b>11</b>
5.1 Class List . . . . .	11
<b>6 File Index</b>	<b>13</b>
6.1 File List . . . . .	13
<b>7 Module Documentation</b>	<b>15</b>
7.1 Instance Flags . . . . .	15
7.1.1 Detailed Description . . . . .	15
7.2 IrisInstanceBuilder resource APIs . . . . .	15
7.2.1 Detailed Description . . . . .	16
7.2.2 Function Documentation . . . . .	16
7.2.2.1 addNoValueRegister() . . . . .	17
7.2.2.2 addParameter() . . . . .	17
7.2.2.3 addRegister() . . . . .	17
7.2.2.4 addStringParameter() . . . . .	18
7.2.2.5 addStringRegister() . . . . .	19
7.2.2.6 beginResourceGroup() . . . . .	19
7.2.2.7 enhanceParameter() . . . . .	20
7.2.2.8 enhanceRegister() . . . . .	20
7.2.2.9 getResourceInfo() . . . . .	20
7.2.2.10 setDefaultResourceDelegates() . . . . .	21
7.2.2.11 setDefaultResourceReadDelegate() [1/3] . . . . .	21
7.2.2.12 setDefaultResourceReadDelegate() [2/3] . . . . .	21
7.2.2.13 setDefaultResourceReadDelegate() [3/3] . . . . .	22
7.2.2.14 setDefaultResourceWriteDelegate() [1/3] . . . . .	22
7.2.2.15 setDefaultResourceWriteDelegate() [2/3] . . . . .	23
7.2.2.16 setDefaultResourceWriteDelegate() [3/3] . . . . .	23
7.2.2.17 setNextSubRscId() . . . . .	24
7.2.2.18 setPropertyCanonicalRnScheme() . . . . .	24
7.2.2.19 setTag() . . . . .	24
7.3 IrisInstanceBuilder event APIs . . . . .	24
7.3.1 Detailed Description . . . . .	25
7.3.2 Function Documentation . . . . .	25

7.3.2.1 addEventSource() [1/2]	26
7.3.2.2 addEventSource() [2/2]	26
7.3.2.3 deleteEventSource()	26
7.3.2.4 enhanceEventSource()	27
7.3.2.5 finalizeRegisterReadEvent()	27
7.3.2.6 finalizeRegisterUpdateEvent()	27
7.3.2.7 getIrisInstanceEvent()	27
7.3.2.8 hasEventSource()	27
7.3.2.9 resetRegisterReadEvent()	27
7.3.2.10 resetRegisterUpdateEvent()	28
7.3.2.11 setDefaultEsCreateDelegate() [1/3]	28
7.3.2.12 setDefaultEsCreateDelegate() [2/3]	28
7.3.2.13 setDefaultEsCreateDelegate() [3/3]	29
7.3.2.14 setRegisterReadEvent() [1/2]	29
7.3.2.15 setRegisterReadEvent() [2/2]	30
7.3.2.16 setRegisterUpdateEvent() [1/2]	30
7.3.2.17 setRegisterUpdateEvent() [2/2]	31
7.4 IrisInstanceBuilder breakpoint APIs	31
7.4.1 Detailed Description	32
7.4.2 Function Documentation	32
7.4.2.1 getBreakpointInfo()	32
7.4.2.2 notifyBreakpointHit()	33
7.4.2.3 notifyBreakpointHitData()	33
7.4.2.4 notifyBreakpointHitRegister()	33
7.4.2.5 setBreakpointDeleteDelegate() [1/3]	34
7.4.2.6 setBreakpointDeleteDelegate() [2/3]	34
7.4.2.7 setBreakpointDeleteDelegate() [3/3]	34
7.4.2.8 setBreakpointSetDelegate() [1/3]	35
7.4.2.9 setBreakpointSetDelegate() [2/3]	35
7.4.2.10 setBreakpointSetDelegate() [3/3]	35
7.4.2.11 setHandleBreakpointHitDelegate() [1/3]	36
7.4.2.12 setHandleBreakpointHitDelegate() [2/3]	36
7.4.2.13 setHandleBreakpointHitDelegate() [3/3]	36
7.5 IrisInstanceBuilder memory APIs	37
7.5.1 Detailed Description	38
7.5.2 Function Documentation	38
7.5.2.1 addAddressTranslation()	38
7.5.2.2 addMemorySpace()	39
7.5.2.3 setDefaultAddressTranslateDelegate() [1/3]	39
7.5.2.4 setDefaultAddressTranslateDelegate() [2/3]	39
7.5.2.5 setDefaultAddressTranslateDelegate() [3/3]	40
7.5.2.6 setDefaultGetMemorySidebandInfoDelegate() [1/3]	40

7.5.2.7 setDefaultGetMemorySidebandInfoDelegate() [2/3]	41
7.5.2.8 setDefaultGetMemorySidebandInfoDelegate() [3/3]	41
7.5.2.9 setDefaultMemoryReadDelegate() [1/3]	42
7.5.2.10 setDefaultMemoryReadDelegate() [2/3]	42
7.5.2.11 setDefaultMemoryReadDelegate() [3/3]	43
7.5.2.12 setDefaultMemoryWriteDelegate() [1/3]	43
7.5.2.13 setDefaultMemoryWriteDelegate() [2/3]	44
7.5.2.14 setDefaultMemoryWriteDelegate() [3/3]	44
7.5.2.15 setPropertyCanonicalMsnScheme()	45
7.6 IrisInstanceBuilder image loading APIs	45
7.6.1 Detailed Description	45
7.6.2 Function Documentation	45
7.6.2.1 setLoadImageDataDelegate() [1/3]	45
7.6.2.2 setLoadImageDataDelegate() [2/3]	47
7.6.2.3 setLoadImageDataDelegate() [3/3]	47
7.6.2.4 setLoadImageFileDelegate() [1/3]	47
7.6.2.5 setLoadImageFileDelegate() [2/3]	48
7.6.2.6 setLoadImageFileDelegate() [3/3]	48
7.7 IrisInstanceBuilder image readData callback APIs.	49
7.7.1 Detailed Description	49
7.7.2 Function Documentation	49
7.7.2.1 openImage()	49
7.8 IrisInstanceBuilder execution stepping APIs	49
7.8.1 Detailed Description	50
7.8.2 Function Documentation	50
7.8.2.1 setRemainingStepGetDelegate() [1/3]	50
7.8.2.2 setRemainingStepGetDelegate() [2/3]	50
7.8.2.3 setRemainingStepGetDelegate() [3/3]	50
7.8.2.4 setRemainingStepSetDelegate() [1/3]	51
7.8.2.5 setRemainingStepSetDelegate() [2/3]	51
7.8.2.6 setRemainingStepSetDelegate() [3/3]	52
7.8.2.7 setStepCountGetDelegate() [1/3]	52
7.8.2.8 setStepCountGetDelegate() [2/3]	52
7.8.2.9 setStepCountGetDelegate() [3/3]	53
7.9 Disassembler delegate functions	53
7.9.1 Detailed Description	54
7.9.2 Typedef Documentation	54
7.9.2.1 DisassembleOpcodeDelegate	54
7.9.2.2 GetCurrentDisassemblyModeDelegate	54
7.9.2.3 GetDisassemblyDelegate	54
7.9.3 Function Documentation	54
7.9.3.1 addDisassemblyMode()	54

7.9.3.2 attachTo()	55
7.9.3.3 IrisInstanceDisassembler()	55
7.9.3.4 setDisassembleOpcodeDelegate()	55
7.9.3.5 setGetCurrentModeDelegate()	55
7.9.3.6 setGetDisassemblyDelegate()	55
7.10 Semihosting data request flag constants	56
7.10.1 Detailed Description	56
<b>8 Class Documentation</b>	<b>57</b>
8.1 iris::IrisInstanceBuilder::AddressTranslationBuilder Class Reference	57
8.1.1 Detailed Description	57
8.1.2 Member Function Documentation	57
8.1.2.1 setTranslateDelegate() [1/3]	57
8.1.2.2 setTranslateDelegate() [2/3]	58
8.1.2.3 setTranslateDelegate() [3/3]	58
8.2 iris::IrisInstanceMemory::AddressTranslationInfoAndAccess Struct Reference	59
8.2.1 Detailed Description	59
8.3 iris::BreakpointHitInfo Struct Reference	59
8.4 iris::IrisInstanceBuilder::EventSourceBuilder Class Reference	59
8.4.1 Detailed Description	60
8.4.2 Member Function Documentation	60
8.4.2.1 addEnumElement()	60
8.4.2.2 addField()	60
8.4.2.3 addOption()	61
8.4.2.4 hasSideEffects()	61
8.4.2.5 setCounter()	62
8.4.2.6 setDescription()	62
8.4.2.7 setEventStreamCreateDelegate() [1/2]	62
8.4.2.8 setEventStreamCreateDelegate() [2/2]	63
8.4.2.9 setFormat()	63
8.4.2.10 setHidden()	63
8.4.2.11 setName()	64
8.5 iris::IrisInstanceEvent::EventSourceInfoAndDelegate Struct Reference	64
8.5.1 Detailed Description	64
8.6 iris::EventStream Class Reference	64
8.6.1 Detailed Description	67
8.6.2 Member Function Documentation	67
8.6.2.1 action()	67
8.6.2.2 addField() [1/5]	67
8.6.2.3 addField() [2/5]	67
8.6.2.4 addField() [3/5]	68
8.6.2.5 addField() [4/5]	68

8.6.2.6 addField() [5/5]	68
8.6.2.7 addFieldSlow() [1/5]	69
8.6.2.8 addFieldSlow() [2/5]	69
8.6.2.9 addFieldSlow() [3/5]	69
8.6.2.10 addFieldSlow() [4/5]	69
8.6.2.11 addFieldSlow() [5/5]	70
8.6.2.12 checkRangePc()	70
8.6.2.13 disable()	70
8.6.2.14 emitEventBegin() [1/2]	70
8.6.2.15 emitEventBegin() [2/2]	71
8.6.2.16 emitEventEnd()	71
8.6.2.17 enable()	71
8.6.2.18 flush()	71
8.6.2.19 getCountVal()	72
8.6.2.20 getEcInstId()	72
8.6.2.21 getEsId()	72
8.6.2.22 getEventSourceInfo()	72
8.6.2.23 getProxiedByInstancId()	72
8.6.2.24 getState()	73
8.6.2.25 isCounter()	73
8.6.2.26 isEnabled()	73
8.6.2.27 IsProxiedByOtherInstance()	73
8.6.2.28 IsProxyForOtherInstance()	73
8.6.2.29 selfRelease()	74
8.6.2.30 setCounter()	74
8.6.2.31 setOptions()	74
8.6.2.32 setProperties()	74
8.6.2.33 setProxiedByInstancId()	75
8.6.2.34 setRanges()	75
8.6.3 Member Data Documentation	75
8.6.3.1 counter	75
8.6.3.2 irisInstance	76
8.6.3.3 proxiedByInstancId	76
8.7 iris::IrisInstanceBuilder::FieldBuilder Class Reference	76
8.7.1 Detailed Description	78
8.7.2 Member Function Documentation	78
8.7.2.1 addEnum()	78
8.7.2.2 addField()	78
8.7.2.3 addLogicalField()	78
8.7.2.4 addStringEnum()	79
8.7.2.5 getRsclId() [1/2]	79
8.7.2.6 getRsclId() [2/2]	79

8.7.2.7 parent()	79
8.7.2.8 setAddressOffset()	79
8.7.2.9 setBitWidth()	80
8.7.2.10 setCanonicalRn()	80
8.7.2.11 setCanonicalRnElfDwarf()	80
8.7.2.12 setCname()	81
8.7.2.13 setDescription()	81
8.7.2.14 setFormat()	81
8.7.2.15 setLsbOffset()	81
8.7.2.16 setName()	82
8.7.2.17 setParentRscId()	82
8.7.2.18 setReadDelegate() [1/3]	82
8.7.2.19 setReadDelegate() [2/3]	83
8.7.2.20 setReadDelegate() [3/3]	83
8.7.2.21 setResetData() [1/2]	84
8.7.2.22 setResetData() [2/2]	84
8.7.2.23 setResetDataFromContainer()	84
8.7.2.24 setResetString()	85
8.7.2.25 setRwMode()	85
8.7.2.26 setSubRscId()	85
8.7.2.27 setTag() [1/2]	85
8.7.2.28 setTag() [2/2]	86
8.7.2.29 setType()	86
8.7.2.30 setWriteDelegate() [1/3]	86
8.7.2.31 setWriteDelegate() [2/3]	87
8.7.2.32 setWriteDelegate() [3/3]	87
8.7.2.33 setWriteMask() [1/2]	87
8.7.2.34 setWriteMask() [2/2]	88
8.7.2.35 setWriteMaskFromContainer()	88
8.8 iris::IrisCConnection Class Reference	89
8.8.1 Detailed Description	89
8.9 iris::IrisClient Class Reference	89
8.9.1 Constructor & Destructor Documentation	91
8.9.1.1 IrisClient()	91
8.9.2 Member Function Documentation	91
8.9.2.1 connect() [1/2]	91
8.9.2.2 connect() [2/2]	91
8.9.2.3 connectSocketFd()	92
8.9.2.4 disconnect()	92
8.9.2.5 disconnectAndWaitForChildToExit()	92
8.9.2.6 getIrisInstance()	92
8.9.2.7 initServiceServer()	92

8.9.2.8 loadPlugin()	92
8.9.2.9 processEvents()	92
8.9.2.10 setInstanceName()	93
8.9.2.11 setSleepOnDestructionMs()	93
8.9.2.12 spawnAndConnect()	93
8.9.2.13 stopWaitForEvent()	93
8.9.2.14 waitForEvent()	93
8.9.2.15 waitpidWithTimeout()	93
8.9.3 Member Data Documentation	93
8.9.3.1 connectionHelpStr	94
8.10 iris::IrisCommandLineParser Class Reference	94
8.10.1 Detailed Description	95
8.10.2 Member Function Documentation	95
8.10.2.1 addOption()	95
8.10.2.2 clear()	95
8.10.2.3 defaultMessageFunc()	96
8.10.2.4 getDbf()	96
8.10.2.5 getHelpMessage()	96
8.10.2.6 getInt()	96
8.10.2.7 getMap()	96
8.10.2.8 getUInt()	96
8.10.2.9 isSpecified()	96
8.10.2.10 noNonOptionArguments()	96
8.10.2.11 parseCommandLine()	96
8.10.2.12 pleaseSpecifyOneOf()	97
8.10.2.13 printErrorAndExit() [1/3]	97
8.10.2.14 printErrorAndExit() [2/3]	97
8.10.2.15 printErrorAndExit() [3/3]	97
8.10.2.16 printMessage()	97
8.10.2.17 setMessageFunc()	97
8.10.2.18 setValue()	98
8.10.2.19 unsetValue()	98
8.11 iris::IrisEventEmitter< ARGS > Class Template Reference	98
8.11.1 Detailed Description	98
8.11.2 Member Function Documentation	99
8.11.2.1 operator()()	99
8.12 iris::IrisEventRegistry Class Reference	99
8.12.1 Detailed Description	99
8.12.2 Member Function Documentation	100
8.12.2.1 addField()	100
8.12.2.2 addFieldSlow()	100
8.12.2.3 begin()	100



8.12.2.4 emitEventEnd()	101
8.12.2.5 empty()	101
8.12.2.6 end()	101
8.12.2.7 forEach()	101
8.12.2.8 registerEventStream()	102
8.12.2.9 unregisterEventStream()	102
8.13 iris::IrisEventStream Class Reference	102
8.13.1 Detailed Description	102
8.13.2 Member Function Documentation	102
8.13.2.1 disable()	103
8.13.2.2 enable()	103
8.14 iris::IrisGlobalInstance Class Reference	103
8.14.1 Member Function Documentation	103
8.14.1.1 getIrisInstance()	104
8.14.1.2 registerChannel()	104
8.14.1.3 registerIrisInterfaceChannel()	104
8.14.1.4 unregisterIrisInterfaceChannel()	104
8.15 iris::IrisInstance Class Reference	104
8.15.1 Member Typedef Documentation	108
8.15.1.1 EventCallbackFunction	108
8.15.2 Constructor & Destructor Documentation	108
8.15.2.1 IrisInstance() [1/2]	108
8.15.2.2 IrisInstance() [2/2]	108
8.15.3 Member Function Documentation	109
8.15.3.1 addCallback_IRIS_INSTANCE_REGISTRY_CHANGED()	109
8.15.3.2 disableEvent()	109
8.15.3.3 enableEvent() [1/2]	109
8.15.3.4 enableEvent() [2/2]	109
8.15.3.5 findEventSources()	110
8.15.3.6 findEventSourcesAndFields()	110
8.15.3.7 findInstanceInfos()	111
8.15.3.8 getBuilder()	111
8.15.3.9 getInstanceId()	112
8.15.3.10 getInstanceInfo() [1/2]	112
8.15.3.11 getInstanceInfo() [2/2]	112
8.15.3.12 getInstanceList()	112
8.15.3.13 getInstanceName() [1/2]	112
8.15.3.14 getInstanceName() [2/2]	113
8.15.3.15 getInstId()	113
8.15.3.16 getLocalIrisInterface()	113
8.15.3.17 getMemorySpaceId()	113
8.15.3.18 getMemorySpaceInfo()	113

8.15.3.19	getPropertyMap()	113
8.15.3.20	getRemoteIrisInterface()	114
8.15.3.21	getResourceId()	114
8.15.3.22	irisCall()	114
8.15.3.23	irisCallNoThrow()	114
8.15.3.24	irisCallThrow()	114
8.15.3.25	isRegistered()	114
8.15.3.26	isValidEvBufId()	115
8.15.3.27	notifyStateChanged()	115
8.15.3.28	publishCppInterface()	115
8.15.3.29	registerEventBufferCallback() [1/3]	115
8.15.3.30	registerEventBufferCallback() [2/3]	116
8.15.3.31	registerEventBufferCallback() [3/3]	116
8.15.3.32	registerEventCallback() [1/3]	116
8.15.3.33	registerEventCallback() [2/3]	117
8.15.3.34	registerEventCallback() [3/3]	117
8.15.3.35	registerFunction()	117
8.15.3.36	registerInstance()	118
8.15.3.37	resourceRead()	118
8.15.3.38	resourceReadCrn()	119
8.15.3.39	resourceReadStr()	119
8.15.3.40	resourceWrite()	119
8.15.3.41	resourceWriteCrn()	119
8.15.3.42	resourceWriteStr()	119
8.15.3.43	sendRequest()	120
8.15.3.44	sendResponse()	120
8.15.3.45	setCallback_IRIS_SHUTDOWN_LEAVE()	120
8.15.3.46	setCallback_IRIS_SIMULATION_TIME_EVENT()	120
8.15.3.47	setConnectionInterface()	120
8.15.3.48	setPendingSyncStepResponse()	121
8.15.3.49	setProperty()	121
8.15.3.50	setThrowOnError()	121
8.15.3.51	simulationTimeDisableEvents()	121
8.15.3.52	simulationTimeIsRunning()	121
8.15.3.53	simulationTimeRun()	122
8.15.3.54	simulationTimeRunUntilStop()	122
8.15.3.55	simulationTimeStop()	122
8.15.3.56	simulationTimeWaitForStop()	122
8.15.3.57	unpublishCppInterface()	122
8.15.3.58	unregisterInstance()	123
8.16	iris::IrisInstanceBreakpoint Class Reference	123
8.16.1	Detailed Description	123

8.16.2 Member Function Documentation	124
8.16.2.1 addCondition()	124
8.16.2.2 attachTo()	124
8.16.2.3 getBreakpointInfo()	124
8.16.2.4 handleBreakpointHit()	124
8.16.2.5 notifyBreakpointHit()	125
8.16.2.6 notifyBreakpointHitData()	125
8.16.2.7 notifyBreakpointHitRegister()	125
8.16.2.8 setBreakpointDeleteDelegate()	126
8.16.2.9 setBreakpointSetDelegate()	126
8.16.2.10 setEventHandler()	126
8.16.2.11 setHandleBreakpointHitDelegate()	126
8.17 iris::IrisInstanceBuilder Class Reference	127
8.17.1 Detailed Description	133
8.17.2 Constructor & Destructor Documentation	133
8.17.2.1 IrisInstanceBuilder()	133
8.17.3 Member Function Documentation	133
8.17.3.1 addTable()	133
8.17.3.2 enableSemihostingAndGetManager()	134
8.17.3.3 setDbgStateDelegates()	134
8.17.3.4 setDbgStateGetAcknowledgeDelegate() [1/3]	135
8.17.3.5 setDbgStateGetAcknowledgeDelegate() [2/3]	135
8.17.3.6 setDbgStateGetAcknowledgeDelegate() [3/3]	135
8.17.3.7 setDbgStateSetRequestDelegate() [1/3]	136
8.17.3.8 setDbgStateSetRequestDelegate() [2/3]	136
8.17.3.9 setDbgStateSetRequestDelegate() [3/3]	136
8.17.3.10 setDefaultTableReadDelegate() [1/3]	137
8.17.3.11 setDefaultTableReadDelegate() [2/3]	137
8.17.3.12 setDefaultTableReadDelegate() [3/3]	138
8.17.3.13 setDefaultTableWriteDelegate() [1/3]	138
8.17.3.14 setDefaultTableWriteDelegate() [2/3]	138
8.17.3.15 setDefaultTableWriteDelegate() [3/3]	139
8.17.3.16 setExecutionStateGetDelegate() [1/3]	139
8.17.3.17 setExecutionStateGetDelegate() [2/3]	140
8.17.3.18 setExecutionStateGetDelegate() [3/3]	140
8.17.3.19 setExecutionStateSetDelegate() [1/3]	140
8.17.3.20 setExecutionStateSetDelegate() [2/3]	141
8.17.3.21 setExecutionStateSetDelegate() [3/3]	141
8.17.3.22 setGetCurrentDisassemblyModeDelegate()	141
8.18 iris::IrisInstanceCheckpoint Class Reference	142
8.18.1 Detailed Description	142
8.18.2 Member Function Documentation	142

8.18.2.1 attachTo()	142
8.18.2.2 setCheckpointRestoreDelegate()	142
8.18.2.3 setCheckpointSaveDelegate()	143
8.19 iris::IrisInstanceDebuggableState Class Reference	143
8.19.1 Detailed Description	143
8.19.2 Member Function Documentation	143
8.19.2.1 attachTo()	143
8.19.2.2 setGetAcknowledgeDelegate()	143
8.19.2.3 setSetRequestDelegate()	144
8.20 iris::IrisInstanceDisassembler Class Reference	144
8.20.1 Detailed Description	144
8.21 iris::IrisInstanceEvent Class Reference	144
8.21.1 Detailed Description	145
8.21.2 Constructor & Destructor Documentation	145
8.21.2.1 IrisInstanceEvent()	146
8.21.3 Member Function Documentation	146
8.21.3.1 addEventSource() [1/2]	146
8.21.3.2 addEventSource() [2/2]	146
8.21.3.3 attachTo()	146
8.21.3.4 deleteEventSource()	147
8.21.3.5 enhanceEventSource()	147
8.21.3.6 eventBufferClear()	147
8.21.3.7 eventBufferGetSyncStepResponse()	147
8.21.3.8 hasEventSource()	148
8.21.3.9 isValidEvBufId()	148
8.21.3.10 setDefaultEsCreateDelegate()	148
8.22 iris::IrisInstanceFactoryBuilder Class Reference	148
8.22.1 Detailed Description	149
8.22.2 Constructor & Destructor Documentation	149
8.22.2.1 IrisInstanceFactoryBuilder()	149
8.22.3 Member Function Documentation	149
8.22.3.1 addBooleanParameter()	149
8.22.3.2 addHiddenBooleanParameter()	151
8.22.3.3 addHiddenParameter()	151
8.22.3.4 addHiddenStringParameter()	151
8.22.3.5 addParameter()	153
8.22.3.6 addStringParameter()	153
8.22.3.7 getHiddenParameterInfo()	153
8.22.3.8 getParameterInfo()	154
8.23 iris::IrisInstanceImage Class Reference	154
8.23.1 Detailed Description	154
8.23.2 Constructor & Destructor Documentation	154

8.23.2.1 IrisInstanceImage()	155
8.23.3 Member Function Documentation	155
8.23.3.1 attachTo()	155
8.23.3.2 readFileData()	155
8.23.3.3 setLoadImageDataDelegate()	155
8.23.3.4 setLoadImageFileDelegate()	156
8.24 iris::IrisInstanceImage_Callback Class Reference	156
8.24.1 Detailed Description	156
8.24.2 Constructor & Destructor Documentation	156
8.24.2.1 IrisInstanceImage_Callback()	156
8.24.3 Member Function Documentation	157
8.24.3.1 attachTo()	157
8.24.3.2 openImage()	157
8.25 iris::IrisInstanceMemory Class Reference	157
8.25.1 Detailed Description	158
8.25.2 Constructor & Destructor Documentation	158
8.25.2.1 IrisInstanceMemory()	158
8.25.3 Member Function Documentation	158
8.25.3.1 addAddressTranslation()	158
8.25.3.2 addMemorySpace()	159
8.25.3.3 attachTo()	159
8.25.3.4 setDefaultGetSidebandInfoDelegate()	159
8.25.3.5 setDefaultReadDelegate()	160
8.25.3.6 setDefaultTranslateDelegate()	160
8.25.3.7 setDefaultWriteDelegate()	160
8.26 iris::IrisInstancePerInstanceExecution Class Reference	160
8.26.1 Detailed Description	161
8.26.2 Constructor & Destructor Documentation	161
8.26.2.1 IrisInstancePerInstanceExecution()	161
8.26.3 Member Function Documentation	161
8.26.3.1 attachTo()	161
8.26.3.2 setExecutionStateGetDelegate()	161
8.26.3.3 setExecutionStateSetDelegate()	161
8.27 iris::IrisInstanceResource Class Reference	162
8.27.1 Detailed Description	162
8.27.2 Constructor & Destructor Documentation	163
8.27.2.1 IrisInstanceResource()	163
8.27.3 Member Function Documentation	163
8.27.3.1 addResource()	163
8.27.3.2 attachTo()	163
8.27.3.3 beginResourceGroup()	164
8.27.3.4 calcHierarchicalNames()	164

8.27.3.5 getResourceInfo()	164
8.27.3.6 makeNamesHierarchical()	165
8.27.3.7 setNextSubRscId()	165
8.27.3.8 setTag()	165
8.28 iris::IrisInstanceSemihosting Class Reference	166
8.28.1 Member Function Documentation	166
8.28.1.1 attachTo()	166
8.28.1.2 readData()	166
8.28.1.3 semihostedCall()	167
8.28.1.4 setEventHandler()	167
8.29 iris::IrisInstanceSimulation Class Reference	167
8.29.1 Detailed Description	169
8.29.2 Constructor & Destructor Documentation	169
8.29.2.1 IrisInstanceSimulation()	169
8.29.3 Member Function Documentation	169
8.29.3.1 attachTo()	169
8.29.3.2 enterPostInstantiationPhase()	169
8.29.3.3 getSimulationPhaseDescription()	169
8.29.3.4 getSimulationPhaseName()	170
8.29.3.5 notifySimPhase()	170
8.29.3.6 registerSimEventsOnGlobalInstance()	170
8.29.3.7 setConnectionInterface()	170
8.29.3.8 setEventHandler()	170
8.29.3.9 setGetParameterInfoDelegate() [1/3]	170
8.29.3.10 setGetParameterInfoDelegate() [2/3]	171
8.29.3.11 setGetParameterInfoDelegate() [3/3]	171
8.29.3.12 setInstantiateDelegate() [1/3]	171
8.29.3.13 setInstantiateDelegate() [2/3]	172
8.29.3.14 setInstantiateDelegate() [3/3]	172
8.29.3.15 setLogLevel()	172
8.29.3.16 setRequestShutdownDelegate() [1/3]	172
8.29.3.17 setRequestShutdownDelegate() [2/3]	173
8.29.3.18 setRequestShutdownDelegate() [3/3]	173
8.29.3.19 setResetDelegate() [1/3]	173
8.29.3.20 setResetDelegate() [2/3]	173
8.29.3.21 setResetDelegate() [3/3]	174
8.29.3.22 setSetParameterValueDelegate() [1/3]	174
8.29.3.23 setSetParameterValueDelegate() [2/3]	174
8.29.3.24 setSetParameterValueDelegate() [3/3]	174
8.30 iris::IrisInstanceSimulationTime Class Reference	175
8.30.1 Detailed Description	176
8.30.2 Constructor & Destructor Documentation	176

8.30.2.1 IrisInstanceSimulationTime()	176
8.30.3 Member Function Documentation	176
8.30.3.1 attachTo()	176
8.30.3.2 registerSimTimeEventsOnGlobalInstance()	176
8.30.3.3 setEventHandler()	176
8.30.3.4 setSimTimeGetDelegate() [1/3]	177
8.30.3.5 setSimTimeGetDelegate() [2/3]	177
8.30.3.6 setSimTimeGetDelegate() [3/3]	177
8.30.3.7 setSimTimeNotifyStateChanged()	177
8.30.3.8 setSimTimeRunDelegate() [1/3]	178
8.30.3.9 setSimTimeRunDelegate() [2/3]	178
8.30.3.10 setSimTimeRunDelegate() [3/3]	178
8.30.3.11 setSimTimeStopDelegate() [1/3]	179
8.30.3.12 setSimTimeStopDelegate() [2/3]	179
8.30.3.13 setSimTimeStopDelegate() [3/3]	179
8.31 iris::IrisInstanceStep Class Reference	179
8.31.1 Detailed Description	180
8.31.2 Constructor & Destructor Documentation	180
8.31.2.1 IrisInstanceStep()	180
8.31.3 Member Function Documentation	180
8.31.3.1 attachTo()	180
8.31.3.2 setRemainingStepGetDelegate()	180
8.31.3.3 setRemainingStepSetDelegate()	181
8.31.3.4 setStepCountGetDelegate()	181
8.32 iris::IrisInstanceTable Class Reference	181
8.32.1 Detailed Description	181
8.32.2 Constructor & Destructor Documentation	182
8.32.2.1 IrisInstanceTable()	182
8.32.3 Member Function Documentation	182
8.32.3.1 addTableInfo()	182
8.32.3.2 attachTo()	182
8.32.3.3 setDefaultReadDelegate()	182
8.32.3.4 setDefaultWriteDelegate()	183
8.33 iris::IrisInstantiationContext Class Reference	183
8.33.1 Detailed Description	184
8.33.2 Member Function Documentation	184
8.33.2.1 error()	184
8.33.2.2 getBoolParameter()	184
8.33.2.3 getConnectionInterface()	184
8.33.2.4 getInstanceName()	185
8.33.2.5 getParameter() [1/3]	185
8.33.2.6 getParameter() [2/3]	185

8.33.2.7 <a href="#">getParameter()</a> [3/3]	185
8.33.2.8 <a href="#">getRecommendedInstanceFlags()</a>	186
8.33.2.9 <a href="#">getS64Parameter()</a>	186
8.33.2.10 <a href="#">getStringParameter()</a>	186
8.33.2.11 <a href="#">getSubcomponentContext()</a>	186
8.33.2.12 <a href="#">getU64Parameter()</a>	187
8.33.2.13 <a href="#">parameterError()</a>	187
8.33.2.14 <a href="#">parameterWarning()</a>	187
8.33.2.15 <a href="#">warning()</a>	188
8.34 <a href="#">iris::IrisNonFactoryPlugin&lt; PLUGIN_CLASS &gt; Class Template Reference</a>	188
8.34.1 Detailed Description	188
8.35 <a href="#">iris::IrisParameterBuilder Class Reference</a>	190
8.35.1 Detailed Description	191
8.35.2 Constructor & Destructor Documentation	191
8.35.2.1 <a href="#">IrisParameterBuilder()</a>	191
8.35.3 Member Function Documentation	192
8.35.3.1 <a href="#">addEnum()</a>	192
8.35.3.2 <a href="#">addStringEnum()</a>	192
8.35.3.3 <a href="#">setBitWidth()</a>	192
8.35.3.4 <a href="#">setDefault()</a> [1/3]	193
8.35.3.5 <a href="#">setDefault()</a> [2/3]	193
8.35.3.6 <a href="#">setDefault()</a> [3/3]	193
8.35.3.7 <a href="#">setDefaultFloat()</a>	193
8.35.3.8 <a href="#">setDefaultSigned()</a> [1/2]	194
8.35.3.9 <a href="#">setDefaultSigned()</a> [2/2]	194
8.35.3.10 <a href="#">setDescr()</a>	194
8.35.3.11 <a href="#">setFormat()</a>	195
8.35.3.12 <a href="#">setHidden()</a>	195
8.35.3.13 <a href="#">setInitOnly()</a>	195
8.35.3.14 <a href="#">setMax()</a> [1/2]	195
8.35.3.15 <a href="#">setMax()</a> [2/2]	196
8.35.3.16 <a href="#">setMaxFloat()</a>	196
8.35.3.17 <a href="#">setMaxSigned()</a> [1/2]	196
8.35.3.18 <a href="#">setMaxSigned()</a> [2/2]	196
8.35.3.19 <a href="#">setMin()</a> [1/2]	197
8.35.3.20 <a href="#">setMin()</a> [2/2]	197
8.35.3.21 <a href="#">setMinFloat()</a>	197
8.35.3.22 <a href="#">setMinSigned()</a> [1/2]	198
8.35.3.23 <a href="#">setMinSigned()</a> [2/2]	198
8.35.3.24 <a href="#">setName()</a>	198
8.35.3.25 <a href="#">setRange()</a> [1/2]	198
8.35.3.26 <a href="#">setRange()</a> [2/2]	199



8.35.3.27 setRangeFloat()	199
8.35.3.28 setRangeSigned() [1/2]	199
8.35.3.29 setRangeSigned() [2/2]	200
8.35.3.30 setRwMode()	200
8.35.3.31 setSubRscId()	200
8.35.3.32 setTag() [1/2]	201
8.35.3.33 setTag() [2/2]	201
8.35.3.34 setTopology()	201
8.35.3.35 setType()	202
8.36 iris::IrisPluginFactory< PLUGIN_CLASS > Class Template Reference	202
8.37 iris::IrisPluginFactoryBuilder Class Reference	202
8.37.1 Detailed Description	203
8.37.2 Constructor & Destructor Documentation	203
8.37.2.1 IrisPluginFactoryBuilder()	203
8.37.3 Member Function Documentation	203
8.37.3.1 getDefaultInstanceName()	203
8.37.3.2 getInstanceNamePrefix()	203
8.37.3.3 getPluginName()	203
8.37.3.4 setDefaultInstanceName()	204
8.37.3.5 setInstanceNamePrefix()	204
8.37.3.6 setPluginName()	204
8.38 iris::IrisRegisterReadEventEmitter< REG_T, ARGS > Class Template Reference	204
8.38.1 Detailed Description	204
8.38.2 Member Function Documentation	205
8.38.2.1 operator()()	205
8.39 iris::IrisRegisterUpdateEventEmitter< REG_T, ARGS > Class Template Reference	206
8.39.1 Detailed Description	206
8.39.2 Member Function Documentation	206
8.39.2.1 operator()()	206
8.40 iris::IrisSimulationResetContext Class Reference	207
8.40.1 Detailed Description	207
8.40.2 Member Function Documentation	207
8.40.2.1 getAllowPartialReset()	207
8.41 iris::IrisInstanceBuilder::MemorySpaceBuilder Class Reference	207
8.41.1 Detailed Description	208
8.41.2 Member Function Documentation	208
8.41.2.1 addAttribute()	209
8.41.2.2 getSpaceId()	209
8.41.2.3 setAttributeDefault()	209
8.41.2.4 setCanonicalMsn()	209
8.41.2.5 setDescription()	210
8.41.2.6 setEndianness()	210

8.41.2.7 setMaxAddr()	210
8.41.2.8 setMinAddr()	210
8.41.2.9 setName()	211
8.41.2.10 setReadDelegate() [1/3]	211
8.41.2.11 setReadDelegate() [2/3]	211
8.41.2.12 setReadDelegate() [3/3]	212
8.41.2.13 setSidebandDelegate() [1/3]	212
8.41.2.14 setSidebandDelegate() [2/3]	213
8.41.2.15 setSidebandDelegate() [3/3]	213
8.41.2.16 setSupportedByteWidths()	213
8.41.2.17 setWriteDelegate() [1/3]	214
8.41.2.18 setWriteDelegate() [2/3]	214
8.41.2.19 setWriteDelegate() [3/3]	215
8.42 iris::IrisCommandLineParser::Option Struct Reference	215
8.42.1 Detailed Description	215
8.42.2 Member Function Documentation	215
8.42.2.1 setList()	216
8.43 iris::IrisInstanceBuilder::ParameterBuilder Class Reference	216
8.43.1 Detailed Description	217
8.43.2 Member Function Documentation	217
8.43.2.1 addEnum()	218
8.43.2.2 addStringEnum()	218
8.43.2.3 getRscId() [1/2]	218
8.43.2.4 getRscId() [2/2]	218
8.43.2.5 setBitWidth()	219
8.43.2.6 setCname()	219
8.43.2.7 setDefaultData() [1/2]	219
8.43.2.8 setDefaultData() [2/2]	219
8.43.2.9 setDefaultDataFromContainer()	220
8.43.2.10 setDefaultString()	220
8.43.2.11 setDescription()	220
8.43.2.12 setFormat()	221
8.43.2.13 setHidden()	221
8.43.2.14 setInitOnly()	221
8.43.2.15 setMax() [1/2]	222
8.43.2.16 setMax() [2/2]	222
8.43.2.17 setMaxFromContainer()	222
8.43.2.18 setMin() [1/2]	223
8.43.2.19 setMin() [2/2]	223
8.43.2.20 setMinFromContainer()	223
8.43.2.21 setName()	224
8.43.2.22 setParentRscId()	224

8.43.2.23 setReadDelegate() [1/3]	224
8.43.2.24 setReadDelegate() [2/3]	224
8.43.2.25 setReadDelegate() [3/3]	225
8.43.2.26 setRwMode()	225
8.43.2.27 setSubRscId()	226
8.43.2.28 setTag() [1/2]	226
8.43.2.29 setTag() [2/2]	226
8.43.2.30 setType()	226
8.43.2.31 setWriteDelegate() [1/3]	227
8.43.2.32 setWriteDelegate() [2/3]	227
8.43.2.33 setWriteDelegate() [3/3]	227
8.44 iris::IrisInstanceEvent::ProxyEventInfo Struct Reference	228
8.44.1 Detailed Description	228
8.45 iris::IrisInstanceBuilder::RegisterBuilder Class Reference	228
8.45.1 Detailed Description	230
8.45.2 Member Function Documentation	230
8.45.2.1 addEnum()	230
8.45.2.2 addField()	231
8.45.2.3 addLogicalField()	231
8.45.2.4 addStringEnum()	231
8.45.2.5 getRscId() [1/2]	232
8.45.2.6 getRscId() [2/2]	232
8.45.2.7 setAddressOffset()	232
8.45.2.8 setBitWidth()	232
8.45.2.9 setCanonicalRn()	233
8.45.2.10 setCanonicalRnElfDwarf()	233
8.45.2.11 setCname()	233
8.45.2.12 setDescription()	233
8.45.2.13 setFormat()	234
8.45.2.14 setLsbOffset()	234
8.45.2.15 setName()	234
8.45.2.16 setParentRscId()	235
8.45.2.17 setReadDelegate() [1/3]	235
8.45.2.18 setReadDelegate() [2/3]	235
8.45.2.19 setReadDelegate() [3/3]	236
8.45.2.20 setResetData() [1/2]	236
8.45.2.21 setResetData() [2/2]	236
8.45.2.22 setResetDataFromContainer()	237
8.45.2.23 setResetString()	237
8.45.2.24 setRwMode()	237
8.45.2.25 setSubRscId()	238
8.45.2.26 setTag() [1/2]	238

8.45.2.27 setTag() [2/2]	238
8.45.2.28 setType()	239
8.45.2.29 setWriteDelegate() [1/3]	239
8.45.2.30 setWriteDelegate() [2/3]	239
8.45.2.31 setWriteDelegate() [3/3]	240
8.45.2.32 setWriteMask() [1/2]	240
8.45.2.33 setWriteMask() [2/2]	240
8.45.2.34 setWriteMaskFromContainer()	241
8.46 iris::IrisInstanceResource::ResourceInfoAndAccess Struct Reference	241
8.46.1 Detailed Description	241
8.47 iris::ResourceWriteValue Struct Reference	242
8.47.1 Detailed Description	242
8.48 iris::IrisInstanceBuilder::SemihostingManager Class Reference	242
8.48.1 Detailed Description	242
8.48.2 Member Function Documentation	242
8.48.2.1 readData()	242
8.48.2.2 semihostedCall()	243
8.49 iris::IrisInstanceMemory::SpaceInfoAndAccess Struct Reference	243
8.49.1 Detailed Description	243
8.50 iris::IrisInstanceBuilder::TableBuilder Class Reference	243
8.50.1 Detailed Description	244
8.50.2 Member Function Documentation	244
8.50.2.1 addColumn()	244
8.50.2.2 addColumnInfo()	245
8.50.2.3 setDescription()	245
8.50.2.4 setFormatLong()	245
8.50.2.5 setFormatShort()	246
8.50.2.6 setIndexFormatHint()	246
8.50.2.7 setMaxIndex()	246
8.50.2.8 setMinIndex()	246
8.50.2.9 setName()	247
8.50.2.10 setReadDelegate() [1/3]	247
8.50.2.11 setReadDelegate() [2/3]	247
8.50.2.12 setReadDelegate() [3/3]	248
8.50.2.13 setWriteDelegate() [1/3]	248
8.50.2.14 setWriteDelegate() [2/3]	249
8.50.2.15 setWriteDelegate() [3/3]	249
8.51 iris::IrisInstanceBuilder::TableColumnBuilder Class Reference	249
8.51.1 Detailed Description	250
8.51.2 Member Function Documentation	250
8.51.2.1 addColumn()	250
8.51.2.2 addColumnInfo()	251

8.51.2.3 endColumn()	251
8.51.2.4 setBitWidth()	251
8.51.2.5 setDescription()	251
8.51.2.6 setFormat()	252
8.51.2.7 setFormatLong()	252
8.51.2.8 setFormatShort()	252
8.51.2.9 setName()	253
8.51.2.10 setRwMode()	253
8.51.2.11 setType()	253
8.52 iris::IrisInstanceTable::TableInfoAndAccess Struct Reference	253
8.52.1 Detailed Description	254
<b>9 File Documentation</b>	<b>255</b>
9.1 IrisCanonicalMsnArm.h File Reference	255
9.1.1 Detailed Description	255
9.2 IrisCanonicalMsnArm.h	255
9.3 IrisCConnection.h File Reference	256
9.3.1 Detailed Description	256
9.4 IrisCConnection.h	256
9.5 IrisClient.h File Reference	258
9.5.1 Detailed Description	259
9.6 IrisClient.h	259
9.7 IrisCommandLineParser.h File Reference	275
9.7.1 Detailed Description	276
9.8 IrisCommandLineParser.h	276
9.9 IrisElfDwarfArm.h File Reference	278
9.9.1 Detailed Description	279
9.10 IrisElfDwarfArm.h	279
9.11 IrisEventEmitter.h File Reference	281
9.11.1 Detailed Description	281
9.12 IrisEventEmitter.h	281
9.13 IrisGlobalInstance.h File Reference	282
9.13.1 Detailed Description	282
9.14 IrisGlobalInstance.h	282
9.15 IrisInstance.h File Reference	285
9.15.1 Detailed Description	286
9.15.2 Typedef Documentation	286
9.15.2.1 EventCallbackDelegate	287
9.16 IrisInstance.h	287
9.17 IrisInstanceBreakpoint.h File Reference	294
9.17.1 Detailed Description	294
9.17.2 Typedef Documentation	294

9.17.2.1 BreakpointDeleteDelegate . . . . .	295
9.17.2.2 BreakpointSetDelegate . . . . .	295
9.17.2.3 HandleBreakpointHitDelegate . . . . .	295
9.18 IrisInstanceBreakpoint.h . . . . .	295
9.19 IrisInstanceBuilder.h File Reference . . . . .	296
9.19.1 Detailed Description . . . . .	297
9.20 IrisInstanceBuilder.h . . . . .	297
9.21 IrisInstanceCheckpoint.h File Reference . . . . .	323
9.21.1 Detailed Description . . . . .	323
9.21.2 Typedef Documentation . . . . .	323
9.21.2.1 CheckpointRestoreDelegate . . . . .	323
9.21.2.2 CheckpointSaveDelegate . . . . .	323
9.22 IrisInstanceCheckpoint.h . . . . .	323
9.23 IrisInstanceDebuggableState.h File Reference . . . . .	324
9.23.1 Detailed Description . . . . .	324
9.23.2 Typedef Documentation . . . . .	324
9.23.2.1 DebuggableStateGetAcknowledgeDelegate . . . . .	324
9.23.2.2 DebuggableStateSetRequestDelegate . . . . .	325
9.24 IrisInstanceDebuggableState.h . . . . .	325
9.25 IrisInstanceDisassembler.h File Reference . . . . .	325
9.25.1 Detailed Description . . . . .	326
9.26 IrisInstanceDisassembler.h . . . . .	326
9.27 IrisInstanceEvent.h File Reference . . . . .	327
9.27.1 Detailed Description . . . . .	328
9.27.2 Typedef Documentation . . . . .	328
9.27.2.1 EventStreamCreateDelegate . . . . .	328
9.28 IrisInstanceEvent.h . . . . .	328
9.29 IrisInstanceFactoryBuilder.h File Reference . . . . .	336
9.29.1 Detailed Description . . . . .	336
9.30 IrisInstanceFactoryBuilder.h . . . . .	336
9.31 IrisInstanceImage.h File Reference . . . . .	337
9.31.1 Detailed Description . . . . .	338
9.31.2 Typedef Documentation . . . . .	338
9.31.2.1 ImageLoadDataDelegate . . . . .	338
9.31.2.2 ImageLoadFileDelegate . . . . .	339
9.32 IrisInstanceImage.h . . . . .	339
9.33 IrisInstanceMemory.h File Reference . . . . .	340
9.33.1 Detailed Description . . . . .	341
9.33.2 Typedef Documentation . . . . .	341
9.33.2.1 MemoryAddressTranslateDelegate . . . . .	341
9.33.2.2 MemoryGetSidebandInfoDelegate . . . . .	341
9.33.2.3 MemoryReadDelegate . . . . .	341

9.33.2.4 MemoryWriteDelegate . . . . .	342
9.34 IrisInstanceMemory.h . . . . .	342
9.35 IrisInstancePerInstanceExecution.h File Reference . . . . .	344
9.35.1 Detailed Description . . . . .	344
9.35.2 Typedef Documentation . . . . .	344
9.35.2.1 PerInstanceExecutionStateGetDelegate . . . . .	344
9.35.2.2 PerInstanceExecutionStateSetDelegate . . . . .	344
9.36 IrisInstancePerInstanceExecution.h . . . . .	344
9.37 IrisInstanceResource.h File Reference . . . . .	345
9.37.1 Detailed Description . . . . .	346
9.37.2 Typedef Documentation . . . . .	346
9.37.2.1 ResourceReadDelegate . . . . .	346
9.37.2.2 ResourceWriteDelegate . . . . .	346
9.37.3 Function Documentation . . . . .	347
9.37.3.1 resourceReadBitField() . . . . .	347
9.37.3.2 resourceWriteBitField() . . . . .	347
9.38 IrisInstanceResource.h . . . . .	347
9.39 IrisInstanceSemihosting.h File Reference . . . . .	348
9.39.1 Detailed Description . . . . .	349
9.40 IrisInstanceSemihosting.h . . . . .	349
9.41 IrisInstanceSimulation.h File Reference . . . . .	350
9.41.1 Detailed Description . . . . .	351
9.41.2 Typedef Documentation . . . . .	351
9.41.2.1 SimulationGetParameterInfoDelegate . . . . .	352
9.41.2.2 SimulationInstantiateDelegate . . . . .	352
9.41.2.3 SimulationRequestShutdownDelegate . . . . .	352
9.41.2.4 SimulationResetDelegate . . . . .	352
9.41.2.5 SimulationSetParameterValueDelegate . . . . .	352
9.42 IrisInstanceSimulation.h . . . . .	352
9.43 IrisInstanceSimulationTime.h File Reference . . . . .	355
9.43.1 Detailed Description . . . . .	356
9.43.2 Typedef Documentation . . . . .	356
9.43.2.1 SimulationTimeGetDelegate . . . . .	356
9.43.2.2 SimulationTimeRunDelegate . . . . .	356
9.43.2.3 SimulationTimeStopDelegate . . . . .	356
9.43.3 Enumeration Type Documentation . . . . .	356
9.43.3.1 TIME_EVENT_REASON . . . . .	357
9.44 IrisInstanceSimulationTime.h . . . . .	357
9.45 IrisInstanceStep.h File Reference . . . . .	359
9.45.1 Detailed Description . . . . .	359
9.45.2 Typedef Documentation . . . . .	359
9.45.2.1 RemainingStepGetDelegate . . . . .	359

9.45.2.2 RemainingStepSetDelegate . . . . .	359
9.45.2.3 StepCountGetDelegate . . . . .	359
9.46 IrisInstanceStep.h . . . . .	360
9.47 IrisInstanceTable.h File Reference . . . . .	360
9.47.1 Detailed Description . . . . .	361
9.47.2 Typedef Documentation . . . . .	361
9.47.2.1 TableReadDelegate . . . . .	361
9.47.2.2 TableWriteDelegate . . . . .	361
9.48 IrisInstanceTable.h . . . . .	361
9.49 IrisInstantiationContext.h File Reference . . . . .	362
9.49.1 Detailed Description . . . . .	362
9.50 IrisInstantiationContext.h . . . . .	362
9.51 IrisParameterBuilder.h File Reference . . . . .	364
9.51.1 Detailed Description . . . . .	364
9.52 IrisParameterBuilder.h . . . . .	364
9.53 IrisPluginFactory.h File Reference . . . . .	368
9.53.1 Detailed Description . . . . .	368
9.53.2 Macro Definition Documentation . . . . .	368
9.53.2.1 IRIS_NON_FACTORY_PLUGIN . . . . .	369
9.53.2.2 IRIS_PLUGIN_FACTORY . . . . .	369
9.54 IrisPluginFactory.h . . . . .	369
9.55 IrisRegisterEventEmitter.h File Reference . . . . .	373
9.55.1 Detailed Description . . . . .	373
9.56 IrisRegisterEventEmitter.h . . . . .	374
9.57 IrisTcpClient.h File Reference . . . . .	374
9.57.1 Detailed Description . . . . .	375
9.58 IrisTcpClient.h . . . . .	375





# Chapter 1

## IrisSupportLib Reference Guide

Copyright © 2018-2023 Arm Limited or its affiliates. All rights reserved.

---

### About this book

This book contains API reference documentation for IrisSupportLib. It was generated from the source code using Doxygen.

The IrisSupportLib library contains the code to create an IrisInstance object and helper classes to add functionality to the instance. It also contains the code to communicate with the Iris system using U64JSON and general support code used by the library, for example thread abstraction.

IrisSupportLib is built as a static library. It must be linked in to any executable or DSO that needs to connect to Iris. The library is provided pre-compiled in \$IRIS\_HOME/<OS\_Compiler>/libIrisSupport.a|IrisSupport.lib. Headers are provided in the directory \$IRIS\_HOME/include/iris/ and the source code is provided in the directory \$IRIS\_HOME/↔ IrisSupportLib/.

### Other information

For more information about Iris, see the [Iris User Guide](#).  
See the following locations for examples of Iris clients and plug-ins:

- \$IRIS\_HOME/Examples/Client/ for Iris C++ client examples.
- \$IRIS\_HOME/Python/Examples/ for Iris Python client examples.
- \$IRIS\_HOME/Examples/Plugin/ for Iris plug-in examples.

### Feedback

**Feedback on this product** If you have any comments or suggestions about this product, contact your supplier and give:

- The product name.
- The product revision or version.
- An explanation with as much information as you can provide. Include symptoms and diagnostic procedures if appropriate.

**Feedback on content** If you have any comments on content, send an e-mail to [errata@arm.com](mailto:errata@arm.com). Give:

- The title *IrisSupportLib Reference Guide*.
- The number 101319\_0100\_15\_en.
- If applicable, the relevant page number(s) to which your comments refer.
- A concise explanation of your comments.

Arm also welcomes general suggestions for additions and improvements.

## Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used language that can be offensive. Arm strives to lead the industry and create change.

This document includes language that can be offensive. We will replace this language in a future issue of this document.

To report offensive language in this document, email [terms@arm.com](mailto:terms@arm.com).

## Non-Confidential Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm.

**No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.**

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

If any of the provisions contained in these terms conflict with any of the provisions of any click through or signed written agreement covering this document with Arm, then the click through or signed written agreement prevails over and supersedes the conflicting provisions of these terms. This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with © or ™ are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm's trademark usage guidelines at <http://www.arm.com/company/policies/trademarks>.

Copyright © 2018-2023 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

LES-PRE-20349

## Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

## Product Status

The information in this document is Final, that is for a developed product.

## Web Address

<http://www.arm.com>.

## Release Information

Document History			
Issue	Date	Confidentiality	Change

Document History			
0100-00	23 Nov 2018	Non-Confidential	New document for Fast Models v11.5.
0100-01	26 Feb 2019	Non-Confidential	Update for v11.6.
0100-02	17 May 2019	Non-Confidential	Update for v11.7.
0100-03	05 Sep 2019	Non-Confidential	Update for v11.8.
0100-04	28 Nov 2019	Non-Confidential	Update for v11.9.
0100-05	12 Mar 2020	Non-Confidential	Update for v11.10.
0100-06	22 Sep 2020	Non-Confidential	Update for v11.12.
0100-07	09 Dec 2020	Non-Confidential	Update for v11.13.
0100-08	17 Mar 2021	Non-Confidential	Update for v11.14.
0100-09	29 Jun 2021	Non-Confidential	Update for v11.15.
0100-10	06 Oct 2021	Non-Confidential	Update for v11.16.
0100-11	16 Feb 2022	Non-Confidential	Update for v11.17.
0100-12	15 Jun 2022	Non-Confidential	Update for v11.18.
0100-13	14 Sept 2022	Non-Confidential	Update for v11.19.
0100-14	07 Dec 2022	Non-Confidential	Update for v11.20.
0100-15	22 Mar 2023	Non-Confidential	Update for v11.21.



## Chapter 2

# IrisSupportLib NAMESPACE macros

To allow multiple different versions of IrisSupportLib to be used by different components in the same executable, all IrisSupportLib code is defined in a hidden inner namespace. This namespace is constructed from the revision and fork from `iris/detail/IrisSupportLibRevision.h`. For example, if revision=0 and fork=master, this means IrisSupportLib code is in the namespace `iris::r0master`.

This is then imported into the namespace `iris` so all Iris code can be used without the hidden internal namespace.

Make sure you include the Iris NAMESPACE\_ macros in any new source files, for example:

```
...
#ifndef ARM_INCLUDE_MyHeader_h
#define ARM_INCLUDE_MyHeader_h

#include "iris/detail/IrisCommon.h"

NAMESPACE_IRIS_START

// Code goes here

NAMESPACE_IRIS_END

#endif // ARM_INCLUDE_MyHeader_h
```



## Chapter 3

# Module Index

### 3.1 Modules

Here is a list of all modules:

Instance Flags . . . . .	15
IrisInstanceBuilder resource APIs . . . . .	15
IrisInstanceBuilder event APIs . . . . .	24
IrisInstanceBuilder breakpoint APIs . . . . .	31
IrisInstanceBuilder memory APIs . . . . .	37
IrisInstanceBuilder image loading APIs . . . . .	45
IrisInstanceBuilder image readData callback APIs. . . . .	49
IrisInstanceBuilder execution stepping APIs . . . . .	49
Disassembler delegate functions . . . . .	53
Semihosting data request flag constants . . . . .	56





## Chapter 4

# Hierarchical Index

### 4.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

iris::IrisInstanceBuilder::AddressTranslationBuilder . . . . .	57
iris::IrisInstanceMemory::AddressTranslationInfoAndAccess . . . . .	59
iris::BreakpointHitInfo . . . . .	59
iris::IrisInstanceBuilder::EventSourceBuilder . . . . .	59
iris::IrisInstanceEvent::EventSourceInfoAndDelegate . . . . .	64
iris::EventStream . . . . .	64
iris::IrisEventStream . . . . .	102
iris::IrisInstanceBuilder::FieldBuilder . . . . .	76
iris::IrisCommandLineParser . . . . .	94
IrisConnectionInterface	
iris::IrisCConnection . . . . .	89
iris::IrisClient . . . . .	89
iris::IrisGlobalInstance . . . . .	103
IrisEventEmitterBase	
iris::IrisEventEmitter< ARGS > . . . . .	98
iris::IrisEventRegistry . . . . .	99
iris::IrisInstance . . . . .	104
iris::IrisInstanceBreakpoint . . . . .	123
iris::IrisInstanceBuilder . . . . .	127
iris::IrisInstanceCheckpoint . . . . .	142
iris::IrisInstanceDebuggableState . . . . .	143
iris::IrisInstanceDisassembler . . . . .	144
iris::IrisInstanceEvent . . . . .	144
iris::IrisInstanceFactoryBuilder . . . . .	148
iris::IrisPluginFactoryBuilder . . . . .	202
iris::IrisInstanceImage . . . . .	154
iris::IrisInstanceImage_Callback . . . . .	156
iris::IrisInstanceMemory . . . . .	157
iris::IrisInstancePerInstanceExecution . . . . .	160
iris::IrisInstanceResource . . . . .	162
iris::IrisInstanceSemihosting . . . . .	166
iris::IrisInstanceSimulation . . . . .	167
iris::IrisInstanceSimulationTime . . . . .	175
iris::IrisInstanceStep . . . . .	179
iris::IrisInstanceTable . . . . .	181
iris::IrisInstantiationContext . . . . .	183
IrisInterface	
iris::IrisClient . . . . .	89
iris::IrisGlobalInstance . . . . .	103
iris::IrisNonFactoryPlugin< PLUGIN_CLASS > . . . . .	188

iris::IrisParameterBuilder . . . . .	190
iris::IrisPluginFactory< PLUGIN_CLASS > . . . . .	202
impl::IrisProcessEventsInterface	
iris::IrisClient . . . . .	89
IrisRegisterEventEmitterBase	
iris::IrisRegisterReadEventEmitter< REG_T, ARGS > . . . . .	204
iris::IrisRegisterUpdateEventEmitter< REG_T, ARGS > . . . . .	206
iris::IrisSimulationResetContext . . . . .	207
iris::IrisInstanceBuilder::MemorySpaceBuilder . . . . .	207
iris::IrisCommandLineParser::Option . . . . .	215
iris::IrisInstanceBuilder::ParameterBuilder . . . . .	216
iris::IrisInstanceEvent::ProxyEventInfo . . . . .	228
iris::IrisInstanceBuilder::RegisterBuilder . . . . .	228
iris::IrisInstanceResource::ResourceInfoAndAccess . . . . .	241
iris::ResourceWriteValue . . . . .	242
iris::IrisInstanceBuilder::SemihostingManager . . . . .	242
iris::IrisInstanceMemory::SpaceInfoAndAccess . . . . .	243
iris::IrisInstanceBuilder::TableBuilder . . . . .	243
iris::IrisInstanceBuilder::TableColumnBuilder . . . . .	249
iris::IrisInstanceTable::TableInfoAndAccess . . . . .	253

## Chapter 5

# Class Index

### 5.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

<a href="#">iris::IrisInstanceBuilder::AddressTranslationBuilder</a>	57
Used to set metadata for an address translation . . . . .	
<a href="#">iris::IrisInstanceMemory::AddressTranslationInfoAndAccess</a>	59
Contains static address translation information . . . . .	
<a href="#">iris::BreakpointHitInfo</a>	59
<a href="#">iris::IrisInstanceBuilder::EventSourceBuilder</a>	
Used to set metadata on an EventSource . . . . .	59
<a href="#">iris::IrisInstanceEvent::EventSourceInfoAndDelegate</a>	
Contains the metadata and delegates for a single EventSource . . . . .	64
<a href="#">iris::EventStream</a>	
Base class for event streams . . . . .	64
<a href="#">iris::IrisInstanceBuilder::FieldBuilder</a>	
Used to set metadata on a register field resource . . . . .	76
<a href="#">iris::IrisCConnection</a>	
Provide an IrisConnectionInterface which loads an IrisC library . . . . .	89
<a href="#">iris::IrisClient</a>	89
<a href="#">iris::IrisCommandLineParser</a>	94
<a href="#">iris::IrisEventEmitter&lt; ARGS &gt;</a>	
A helper class for generating Iris events . . . . .	98
<a href="#">iris::IrisEventRegistry</a>	
Class to register Iris event streams for an event . . . . .	99
<a href="#">iris::IrisEventStream</a>	
Event stream class for Iris-specific events . . . . .	102
<a href="#">iris::IrisGlobalInstance</a>	103
<a href="#">iris::IrisInstance</a>	104
<a href="#">iris::IrisInstanceBreakpoint</a>	
Breakpoint add-on for <a href="#">IrisInstance</a> . . . . .	123
<a href="#">iris::IrisInstanceBuilder</a>	
Builder interface to populate an <a href="#">IrisInstance</a> with registers, memory etc . . . . .	127
<a href="#">iris::IrisInstanceCheckpoint</a>	
Checkpoint add-on for <a href="#">IrisInstance</a> . . . . .	142
<a href="#">iris::IrisInstanceDebuggableState</a>	
Debuggable-state add-on for <a href="#">IrisInstance</a> . . . . .	143
<a href="#">iris::IrisInstanceDisassembler</a>	
Disassembler add-on for <a href="#">IrisInstance</a> . . . . .	144
<a href="#">iris::IrisInstanceEvent</a>	
Event add-on for <a href="#">IrisInstance</a> . . . . .	144
<a href="#">iris::IrisInstanceFactoryBuilder</a>	
A builder class to construct instantiation parameter metadata . . . . .	148

<a href="#">iris::IrisInstanceImage</a>	
Image loading add-on for <a href="#">IrisInstance</a>	154
<a href="#">iris::IrisInstanceImage_Callback</a>	
Image loading add-on for <a href="#">IrisInstance</a> clients implementing <code>image_loadDataRead()</code>	156
<a href="#">iris::IrisInstanceMemory</a>	
Memory add-on for <a href="#">IrisInstance</a>	157
<a href="#">iris::IrisInstancePerInstanceExecution</a>	
Per-instance execution control add-on for <a href="#">IrisInstance</a>	160
<a href="#">iris::IrisInstanceResource</a>	
Resource add-on for <a href="#">IrisInstance</a>	162
<a href="#">iris::IrisInstanceSemihosting</a>	166
<a href="#">iris::IrisInstanceSimulation</a>	
An <a href="#">IrisInstance</a> add-on that adds simulation functions for the <a href="#">SimulationEngine</a> instance	167
<a href="#">iris::IrisInstanceSimulationTime</a>	
Simulation time add-on for <a href="#">IrisInstance</a>	175
<a href="#">iris::IrisInstanceStep</a>	
Step add-on for <a href="#">IrisInstance</a>	179
<a href="#">iris::IrisInstanceTable</a>	
Table add-on for <a href="#">IrisInstance</a>	181
<a href="#">iris::IrisInstantiationContext</a>	
Provides context when instantiating an <a href="#">Iris</a> instance from a factory	183
<a href="#">iris::IrisNonFactoryPlugin&lt; PLUGIN_CLASS &gt;</a>	
Wrapper to instantiate a non-factory plugin	188
<a href="#">iris::IrisParameterBuilder</a>	
Helper class to construct instantiation parameters	190
<a href="#">iris::IrisPluginFactory&lt; PLUGIN_CLASS &gt;</a>	202
<a href="#">iris::IrisPluginBuilderFactory</a>	
Set meta data for instantiating a plug-in instance	202
<a href="#">iris::IrisRegisterReadEventEmitter&lt; REG_T, ARGS &gt;</a>	
An <a href="#">EventEmitter</a> class for register read events	204
<a href="#">iris::IrisRegisterUpdateEventEmitter&lt; REG_T, ARGS &gt;</a>	
An <a href="#">EventEmitter</a> class for register update events	206
<a href="#">iris::IrisSimulationResetContext</a>	
Provides context to a reset delegate call	207
<a href="#">iris::IrisInstanceBuilder::MemorySpaceBuilder</a>	
Used to set metadata for a memory space	207
<a href="#">iris::IrisCommandLineParser::Option</a>	
Option container	215
<a href="#">iris::IrisInstanceBuilder::ParameterBuilder</a>	
Used to set metadata on a parameter	216
<a href="#">iris::IrisInstanceEvent::ProxyEventInfo</a>	
Contains information for a single proxy <a href="#">EventSource</a>	228
<a href="#">iris::IrisInstanceBuilder::RegisterBuilder</a>	
Used to set metadata on a register resource	228
<a href="#">iris::IrisInstanceResource::ResourceInfoAndAccess</a>	
Entry in 'resourceInfos'	241
<a href="#">iris::ResourceWriteValue</a>	242
<a href="#">iris::IrisInstanceBuilder::SemihostingManager</a>	
Semihosting_apis <a href="#">IrisInstanceBuilder</a> semihosting APIs	242
<a href="#">iris::IrisInstanceMemory::SpaceInfoAndAccess</a>	
Entry in 'spaceInfos'	243
<a href="#">iris::IrisInstanceBuilder::TableBuilder</a>	
Used to set metadata for a table	243
<a href="#">iris::IrisInstanceBuilder::TableColumnBuilder</a>	
Used to set metadata for a table column	249
<a href="#">iris::IrisInstanceTable::TableInfoAndAccess</a>	
Entry in 'tableInfos'	253

## Chapter 6

# File Index

### 6.1 File List

Here is a list of all documented files with brief descriptions:

<a href="#">IrisCanonicalMsnArm.h</a>	Constants for the memory.canonicalMsnScheme arm.com/memoryspaces . . . . .	255
<a href="#">IrisCConnection.h</a>	IrisConnectionInterface implementation based on IrisC . . . . .	256
<a href="#">IrisClient.h</a>	Iris client which supports multiple methods to connect to other Iris executables . . . . .	258
<a href="#">IrisCommandLineParser.h</a>	Generic command line parser . . . . .	275
<a href="#">IrisElfDwarfArm.h</a>	Constants for the register.canonicalRnScheme "ElfDwarf" for architecture Arm . . . . .	278
<a href="#">IrisEventEmitter.h</a>	A utility class for emitting Iris events . . . . .	281
<a href="#">IrisGlobalInstance.h</a>	Central instance which lives in the simulation engine and distributes all Iris messages . . . . .	282
<a href="#">IrisInstance.h</a>	Boilerplate code for an Iris instance, including clients and components . . . . .	285
<a href="#">IrisInstanceBreakpoint.h</a>	Breakpoint add-on to IrisInstance . . . . .	294
<a href="#">IrisInstanceBuilder.h</a>	A high level interface to build up functionality on an IrisInstance . . . . .	296
<a href="#">IrisInstanceCheckpoint.h</a>	Checkpoint add-on to IrisInstance . . . . .	323
<a href="#">IrisInstanceDebuggableState.h</a>	IrisInstance add-on to implement debuggableState functions . . . . .	324
<a href="#">IrisInstanceDisassembler.h</a>	Disassembler add-on to IrisInstance . . . . .	325
<a href="#">IrisInstanceEvent.h</a>	Event add-on to IrisInstance . . . . .	327
<a href="#">IrisInstanceFactoryBuilder.h</a>	A helper class to build instantiation parameter metadata . . . . .	336
<a href="#">IrisInstanceImage.h</a>	Image-loading add-on to IrisInstance and image-loading callback add-on to the caller . . . . .	337
<a href="#">IrisInstanceMemory.h</a>	Memory add-on to IrisInstance . . . . .	340
<a href="#">IrisInstancePerInstanceExecution.h</a>	Per-instance execution control add-on to IrisInstance . . . . .	344
<a href="#">IrisInstanceResource.h</a>	Resource add-on to IrisInstance . . . . .	345
<a href="#">IrisInstanceSemihosting.h</a>	IrisInstance add-on to implement semihosting functionality . . . . .	348

<a href="#">IrisInstanceSimulation.h</a>	
IrisInstance add-on to implement simulation_* functions . . . . .	350
<a href="#">IrisInstanceSimulationTime.h</a>	
IrisInstance add-on to implement simulationTime functions . . . . .	355
<a href="#">IrisInstanceStep.h</a>	
Stepping-related add-on to an IrisInstance . . . . .	359
<a href="#">IrisInstanceTable.h</a>	
Table add-on to IrisInstance . . . . .	360
<a href="#">IrisInstantiationContext.h</a>	
Helper class used to instantiate Iris instances from generic factories . . . . .	362
<a href="#">IrisParameterBuilder.h</a>	
Helper class to construct instantiation parameters . . . . .	364
<a href="#">IrisPluginFactory.h</a>	
A generic plug-in factory for instantiating plug-in instances . . . . .	368
<a href="#">IrisRegisterEventEmitter.h</a>	
Utility classes for emitting register read and register update events . . . . .	373
<a href="#">IrisTcpClient.h</a>	
IrisTcpClient Type alias for IrisClient . . . . .	374

## Chapter 7

# Module Documentation

### 7.1 Instance Flags

Flags that can be set when registering an [IrisInstance](#).

#### Variables

- static const uint64\_t [iris::IrisInstance::DEFAULT\\_FLAGS](#) = [THROW\\_ON\\_ERROR](#)  
*Default flags used if not otherwise specified.*
- static const uint64\_t [iris::IrisInstance::THROW\\_ON\\_ERROR](#) = (1 << 1)  
*Throw an exception when an Iris call returns an error response.*
- static const uint64\_t [iris::IrisInstance::UNQUIFY](#) = (1 << 0)  
*Uniquify instance name when registering.*

#### 7.1.1 Detailed Description

Flags that can be set when registering an [IrisInstance](#).

### 7.2 IrisInstanceBuilder resource APIs

Set up resource and register metadata and delegates.

#### Classes

- class [iris::IrisInstanceBuilder::FieldBuilder](#)  
*Used to set metadata on a register field resource.*
- class [iris::IrisInstanceBuilder::ParameterBuilder](#)  
*Used to set metadata on a parameter.*
- class [iris::IrisInstanceBuilder::RegisterBuilder](#)  
*Used to set metadata on a register resource.*

#### Functions

- [RegisterBuilder iris::IrisInstanceBuilder::addNoValueRegister](#) (const std::string &name, const std::string &description, const std::string &format)  
*Add metadata for one noValue resource.*
- [ParameterBuilder iris::IrisInstanceBuilder::addParameter](#) (const std::string &name, uint64\_t bitWidth, const std::string &description)  
*Add numeric parameter.*



- [RegisterBuilder iris::IrisInstanceBuilder::addRegister](#) (const std::string &name, uint64\_t bitWidth, const std::string &description, uint64\_t addressOffset=IRIS\_UINT64\_MAX, uint64\_t canonicalRn=IRIS\_UINT64\_MAX)  
*Add metadata for one numeric register resource.*
- [ParameterBuilder iris::IrisInstanceBuilder::addStringParameter](#) (const std::string &name, const std::string &description)  
*Add string parameter.*
- [RegisterBuilder iris::IrisInstanceBuilder::addStringRegister](#) (const std::string &name, const std::string &description)  
*Add metadata for one string register resource.*
- void [iris::IrisInstanceBuilder::beginResourceGroup](#) (const std::string &name, const std::string &description, uint64\_t subRscldStart=IRIS\_UINT64\_MAX, const std::string &cname=std::string())  
*Begin a new resource group.*
- [ParameterBuilder iris::IrisInstanceBuilder::enhanceParameter](#) (ResourceId rscld)  
*Get [ParameterBuilder](#) to enhance a parameter.*
- [RegisterBuilder iris::IrisInstanceBuilder::enhanceRegister](#) (ResourceId rscld)  
*Get [RegisterBuilder](#) to enhance register.*
- const ResourceInfo & [iris::IrisInstanceBuilder::getResourceInfo](#) (ResourceId rscld)  
*Get ResourceInfo of a previously added register.*
- template<typename T , IrisErrorCode(T::\*)(const ResourceInfo &, ResourceReadResult &) READER, IrisErrorCode(T::\*)(const ResourceInfo &, const [ResourceWriteValue](#) &) WRITER>  
void [iris::IrisInstanceBuilder::setDefaultResourceDelegates](#) (T \*instance)  
*Set both read and write resource delegates if they are defined in the same class.*
- template<IrisErrorCode(\*)(const ResourceInfo &, ResourceReadResult &) FUNC>  
void [iris::IrisInstanceBuilder::setDefaultResourceReadDelegate](#) ()  
*Set default read access function for all subsequently added resources.*
- void [iris::IrisInstanceBuilder::setDefaultResourceReadDelegate](#) ([ResourceReadDelegate](#) delegate=[ResourceReadDelegate](#)())  
*Set default read access function for all subsequently added resources.*
- template<typename T , IrisErrorCode(T::\*)(const ResourceInfo &, ResourceReadResult &) METHOD>  
void [iris::IrisInstanceBuilder::setDefaultResourceReadDelegate](#) (T \*instance)  
*Set default read access function for all subsequently added resources.*
- template<IrisErrorCode(\*)(const ResourceInfo &, const [ResourceWriteValue](#) &) FUNC>  
void [iris::IrisInstanceBuilder::setDefaultResourceWriteDelegate](#) ()  
*Set default write access function for all subsequently added resources.*
- void [iris::IrisInstanceBuilder::setDefaultResourceWriteDelegate](#) ([ResourceWriteDelegate](#) delegate=[ResourceWriteDelegate](#)())  
*Set default write access function for all subsequently added resources.*
- template<typename T , IrisErrorCode(T::\*)(const ResourceInfo &, const [ResourceWriteValue](#) &) METHOD>  
void [iris::IrisInstanceBuilder::setDefaultResourceWriteDelegate](#) (T \*instance)  
*Set default write access function for all subsequently added resources.*
- void [iris::IrisInstanceBuilder::setNextSubRscld](#) (uint64\_t nextSubRscld)  
*Set the rscld that will be used for the next resource to be added.*
- void [iris::IrisInstanceBuilder::setPropertyCanonicalRnScheme](#) (const std::string &canonicalRnScheme)  
*Set the register.canonicalRnScheme instance property.*
- void [iris::IrisInstanceBuilder::setTag](#) (ResourceId rscld, const std::string &tag)  
*Set a tag for a specific resource.*

## 7.2.1 Detailed Description

Set up resource and register metadata and delegates.

## 7.2.2 Function Documentation

### 7.2.2.1 addNoValueRegister()

```
RegisterBuilder iris::IrisInstanceBuilder::addNoValueRegister (
    const std::string & name,
    const std::string & description,
    const std::string & format )
```

Add metadata for one noValue resource.

Resource group: [beginResourceGroup\(\)](#) must have been called before calling this function. The added resource is automatically added to the last group added by [beginResourceGroup\(\)](#).

Type: The added resource is of type 'noValue'. Use [addRegister\(\)](#) to add a register of type 'numeric' or 'numericFp'. Use [addStringRegister\(\)](#) to add a register of type 'string'.

The returned builder object is only valid until another resource is added. It is only intended to modify the resource that was added last.

#### Parameters

<i>name</i>	Name of the resource. This is the same as the 'name' field of ResourceInfo.
<i>description</i>	Human readable description of the resource. This is the same as the 'description' field of ResourceInfo.
<i>format</i>	The format used to display this resource.

#### Returns

A [RegisterBuilder](#) object that can be used to set additional metadata for this resource.

### 7.2.2.2 addParameter()

```
ParameterBuilder iris::IrisInstanceBuilder::addParameter (
    const std::string & name,
    uint64_t bitWidth,
    const std::string & description )
```

Add numeric parameter.

Resource group: [beginResourceGroup\(\)](#) must have been called before calling this function. The added parameter is automatically added to the last group added by [beginResourceGroup\(\)](#).

Type: The added parameter is of type 'numeric'. Call setType("numericFp") on the returned [ParameterBuilder](#) to add a 'numericFp' (pure floating point) parameter. Use [addStringParameter\(\)](#) to add a parameter of type 'string'.

The returned builder object is only valid until another resource is added. It is only intended to modify the resource that was added last.

#### Parameters

<i>name</i>	Name of the parameter. This is the same as the 'name' field of ResourceInfo.
<i>bitWidth</i>	Width of the parameter in bits. This is the same as the 'bitWidth' field of ResourceInfo.
<i>description</i>	Human readable description of the parameter. This is the same as the 'description' field of ResourceInfo.

#### Returns

A [ParameterBuilder](#) object that can be used to set additional metadata for this parameter.

### 7.2.2.3 addRegister()

```
RegisterBuilder iris::IrisInstanceBuilder::addRegister (
    const std::string & name,
    uint64_t bitWidth,
```

```
const std::string & description,
uint64_t addressOffset = IRIS_UINT64_MAX,
uint64_t canonicalRn = IRIS_UINT64_MAX )
```

Add metadata for one numeric register resource.

Resource group: [beginResourceGroup\(\)](#) must have been called before calling this function. The added resource is automatically added to the last group added by [beginResourceGroup\(\)](#).

Type: The added resource is of type 'numeric'. Call `setType("numericFp")` on the returned [RegisterBuilder](#) to add a 'numericFp' (pure floating-point) register. Use [addStringRegister\(\)](#) to add a register of type 'string'.

The returned builder object is only valid until another resource is added. It is only intended to modify the resource that was added last.

#### Parameters

<i>name</i>	Name of the register. This is the same as the 'name' field of ResourceInfo.
<i>bitWidth</i>	Width of the resource in bits. This is the same as the 'bitWidth' field of ResourceInfo.
<i>description</i>	Human readable description of the resource. This is the same as the 'description' field of ResourceInfo.
<i>addressOffset</i>	The address offset of this register inside the parent device. This is the same as the 'addressOffset' field of RegisterInfo.
<i>canonicalRn</i>	Canonical Register Number. This is the same as the 'canonicalRn' field of RegisterInfo.

#### Returns

A [RegisterBuilder](#) object that can be used to set additional metadata for this register resource.

#### Remarks

A value of  $2^{*64}-1$  (0xFFFFFFFFFFFFFFFF) for the arguments *addressOffset* and *canonicalRn* (the default value) is used to indicate that the field is not set. To set an addressOffset of  $2^{*64}-1$  use

```
addRegister(...).setAddressOffset(iris::IRIS_UINT64_MAX);
```

To set a canonicalRn of  $2^{*64}-1$  use

```
addRegister(...).setCanonicalRn(iris::IRIS_UINT64_MAX);
```

### 7.2.2.4 addStringParameter()

```
ParameterBuilder iris::IrisInstanceBuilder::addStringParameter (
    const std::string & name,
    const std::string & description )
```

Add string parameter.

Resource group: [beginResourceGroup\(\)](#) must have been called before calling this function. The added parameter is automatically added to the last group added by [beginResourceGroup\(\)](#).

Type: The added parameter is of type 'string'. Use [addParameter\(\)](#) to add a parameter of a type 'numeric' or 'numericFp'.

The returned builder object is only valid until another resource is added. It is only intended to modify the resource that was added last.

#### Parameters

<i>name</i>	Name of the parameter. This is the same as the 'name' field of ResourceInfo.
<i>description</i>	Human readable description of the parameter. This is the same as the 'description' field of ResourceInfo.

#### Returns

A [ParameterBuilder](#) object that can be used to set additional metadata for this parameter.

### 7.2.2.5 addStringRegister()

```
RegisterBuilder iris::IrisInstanceBuilder::addStringRegister (
    const std::string & name,
    const std::string & description )
```

Add metadata for one string register resource.

Resource group: [beginResourceGroup\(\)](#) must have been called before calling this function. The added resource is automatically added to the last group added by [beginResourceGroup\(\)](#).

Type: The added resource is of type 'string'. Use [addRegister\(\)](#) to add a register of type 'numeric'.

The returned builder object is only valid until another resource is added. It is only intended to modify the resource that was added last.

#### Parameters

<i>name</i>	Name of the register. This is the same as the 'name' field of ResourceInfo.
<i>description</i>	Human readable description of the resource. This is the same as the 'description' field of ResourceInfo.

#### Returns

A [RegisterBuilder](#) object that can be used to set additional metadata for this register resource.

### 7.2.2.6 beginResourceGroup()

```
void iris::IrisInstanceBuilder::beginResourceGroup (
    const std::string & name,
    const std::string & description,
    uint64_t subRscIdStart = IRIS_UINT64_MAX,
    const std::string & cname = std::string() )
```

Begin a new resource group.

This has the following effects:

- Add a resource group if it does not yet exist. (If it already exists under 'name' all other parameters are ignored.)
- Assign all resources that are added by subsequent [addRegister\(\)](#) or [addParameter\(\)](#) calls to this group.

This function must be called before the first resource is added.

#### Parameters

<i>name</i>	Name of the resource group.
<i>description</i>	Description of the resource group.
<i>subRscIdStart</i>	If not IRIS_UINT64_MAX, start counting from this subRscId when new resources are added.
<i>cname</i>	C identifier-style name to use for this group if it is different from <i>name</i> .

#### See also

[addParameter](#)  
[addStringParameter](#)  
[addRegister](#)  
[addStringRegister](#)  
[addNoValueRegister](#)

### 7.2.2.7 enhanceParameter()

```
ParameterBuilder iris::IrisInstanceBuilder::enhanceParameter (
    ResourceId rscId ) [inline]
```

Get [ParameterBuilder](#) to enhance a parameter.

This function can be used to add/set meta info to an existing parameter. There is no strong use case for this function as all meta info can be set/added by using chained calls to the set...()/add...() functions directly after adding the parameter.

Usage: irisInstance.getBuilder().enhanceParameter(rscId).setFoo(...).setBar(...);

The returned builder object is only valid until another resource is added. It is only intended to modify the specified resource and to add fields to this resource.

#### Parameters

<i>rscId</i>	ResourceId of the parameter which is to be modified.
--------------	--

#### Returns

A [ParameterBuilder](#) object that can be used to set additional metadata for this parameter.

### 7.2.2.8 enhanceRegister()

```
RegisterBuilder iris::IrisInstanceBuilder::enhanceRegister (
    ResourceId rscId ) [inline]
```

Get [RegisterBuilder](#) to enhance register.

This function can be used to add sub-fields to register fields which is not possible in a chained call. The rscId can be retrieved by using getRscId() in the chained call. This function does not add any resource and does not modify any state.

Usage: irisInstance.getBuilder().enhanceRegister(rscId).setFoo(...).setBar(...).addField(...);

See DummyComponent.h for an example.

The returned builder object is only valid until another resource is added. It is only intended to modify the specified resource and to add fields to this resource.

#### Parameters

<i>rscId</i>	ResourceId of the resource which is to be modified or to which fields are to be added.
--------------	--

#### Returns

A [RegisterBuilder](#) object that can be used to set additional metadata for this resource.

### 7.2.2.9 getResourceInfo()

```
const ResourceInfo & iris::IrisInstanceBuilder::getResourceInfo (
    ResourceId rscId ) [inline]
```

Get ResourceInfo of a previously added register.

The returned reference will only be valid until more resources are added.

#### Parameters

<i>rscId</i>	Resource Id of the resource.
--------------	------------------------------

### 7.2.2.10 setDefaultResourceDelegates()

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) READER,
IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &) WRITER>
void iris::IrisInstanceBuilder::setDefaultResourceDelegates (
    T * instance ) [inline]
```

Set both read and write resource delegates if they are defined in the same class.

See also

[setDefaultResourceReadDelegate](#)

[setDefaultResourceWriteDelegate](#)

#### Template Parameters

<i>T</i>	Class that defines resource read and write delegate methods.
<i>READER</i>	A method of class T which is a resource read delegate.
<i>WRITER</i>	A method of class T which is a resource write delegate.

#### Parameters

<i>instance</i>	An instance of class T on which READER and WRITER should be called.
-----------------	---

### 7.2.2.11 setDefaultResourceReadDelegate() [1/3]

```
template<IrisErrorCode(*) (const ResourceInfo &, ResourceReadResult &) FUNC>
void iris::IrisInstanceBuilder::setDefaultResourceReadDelegate ( ) [inline]
```

Set default read access function for all subsequently added resources.

Resources that do not explicitly override the access function using

[addRegister\(...\).setReadDelegate\(...\)](#)

will use this delegate.

Usage: Pass in a global function to delegate resource reading to that function:

```
iris::IrisErrorCode myReadFunction(const iris::ResourceInfo &resourceInfo,
                                   iris::ResourceReadResult &result);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultReadDelegate<myReadFunction>();
builder->addRegister(...); // Uses myReadFunction
```

#### Template Parameters

<i>FUNC</i>	A function which is a resource read delegate.
-------------	---

### 7.2.2.12 setDefaultResourceReadDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultResourceReadDelegate (
    ResourceReadDelegate delegate = ResourceReadDelegate() ) [inline]
```

Set default read access function for all subsequently added resources.

Resources that do not explicitly override the access function using

[addRegister\(...\).setReadDelegate\(...\)](#)

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` not\_implemented for all resources.

Usage: Pass an instance of ResourceReadDelegate into this function to delegate reading to any class T:

```

class MyClass
{
    ...
    iris::IrisErrorCode myReadFunction(const iris::ResourceInfo &resourceInfo,
                                      iris::ResourceReadResult &result);
};
MyClass myInstanceOfMyClass;
ResourceReadDelegate delegate =
    ResourceReadDelegate::make<MyClass, &MyClass::myReadFunction>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultReadDelegate(delegate);
builder->addRegister(...); // Uses myReadFunction

```

#### Parameters

<i>delegate</i>	Delegate object which will be called to read resources.
-----------------	---

#### 7.2.2.13 setDefaultResourceReadDelegate() [3/3]

```

template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) METHOD>
void iris::IrisInstanceBuilder::setDefaultResourceReadDelegate (
    T * instance ) [inline]

```

Set default read access function for all subsequently added resources.

Resources that do not explicitly override the access function using

`addRegister(...).setReadDelegate(...)`

will use this delegate.

Usage: Pass an instance of class T where T::METHOD() is a resource read method:

```

class MyClass
{
    ...
    iris::IrisErrorCode myReadFunction(const iris::ResourceInfo &resourceInfo,
                                      iris::ResourceReadResult &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultReadDelegate<MyClass, &MyClass::myReadFunction>(myInstanceOfMyClass);
builder->addRegister(...); // Uses myReadFunction

```

#### Template Parameters

<i>T</i>	Class that defines a resource read delegate method.
<i>METHOD</i>	A method of class T which is a resource read delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

#### 7.2.2.14 setDefaultResourceWriteDelegate() [1/3]

```

template<IrisErrorCode(*) (const ResourceInfo &, const ResourceWriteValue &) FUNC>
void iris::IrisInstanceBuilder::setDefaultResourceWriteDelegate ( ) [inline]

```

Set default write access function for all subsequently added resources.

Resources that do not explicitly override the access function using

`addRegister(...).setWriteDelegate(...)`

will use this delegate.

Usage: Pass in a global function to delegate resource writing to that function:

```

iris::IrisErrorCode myWriteFunction(const iris::ResourceInfo &resourceInfo, const uint64_t *data);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultWriteDelegate<myWriteFunction>();
builder->addRegister(...); // Uses myWriteFunction

```

## Template Parameters

<i>FUNC</i>	A function that is a resource write delegate.
-------------	---

## 7.2.2.15 setDefaultResourceWriteDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultResourceWriteDelegate (
    ResourceWriteDelegate delegate = ResourceWriteDelegate() ) [inline]
```

Set default write access function for all subsequently added resources.

Resources that do not explicitly override the access function using

```
addRegister(...).setWriteDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↵` not\_implemented for all resources.

Usage: Pass an instance of class T where `T::METHOD()` is a resource write method:

```
class MyClass
{
    ...
    iris::IrisErrorCode myWriteFunction(const iris::ResourceInfo &resourceInfo, const uint64_t *data);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
iris::ResourceWriteDelegate delegate =
    iris::ResourceWriteDelegate::make<MyClass, &MyClass::myWriteFunction>(myInstanceOfMyClass);
builder->setDefaultWriteDelegate(delegate);
builder->addRegister(...); // Uses myWriteFunction
```

## Parameters

<i>delegate</i>	Delegate object which will be called to write resources.
-----------------	--

## 7.2.2.16 setDefaultResourceWriteDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &)
METHOD>
```

```
void iris::IrisInstanceBuilder::setDefaultResourceWriteDelegate (
    T * instance ) [inline]
```

Set default write access function for all subsequently added resources.

Resources that do not explicitly override the access function using

```
addRegister(...).setWriteDelegate(...)
```

will use this delegate.

Usage: Pass an instance of class T where `T::METHOD()` is a resource write method:

```
class MyClass
{
    ...
    iris::IrisErrorCode myWriteFunction(const iris::ResourceInfo &resourceInfo, const uint64_t *data);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultWriteDelegate<MyClass, &MyClass::myWriteFunction>(myInstanceOfMyClass);
builder->addRegister(...); // Uses myWriteFunction
```

## Template Parameters

<i>T</i>	Class that defines a resource write delegate method.
<i>METHOD</i>	A method of class T which is a resource write delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--



### 7.2.2.17 setNextSubRscId()

```
void iris::IrisInstanceBuilder::setNextSubRscId (
    uint64_t nextSubRscId ) [inline]
```

Set the rscId that will be used for the next resource to be added.

Resources that are added following this call are assigned subRscIds starting at nextSubRscId.

#### Parameters

<i>nextSubRscId</i>	The subRscId that is used for the next resource to be added.
---------------------	--

### 7.2.2.18 setPropertyCanonicalRnScheme()

```
void iris::IrisInstanceBuilder::setPropertyCanonicalRnScheme (
    const std::string & canonicalRnScheme )
```

Set the register.canonicalRnScheme instance property.

This property is visible in the list of properties returned by instance\_getProperties().

This property defines the scheme used by the 'canonicalRn' member of the RegisterInfo object. This should be called upon initialization, before other instances have a chance to call instance\_getProperties().

When using the function setCanonicalRnElfDwarf() the property is set automatically to "ElfDwarf" and it is not necessary to call this function.

When not calling setCanonicalRn() for any register it is not necessary to call this function. In this case the property will not exist which is ok.

Custom scheme names (other than ElfDwarf) should always be of the form <comnapy-name>.com/<scheme-name> to avoid conflicts.

#### Parameters

<i>canonicalRnScheme</i>	Name of the canonical register number scheme used by this instance.
--------------------------	---

### 7.2.2.19 setTag()

```
void iris::IrisInstanceBuilder::setTag (
    ResourceId rscId,
    const std::string & tag )
```

Set a tag for a specific resource.

#### Parameters

<i>rscId</i>	Resource Id for the resource that will have this tag set.
<i>tag</i>	Name of the boolean tag that will be set to true.

#### See also

[ResourceBuilder::setTag](#)

[RegisterBuilder::setTag](#)

## 7.3 IrisInstanceBuilder event APIs

Set up event source metadata and event stream delegates.

## Classes

- class [iris::IrisInstanceBuilder::EventSourceBuilder](#)

*Used to set metadata on an EventSource.*

## Functions

- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::addEventSource](#) (const std::string &name, bool isHidden=false)  
*Add metadata for an event source.*
- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::addEventSource](#) (const std::string &name, IrisEventEmitterBase &event\_emitter, bool isHidden=false)  
*Add metadata for an event source that uses an [IrisEventEmitter](#).*
- void [iris::IrisInstanceBuilder::deleteEventSource](#) (const std::string &name)  
*Delete event source.*
- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::enhanceEventSource](#) (const std::string &name)  
*Enhance existing event source.*
- void [iris::IrisInstanceBuilder::finalizeRegisterReadEvent](#) ()  
*Finalize set up of an [IrisEventEmitter](#).*
- void [iris::IrisInstanceBuilder::finalizeRegisterUpdateEvent](#) ()  
*Finalize set up of an [IrisEventEmitter](#).*
- [IrisInstanceEvent](#) \* [iris::IrisInstanceBuilder::getIrisInstanceEvent](#) ()
- bool [iris::IrisInstanceBuilder::hasEventSource](#) (const std::string &name)  
*Check whether event source already exists.*
- void [iris::IrisInstanceBuilder::resetRegisterReadEvent](#) ()  
*Reset the active register read event.*
- void [iris::IrisInstanceBuilder::resetRegisterUpdateEvent](#) ()  
*Reset the active register update event.*
- template<IrisErrorCode(\*)(<EventStream \*&, const EventSourceInfo &, const std::vector< std::string > &) FUNC>  
void [iris::IrisInstanceBuilder::setDefaultEsCreateDelegate](#) ()  
*Set the delegate that helps to create a new event stream for the simulation-specific event.*
- void [iris::IrisInstanceBuilder::setDefaultEsCreateDelegate](#) ([EventStreamCreateDelegate](#) delegate)  
*Set the delegate that helps to create a new event stream for the simulation-specific event.*
- template<typename T , IrisErrorCode(T::\*)(<EventStream \*&, const EventSourceInfo &, const std::vector< std::string > &) METHOD>  
void [iris::IrisInstanceBuilder::setDefaultEsCreateDelegate](#) (T \*instance)  
*Set the delegate that helps to create a new event stream for the simulation-specific event.*
- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::setRegisterReadEvent](#) (const std::string &name, const std::string &description=std::string())  
*Add a new register read event source.*
- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::setRegisterReadEvent](#) (const std::string &name, IrisRegisterEventEmitterBase &event\_emitter)  
*Add a new register read event source.*
- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::setRegisterUpdateEvent](#) (const std::string &name, const std::string &description=std::string())  
*Add a new register update event source.*
- [EventSourceBuilder](#) [iris::IrisInstanceBuilder::setRegisterUpdateEvent](#) (const std::string &name, IrisRegisterEventEmitterBase &event\_emitter)  
*Add a new register update event source.*

### 7.3.1 Detailed Description

Set up event source metadata and event stream delegates.

### 7.3.2 Function Documentation

### 7.3.2.1 addEventSource() [1/2]

```
EventSourceBuilder iris::IrisInstanceBuilder::addEventSource (
    const std::string & name,
    bool isHidden = false ) [inline]
```

Add metadata for an event source.

Consider using `addEventSource(const std::string& name, IrisEventEmitterBase& event_emitter)` instead. Only use this if you want to implement a non-trivial trace source with its own event emitter handling.

#### Parameters

<i>name</i>	The name of the new event source.
<i>isHidden</i>	If true, the event source is hidden.

#### See also

[EventSourceBuilder::setHidden](#)

#### Returns

An [EventSourceBuilder](#) object that can be used to set additional attributes for this event source. The returned [EventSourceBuilder](#) is only valid until the next call to [addEventSource\(\)](#).

### 7.3.2.2 addEventSource() [2/2]

```
EventSourceBuilder iris::IrisInstanceBuilder::addEventSource (
    const std::string & name,
    IrisEventEmitterBase & event_emitter,
    bool isHidden = false ) [inline]
```

Add metadata for an event source that uses an [IrisEventEmitter](#).

#### Parameters

<i>name</i>	The name of the new event source.
<i>event_emitter</i>	The <a href="#">IrisEventEmitter</a> for this event source.
<i>isHidden</i>	If true, the event source is hidden.

#### See also

[EventSourceBuilder::setHidden](#)

#### Returns

An [EventSourceBuilder](#) object that can be used to set additional attributes for this event source. The returned [EventSourceBuilder](#) is only valid until the next call to [addEventSource\(\)](#), [setRegisterReadEvent\(\)](#), or [setRegisterWriteEvent\(\)](#).

### 7.3.2.3 deleteEventSource()

```
void iris::IrisInstanceBuilder::deleteEventSource (
    const std::string & name ) [inline]
```

Delete event source.

#### Parameters

<i>name</i>	The name of the event source.
-------------	-------------------------------

#### 7.3.2.4 enhanceEventSource()

```
EventSourceBuilder iris::IrisInstanceBuilder::enhanceEventSource (
    const std::string & name ) [inline]
```

Enhance existing event source.

##### Parameters

<i>name</i>	The name of the event source.
-------------	-------------------------------

##### Returns

An [EventSourceBuilder](#) object that can be used to set additional attributes for this event source. The returned [EventSourceBuilder](#) is only valid until the next call to [addEventSource\(\)](#), [setRegisterReadEvent\(\)](#), or [setRegisterWriteEvent\(\)](#).

#### 7.3.2.5 finalizeRegisterReadEvent()

```
void iris::IrisInstanceBuilder::finalizeRegisterReadEvent ( )
```

Finalize the setup of an [IrisEventEmitter](#).

When all the registers associated with all the read events have been added, call [finalizeRegisterReadEvent\(\)](#) to add the event sources to the [IrisInstance](#).

#### 7.3.2.6 finalizeRegisterUpdateEvent()

```
void iris::IrisInstanceBuilder::finalizeRegisterUpdateEvent ( )
```

Finalize set up of an [IrisEventEmitter](#).

When all the registers associated with all the write events have been added, call [finalizeRegisterUpdateEvent\(\)](#) to add the event sources to the [IrisInstance](#).

#### 7.3.2.7 getIrisInstanceEvent()

```
IrisInstanceEvent * iris::IrisInstanceBuilder::getIrisInstanceEvent ( ) [inline]
```

Direct access to [IrisInstanceEvent](#).

Do not use! This will be removed! Use the event api of [IrisInstanceBuilder](#) instead. This is a temporary hack.

#### 7.3.2.8 hasEventSource()

```
bool iris::IrisInstanceBuilder::hasEventSource (
    const std::string & name ) [inline]
```

Check whether event source already exists.

##### Parameters

<i>name</i>	The name of the event source.
-------------	-------------------------------

##### Returns

True iff the event source already exists.

#### 7.3.2.9 resetRegisterReadEvent()

```
void iris::IrisInstanceBuilder::resetRegisterReadEvent ( )
```

Reset the active register read event.

setRegisterReadEvent and resetRegisterReadEvent should be called in pair to scope the registers being added to be associated with a certain read event.

### 7.3.2.10 resetRegisterUpdateEvent()

```
void iris::IrisInstanceBuilder::resetRegisterUpdateEvent ( )
```

Reset the active register update event.

setRegisterUpdateEvent and resetRegisterUpdateEvent should be called in pair to scope the registers being added to be associated with a certain update event.

### 7.3.2.11 setDefaultEsCreateDelegate() [1/3]

```
template<IrisErrorCode(*) (EventStream *&, const EventSourceInfo &, const std::vector< std::string > &) FUNC>
```

```
void iris::IrisInstanceBuilder::setDefaultEsCreateDelegate ( ) [inline]
```

Set the delegate that helps to create a new event stream for the simulation-specific event.

Consider using addEventSource(const std::string& name, IrisEventEmitterBase& event\_emitter) instead. Only use this if you want to implement a non-trivial trace source with its own event emitter handling.

Event sources that do not explicitly override the access function using

```
addEventSource(...).setEventStreamCreateDelegate(...)
```

use this delegate.

Usage: Pass in a global function to which to delegate event stream creation:

```
iris::IrisErrorCode createEventStream(iris::EventStream*&, const iris::EventSourceInfo&,
                                     const std::vector<std::string>&)>
builder->setDefaultEsCreateDelegate<&MyClass::createEventStream>();
builder->addEventSource(...); // Uses createEventStream
```

#### Template Parameters

<i><b>FUNC</b></i>	Global function to which to delegate event stream creation.
--------------------	---

### 7.3.2.12 setDefaultEsCreateDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultEsCreateDelegate (
```

```
    EventStreamCreateDelegate delegate ) [inline]
```

Set the delegate that helps to create a new event stream for the simulation-specific event.

Consider using addEventSource(const std::string& name, IrisEventEmitterBase& event\_emitter) instead. Only use this if you want to implement a non-trivial trace source with its own event emitter handling.

Event sources that do not explicitly override the access function using

```
addEventSource(...).setEventStreamCreateDelegate(...)
```

use this delegate.

Usage: Pass an instance of class T where T::METHOD() is an event stream creation method:

```
class MyClass
{
    ...
    iris::IrisErrorCode createEventStream(iris::EventStream*&, const iris::EventSourceInfo&,
                                         const std::vector<std::string>&)>
};
MyClass myInstanceOfMyClass;
EventStreamCreateDelegate delegate = EventStreamCreateDelegate::make<MyClass,
    &MyClass::createEventStream>(myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultEsCreateDelegateC(delegate);
builder->addEventSource(...); // Uses createEventStream
```

#### Parameters

<i><b>delegate</b></i>	Delegate object that will be called to create an event stream.
------------------------	--

**7.3.2.13 setDefaultEsCreateDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(EventStream * &, const EventSourceInfo &, const std::vector< std::string > &) METHOD>
void iris::IrisInstanceBuilder::setDefaultEsCreateDelegate (
    T * instance ) [inline]
```

Set the delegate that helps to create a new event stream for the simulation-specific event.

Consider using `addEventSource(const std::string& name, IrisEventEmitterBase& event_emitter)` instead. Only use this if you want to implement a non-trivial trace source with its own event emitter handling.

Event sources that do not explicitly override the access function using

`addEventSource(...).setEventStreamCreateDelegate(...)`

use this delegate.

Usage: Pass an instance of class T where T::METHOD() is an event stream creation method:

```
class MyClass
{
    ...
    iris::IrisErrorCode createEventStream(iris::EventStream* &, const iris::EventSourceInfo&,
                                         const std::vector<std::string> & )
};
MyClass myInstanceOfMyClass;
builder->setDefaultEsCreateDelegate<MyClass, &MyClass::createEventStream>(myInstanceOfMyClass);
builder->addEventSource(...); // Uses createEventStream
```

**Template Parameters**

<i>T</i>	Class that defines an event stream creation method.
<i>METHOD</i>	A method of class T which is an event stream creation method.

**Parameters**

<i>instance</i>	The instance of class T on which METHOD should be called.
-----------------	---

**7.3.2.14 setRegisterReadEvent()** [1/2]

```
EventSourceBuilder iris::IrisInstanceBuilder::setRegisterReadEvent (
    const std::string & name,
    const std::string & description = std::string() )
```

Add a new register read event source.

Any registers added after calling `setRegisterReadEvent()` and before the next call to `setRegisterReadEvent()` or `finalizeRegisterReadEvent()` are associated with this event.

A call to `setRegisterReadEvent()` implicitly calls `finalizeRegisterReadEvent()` on the event source with name `name` iff an event emitter object (type `IrisRegisterEventEmitterBase`) is provided as an argument.

If the register read event source already exists (identified by name), the active register read event source simply switches to it.

Register read events have three standard fields:

Field	Description
REGISTER	The Iris rscl of the register accessed.
DEBUG	True if the read originated from a debug access.
VALUE	The value that was read.

**Parameters**

<i>name</i>	Name of the event source.
<i>description</i>	Description of the event source.

## Returns

An [EventSourceBuilder](#) for the event allowing extra custom fields to be added.

### 7.3.2.15 setRegisterReadEvent() [2/2]

```
EventSourceBuilder iris::IrisInstanceBuilder::setRegisterReadEvent (
    const std::string & name,
    IrisRegisterEventEmitterBase & event_emitter )
```

Add a new register read event source.

Any registers added after calling [setRegisterReadEvent\(\)](#) and before the next call to [setRegisterReadEvent\(\)](#) or [finalizeRegisterReadEvent\(\)](#) are associated with this event.

A call to [setRegisterReadEvent\(\)](#) implicitly calls [finalizeRegisterReadEvent\(\)](#) on the event source with name `name` iff an event emitter object (type `IrisRegisterEventEmitterBase`) is provided as an argument.

If the register read event source already exists (identified by name), the active register read event source simply switches to it.

Register read events have three standard fields:

Field	Description
REGISTER	The Iris rsclid of the register accessed.
DEBUG	True if the read originated from a debug access.
VALUE	The value that was read.

## Parameters

<i>name</i>	Name of the event source.
<i>event_emitter</i>	The event_emitter to associate with this event source.

## Returns

An [EventSourceBuilder](#) for the event allowing extra custom fields to be added.

### 7.3.2.16 setRegisterUpdateEvent() [1/2]

```
EventSourceBuilder iris::IrisInstanceBuilder::setRegisterUpdateEvent (
    const std::string & name,
    const std::string & description = std::string() )
```

Add a new register update event source.

Any registers added after calling [setRegisterUpdateEvent\(\)](#) and before the next call to [setRegisterUpdateEvent\(\)](#) or [finalizeRegisterUpdateEvent\(\)](#) are associated with this event.

A call to [setRegisterUpdateEvent](#) implicitly calls [finalizeRegisterUpdateEvent\(\)](#) on the event source with name `name` iff an event emitter object (type `IrisRegisterEventEmitterBase`) is provided as an argument.

If the register update event source (identified by name) already exists, the active register update event source simply switches to it.

Register update events have four standard fields:

Field	Description
REGISTER	The Iris rsclid of the register accessed.
DEBUG	True if the update originated from a debug access.
OLD_VALUE	The value that would have been read before the access was made.
NEW_VALUE	The value that would be read after the access was made.

## Parameters

<i>name</i>	Name of the event source.
<i>description</i>	Description of the event source.

## Returns

An [EventSourceBuilder](#) for the event allowing extra custom fields to be added.

## 7.3.2.17 setRegisterUpdateEvent() [2/2]

```
EventSourceBuilder iris::IrisInstanceBuilder::setRegisterUpdateEvent (
    const std::string & name,
    IrisRegisterEventEmitterBase & event_emitter )
```

Add a new register update event source.

Any registers added after calling [setRegisterUpdateEvent\(\)](#) and before the next call to [setRegisterUpdateEvent\(\)](#) or [finalizeRegisterUpdateEvent\(\)](#) are associated with this event.

A call to [setRegisterUpdateEvent](#) implicitly calls [finalizeRegisterUpdateEvent\(\)](#) on the event source with name `name` iff an event emitter object (type `IrisRegisterEventEmitterBase`) is provided as an argument.

If the register update event source (identified by name) already exists, the active register update event source simply switches to it.

Register update events have four standard fields:

Field	Description
REGISTER	The Iris rsclid of the register accessed.
DEBUG	True if the update originated from a debug access.
OLD_VALUE	The value that would have been read before the access was made.
NEW_VALUE	The value that would be read after the access was made.

## Parameters

<i>name</i>	Name of the event source.
<i>event_emitter</i>	The event_emitter to associate with this event source.

## Returns

An [EventSourceBuilder](#) for the event allowing extra custom fields to be added.

## 7.4 IrisInstanceBuilder breakpoint APIs

Set up breakpoint hit notifications and breakpoint delegates.

## Functions

- void **iris::IrisInstanceBuilder::addBreakpointCondition** (const std::string &name, const std::string &type, const std::string &description, const std::vector< std::string > bpt\_types=std::vector< std::string >())

*Add an optional component-specific condition.*

- const BreakpointInfo \* **iris::IrisInstanceBuilder::getBreakpointInfo** (BreakpointId bptId)

*Get the breakpoint information for a given breakpoint.*

- void **iris::IrisInstanceBuilder::notifyBreakpointHit** (BreakpointId bptId, uint64\_t time, uint64\_t pc, Memory↔SpaceId pcSpaceId)

*Notify clients that a code breakpoint was hit.*



- void [iris::IrisInstanceBuilder::notifyBreakpointHitData](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId, uint64\_t accessAddr, uint64\_t accessSize, const std::string &accessRw, const std::vector< uint64\_t > &data)  
*Notify clients that a data breakpoint was hit (IRIS\_BREAKPOINT\_HIT).*
- void [iris::IrisInstanceBuilder::notifyBreakpointHitRegister](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId, const std::string &accessRw, const std::vector< uint64\_t > &data)  
*Notify clients that a register breakpoint was hit (IRIS\_BREAKPOINT\_HIT).*
- template<IrisErrorCode(\*) (const BreakpointInfo &) FUNC>  
void [iris::IrisInstanceBuilder::setBreakpointDeleteDelegate](#) ()  
*Set the delegate that is called when a breakpoint is deleted.*
- void [iris::IrisInstanceBuilder::setBreakpointDeleteDelegate](#) (BreakpointDeleteDelegate delegate)  
*Set the delegate that is called when a breakpoint is deleted.*
- template<typename T, IrisErrorCode(T::\*)(const BreakpointInfo &) METHOD>  
void [iris::IrisInstanceBuilder::setBreakpointDeleteDelegate](#) (T \*instance)  
*Set the delegate that is called when a breakpoint is deleted.*
- template<IrisErrorCode(\*) (BreakpointInfo &) FUNC>  
void [iris::IrisInstanceBuilder::setBreakpointSetDelegate](#) ()  
*Set the delegate that is called when a breakpoint is set.*
- void [iris::IrisInstanceBuilder::setBreakpointSetDelegate](#) (BreakpointSetDelegate delegate)  
*Set the delegate that is called when a breakpoint is set.*
- template<typename T, IrisErrorCode(T::\*)(BreakpointInfo &) METHOD>  
void [iris::IrisInstanceBuilder::setBreakpointSetDelegate](#) (T \*instance)  
*Set the delegate that is called when a breakpoint is set.*
- template<IrisErrorCode(\*) (const BreakpointHitInfo &) FUNC>  
void [iris::IrisInstanceBuilder::setHandleBreakpointHitDelegate](#) ()  
*Set the delegate that is called when a breakpoint is hit.*
- void [iris::IrisInstanceBuilder::setHandleBreakpointHitDelegate](#) (HandleBreakpointHitDelegate delegate)  
*Set the delegate that is called when a breakpoint is hit.*
- template<typename T, IrisErrorCode(T::\*)(const BreakpointHitInfo &) METHOD>  
void [iris::IrisInstanceBuilder::setHandleBreakpointHitDelegate](#) (T \*instance)  
*Set the delegate that is called when a breakpoint is hit.*

## 7.4.1 Detailed Description

Set up breakpoint hit notifications and breakpoint delegates.

## 7.4.2 Function Documentation

### 7.4.2.1 getBreakpointInfo()

```
const BreakpointInfo * iris::IrisInstanceBuilder::getBreakpointInfo (
    BreakpointId bptId ) [inline]
```

Get the breakpoint information for a given breakpoint.

#### Parameters

<i>bptId</i>	The breakpoint id of the breakpoint for which information is being requested.
--------------	---

#### Returns

The breakpoint information for the requested breakpoint. This returns nullptr if *bptId* is invalid.

### 7.4.2.2 notifyBreakpointHit()

```
void iris::IrisInstanceBuilder::notifyBreakpointHit (
    BreakpointId bptId,
    uint64_t time,
    uint64_t pc,
    MemorySpaceId pcSpaceId ) [inline]
```

Notify clients that a code breakpoint was hit.

This emits an (IRIS\_BREAKPOINT\_HIT) event.

#### Parameters

<i>bptId</i>	Breakpoint id for the breakpoint that was hit.
<i>time</i>	Simulation time at which the breakpoint was hit.
<i>pc</i>	Value of the program counter when the breakpoint was hit.
<i>pc</i> ↔ <i>SpaceId</i>	Memory space id for the PC when the breakpoint was hit.

### 7.4.2.3 notifyBreakpointHitData()

```
void iris::IrisInstanceBuilder::notifyBreakpointHitData (
    BreakpointId bptId,
    uint64_t time,
    uint64_t pc,
    MemorySpaceId pcSpaceId,
    uint64_t accessAddr,
    uint64_t accessSize,
    const std::string & accessRw,
    const std::vector< uint64_t > & data ) [inline]
```

Notify clients that a data breakpoint was hit (IRIS\_BREAKPOINT\_HIT).

This emits an (IRIS\_BREAKPOINT\_HIT) event.

#### Parameters

<i>bptId</i>	Breakpoint id for the breakpoint that was hit.
<i>time</i>	Simulation time at which the breakpoint was hit.
<i>pc</i>	Value of the program counter when the breakpoint was hit.
<i>pcSpaceId</i>	Memory space id for the PC when the breakpoint was hit.
<i>accessAddr</i>	Address of the access that hit.
<i>accessSize</i>	Size in bytes of the access that hit.
<i>accessRw</i>	Access direction. Should be "r" for a read access or "w" for a write access.
<i>data</i>	The data transferred by the access that hit.

### 7.4.2.4 notifyBreakpointHitRegister()

```
void iris::IrisInstanceBuilder::notifyBreakpointHitRegister (
    BreakpointId bptId,
    uint64_t time,
    uint64_t pc,
    MemorySpaceId pcSpaceId,
    const std::string & accessRw,
    const std::vector< uint64_t > & data ) [inline]
```

Notify clients that a register breakpoint was hit (IRIS\_BREAKPOINT\_HIT).

This emits an (IRIS\_BREAKPOINT\_HIT) event.

#### Parameters

<i>bptId</i>	Breakpoint id for the breakpoint that was hit.
<i>time</i>	Simulation time at which the breakpoint was hit.
<i>pc</i>	Value of the program counter when the breakpoint was hit.
<i>pc</i> ↔ <i>SpaceId</i>	Memory space id for the PC when the breakpoint was hit.
<i>accessRw</i>	Access direction. Should be "r" for a read access or "w" for a write access.
<i>data</i>	The data transferred by the access that hit.

#### 7.4.2.5 setBreakpointDeleteDelegate() [1/3]

```
template<IrisErrorCode(*) (const BreakpointInfo &) FUNC>
void iris::IrisInstanceBuilder::setBreakpointDeleteDelegate ( ) [inline]
```

Set the delegate that is called when a breakpoint is deleted.

Usage: Pass in a global function to call when a breakpoint is deleted:

```
iris::IrisErrorCode deleteBreakpoint(const iris::BreakpointInfo&);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setBreakpointDeleteDelegate(&deleteBreakpoint>();
```

#### Template Parameters

<i>FUNC</i>	Global function to call when a breakpoint is deleted.
-------------	---

#### 7.4.2.6 setBreakpointDeleteDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setBreakpointDeleteDelegate (
    BreakpointDeleteDelegate delegate ) [inline]
```

Set the delegate that is called when a breakpoint is deleted.

Usage: Pass a breakpoint delete delegate:

```
class MyClass
{
    ...
    iris::IrisErrorCode deleteBreakpoint(const iris::BreakpointInfo&);
};
MyClass myInstanceOfMyClass;
BreakpointDeleteDelegate delegate = BreakpointDeleteDelegate::make<MyClass,
    &MyClass::deleteBreakpoint>(myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setBreakpointDeleteDelegate(delegate);
```

#### Parameters

<i>delegate</i>	Delegate object which will be called to delete a breakpoint.
-----------------	--

#### 7.4.2.7 setBreakpointDeleteDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const BreakpointInfo &) METHOD>
void iris::IrisInstanceBuilder::setBreakpointDeleteDelegate (
    T * instance ) [inline]
```

Set the delegate that is called when a breakpoint is deleted.

Usage: Pass an instance of class T, where T::METHOD() is a breakpoint delete delegate:

```
class MyClass
{
```

```

...
    iris::IrisErrorCode deleteBreakpoint(const iris::BreakpointInfo&);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setBreakpointDeleteDelegate<MyClass, &MyClass::deleteBreakpoint>(myInstanceOfMyClass);

```

#### Template Parameters

<i>T</i>	Class that defines a breakpoint delete method.
<i>METHOD</i>	A method of class T which is a breakpoint delete delegate method.

#### Parameters

<i>instance</i>	The instance of class T on which METHOD should be called.
-----------------	---

#### 7.4.2.8 setBreakpointSetDelegate() [1/3]

```

template<IrisErrorCode(*) (BreakpointInfo &) FUNC>
void iris::IrisInstanceBuilder::setBreakpointSetDelegate ( ) [inline]

```

Set the delegate that is called when a breakpoint is set.

Usage: Pass in a global function to call when a breakpoint is set:

```

iris::IrisErrorCode setBreakpoint(iris::BreakpointInfo&);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setBreakpointSetDelegate<&setBreakpoint>();

```

#### Template Parameters

<i>FUNC</i>	Global function to call when a breakpoint is set.
-------------	---

#### 7.4.2.9 setBreakpointSetDelegate() [2/3]

```

void iris::IrisInstanceBuilder::setBreakpointSetDelegate (
    BreakpointSetDelegate delegate ) [inline]

```

Set the delegate that is called when a breakpoint is set.

Usage: Pass a breakpoint set delegate:

```

class MyClass
{
    ...
    iris::IrisErrorCode setBreakpoint(iris::BreakpointInfo&);
};
MyClass myInstanceOfMyClass;
BreakpointSetDelegate delegate = BreakpointSetDelegate::make<MyClass,
    &MyClass::setBreakpoint>(myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setBreakpointSetDelegate(delegate);

```

#### Parameters

<i>delegate</i>	Delegate object which will be called to set a breakpoint.
-----------------	---

#### 7.4.2.10 setBreakpointSetDelegate() [3/3]

```

template<typename T , IrisErrorCode(T::*)(BreakpointInfo &) METHOD>
void iris::IrisInstanceBuilder::setBreakpointSetDelegate (
    T * instance ) [inline]

```

Set the delegate that is called when a breakpoint is set.

Usage: Pass an instance of class T, where T::METHOD() is a breakpoint set delegate:

```
class MyClass
{
    ...
    iris::IrisErrorCode setBreakpoint(iris::BreakpointInfo&);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setBreakpointSetDelegate<MyClass, &MyClass::setBreakpoint>(myInstanceOfMyClass);
```

#### Template Parameters

<i>T</i>	Class that defines a breakpoint set method.
<i>METHOD</i>	A method of class T which is a breakpoint set delegate method.

#### Parameters

<i>instance</i>	The instance of class T on which METHOD should be called.
-----------------	---

#### 7.4.2.11 setHandleBreakpointHitDelegate() [1/3]

```
template<IrisErrorCode(*) (const BreakpointHitInfo &) FUNC>
void iris::IrisInstanceBuilder::setHandleBreakpointHitDelegate ( ) [inline]
```

Set the delegate that is called when a breakpoint is hit.

Usage: Pass in a global function to call when a breakpoint is hit.

```
iris::IrisErrorCode handleBreakpointHit(const iris::BreakpointHitInfo&);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setHandleBreakpointHitDelegate<&handleBreakpointHit>();
```

#### Template Parameters

<i>FUNC</i>	Global function to call when a breakpoint is hit.
-------------	---

#### 7.4.2.12 setHandleBreakpointHitDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setHandleBreakpointHitDelegate (
    HandleBreakpointHitDelegate delegate ) [inline]
```

Set the delegate that is called when a breakpoint is hit.

Usage: Pass a handle breakpoint hit delegate:

```
class MyClass
{
    ...
    iris::IrisErrorCode handleBreakpointHit(const iris::BreakpointHitInfo&);
};
MyClass myInstanceOfMyClass;
HandleBreakpointHitDelegate delegate = HandleBreakpointHitDelegate::make<MyClass,
    &MyClass::handleBreakpointHit>(myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setHandleBreakpointHitDelegate(delegate);
```

#### Parameters

<i>delegate</i>	Delegate object which will be called to handle a breakpoint hit.
-----------------	--

#### 7.4.2.13 setHandleBreakpointHitDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const BreakpointHitInfo &) METHOD>
void iris::IrisInstanceBuilder::setHandleBreakpointHitDelegate (
```

```
T * instance ) [inline]
```

Set the delegate that is called when a breakpoint is hit.

Usage: Pass an instance of class T, where T::METHOD() is a handle breakpoint hit delegate:

```
class MyClass
{
    ...
    iris::IrisErrorCode handleBreakpointHit(const iris::BreakpointHitInfo&);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setHandleBreakpointHitDelegate<MyClass, &MyClass::handleBreakpointHit>(myInstanceOfMyClass);
```

#### Template Parameters

<i>T</i>	Class that defines a handle breakpoint hit method.
<i>METHOD</i>	A method of class T which is a handle breakpoint hit delegate method.

#### Parameters

<i>instance</i>	The instance of class T on which METHOD should be called.
-----------------	---

## 7.5 IrisInstanceBuilder memory APIs

Set up address translation and memory space metadata and delegates.

### Classes

- class [iris::IrisInstanceBuilder::AddressTranslationBuilder](#)  
*Used to set metadata for an address translation.*
- class [iris::IrisInstanceBuilder::MemorySpaceBuilder](#)  
*Used to set metadata for a memory space.*

### Functions

- [AddressTranslationBuilder](#) [iris::IrisInstanceBuilder::addAddressTranslation](#) (MemorySpaceId inSpaceId, MemorySpaceId outSpaceId, const std::string &description)  
*Add an address translation.*
- [MemorySpaceBuilder](#) [iris::IrisInstanceBuilder::addMemorySpace](#) (const std::string &name)  
*Add metadata for one memory space.*
- template<IrisErrorCode(\*)>(uint64\_t, uint64\_t, uint64\_t, MemoryAddressTranslationResult &) FUNC>  
void [iris::IrisInstanceBuilder::setDefaultAddressTranslateDelegate](#) ()  
*Set the default address translation function for all subsequently added memory spaces.*
- void [iris::IrisInstanceBuilder::setDefaultAddressTranslateDelegate](#) (MemoryAddressTranslateDelegate delegate=[MemoryAddressTranslateDelegate](#)())  
*Set the default address translation function for all subsequently added memory spaces.*
- template<typename T, IrisErrorCode(T::\*)(uint64\_t, uint64\_t, uint64\_t, MemoryAddressTranslationResult &) METHOD>  
void [iris::IrisInstanceBuilder::setDefaultAddressTranslateDelegate](#) (T \*instance)  
*Set the default address translation function for all subsequently added memory spaces.*
- template<IrisErrorCode(\*)>(const MemorySpaceInfo &, uint64\_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) FUNC>  
void [iris::IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate](#) ()  
*Set the default sideband info function for all subsequently added memory spaces.*
- void [iris::IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate](#) (MemoryGetSidebandInfoDelegate delegate)  
*Set the default sideband info function for all subsequently added memory spaces.*

- `template<typename T, IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) METHOD>`  
`void iris::IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate (T *instance)`  
*Set the default sideband info function for all subsequently added memory spaces.*
- `template<IrisErrorCode(*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, MemoryReadResult &) FUNC>`  
`void iris::IrisInstanceBuilder::setDefaultMemoryReadDelegate ()`  
*Set the default read function for all subsequently added memory spaces.*
- `void iris::IrisInstanceBuilder::setDefaultMemoryReadDelegate (MemoryReadDelegate delegate=MemoryReadDelegate())`  
*Set the default read function for all subsequently added memory spaces.*
- `template<typename T, IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, MemoryReadResult &) METHOD>`  
`void iris::IrisInstanceBuilder::setDefaultMemoryReadDelegate (T *instance)`  
*Set the default read function for all subsequently added memory spaces.*
- `template<IrisErrorCode(*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) FUNC>`  
`void iris::IrisInstanceBuilder::setDefaultMemoryWriteDelegate ()`  
*Set default write function for all subsequently added memory spaces.*
- `void iris::IrisInstanceBuilder::setDefaultMemoryWriteDelegate (MemoryWriteDelegate delegate=MemoryWriteDelegate())`  
*Set the default write function for all subsequently added memory spaces.*
- `template<typename T, IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) METHOD>`  
`void iris::IrisInstanceBuilder::setDefaultMemoryWriteDelegate (T *instance)`  
*Set the default write function for all subsequently added memory spaces.*
- `void iris::IrisInstanceBuilder::setPropertyCanonicalMsnScheme (const std::string &canonicalMsnScheme)`  
*Set the memory.canonicalMsnScheme instance property.*

## 7.5.1 Detailed Description

Set up address translation and memory space metadata and delegates.

## 7.5.2 Function Documentation

### 7.5.2.1 addAddressTranslation()

```
AddressTranslationBuilder iris::IrisInstanceBuilder::addAddressTranslation (
    MemorySpaceId inSpaceId,
    MemorySpaceId outSpaceId,
    const std::string & description ) [inline]
```

Add an address translation.

Add metadata for the address translation from the memory space indicated by *inSpaceId* to the memory space indicated by *outSpaceId*.

By explicitly adding an address translation using this function, the Iris instance can tell clients which address translations are supported and a component can provide a specific delegate function to perform that translation.

#### Parameters

<i>inSpaceId</i>	Memory space id for the input memory space of this translation.
<i>outSpaceId</i>	Memory space id for the output memory space of this translation.
<i>description</i>	A human readable description of this translation. return An <a href="#">AddressTranslationBuilder</a> object which allows additional configuration of this translation.

### 7.5.2.2 addMemorySpace()

```
MemorySpaceBuilder iris::IrisInstanceBuilder::addMemorySpace (
    const std::string & name ) [inline]
```

Add metadata for one memory space.

Typical use pattern:

```
addMemorySpace("name")
    .setDescription("description")
    .setMinAddr(...)
    .setMaxAddr(...)
    .setEndianness(...)
    .addAttribute(...)
    .addAttributeDefault(...);
```

#### Parameters

<i>name</i>	Name of the memory space to add.
-------------	----------------------------------

#### Returns

A [MemorySpaceBuilder](#) object which can be used to configure metadata for the memory space.

### 7.5.2.3 setDefaultAddressTranslateDelegate() [1/3]

```
template<IrisErrorCode*>(uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &)
FUNC>
```

```
void iris::IrisInstanceBuilder::setDefaultAddressTranslateDelegate ( ) [inline]
```

Set the default address translation function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

```
addMemorySpace(...).setTranslationDelegate(...)
```

will use this delegate.

Usage:

```
iris::IrisErrorCode translateAddress(MemorySpaceId inSpaceId, uint64_t address,
                                    MemorySpaceId outSpaceId,
                                    iris::MemoryAddressTranslationResult &result);

iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultAddressTranslateDelegate<&translateAddress>();
builder->addMemorySpace(...); // Uses translateAddress
```

#### Template Parameters

<i>FUNC</i>	Global function to call to translate addresses.
-------------	---

### 7.5.2.4 setDefaultAddressTranslateDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultAddressTranslateDelegate (
    MemoryAddressTranslateDelegate delegate = MemoryAddressTranslateDelegate() )
[inline]
```

Set the default address translation function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

```
addMemorySpace(...).setTranslationDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` not\_implemented for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode translateAddress(MemorySpaceId inSpaceId, uint64_t address,
```



```

        MemorySpaceId outSpaceId,
        iris::MemoryAddressTranslationResult &result);
};
MyClass myInstanceOfMyClass;
iris::MemoryAddressTranslateDelegate delegate =
    iris::MemoryAddressTranslateDelegate::make<MyClass, &MyClass::translateAddress>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultAddressTranslateDelegate(delegate);
builder->addMemorySpace(...); // Uses translateAddress

```

#### Parameters

<i>delegate</i>	Delegate object which will be called to translate addresses.
-----------------	--

### 7.5.2.5 setDefaultAddressTranslateDelegate() [3/3]

```

template<typename T , IrisErrorCode(T::*)(uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &) METHOD>
void iris::IrisInstanceBuilder::setDefaultAddressTranslateDelegate (
    T * instance ) [inline]

```

Set the default address translation function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

`addMemorySpace(...).setTranslationDelegate(...)`

will use this delegate.

#### Usage:

```

class MyClass
{
    ...
    iris::IrisErrorCode translateAddress(MemorySpaceId inSpaceId, uint64_t address,
                                        MemorySpaceId outSpaceId,
                                        iris::MemoryAddressTranslationResult &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultAddressTranslateDelegate<MyClass, &MyClass::translateAddress>(&myInstanceOfMyClass);
builder->addMemorySpace(...); // Uses translateAddress

```

#### Template Parameters

<i>T</i>	Class that defines an address translation delegate method.
<i>METHOD</i>	A method of class T which is an address translation delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

### 7.5.2.6 setDefaultGetMemorySidebandInfoDelegate() [1/3]

```

template<IrisErrorCode(*) (const MemorySpaceInfo &, uint64_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) FUNC>
void iris::IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate ( ) [inline]

```

Set the default sideband info function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the sideband function using

`addMemorySpace(...).setSidebandDelegate(...)`

will use this delegate.

#### Usage:

```

iris::IrisErrorCode getSidebandInfo(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                   const iris::IrisValueMap &attrib,
                                   const std::vector<std::string> &request,
                                   iris::IrisValueMap &result);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultGetMemorySidebandInfoDelegate<&getSidebandInfo>();

```

```
builder->addMemorySpace(...); // Uses getSidebandInfo
```

#### Template Parameters

<i>FUNC</i>	Global function to call to get sideband info.
-------------	---

#### 7.5.2.7 setDefaultGetMemorySidebandInfoDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate (
    MemoryGetSidebandInfoDelegate delegate ) [inline]
```

Set the default sideband info function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the sideband function using

```
addMemorySpace(...).setSidebandDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` not\_implemented for all requests.

#### Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getSidebandInfo(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                        const iris::IrisValueMap &attrib,
                                        const std::vector<std::string> &request,
                                        iris::IrisValueMap &result);
};
MyClass myInstanceOfMyClass;
iris::MemoryAddressTranslateDelegate delegate =
    iris::MemoryAddressTranslateDelegate::make<MyClass, &MyClass::getSidebandInfo>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultGetMemorySidebandInfoDelegate(delegate);
builder->addMemorySpace(...); // Uses getSidebandInfo
```

#### Parameters

<i>delegate</i>	Delegate object which will be called to get sideband info.
-----------------	--

#### 7.5.2.8 setDefaultGetMemorySidebandInfoDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, const IrisValue↔
Map &, const std::vector< std::string > &, IrisValueMap &) METHOD>
```

```
void iris::IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate (
    T * instance ) [inline]
```

Set the default sideband info function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the sideband function using

```
addMemorySpace(...).setSidebandDelegate(...)
```

will use this delegate.

#### Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getSidebandInfo(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                        const iris::IrisValueMap &attrib,
                                        const std::vector<std::string> &request,
                                        iris::IrisValueMap &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultGetMemorySidebandInfoDelegate<MyClass, &MyClass::getSidebandInfo>(&myInstanceOfMyClass);
builder->addMemorySpace(...); // Uses getSidebandInfo
```

#### Template Parameters

<i>T</i>	Class that defines a sideband info delegate method.
<i>METHOD</i>	A method of class T which is a sideband info delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 7.5.2.9 setDefaultMemoryReadDelegate() [1/3]

```
template<IrisErrorCode(*) (const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const Attribute↵
ValueMap &, MemoryReadResult &) FUNC>
```

```
void iris::IrisInstanceBuilder::setDefaultMemoryReadDelegate ( ) [inline]
```

Set the default read function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

```
addMemorySpace(...).setReadDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns E\_↵  
not\_implemented for all requests.

Usage: Pass an instance of class T, where T::METHOD() is a memory read method:

```
iris::IrisErrorCode readMemory(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                             uint64_t byteWidth, uint64_t count,
                             const iris::IrisValueMap &attrib,
                             iris::MemoryReadResult &result);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultMemoryReadDelegate<readMemory>();
builder->addMemorySpace(...); // Uses readMemory
```

## Template Parameters

<i>FUNC</i>	A memory read delegate function.
-------------	----------------------------------

## 7.5.2.10 setDefaultMemoryReadDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultMemoryReadDelegate (
    MemoryReadDelegate delegate = MemoryReadDelegate() ) [inline]
```

Set the default read function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

```
addMemorySpace(...).setReadDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns E\_↵  
not\_implemented for all requests.

Usage: Pass an instance of class T, where T::METHOD() is a memory read method:

```
class MyClass
{
    ...
    iris::IrisErrorCode readMemory(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                  uint64_t byteWidth, uint64_t count,
                                  const iris::IrisValueMap &attrib,
                                  iris::MemoryReadResult &result);
};
MyClass myInstanceOfMyClass;
iris::MemoryReadDelegate delegate =
    iris::MemoryReadDelegate::make<MyClass, &MyClass::readMemory>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultMemoryReadDelegate(delegate);
builder->addMemorySpace(...); // Uses readMemory
```

## Parameters

<i>delegate</i>	Delegate object which will be called to read memory.
-----------------	--

**7.5.2.11 setDefaultMemoryReadDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, MemoryReadResult &) METHOD>
void iris::IrisInstanceBuilder::setDefaultMemoryReadDelegate (
    T * instance ) [inline]
```

Set the default read function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

`addMemorySpace(...).setReadDelegate(...)`

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_not_implemented` for all requests.

Usage: Pass an instance of class T, where `T::METHOD()` is a memory read method:

```
class MyClass
{
    ...
    iris::IrisErrorCode readMemory(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                   uint64_t byteWidth, uint64_t count,
                                   const iris::IrisValueMap &attrib,
                                   iris::MemoryReadResult &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultMemoryReadDelegate<MyClass, &MyClass::readMemory>(myInstanceOfMyClass);
builder->addMemorySpace(...); // Uses readMemory
```

**Template Parameters**

<i>T</i>	Class that defines a memory read delegate method.
<i>METHOD</i>	A method of class T which is a memory read delegate.

**Parameters**

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

**7.5.2.12 setDefaultMemoryWriteDelegate() [1/3]**

```
template<IrisErrorCode(*) (const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) FUNC>
void iris::IrisInstanceBuilder::setDefaultMemoryWriteDelegate ( ) [inline]
```

Set default write function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

`addMemorySpace(...).setWriteDelegate(...)`

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_not_implemented` for all requests.

Usage: Pass an instance of class T, where `T::METHOD()` is a memory read method:

```
iris::IrisErrorCode writeMemory(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                uint64_t byteWidth, uint64_t count,
                                const iris::IrisValueMap &attrib,
                                const uint64_t *data,
                                iris::MemoryWriteResult &result);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultMemoryWriteDelegate<&writeMemory>();
builder->addMemorySpace(...); // Uses writeMemory
```

**Template Parameters**

<i>FUNC</i>	Global function to call to write memory.
-------------	--

### 7.5.2.13 setDefaultMemoryWriteDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setDefaultMemoryWriteDelegate (
    MemoryWriteDelegate delegate = MemoryWriteDelegate() ) [inline]
```

Set the default write function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

```
addMemorySpace(...).setWriteDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔ not_implemented` for all requests.

Usage: Pass an instance of class T, where `T::METHOD()` is a memory read method:

```
class MyClass
{
    ...
    iris::IrisErrorCode writeMemory(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                    uint64_t byteWidth, uint64_t count,
                                    const iris::IrisValueMap &attrib,
                                    const uint64_t *data,
                                    iris::MemoryWriteResult &result);
};
MyClass myInstanceOfMyClass;
iris::MemoryReadDelegate delegate =
    iris::MemoryWriteDelegate::make<MyClass, &MyClass::writeMemory>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultMemoryWriteDelegate(delegate);
builder->addMemorySpace(...); // Uses writeMemory
```

#### Parameters

<i>delegate</i>	Delegate object which will be called to write memory.
-----------------	---

### 7.5.2.14 setDefaultMemoryWriteDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t,
    _t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) METHOD>
```

```
void iris::IrisInstanceBuilder::setDefaultMemoryWriteDelegate (
    T * instance ) [inline]
```

Set the default write function for all subsequently added memory spaces.

Memory spaces that do not explicitly override the access function using

```
addMemorySpace(...).setWriteDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔ not_implemented` for all requests.

Usage: Pass an instance of class T, where `T::METHOD()` is a memory read method:

```
class MyClass
{
    ...
    iris::IrisErrorCode writeMemory(const iris::MemorySpaceInfo &spaceInfo, uint64_t address,
                                    uint64_t byteWidth, uint64_t count,
                                    const iris::IrisValueMap &attrib,
                                    const uint64_t *data,
                                    iris::MemoryWriteResult &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultMemoryWriteDelegate<MyClass, &MyClass::writeMemory>(&myInstanceOfMyClass);
builder->addMemorySpace(...); // Uses writeMemory
```

#### Template Parameters

<i>T</i>	Class that defines a memory read delegate method.
<i>METHOD</i>	A method of class T which is a memory read delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

### 7.5.2.15 setPropertyCanonicalMsnScheme()

```
void iris::IrisInstanceBuilder::setPropertyCanonicalMsnScheme (
    const std::string & canonicalMsnScheme )
```

Set the memory.canonicalMsnScheme instance property.

This property is visible in the list of properties returned by instance\_getProperties().

This property defines the scheme used by the 'canonicalMsn' member of the MemorySpaceInfo object. The default is 'arm.com/memoryspaces' which is used by all Arm components. This default can be overridden by calling this function. This should be called upon initialisation, before other instances have a chance to call instance\_getProperties().

#### Parameters

<i>canonicalMsnScheme</i>	Name of the canonical memory space number scheme used by this instance.
---------------------------	---

## 7.6 IrisInstanceBuilder image loading APIs

Set up image-loading delegates.

### Functions

- `template<IrisErrorCode(*) (const std::vector< uint8_t > &) FUNC>`  
`void iris::IrisInstanceBuilder::setLoadImageDataDelegate ()`  
*Set the delegate to load an image from the data provided.*
- `void iris::IrisInstanceBuilder::setLoadImageDataDelegate (ImageLoadDataDelegate delegate=ImageLoadDataDelegate())`  
*Set the delegate to load an image from the data provided.*
- `template<typename T , IrisErrorCode(T::*)(const std::vector< uint8_t > &) METHOD>`  
`void iris::IrisInstanceBuilder::setLoadImageDataDelegate (T *instance)`  
*Set the delegate to load an image from the data provided.*
- `template<IrisErrorCode(*) (const std::string &) FUNC>`  
`void iris::IrisInstanceBuilder::setLoadImageFileDelegate ()`  
*Set the delegate to load an image from a file.*
- `void iris::IrisInstanceBuilder::setLoadImageFileDelegate (ImageLoadFileDelegate delegate=ImageLoadFileDelegate())`  
*Set the delegate to load an image from a file.*
- `template<typename T , IrisErrorCode(T::*)(const std::string &) METHOD>`  
`void iris::IrisInstanceBuilder::setLoadImageFileDelegate (T *instance)`  
*Set the delegate to load an image from a file.*

### 7.6.1 Detailed Description

Set up image-loading delegates.

### 7.6.2 Function Documentation

#### 7.6.2.1 setLoadImageDataDelegate() [1/3]

```
template<IrisErrorCode(*) (const std::vector< uint8_t > &) FUNC>
void iris::IrisInstanceBuilder::setLoadImageDataDelegate ( ) [inline]
```

Set the delegate to load an image from the data provided.

Usage:

```
iris::IrisErrorCode loadImageData(const std::vector<uint64_t> &data, uint64_t dataSizeInBytes);
```

```
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();  
builder->setLoadImageDataDelegate(&loadImageData());
```

## Template Parameters

<i>FUNC</i>	Global function to call for image loading.
-------------	--

## 7.6.2.2 setLoadImageDataDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setLoadImageDataDelegate (
    ImageLoadDataDelegate delegate = ImageLoadDataDelegate() ) [inline]
```

Set the delegate to load an image from the data provided.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔ not_implemented` for all requests.

## Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode loadImageData(const std::vector<uint64_t> &data, uint64_t dataSizeInBytes);
};
MyClass myInstanceOfMyClass;
iris::MemoryAddressTranslateDelegate delegate =
    iris::MemoryAddressTranslateDelegate::make<MyClass, &MyClass::loadImageData>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setLoadImageDataDelegate(delegate);
```

## Parameters

<i>delegate</i>	Delegate object to call for image loading.
-----------------	--

## 7.6.2.3 setLoadImageDataDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const std::vector< uint8_t > &) METHOD>
void iris::IrisInstanceBuilder::setLoadImageDataDelegate (
    T * instance ) [inline]
```

Set the delegate to load an image from the data provided.

## Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode loadImageData(const std::vector<uint64_t> &data, uint64_t dataSizeInBytes);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setLoadImageDataDelegate<MyClass, &MyClass::loadImageData>(&myInstanceOfMyClass);
```

## Template Parameters

<i>T</i>	Class that defines an image-loading delegate method.
<i>METHOD</i>	A method of class T which is an image-loading delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 7.6.2.4 setLoadImageFileDelegate() [1/3]

```
template<IrisErrorCode(*) (const std::string &) FUNC>
void iris::IrisInstanceBuilder::setLoadImageFileDelegate ( ) [inline]
```



Set the delegate to load an image from a file.

Usage:

```
iris::IrisErrorCode loadImageFile(const std::string &path);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setLoadImageFileDelegate(&loadImageFile);
```

#### Template Parameters

<i>FUNC</i>	Global function to call for image loading.
-------------	--

### 7.6.2.5 setLoadImageFileDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setLoadImageFileDelegate (
    ImageLoadFileDelegate delegate = ImageLoadFileDelegate() ) [inline]
```

Set the delegate to load an image from a file.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` not implemented for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode loadImageFile(const std::string &path);
};
MyClass myInstanceOfMyClass;
iris::MemoryAddressTranslateDelegate delegate =
    iris::MemoryAddressTranslateDelegate::make<MyClass, &MyClass::loadImageFile>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setLoadImageFileDelegate(delegate);
```

#### Parameters

<i>delegate</i>	Delegate object to call for image loading.
-----------------	--

### 7.6.2.6 setLoadImageFileDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const std::string &) METHOD>
void iris::IrisInstanceBuilder::setLoadImageFileDelegate (
    T * instance ) [inline]
```

Set the delegate to load an image from a file.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode loadImageFile(const std::string &path);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setLoadImageFileDelegate<MyClass, &MyClass::loadImageFile>(&myInstanceOfMyClass);
```

#### Template Parameters

<i>T</i>	Class that defines an image-loading delegate method.
<i>METHOD</i>	A method of class T which is an image-loading delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 7.7 IrisInstanceBuilder image readData callback APIs.

Open images for reading.

### Functions

- uint64\_t [iris::IrisInstanceBuilder::openImage](#) (const std::string &filename)  
*Open an image to be read using image\_loadDataPull() or image\_loadDataRead().*

#### 7.7.1 Detailed Description

Open images for reading.

#### 7.7.2 Function Documentation

##### 7.7.2.1 openImage()

```
uint64_t iris::IrisInstanceBuilder::openImage (
    const std::string & filename ) [inline]
```

Open an image to be read using image\_loadDataPull() or image\_loadDataRead().

##### Parameters

<i>filename</i>	The name of the file to be read.
-----------------	----------------------------------

##### Returns

The tag number to use when calling image\_loadDataPull().

## 7.8 IrisInstanceBuilder execution stepping APIs

Set up delegates to set and get the step count and the remaining steps.

### Functions

- template<IrisErrorCode(\*)>(uint64\_t &, const std::string &) FUNC>  
void [iris::IrisInstanceBuilder::setRemainingStepGetDelegate](#) ()  
*Set the delegate to get the remaining steps for this instance.*
- void [iris::IrisInstanceBuilder::setRemainingStepGetDelegate](#) (RemainingStepGetDelegate delegate)  
*Set the delegate to get the remaining steps for this instance.*
- template<typename T , IrisErrorCode(T::\*)(uint64\_t &, const std::string &) METHOD>  
void [iris::IrisInstanceBuilder::setRemainingStepGetDelegate](#) (T \*instance)  
*Set the delegate to get the remaining steps for this instance.*
- template<IrisErrorCode(\*)>(uint64\_t, const std::string &) FUNC>  
void [iris::IrisInstanceBuilder::setRemainingStepSetDelegate](#) ()  
*Set the delegate to set the remaining steps for this instance.*
- void [iris::IrisInstanceBuilder::setRemainingStepSetDelegate](#) (RemainingStepSetDelegate delegate=[RemainingStepSetDelegate](#))  
*Set the delegate to set the remaining steps for this instance.*
- template<typename T , IrisErrorCode(T::\*)(uint64\_t, const std::string &) METHOD>  
void [iris::IrisInstanceBuilder::setRemainingStepSetDelegate](#) (T \*instance)  
*Set the delegate to set the remaining steps for this instance.*
- template<IrisErrorCode(\*)>(uint64\_t &, const std::string &) FUNC>  
void [iris::IrisInstanceBuilder::setStepCountGetDelegate](#) ()

*Set the delegate to get the step count for this instance.*

- void `iris::IrisInstanceBuilder::setStepCountGetDelegate` (`StepCountGetDelegate` delegate=`StepCountGetDelegate`())

*Set the delegate to get the step count for this instance.*

- template<typename T , IrisErrorCode(T::\*)(uint64\_t &, const std::string &) METHOD>  
void `iris::IrisInstanceBuilder::setStepCountGetDelegate` (T \*instance)

*Set the delegate to get the step count for this instance.*

## 7.8.1 Detailed Description

Set up delegates to set and get the step count and the remaining steps.

## 7.8.2 Function Documentation

### 7.8.2.1 setRemainingStepGetDelegate() [1/3]

```
template<IrisErrorCode(*) (uint64_t &, const std::string &) FUNC>
void iris::IrisInstanceBuilder::setRemainingStepGetDelegate ( ) [inline]
```

Set the delegate to get the remaining steps for this instance.

Usage:

```
iris::IrisErrorCode getRemainingSteps(uint64_t &steps, const std::string &unit);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setRemainingStepGetDelegate(&getRemainingSteps);
```

Template Parameters

<i><b><code>FUNC</code></b></i>	Global function to call to get the remaining steps.
---------------------------------	---

### 7.8.2.2 setRemainingStepGetDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setRemainingStepGetDelegate (
    RemainingStepGetDelegate delegate ) [inline]
```

Set the delegate to get the remaining steps for this instance.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_not_implemented` for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getRemainingSteps(uint64_t &steps, const std::string &unit);
};
MyClass myInstanceOfMyClass;
iris::RemainingStepGetDelegate delegate =
    iris::RemainingStepGetDelegate::make<MyClass, &MyClass::getRemainingSteps>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setRemainingStepGetDelegate(delegate);
```

Parameters

<i><b><code>delegate</code></b></i>	Delegate object to call to get the remaining steps.
-------------------------------------	---

### 7.8.2.3 setRemainingStepGetDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(uint64_t &, const std::string &) METHOD>
void iris::IrisInstanceBuilder::setRemainingStepGetDelegate (
    T * instance ) [inline]
```

Set the delegate to get the remaining steps for this instance.

## Usage:

```

class MyClass
{
    ...
    iris::IrisErrorCode getRemainingSteps(uint64_t &steps, const std::string &unit);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setRemainingStepGetDelegate<MyClass, &MyClass::getRemainingSteps>(&myInstanceOfMyClass);

```

## Template Parameters

<i>T</i>	Class that defines a get remaining steps delegate method.
<i>METHOD</i>	A method of class T that is a get remaining steps delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 7.8.2.4 setRemainingStepSetDelegate() [1/3]

```

template<IrisErrorCode(*) (uint64_t, const std::string &) FUNC>
void iris::IrisInstanceBuilder::setRemainingStepSetDelegate ( ) [inline]

```

Set the delegate to set the remaining steps for this instance.

## Usage:

```

iris::IrisErrorCode setRemainingSteps(uint64_t steps, const std::string &unit);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setRemainingStepSetDelegate<&setRemainingSteps>();

```

## Template Parameters

<i>FUNC</i>	Global function to call to set the remaining steps.
-------------	---

## 7.8.2.5 setRemainingStepSetDelegate() [2/3]

```

void iris::IrisInstanceBuilder::setRemainingStepSetDelegate (
    RemainingStepSetDelegate delegate = RemainingStepSetDelegate() ) [inline]

```

Set the delegate to set the remaining steps for this instance.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_not_implemented` for all requests.

## Usage:

```

class MyClass
{
    ...
    iris::IrisErrorCode setRemainingSteps(uint64_t steps, const std::string &unit);
};
MyClass myInstanceOfMyClass;
iris::RemainingStepSetDelegate delegate =
    iris::RemainingStepSetDelegate::make<MyClass, &MyClass::setRemainingSteps>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setRemainingStepSetDelegate(delegate);

```

## Parameters

<i>delegate</i>	Delegate object to call to set the remaining steps.
-----------------	---

### 7.8.2.6 setRemainingStepSetDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(uint64_t, const std::string &) METHOD>
void iris::IrisInstanceBuilder::setRemainingStepSetDelegate (
    T * instance ) [inline]
```

Set the delegate to set the remaining steps for this instance.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode setRemainingSteps(uint64_t steps, const std::string &unit);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setRemainingStepSetDelegate<MyClass, &MyClass::setRemainingSteps>(&myInstanceOfMyClass);
```

#### Template Parameters

<i>T</i>	Class that defines a set remaining steps delegate method.
<i>METHOD</i>	A method of class T that is a set remaining steps delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

### 7.8.2.7 setStepCountGetDelegate() [1/3]

```
template<IrisErrorCode(*) (uint64_t &, const std::string &) FUNC>
void iris::IrisInstanceBuilder::setStepCountGetDelegate ( ) [inline]
```

Set the delegate to get the step count for this instance.

Usage:

```
iris::IrisErrorCode getStepCount(uint64_t &count, const std::string &unit);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setStepCountGetDelegate<&getStepCount>();
```

#### Template Parameters

<i>FUNC</i>	Global function to call to get the step count.
-------------	--

### 7.8.2.8 setStepCountGetDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setStepCountGetDelegate (
    StepCountGetDelegate delegate = StepCountGetDelegate() ) [inline]
```

Set the delegate to get the step count for this instance.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` not\_implemented for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getStepCount(uint64_t &count, const std::string &unit);
};
MyClass myInstanceOfMyClass;
iris::StepCountGetDelegate delegate =
    iris::StepCountGetDelegate::make<MyClass, &MyClass::getStepCount>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setStepCountGetDelegate(delegate);
```

#### Parameters

<i>delegate</i>	Delegate object to call to get the step count.
-----------------	--

### 7.8.2.9 setStepCountGetDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(uint64_t &, const std::string &) METHOD>
void iris::IrisInstanceBuilder::setStepCountGetDelegate (
    T * instance ) [inline]
```

Set the delegate to get the step count for this instance.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getStepCount(uint64_t &count, const std::string &unit);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setStepCountGetDelegate<MyClass, &MyClass::getStepCount>(&myInstanceOfMyClass);
```

#### Template Parameters

<i>T</i>	Class that defines a get step count delegate method.
<i>METHOD</i>	A method of class T which is a get step count delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 7.9 Disassembler delegate functions

Set disassembler delegates.

### Classes

- class [iris::IrisInstanceDisassembler](#)  
*Disassembler add-on for [IrisInstance](#).*

### Typedefs

- typedef [IrisDelegate](#)< const std::vector< uint64\_t > &, uint64\_t, const std::string &, DisassembleContext &, DisassemblyLine & > [iris::DisassembleOpcodeDelegate](#)  
*Get the disassembly for an individual opcode.*
- typedef [IrisDelegate](#)< std::string & > [iris::GetCurrentDisassemblyModeDelegate](#)  
*Get the current disassembly mode.*
- typedef [IrisDelegate](#)< uint64\_t, const std::string &, MemoryReadResult &, uint64\_t, uint64\_t, std::vector< DisassemblyLine > & > [iris::GetDisassemblyDelegate](#)  
*Get the disassembly of a chunk of memory.*

### Functions

- void [iris::IrisInstanceDisassembler::addDisassemblyMode](#) (const std::string &name, const std::string &description)  
*Add a disassembly mode.*
- void [iris::IrisInstanceDisassembler::attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [iris::IrisInstanceDisassembler::IrisInstanceDisassembler](#) ([IrisInstance](#) \*irisInstance=nullptr)  
*Construct an [IrisInstanceDisassembler](#).*

- void `iris::IrisInstanceDisassembler::setDisassembleOpcodeDelegate` (`DisassembleOpcodeDelegate` delegate)  
Set the delegate to get the disassembly of Opcode.
- void `iris::IrisInstanceDisassembler::setGetCurrentModeDelegate` (`GetCurrentDisassemblyModeDelegate` delegate)  
Set the delegate to get the current disassembly mode.
- void `iris::IrisInstanceDisassembler::setGetDisassemblyDelegate` (`GetDisassemblyDelegate` delegate)  
Set the delegate to get the disassembly of a chunk of memory.

### 7.9.1 Detailed Description

Set disassembler delegates.

### 7.9.2 Typedef Documentation

#### 7.9.2.1 DisassembleOpcodeDelegate

```
typedef IrisDelegate<const std::vector<uint64_t>&, uint64_t, const std::string&, DisassembleContext&, DisassemblyLine&> iris::DisassembleOpcodeDelegate
Get the disassembly for an individual opcode.
IrisErrorCode disassembleOpcode(const std::vector<uint64_t> &opcode, uint64_t address, const std::string &mode,
                               DisassembleContext &context, DisassemblyLine &disassemblyLineOut)
Error: Return E_* error code if it failed to disassemble.
```

#### 7.9.2.2 GetCurrentDisassemblyModeDelegate

```
typedef IrisDelegate<std::string&> iris::GetCurrentDisassemblyModeDelegate
Get the current disassembly mode.
IrisErrorCode getCurrentMode(std::string &currentMode)
Error: Return E_* error code if it failed to get the current mode.
```

#### 7.9.2.3 GetDisassemblyDelegate

```
typedef IrisDelegate<uint64_t, const std::string&, MemoryReadResult&, uint64_t, uint64_t,
std::vector<DisassemblyLine>&> iris::GetDisassemblyDelegate
Get the disassembly of a chunk of memory.
IrisErrorCode getDisassembly(uint64_t address, const std::string &mode, MemoryReadResult &memoryReadData,
                             uint64_t count, uint64_t maxAddr, std::vector<DisassemblyLine> &disassemblyLineOut)
Error: Return E_* error code if it failed to disassemble.
```

### 7.9.3 Function Documentation

#### 7.9.3.1 addDisassemblyMode()

```
void iris::IrisInstanceDisassembler::addDisassemblyMode (
    const std::string & name,
    const std::string & description )
```

Add a disassembly mode.

This function should only be called during the initial setup of the instance, after which the list of disassembly modes should be static.

#### Parameters

<i>name</i>	Name of the mode being added.
<i>description</i>	Description of the mode being added.

### 7.9.3.2 attachTo()

```
void iris::IrisInstanceDisassembler::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

### 7.9.3.3 IrisInstanceDisassembler()

```
iris::IrisInstanceDisassembler::IrisInstanceDisassembler (
    IrisInstance * irisInstance = nullptr )
```

Construct an [IrisInstanceDisassembler](#).

#### Parameters

<i>irisInstance</i>	<a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

### 7.9.3.4 setDisassembleOpcodeDelegate()

```
void iris::IrisInstanceDisassembler::setDisassembleOpcodeDelegate (
    DisassembleOpcodeDelegate delegate ) [inline]
```

Set the delegate to get the disassembly of Opcode.

#### Parameters

<i>delegate</i>	Delegate object that will be called to get the disassembly of an opcode.
-----------------	--

### 7.9.3.5 setGetCurrentModeDelegate()

```
void iris::IrisInstanceDisassembler::setGetCurrentModeDelegate (
    GetCurrentDisassemblyModeDelegate delegate ) [inline]
```

Set the delegate to get the current disassembly mode.

#### Parameters

<i>delegate</i>	Delegate object that will be called to get the current disassembly mode.
-----------------	--

### 7.9.3.6 setGetDisassemblyDelegate()

```
void iris::IrisInstanceDisassembler::setGetDisassemblyDelegate (
    GetDisassemblyDelegate delegate ) [inline]
```

Set the delegate to get the disassembly of a chunk of memory.

#### Parameters

<i>delegate</i>	Delegate object that will be called to get the disassembly of a chunk of memory.
-----------------	--



## 7.10 Semihosting data request flag constants

Flags used to define the behavior of the readData() method.

### 7.10.1 Detailed Description

Flags used to define the behavior of the readData() method.

## Chapter 8

# Class Documentation

### 8.1 iris::IrisInstanceBuilder::AddressTranslationBuilder Class Reference

Used to set metadata for an address translation.

```
#include <IrisInstanceBuilder.h>
```

#### Public Member Functions

- **AddressTranslationBuilder** ([IrisInstanceMemory::AddressTranslationInfoAndAccess](#) &info\_)
- `template<IrisErrorCode(*) (uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &) FUNC>`  
[AddressTranslationBuilder](#) & [setTranslateDelegate](#) ()  
*Set the delegate to perform an address translation.*
- [AddressTranslationBuilder](#) & [setTranslateDelegate](#) ([MemoryAddressTranslateDelegate](#) delegate)  
*Set the delegate to perform an address translation.*
- `template<typename T, IrisErrorCode(T::*)(uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &) METHOD>`  
[AddressTranslationBuilder](#) & [setTranslateDelegate](#) (T \*instance)  
*Set the delegate to perform an address translation.*

#### 8.1.1 Detailed Description

Used to set metadata for an address translation.

#### 8.1.2 Member Function Documentation

##### 8.1.2.1 setTranslateDelegate() [1/3]

```
template<IrisErrorCode(*) (uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &)  
FUNC>  
AddressTranslationBuilder & iris::IrisInstanceBuilder::AddressTranslationBuilder::setTranslate↵  
Delegate ( ) [inline]
```

Set the delegate to perform an address translation.

If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultAddressTranslationDelegate](#)

#### Template Parameters

<i>FUNC</i>	An address translation delegate function.
-------------	---

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.1.2.2 setTranslateDelegate() [2/3]**

```
AddressTranslationBuilder & iris::IrisInstanceBuilder::AddressTranslationBuilder::setTranslate↵
Delegate (
    MemoryAddressTranslateDelegate delegate ) [inline]
```

Set the delegate to perform an address translation.  
If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultAddressTranslationDelegate](#)

**Parameters**

<i>delegate</i>	MemoryAddressTranslateDelegate object.
-----------------	--

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.1.2.3 setTranslateDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*)(uint64_t, uint64_t, uint64_t, MemoryAddressTranslation↵
Result &) METHOD>
AddressTranslationBuilder & iris::IrisInstanceBuilder::AddressTranslationBuilder::setTranslate↵
Delegate (
    T * instance ) [inline]
```

Set the delegate to perform an address translation.  
If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultAddressTranslationDelegate](#)

**Template Parameters**

<i>T</i>	A class that defines a method with the right signature to be a memory address translation delegate.
<i>METHOD</i>	A memory address translation delegate method in class T.

**Parameters**

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.2 iris::IrisInstanceMemory::AddressTranslationInfoAndAccess Struct Reference

Contains static address translation information.

```
#include <IrisInstanceMemory.h>
```

### Public Member Functions

- **AddressTranslationInfoAndAccess** (MemorySpaceId inSpaceId, MemorySpaceId outSpaceId, const std::string &description)

### Public Attributes

- [MemoryAddressTranslateDelegate](#) **translateDelegate**
- MemorySupportedAddressTranslationResult **translationInfo**

### 8.2.1 Detailed Description

Contains static address translation information.

The documentation for this struct was generated from the following file:

- [IrisInstanceMemory.h](#)

## 8.3 iris::BreakpointHitInfo Struct Reference

### Public Attributes

- const std::vector< uint64\_t > & **accessData**
- const BreakpointInfo & **bptInfo**
- bool **isReadAccess**

The documentation for this struct was generated from the following file:

- [IrisInstanceBreakpoint.h](#)

## 8.4 iris::IrisInstanceBuilder::EventSourceBuilder Class Reference

Used to set metadata on an EventSource.

```
#include <IrisInstanceBuilder.h>
```

### Public Member Functions

- [EventSourceBuilder](#) & **addEnumElement** (uint64\_t value, const std::string &symbol, const std::string &description="")  
*Add an enum element for the last field added.*
- [EventSourceBuilder](#) & **addField** (const std::string &name, const std::string &type, uint64\_t sizeInBytes, const std::string &description)  
*Add a field to this event source.*
- template<typename T >  
[EventSourceBuilder](#) & **addOption** (const std::string &name, const std::string &type, const T &defaultValue, bool optional, const std::string &description)  
*Declare an option for event streams of an event source.*
- **EventSourceBuilder** ([IrisInstanceEvent::EventSourceInfoAndDelegate](#) &info\_)
- [EventSourceBuilder](#) & **hasSideEffects** (bool hasSideEffects\_=true)  
*Set hasSideEffects for this event source.*
- [EventSourceBuilder](#) & **setCounter** (bool counter=true)

- Set the counter field.*
- [EventSourceBuilder](#) & [setDescription](#) (const std::string &description)
- Set the description field.*
- [EventSourceBuilder](#) & [setEventStreamCreateDelegate](#) ([EventStreamCreateDelegate](#) delegate)
- Set the delegate to create an event stream.*
- template<typename T, IrisErrorCode(T::\*)([EventStream](#) \*&, const EventSourceInfo &, const std::vector< std::string > &) METHOD>  
[EventSourceBuilder](#) & [setEventStreamCreateDelegate](#) (T \*instance)
- Set the delegate to create an event stream.*
- [EventSourceBuilder](#) & [setFormat](#) (const std::string &format)
- Set the format field.*
- [EventSourceBuilder](#) & [setHidden](#) (bool hidden=true)
- Hide/unhide this event source.*
- [EventSourceBuilder](#) & [setName](#) (const std::string &name)
- Set the name field.*

### 8.4.1 Detailed Description

Used to set metadata on an EventSource.

### 8.4.2 Member Function Documentation

#### 8.4.2.1 addEnumElement()

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::addEnumElement (
    uint64_t value,
    const std::string & symbol,
    const std::string & description = "" ) [inline]
```

Add an enum element for the last field added.

This must be called after [addField\(\)](#).

#### Parameters

<i>value</i>	The value of the enum element.
<i>symbol</i>	The symbol string that will be displayed instead of the value.
<i>description</i>	A human readable description of this enum.

#### Returns

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

#### 8.4.2.2 addField()

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::addField (
    const std::string & name,
    const std::string & type,
    uint64_t sizeInBytes,
    const std::string & description ) [inline]
```

Add a field to this event source.

This method constructs an EventSourceFieldInfo object and adds it to the EventSource. It should be called multiple times to add multiple fields.

## Parameters

<i>name</i>	The name of the field.
<i>type</i>	The type of the field.
<i>sizeInBytes</i>	The size of the field in bytes.
<i>description</i>	A human readable description of the field.

## Returns

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

## 8.4.2.3 addOption()

```
template<typename T >
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::addOption (
    const std::string & name,
    const std::string & type,
    const T & defaultValue,
    bool optional,
    const std::string & description ) [inline]
```

Declare an option for event streams of an event source.

This method fills the 'options' member of EventSourceInfo. It may be called multiple times to add multiple options.

## Parameters

<i>name</i>	The name of the option.
<i>type</i>	The type of the option.
<i>defaultValue</i>	The default value of the option.
<i>optional</i>	True if the option is optional, False otherwise.
<i>description</i>	A human readable description of the option.

## Returns

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

## 8.4.2.4 hasSideEffects()

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::hasSideEffects (
    bool hasSideEffects_ = true ) [inline]
```

Set hasSideEffects for this event source.

## Parameters

<i>hasSideEffects_</i>	If true, this event source has side effects. This is exotic. Normal event sources do not have side effects. For example semihosting events have side effects.
------------------------	---

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.5 setCounter()**

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setCounter (
    bool counter = true ) [inline]
```

Set the counter field.

**Parameters**

<i>counter</i>	The counter field of the EventSourceInfo object.
----------------	--

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.6 setDescription()**

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setDescription (
    const std::string & description ) [inline]
```

Set the description field.

**Parameters**

<i>description</i>	The description field of the EventSourceInfo object.
--------------------	--

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.7 setEventStreamCreateDelegate() [1/2]**

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setEventStreamCreateDelegate (
    EventStreamCreateDelegate delegate ) [inline]
```

Set the delegate to create an event stream.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultEsCreateDelegate](#)

**Parameters**

<i>delegate</i>	EventStreamCreateDelegate object.
-----------------	-----------------------------------

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.8 setEventStreamCreateDelegate() [2/2]**

```
template<typename T , IrisErrorCode(T::*)(EventStream * &, const EventSourceInfo &, const std::vector< std::string > &) METHOD>
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setEventStreamCreateDelegate (
    T * instance ) [inline]
```

Set the delegate to create an event stream.  
If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultEsCreateDelegate](#)

**Template Parameters**

<i>T</i>	A class that defines a method with the right signature to be an event stream creation method.
<i>METHOD</i>	An event stream creation delegate method in class T.

**Parameters**

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.9 setFormat()**

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setFormat (
    const std::string & format ) [inline]
```

Set the `format` field.

**Parameters**

<i>format</i>	The format field of the EventSourceInfo object.
---------------	---

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.10 setHidden()**

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setHidden (
    bool hidden = true ) [inline]
```

Hide/unhide this event source.

**Parameters**

<i>hidden</i>	If true, this event source is not listed in <code>event_getEventSources()</code> calls but can still be accessed by <code>event_getEventSource()</code> for clients that know the event source's name.
---------------	--



**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

**8.4.2.11 setName()**

```
EventSourceBuilder & iris::IrisInstanceBuilder::EventSourceBuilder::setName (
    const std::string & name ) [inline]
```

Set the name field.

**Parameters**

<i>name</i>	The name field of the EventSourceInfo object.
-------------	---

**Returns**

A reference to this [EventSourceBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.5 iris::IrisInstanceEvent::EventSourceInfoAndDelegate Struct Reference

Contains the metadata and delegates for a single EventSource.

```
#include <IrisInstanceEvent.h>
```

**Public Attributes**

- [EventStreamCreateDelegate](#) **createEventStream**
- EventSourceInfo **info**
- bool **isProxy** {false}
- bool **isValid** {true}
- [ProxyEventInfo](#) **proxyEventInfo**

**8.5.1 Detailed Description**

Contains the metadata and delegates for a single EventSource.

The documentation for this struct was generated from the following file:

- [IrisInstanceEvent.h](#)

## 8.6 iris::EventStream Class Reference

Base class for event streams.

```
#include <IrisInstanceEvent.h>
```

Inherited by [iris::IrisEventStream](#).

**Public Member Functions**

- virtual IrisErrorCode [action](#) (const BreakpointAction &action\_)  
*Execute action on trace stream.*
- void [addField](#) (const IrisU64StringConstant &field, bool value)  
*Add a boolean field value.*

- template<class T >  
void [addField](#) (const IrisU64StringConstant &field, const T &value)  
*Add a field value.*
- void [addField](#) (const IrisU64StringConstant &field, const uint8\_t \*data, size\_t sizeInBytes)  
*Add byte array.*
- void [addField](#) (const IrisU64StringConstant &field, int64\_t value)  
*Add a sint field value.*
- void [addField](#) (const IrisU64StringConstant &field, uint64\_t value)  
*Add a uint field value.*
- void [addFieldSlow](#) (const std::string &field, bool value)  
*Add a boolean field value.*
- template<class T >  
void [addFieldSlow](#) (const std::string &field, const T &value)  
*Add a field value.*
- void [addFieldSlow](#) (const std::string &field, const uint8\_t \*data, size\_t sizeInBytes)  
*Add byte array.*
- void [addFieldSlow](#) (const std::string &field, int64\_t value)  
*Add a sint field value.*
- void [addFieldSlow](#) (const std::string &field, uint64\_t value)  
*Add a uint field value.*
- bool [checkRangePc](#) (uint64\_t pc) const  
*Check the range for the PC.*
- virtual IrisErrorCode [disable](#) ()=0  
*Disable this event stream.*
- void [emitEventBegin](#) (IrisRequest &req, uint64\_t time, uint64\_t pc=IRIS\_UINT64\_MAX)  
*Start to emit an event callback.*
- void [emitEventBegin](#) (uint64\_t time, uint64\_t pc=IRIS\_UINT64\_MAX)  
*Start to emit an event callback.*
- void [emitEventEnd](#) (bool send=true)  
*Emit the callback.*
- virtual IrisErrorCode [enable](#) ()=0  
*Enable this event stream.*
- **EventStream** ()  
*Construct a new event stream.*
- virtual IrisErrorCode [flush](#) (RequestId requestId)  
*Flush event stream.*
- uint64\_t [getCountVal](#) () const  
*Get the current value of the counter.*
- InstanceId [getEclnInstId](#) () const  
*Get the event callback instance id for this event stream.*
- EventStreamId [getEsId](#) () const  
*Get the Id of this event stream.*
- const EventSourceInfo \* [getEventSourceInfo](#) () const  
*Get the event source info of this event stream.*
- InstanceId [getProxiedByInstanceId](#) () const  
*Get the instance ID of the Iris instance which is a proxy for this event stream.*
- virtual IrisErrorCode [getState](#) (IrisValueMap &fields)  
*Query the current state of the event.*
- virtual IrisErrorCode [insertTrigger](#) ()
- bool [isCounter](#) () const  
*Is this event stream a counter?*

- bool `isEnabled` () const  
*Is this event stream currently enabled?*
- bool `IsProxiedByOtherInstance` () const  
*Is there another Iris instance which is a proxy for this event stream?*
- bool `IsProxyForOtherInstance` () const  
*Is this event stream a proxy for an event stream in another Iris instance?*
- void `selfRelease` ()  
*Trigger the event stream to be released.*
- void `setCounter` (uint64\_t `startVal`, const EventCounterMode &`counterMode`)  
*Set the counter mode and starting value for this event stream.*
- virtual IrisErrorCode `setOptions` (const AttributeValueMap &`options`, bool `eventStreamCreate`, std::string &`errorMessageOut`)  
*Set options.*
- void `setProperties` (IrisInstance \*`irisInstance`, const EventSourceInfo \*`srcInfo`, InstanceId `ecInstId`, const std::string &`ecFunc`, EventStreamId `esId`, bool `syncEc`)  
*Initialize this event stream.*
- void `setProxiedByInstanceId` (InstanceId `instId`)  
*Saves the instance ID of the Iris instance that is a proxy for this event stream.*
- void `setProxyForOtherInstance` ()  
*Set that this event stream is a proxy for an event stream in another Iris instance.*
- IrisErrorCode `setRanges` (const std::string &`aspect`, const std::vector< uint64\_t > &`ranges`)  
*Set the trace ranges for this event stream.*

## Protected Attributes

- std::string `aspect`  
— members for range —
- bool `aspectFound`  
*Found aspect in one of the fields.*
- bool `counter`  
— members for a counter —
- EventCounterMode `counterMode`  
*Specified counter mode.*
- uint64\_t `curAspectValue`  
*The current aspect value.*
- uint64\_t `curVal`
- std::string `ecFunc`  
*The event callback function name specified by eventEnable().*
- InstanceId `ecInstId`  
*Specify target instance that this event is sent to.*
- bool `enabled`  
*Event is only generated when the event stream is enabled.*
- EventStreamId `esId`  
*The event stream id.*
- IrisU64JsonWriter::Object `fieldObj`
- IrisRequest \* `internal_req`
- IrisInstance \* `irisInstance`  
— basic members —
- bool `isProxyForOtherInstance` {false}  
*Is this event stream a proxy for an event stream in another Iris instance?*
- InstanceId `proxiedByInstanceId` {IRIS\_UINT64\_MAX}
- std::vector< uint64\_t > `ranges`

- `IrisRequest * req`  
*Generate callback requests.*
- `const EventSourceInfo * srcInfo`  
*The event source info.*
- `uint64_t startVal`  
*Start value and current value for a counter.*
- `bool syncEc`  
*Synchronous callback behavior.*

### 8.6.1 Detailed Description

Base class for event streams.

This class is abstract as it is not known how to enable or disable an event for a simulation.

### 8.6.2 Member Function Documentation

#### 8.6.2.1 `action()`

```
virtual IrisErrorCode iris::EventStream::action (
    const BreakpointAction & action_ ) [inline], [virtual]
```

Execute action on trace stream.

This function is usually only ever called by breakpoints which have an action other than `eventStream_enable` or `eventStream_disable`.

This function is only implemented by very specific event streams.

#### Returns

An error code indicating whether the operation was successful.

#### 8.6.2.2 `addField()` [1/5]

```
void iris::EventStream::addField (
    const IrisU64StringConstant & field,
    bool value ) [inline]
```

Add a boolean field value.

Fast variant for argument names up to 23 chars. Use this if you can. This will also record the aspect value if the aspect of range check is set.

#### Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

#### 8.6.2.3 `addField()` [2/5]

```
template<class T >
void iris::EventStream::addField (
    const IrisU64StringConstant & field,
    const T & value ) [inline]
```

Add a field value.

This is supported for all types supported by `IrisU64JsonWriter` and `IrisObjects.h`. Fast variant for argument names up to 23 chars. Use this if you can.

## Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.4 addField() [3/5]**

```
void iris::EventStream::addField (
    const IrisU64StringConstant & field,
    const uint8_t * data,
    size_t sizeInBytes ) [inline]
```

Add byte array.

Fast variant for argument names up to 23 chars. Use this if you can.

## Parameters

<i>field</i>	The name of the field whose value is set.
<i>data</i>	Pointer to byte data.
<i>sizeInBytes</i>	Size of byte data.

**8.6.2.5 addField() [4/5]**

```
void iris::EventStream::addField (
    const IrisU64StringConstant & field,
    int64_t value ) [inline]
```

Add a sint field value.

Fast variant for argument names up to 23 chars. Use this if you can. This will also record the aspect value if the aspect of range check is set.

## Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.6 addField() [5/5]**

```
void iris::EventStream::addField (
    const IrisU64StringConstant & field,
    uint64_t value ) [inline]
```

Add a uint field value.

Fast variant for argument names up to 23 chars. Use this if you can. This will also record the aspect value if the aspect of range check is set.

## Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.7 addFieldSlow() [1/5]**

```
void iris::EventStream::addFieldSlow (
    const std::string & field,
    bool value ) [inline]
```

Add a boolean field value.

Slow variant for argument names with more than 23 chars. Do not use unless you have to. This will also record the aspect value if the aspect of range check is set.

**Parameters**

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.8 addFieldSlow() [2/5]**

```
template<class T >
void iris::EventStream::addFieldSlow (
    const std::string & field,
    const T & value ) [inline]
```

Add a field value.

This is supported for all types supported by IrisU64JsonWriter and IrisObjects.h. Slow variant for argument names with more than 23 chars. Do not use unless you have to.

**Parameters**

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.9 addFieldSlow() [3/5]**

```
void iris::EventStream::addFieldSlow (
    const std::string & field,
    const uint8_t * data,
    size_t sizeInBytes ) [inline]
```

Add byte array.

Slow variant for argument names with more than 23 chars. Do not use unless you have to.

**Parameters**

<i>field</i>	The name of the field whose value is set.
<i>data</i>	Pointer to byte data.
<i>sizeInBytes</i>	Size of byte data.

**8.6.2.10 addFieldSlow() [4/5]**

```
void iris::EventStream::addFieldSlow (
    const std::string & field,
    int64_t value ) [inline]
```

Add a sint field value.

Slow variant for argument names with more than 23 chars. Do not use unless you have to. This will also record the aspect value if the aspect of range check is set.

## Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.11 addFieldSlow()** [5/5]

```
void iris::EventStream::addFieldSlow (
    const std::string & field,
    uint64_t value ) [inline]
```

Add a uint field value.

Slow variant for argument names with more than 23 chars. Do not use unless you have to. This will also record the aspect value if the aspect of range check is set.

## Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

**8.6.2.12 checkRangePc()**

```
bool iris::EventStream::checkRangePc (
    uint64_t pc ) const [inline]
```

Check the range for the PC.

This can optionally be called before generating the callback request (before calling [emitEventBegin\(\)](#)).

## Parameters

<i>pc</i>	The program counter value to check.
-----------	-------------------------------------

## Returns

`true` if the PC value is in range or no range is configured, `false` otherwise.

**8.6.2.13 disable()**

```
virtual IrisErrorCode iris::EventStream::disable ( ) [pure virtual]
```

Disable this event stream.

This function is only called when [isEnabled\(\)](#)/enabled == true. It is not necessary to verify this inside the [disable\(\)](#) method.

## Returns

An error code indicating whether the event stream was successfully disabled. This should be `E_ok` if it was disabled or `E_error_disabling_event_stream` if it could not be disabled.

Implemented in [iris::IrisEventStream](#).

**8.6.2.14 emitEventBegin()** [1/2]

```
void iris::EventStream::emitEventBegin (
    IrisRequest & req,
```

```
uint64_t time,
uint64_t pc = IRIS_UINT64_MAX )
```

Start to emit an event callback.

#### Parameters

<i>req</i>	A request object to use to construct the event callback.
<i>time</i>	The time in simulation ticks at which the event occurred.
<i>pc</i>	The program counter value when the event occurred.

#### 8.6.2.15 emitEventBegin() [2/2]

```
void iris::EventStream::emitEventBegin (
    uint64_t time,
    uint64_t pc = IRIS_UINT64_MAX )
```

Start to emit an event callback.

#### Parameters

<i>time</i>	The time in simulation ticks at which the event occurred.
<i>pc</i>	The program counter value when the event occurred.

#### 8.6.2.16 emitEventEnd()

```
void iris::EventStream::emitEventEnd (
    bool send = true )
```

Emit the callback.

This will also check the ranges and maintain the counter.

#### Parameters

<i>send</i>	If <code>true</code> , event callbacks are sent to the callee immediately. If <code>false</code> , the callback are not sent immediately, allowing the caller to delay sending.
-------------	---

#### 8.6.2.17 enable()

```
virtual IrisErrorCode iris::EventStream::enable ( ) [pure virtual]
```

Enable this event stream.

This function is only called when `isEnabled()/enabled == false`. It is not necessary to verify this inside the `enable()` method.

#### Returns

An error code indicating whether the event stream was successfully enabled. This should be `E_ok` if it was enabled or `E_error_enabling_event_stream` if it could not be enabled.

Implemented in [iris::IrisEventStream](#).

#### 8.6.2.18 flush()

```
virtual IrisErrorCode iris::EventStream::flush (
    RequestId requestId ) [inline], [virtual]
```



Flush event stream.  
Supported in the derived classes for specific event sources.

#### Parameters

<i>requestId</i>	Request id of the eventStream_flush() call. This is returned to the caller in an extra FLUSH_REQUEST_ID field in the response to the flush call.
------------------	--

#### Returns

An error code indicating whether the operation was successful.

#### 8.6.2.19 getCountVal()

```
uint64_t iris::EventStream::getCountVal ( ) const [inline]
```

Get the current value of the counter.

#### Returns

The current value of the event counter.

#### 8.6.2.20 getEcInstId()

```
InstanceId iris::EventStream::getEcInstId ( ) const [inline]
```

Get the event callback instance id for this event stream.

#### Returns

The instId for the instance that this event stream calls when an event fires.

#### 8.6.2.21 getEsId()

```
EventStreamId iris::EventStream::getEsId ( ) const [inline]
```

Get the Id of this event stream.

#### Returns

The esId for this event stream.

#### 8.6.2.22 getEventSourceInfo()

```
const EventSourceInfo * iris::EventStream::getEventSourceInfo ( ) const [inline]
```

Get the event source info of this event stream.

#### Returns

The event source info that was used to create this event stream.

#### 8.6.2.23 getProxiedByInstanceId()

```
InstanceId iris::EventStream::getProxiedByInstanceId ( ) const [inline]
```

Get the instance ID of the Iris instance which is a proxy for this event stream.

#### Returns

The instance ID of the Iris instance which is a proxy

**8.6.2.24 getState()**

```
virtual IrisErrorCode iris::EventStream::getState (
    IrisValueMap & fields ) [inline], [virtual]
```

Query the current state of the event.

Supported in the derived classes for specific event sources.

**Parameters**

<i>fields</i>	A map which will be populated with the current values for this event's fields.
---------------	--

**Returns**

An error code indicating whether the operation was successful.

**8.6.2.25 isCounter()**

```
bool iris::EventStream::isCounter ( ) const [inline]
```

Is this event stream a counter?

**Returns**

`true` if this event stream is a counter, otherwise `false`.

**8.6.2.26 isEnabled()**

```
bool iris::EventStream::isEnabled ( ) const [inline]
```

Is this event stream currently enabled?

**Returns**

`true` if this event stream is enabled or `false` if it disabled.

**8.6.2.27 IsProxiedByOtherInstance()**

```
bool iris::EventStream::IsProxiedByOtherInstance ( ) const [inline]
```

Is there another Iris instance which is a proxy for this event stream?

**Returns**

`true` if this event stream is being proxied by another Iris instance, otherwise `false`.

**8.6.2.28 IsProxyForOtherInstance()**

```
bool iris::EventStream::IsProxyForOtherInstance ( ) const [inline]
```

Is this event stream a proxy for an event stream in another Iris instance?

**Returns**

`true` if this event stream is a proxy, otherwise `false`.

**8.6.2.29 selfRelease()**

```
void iris::EventStream::selfRelease ( ) [inline]
```

Trigger the event stream to be released.

If this event stream is not waiting for any response, release it immediately. Otherwise, release it when it has finished waiting. The event stream is disabled beforehand if it is still enabled.

**Note**

Do not touch anything related to this object after calling this function.

Do not call this function if this object was not created by 'new'.

**8.6.2.30 setCounter()**

```
void iris::EventStream::setCounter (
    uint64_t startVal,
    const EventCounterMode & counterMode )
```

Set the counter mode and starting value for this event stream.

**Parameters**

<i>startVal</i>	The starting value of the counter.
<i>counterMode</i>	The mode in which this counter operates.

**8.6.2.31 setOptions()**

```
virtual IrisErrorCode iris::EventStream::setOptions (
    const AttributeValueMap & options,
    bool eventStreamCreate,
    std::string & errorMessageOut ) [inline], [virtual]
```

Set options.

Supported in the derived classes for specific event sources. This is called by [setPropertyies\(\)](#) which in turn is called when the event stream is created. Creating the event stream will fail when this function returns an error and when an options argument is present in `eventStream_create()`.

**Parameters**

<i>options</i>	Map of options (key/value pairs).
<i>eventStreamCreate</i>	True: These are the options set by <code>eventStream_create()</code> . False: These are options set by <code>eventStream_setOptions()</code> .
<i>errorMessageOut</i>	When this function returns an error it should set <code>errorMessageOut</code> to a meaningful error message.

**Returns**

An error code indicating whether the operation was successful.

**8.6.2.32 setProperties()**

```
void iris::EventStream::setPropertyies (
    IrisInstance * irisInstance,
```

```

    const EventSourceInfo * srcInfo,
    InstanceId ecInstId,
    const std::string & ecFunc,
    EventStreamId esId,
    bool syncEc )

```

Initialize this event stream.

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> that is producing this stream. This will be used to send event callback requests.
<i>srcInfo</i>	The metadata for the event source generating this stream.
<i>ecInstId</i>	The event callback instId: the instance that this stream calls when an event fires.
<i>ecFunc</i>	The event callback function: the function that is called when an event fires.
<i>esId</i>	The event stream id for this event stream.
<i>syncEc</i>	True if this event stream is synchronous and should send event callbacks as requests. If false event callbacks are sent as notifications and do not wait for a response.

#### 8.6.2.33 setProxiedByInstanceId()

```

void iris::EventStream::setProxiedByInstanceId (
    InstanceId instId ) [inline]

```

Saves the instance ID of the Iris instance that is a proxy for this event stream.

#### Parameters

<i>instId</i>	The instance ID of the proxy Iris instance
---------------	--

#### 8.6.2.34 setRanges()

```

IrisErrorCode iris::EventStream::setRanges (
    const std::string & aspect,
    const std::vector< uint64_t > & ranges )

```

Set the trace ranges for this event stream.

#### Parameters

<i>aspect</i>	The field whose range to check.
<i>ranges</i>	A list where each 3 elements form a 3-tuple of (mask, start, end) values to configure ranges.

#### Returns

An error code indicating whether the ranges could be set successfully.

### 8.6.3 Member Data Documentation

#### 8.6.3.1 counter

```
bool iris::EventStream::counter [protected]
```

— members for a counter —

Is a counter?

### 8.6.3.2 irisInstance

`IrisInstance*` `iris::EventStream::irisInstance` [protected]

— basic members —

The Iris instance that created this event.

### 8.6.3.3 proxiedByInstanceId

`InstanceId` `iris::EventStream::proxiedByInstanceId` {`IRIS_UINT64_MAX`} [protected]

An event stream in another Iris instance is a proxy for this event stream `proxiedByInstanceId` - the instance ID of the other Iris instance

The documentation for this class was generated from the following file:

- [IrisInstanceEvent.h](#)

## 8.7 iris::IrisInstanceBuilder::FieldBuilder Class Reference

Used to set metadata on a register field resource.

`#include <IrisInstanceBuilder.h>`

### Public Member Functions

- [FieldBuilder](#) & [addEnum](#) (const std::string &symbol, const IrisValue &value, const std::string &description=std::string())  
Add a symbol to the enums field for numeric resources.
- [FieldBuilder](#) [addField](#) (const std::string &name, uint64\_t lsbOffset, uint64\_t bitWidth, const std::string &description)  
Add another subregister field to the parent register.
- [FieldBuilder](#) [addLogicalField](#) (const std::string &name, uint64\_t bitWidth, const std::string &description)  
Add another logical subregister field to the parent register.
- [FieldBuilder](#) & [addStringEnum](#) (const std::string &stringValue, const std::string &description=std::string())  
Add a symbol to the enums field for string resources.
- **FieldBuilder** ([IrisInstanceResource::ResourceInfoAndAccess](#) &info\_, [RegisterBuilder](#) \*parent\_reg\_, [IrisInstanceBuilder](#) \*instance\_builder\_)
- ResourceId [getRscl](#) () const  
Return the rscl that was allocated for this resource.
- [FieldBuilder](#) & [getRscl](#) (ResourceId &rsclOut)  
Get the rscl that was allocated for this resource.
- [RegisterBuilder](#) & [parent](#) ()  
Get the [RegisterBuilder](#) for the parent register.
- [FieldBuilder](#) & [setAddressOffset](#) (uint64\_t addressOffset)  
Set the `addressOffset` field.
- [FieldBuilder](#) & [setBitWidth](#) (uint64\_t bitWidth)  
Set the `bitWidth` field.
- [FieldBuilder](#) & [setCanonicalRn](#) (uint64\_t canonicalRn\_)  
Set the `canonicalRn` field.
- [FieldBuilder](#) & [setCanonicalRnElfDwarf](#) (uint16\_t architecture, uint16\_t dwarfRegNum)  
Set the `canonicalRn` field for "ElfDwarf" scheme.
- [FieldBuilder](#) & [setName](#) (const std::string &cname)  
Set the `cname` field.
- [FieldBuilder](#) & [setDescription](#) (const std::string &description)  
Obsolete alias for [setDescription\(\)](#). Do not use.
- [FieldBuilder](#) & [setDescription](#) (const std::string &description)  
Set the `description` field.

- [FieldBuilder](#) & [setFormat](#) (const std::string &format)  
*Set the `format` field.*
- [FieldBuilder](#) & [setLsbOffset](#) (uint64\_t lsbOffset)  
*Set the `lsbOffset` field.*
- [FieldBuilder](#) & [setName](#) (const std::string &name)  
*Set the `name` field.*
- [FieldBuilder](#) & [setParentRscId](#) (ResourceId parentRscId)  
*Set the `parentRscId` field.*
- template<IrisErrorCode(\*)>(const ResourceInfo &, ResourceReadResult &) FUNC>  
[FieldBuilder](#) & [setReadDelegate](#) ()  
*Set the delegate to read the resource.*
- [FieldBuilder](#) & [setReadDelegate](#) (ResourceReadDelegate readDelegate)  
*Set the delegate to read the resource.*
- template<typename T , IrisErrorCode(T::\*)>(const ResourceInfo &, ResourceReadResult &) METHOD>  
[FieldBuilder](#) & [setReadDelegate](#) (T \*instance)  
*Set the delegate to read the resource.*
- template<typename T >  
[FieldBuilder](#) & [setResetData](#) (std::initializer\_list< T > &&t)  
*Set the `resetData` field for wide registers.*
- [FieldBuilder](#) & [setResetData](#) (uint64\_t value)  
*Set the `resetData` field to a value <= 64 bit.*
- template<typename Container >  
[FieldBuilder](#) & [setResetDataFromContainer](#) (const Container &container)  
*Set the `resetData` field for wide registers.*
- [FieldBuilder](#) & [setResetString](#) (const std::string &resetString)  
*Set the `resetString` field.*
- [FieldBuilder](#) & [setRwMode](#) (const std::string &rwMode)  
*Set the `rwMode` field.*
- [FieldBuilder](#) & [setSubRscId](#) (uint64\_t subRscId)  
*Set the `subRscId` field.*
- [FieldBuilder](#) & [setTag](#) (const std::string &tag)  
*Set the named boolean tag to true (e.g. `isPc`)*
- [FieldBuilder](#) & [setTag](#) (const std::string &tag, const IrisValue &value)  
*Set a tag to the specified value.*
- [FieldBuilder](#) & [setType](#) (const std::string &type)  
*Set the `type` field.*
- template<IrisErrorCode(\*)>(const ResourceInfo &, const [ResourceWriteValue](#) &) FUNC>  
[FieldBuilder](#) & [setWriteDelegate](#) ()  
*Set the delegate to write the resource.*
- [FieldBuilder](#) & [setWriteDelegate](#) (ResourceWriteDelegate writeDelegate)  
*Set the delegate to write the resource.*
- template<typename T , IrisErrorCode(T::\*)>(const ResourceInfo &, const [ResourceWriteValue](#) &) METHOD>  
[FieldBuilder](#) & [setWriteDelegate](#) (T \*instance)  
*Set the delegate to write the resource.*
- template<typename T >  
[FieldBuilder](#) & [setWriteMask](#) (std::initializer\_list< T > &&t)  
*Set the `writeMask` field for wide registers.*
- [FieldBuilder](#) & [setWriteMask](#) (uint64\_t value)  
*Set the `writeMask` field to a value <= 64 bit.*
- template<typename Container >  
[FieldBuilder](#) & [setWriteMaskFromContainer](#) (const Container &container)  
*Set the `writeMask` field for wide registers.*

## Protected Attributes

- [IrisInstanceResource::ResourceInfoAndAccess](#) \* **info** {}
- [IrisInstanceBuilder](#) \* **instance\_builder** {}
- [RegisterBuilder](#) \* **parent\_reg** {}

### 8.7.1 Detailed Description

Used to set metadata on a register field resource.

### 8.7.2 Member Function Documentation

#### 8.7.2.1 addEnum()

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::addEnum (
    const std::string & symbol,
    const IrisValue & value,
    const std::string & description = std::string() ) [inline]
```

Add a symbol to the enums field for numeric resources.

This should be called multiple times to add multiple symbols.

#### Parameters

<i>symbol</i>	The symbol string to be associated with the specified value.
<i>value</i>	The value of this symbol.
<i>description</i>	A description of this symbol.

#### Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

#### 8.7.2.2 addField()

```
FieldBuilder iris::IrisInstanceBuilder::FieldBuilder::addField (
    const std::string & name,
    uint64_t lsbOffset,
    uint64_t bitWidth,
    const std::string & description ) [inline]
```

Add another subregister field to the parent register.

#### See also

[RegisterBuilder::addField](#)

#### 8.7.2.3 addLogicalField()

```
FieldBuilder iris::IrisInstanceBuilder::FieldBuilder::addLogicalField (
    const std::string & name,
    uint64_t bitWidth,
    const std::string & description ) [inline]
```

Add another logical subregister field to the parent register.

#### See also

[RegisterBuilder::addField](#)

#### 8.7.2.4 addStringEnum()

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::addStringEnum (
    const std::string & stringValue,
    const std::string & description = std::string() ) [inline]
```

Add a symbol to the enums field for string resources.

This should be called multiple times to add multiple symbols.

##### Parameters

<i>value</i>	The string value of this symbol. This is also used as the symbols string.
<i>description</i>	A description of this symbol.

##### Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

#### 8.7.2.5 getRscId() [1/2]

```
ResourceId iris::IrisInstanceBuilder::FieldBuilder::getRscId ( ) const [inline]
```

Return the rscId that was allocated for this resource.

##### Returns

The rscId that was allocated for this resource.

#### 8.7.2.6 getRscId() [2/2]

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::getRscId (
    ResourceId & rscIdOut ) [inline]
```

Get the rscId that was allocated for this resource.

This variant is useful to get the ResourceId of fields added in a chained call where return values are not practical.

##### Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

#### 8.7.2.7 parent()

```
RegisterBuilder & iris::IrisInstanceBuilder::FieldBuilder::parent ( ) [inline]
```

Get the [RegisterBuilder](#) for the parent register.

##### Returns

The [RegisterBuilder](#) object for the parent register.

#### 8.7.2.8 setAddressOffset()

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setAddressOffset (
    uint64_t addressOffset ) [inline]
```

Set the addressOffset field.



## Parameters

<i>addressOffset</i>	The addressOffset field of the RegisterInfo object.
----------------------	---

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.9 setBitWidth()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setBitWidth (
    uint64_t bitWidth ) [inline]
```

Set the bitWidth field.

## Parameters

<i>bitWidth</i>	The bitWidth field of the ResourceInfo object.
-----------------	--

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.10 setCanonicalRn()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setCanonicalRn (
    uint64_t canonicalRn_ ) [inline]
```

Set the canonicalRn field.

Note: Use [setCanonicalRnElfDwarf\(\)](#) when using the "ElfDwarf" scheme.

## Parameters

<i>canonicalRn</i>	The canonicalRn field of the RegisterInfo object.
--------------------	---

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.11 setCanonicalRnElfDwarf()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setCanonicalRnElfDwarf (
    uint16_t architecture,
    uint16_t dwarfRegNum ) [inline]
```

Set the canonicalRn field for "ElfDwarf" scheme.

## Parameters

<i>architecture</i>	ELF EM_* constant for architecture.
<i>dwarfRegNum</i>	DWARF register number for architecture.

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.12 setName()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setName (
    const std::string & cname ) [inline]
```

Set the `cname` field.

**Parameters**

<i>cname</i>	The cname field of the ResourceInfo object.
--------------	---

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.13 setDescription()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setDescription (
    const std::string & description ) [inline]
```

Set the `description` field.

**Parameters**

<i>description</i>	The description field of the ResourceInfo object.
--------------------	---

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.14 setFormat()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setFormat (
    const std::string & format ) [inline]
```

Set the `format` field.

**Parameters**

<i>format</i>	The format field of the ResourceInfo object.
---------------	--

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.15 setLsbOffset()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setLsbOffset (
    uint64_t lsbOffset ) [inline]
```

Set the `lsbOffset` field.

## Parameters

<i>IsbOffset</i>	The IsbOffset field of the RegisterInfo object.
------------------	---

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.16 setName()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setName (
    const std::string & name ) [inline]
```

Set the name field.

## Parameters

<i>name</i>	The name field of the ResourceInfo object.
-------------	--

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.17 setParentRscId()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setParentRscId (
    ResourceId parentRscId ) [inline]
```

Set the parentRscId field.

This function makes this register a child of the specified parent. It is not necessary to call this function when adding child registers using the [addField\(\)](#) function.

## Parameters

<i>parent↵ RscId</i>	The rsclId of the parent register.
--------------------------	------------------------------------

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.18 setReadDelegate() [1/3]**

```
template<IrisErrorCode(*) (const ResourceInfo &, ResourceReadResult &) FUNC>
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setReadDelegate ( ) [inline]
```

Set the delegate to read the resource.

Set a delegate which calls function FUNC().

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

## Template Parameters

<i>FUNC</i>	A resource read delegate function.
-------------	------------------------------------

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.19 setReadDelegate()** [2/3]

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setReadDelegate (
    ResourceReadDelegate readDelegate ) [inline]
```

Set the delegate to read the resource.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

## Parameters

<i>readDelegate</i>	ResourceReadDelegate object.
---------------------	------------------------------

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.20 setReadDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) METHOD>
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setReadDelegate (
    T * instance ) [inline]
```

Set the delegate to read the resource.

Set a delegate which calls METHOD() on an instance of class T.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

## Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a resource read delegate.
<i>METHOD</i>	A resource read delegate method in class T.

## Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

## Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.21 setResetData()** [1/2]

```
template<typename T >
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setResetData (
    std::initializer_list< T > && t ) [inline]
```

Set the `resetData` field for wide registers.

This function accepts a braced initializer-list and is otherwise identical to

[setResetDataFromContainer\(\)](#).

Each element will be promoted/narrowed to `uint64_t`.

**Parameters**

<i>t</i>	Braced initializer-list.
----------	--------------------------

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.22 setResetData()** [2/2]

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setResetData (
    uint64_t value ) [inline]
```

Set the `resetData` field to a value  $\leq 64$  bit.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

**Parameters**

<i>value</i>	resetData value of the register.
--------------	----------------------------------

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.23 setResetDataFromContainer()**

```
template<typename Container >
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setResetDataFromContainer (
    const Container & container ) [inline]
```

Set the `resetData` field for wide registers.

Container must be a type which allows to iterate over `uint64_t` bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to `uint64_t`.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

**Parameters**

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.24 setResetString()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setResetString (
    const std::string & resetString ) [inline]
```

Set the `resetString` field.

Set the reset value for string registers.

**Parameters**

<i>resetString</i>	The <code>resetString</code> field of the <code>RegisterInfo</code> object.
--------------------	---

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.25 setRwMode()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setRwMode (
    const std::string & rwMode ) [inline]
```

Set the `rwMode` field.

**Parameters**

<i>rwMode</i>	The <code>rwMode</code> field of the <code>ResourceInfo</code> object.
---------------	--

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.26 setSubRscId()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setSubRscId (
    uint64_t subRscId ) [inline]
```

Set the `subRscId` field.

**Parameters**

<i>sub↔ RscId</i>	The <code>subRscId</code> field of the <code>ResourceInfo</code> object.
-----------------------	--

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.27 setTag() [1/2]**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setTag (
    const std::string & tag ) [inline]
```

Set the named boolean tag to true (e.g. `isPc`)

**Parameters**

<i>tag</i>	The name of the tag to set.
------------	-----------------------------

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.28 setTag() [2/2]**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setTag (
    const std::string & tag,
    const IrisValue & value ) [inline]
```

Set a tag to the specified value.

**Parameters**

<i>tag</i>	The name of the tag to set.
<i>value</i>	The value to set the tag to.

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.29 setType()**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setType (
    const std::string & type ) [inline]
```

Set the type field.

**Parameters**

<i>type</i>	The type field of the ResourceInfo object.
-------------	--

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.30 setWriteDelegate() [1/3]**

```
template<IrisErrorCode(*) (const ResourceInfo &, const ResourceWriteValue &) FUNC>
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setWriteDelegate ( ) [inline]
```

Set the delegate to write the resource.

Set a delegate which calls function FUNC().

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

**Template Parameters**

<i>FUNC</i>	A resource write delegate function.
-------------	-------------------------------------

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.31 setWriteDelegate() [2/3]**

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setWriteDelegate (
    ResourceWriteDelegate writeDelegate ) [inline]
```

Set the delegate to write the resource.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

**Parameters**

<i>writeDelegate</i>	ResourceWriteDelegate object.
----------------------	-------------------------------

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.32 setWriteDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*) (const ResourceInfo &, const ResourceWriteValue &)>
METHOD>
```

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setWriteDelegate (
    T * instance ) [inline]
```

Set the delegate to write the resource.

Set a delegate which calls METHOD() on an instance of class T.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

**Template Parameters**

<i>T</i>	A class that defines a method with the right signature to be a resource write delegate.
<i>METHOD</i>	A resource write delegate method in class T.

**Parameters**

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

**Returns**

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

**8.7.2.33 setWriteMask() [1/2]**

```
template<typename T >
```



```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setWriteMask (
    std::initializer_list< T > && t ) [inline]
```

Set the `writeMask` field for wide registers.

This function accepts a braced initializer-list and is otherwise identical to [setWriteMaskFromContainer\(\)](#).

Each element will be promoted/narrowed to `uint64_t`.

#### Parameters

<i>t</i>	Braced initializer-list.
----------	--------------------------

#### Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

### 8.7.2.34 setWriteMask() [2/2]

```
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setWriteMask (
    uint64_t value ) [inline]
```

Set the `writeMask` field to a value  $\leq 64$  bit.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>value</i>	<code>writeMask</code> value of the register.
--------------	---

#### Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

### 8.7.2.35 setWriteMaskFromContainer()

```
template<typename Container >
FieldBuilder & iris::IrisInstanceBuilder::FieldBuilder::setWriteMaskFromContainer (
    const Container & container ) [inline]
```

Set the `writeMask` field for wide registers.

Container must be a type which allows to iterate over `uint64_t` bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to `uint64_t`.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

#### Returns

A reference to this [FieldBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.8 iris::IrisCConnection Class Reference

Provide an IrisConnectionInterface which loads an IrisC library.

```
#include <IrisCConnection.h>
```

Inherits IrisConnectionInterface.

### Public Member Functions

- virtual IrisInterface \* **getIrisInterface** () IRIS\_OVERRIDE  
*Get the IrisInterface for this connection. See also IrisConnectionInterface::getIrisInterface().*
- **IrisCConnection** (IrisC\_Funcions \*functions)
- virtual IrisErrorCode **processAsyncMessages** (bool waitForAMessage) IRIS\_OVERRIDE  
*Process asynchronous messages for the calling thread. See also IrisConnectionInterface::processAsyncMessages().*
- virtual uint64\_t **registerIrisInterfaceChannel** (IrisInterface \*iris\_interface) IRIS\_OVERRIDE  
*Register a communication channel. See also IrisConnectionInterface::registerIrisInterfaceChannel().*
- virtual void **unregisterIrisInterfaceChannel** (uint64\_t channelId) IRIS\_OVERRIDE  
*Unregister a communication channel. See also IrisConnectionInterface::unregisterIrisInterfaceChannel().*

### Protected Member Functions

- int64\_t **IrisC\_handleMessage** (const uint64\_t \*message)  
*Wrapper functions to call the underlying IrisC functions.*
- int64\_t **IrisC\_processAsyncMessages** (bool waitForAMessage)
- int64\_t **IrisC\_registerChannel** (IrisC\_CommunicationChannel \*channel, uint64\_t \*channel\_id\_out)
- int64\_t **IrisC\_unregisterChannel** (uint64\_t channel\_id)
- **IrisCConnection** ()  
*Construct an empty object. Used by subclasses that need to load a DSO and call init().*

### Protected Attributes

- void \* **iris\_c\_context**  
*Context pointer to use when calling IrisC\_\* functions. This is also needed by subclasses.*

#### 8.8.1 Detailed Description

Provide an IrisConnectionInterface which loads an IrisC library.

See also

[IrisClient](#)

[IrisGlobalInstance](#)

The documentation for this class was generated from the following file:

- [IrisCConnection.h](#)

## 8.9 iris::IrisClient Class Reference

Inherits IrisInterface, impl::IrisProcessEventsInterface, and IrisConnectionInterface.

## Public Member Functions

- void [connect](#) (const std::string &connectionSpec)
- IrisErrorCode [connect](#) (const std::string &hostname, uint16\_t port, unsigned timeoutInMs, std::string &error←ResponseOut)
- void [connectSocketFd](#) (SocketFd sockfd, unsigned timeoutInMs=1000)
- IrisErrorCode [disconnect](#) ()
- bool [disconnectAndWaitForChildToExit](#) (double timeoutInMs=5000, double timeoutInMsAfterSigInt=5000, double timeoutInMsAfterSigKill=5000)
- pid\_t [getChildPid](#) () const  
*Get child process id of previously spawned process or 0 if no process was spawned yet using [spawnAndConnect](#)().*
- std::string [getConnectionStr](#) () const  
*Get connection string, describing the Iris server we are connected to.*
- impl::IrisRpcAdapterTcp::Format [getEffectiveSendingFormat](#) () const  
*Get effective sending format that Rpc adapter uses.*
- [IrisInstance](#) & [getIrisInstance](#) ()
- virtual IrisInterface \* [getIrisInterface](#) () override
- int [getLastExitStatus](#) () const  
*Get last exit status of child process, or -1 if the child process did not yet exit.*
- IrisInterface \* [getSendingInterface](#) ()  
*Get interface for sending messages to the server.*
- void [initServiceServer](#) (impl::IrisTcpSocket \*socket\_)
- **IrisClient** (const service::IrisServiceTcpServer \*, const std::string &instName=std::string())  
*Service constructor to initialize IrisService Server on IrisService side.*
- [IrisClient](#) (const std::string &hostname, uint16\_t port, const std::string &instName=std::string())  
*Construct a connection to an Iris server.*
- **IrisClient** (const std::string &instName=std::string(), const std::string &connectionSpec=std::string())  
*Client constructor.*
- bool [isConnected](#) () const  
*Return true iff connected to a server.*
- void [loadPlugin](#) (const std::string &plugin\_name)
- virtual IrisErrorCode [processAsyncMessages](#) (bool waitForAMessage) override
- virtual void [processEvents](#) () override
- uint64\_t [registerChannel](#) (IrisC\_CommunicationChannel \*channel)
- uint64\_t [registerChannel](#) (IrisC\_CommunicationChannel \*channel, const std::string &path)
- virtual uint64\_t [registerIrisInterfaceChannel](#) (IrisInterface \*iris\_interface) override
- void [setInstanceName](#) (const std::string &instName)
- void [setIrisMessageLogLevel](#) (unsigned level)  
*Enable message logging.*
- void [setPreferredSendingFormat](#) (impl::IrisRpcAdapterTcp::Format p)  
*Set preferred sending format that Rpc adapter uses.*
- void [setSleepOnDestructionMs](#) (uint64\_t sleepOnDestructionMs\_)
- void [setVerbose](#) (unsigned level, bool increaseOnly=false)  
*Set verbose level.*
- void [spawnAndConnect](#) (const std::vector< std::string > &modelCommandLine, const std::string &additionalServerArgs=std::string(), const std::string &additionalClientArgs=std::string())
- virtual void [stopWaitForEvent](#) () override
- void [unloadPlugin](#) ()
- void [unregisterChannel](#) (uint64\_t channelId)
- virtual void [unregisterIrisInterfaceChannel](#) (uint64\_t channelId) override
- virtual void [waitForEvent](#) () override
- bool [waitpidWithTimeout](#) (pid\_t pid, int \*status, int options, double timeoutInMs)
- virtual ~**IrisClient** ()  
*Destructor.*

## Public Attributes

- const std::string [connectionHelpStr](#)  
*Connection help string.*

## 8.9.1 Constructor & Destructor Documentation

### 8.9.1.1 IrisClient()

```
iris::IrisClient::IrisClient (
    const std::string & hostname,
    uint16_t port,
    const std::string & instName = std::string() ) [inline]
```

Construct a connection to an Iris server.

#### Parameters

<i>hostname</i>	<p>Hostname of the Iris server. This can be an IP address. For example:</p> <ul style="list-style-type: none"> <li>• "192.168.0.5" IP address of a different host.</li> <li>• "127.0.0.1" Loopback IP address to connect to a server on the same machine.</li> <li>• "localhost" Hostname of the loopback interface. Port == 0 means to scan ports 7100 to 7109.</li> <li>• "foo.bar.com" Hostname of a remote machine.</li> </ul>
<i>port</i>	Server port number to connect to on the host.

## 8.9.2 Member Function Documentation

### 8.9.2.1 connect() [1/2]

```
void iris::IrisClient::connect (
    const std::string & connectionSpec ) [inline]
```

Connect to an Iris server.

The connection details are specified as a string. See "connectionHelpStr" for syntax. This function is self documenting: Passing "help" will return a list of all supported connection types and their syntax, as an E\_help\_↔ message error.

This throws E\_not\_connected when connectionSpec was erroneous, and E\_socket\_error or E\_connection\_refused when the connection could not be established. In case of an error the socket is closed.

### 8.9.2.2 connect() [2/2]

```
IrisErrorCode iris::IrisClient::connect (
    const std::string & hostname,
    uint16_t port,
    unsigned timeoutInMs,
    std::string & errorResponseOut ) [inline]
```

Connect to TCP server on hostname:port.

If hostname == "localhost" and port == 0 then a port scan on ports 7100 to 7109 is done. In case of an error the socket is closed.

### 8.9.2.3 connectSocketFd()

```
void iris::IrisClient::connectSocketFd (
    SocketFd socketfd,
    unsigned timeoutInMs = 1000 ) [inline]
```

Connect using an existing socketFd. All errors are reported by exceptions. In case of an error the socket is closed.

### 8.9.2.4 disconnect()

```
IrisErrorCode iris::IrisClient::disconnect ( ) [inline]
```

Disconnect from server. Close socket. (Only for mode IRIS\_TCP\_CLIENT.)

### 8.9.2.5 disconnectAndWaitForChildToExit()

```
bool iris::IrisClient::disconnectAndWaitForChildToExit (
    double timeoutInMs = 5000,
    double timeoutInMsAfterSigInt = 5000,
    double timeoutInMsAfterSigKill = 5000 ) [inline]
```

Disconnect and wait for child process (previously spawned with [spawnAndConnect\(\)](#)) to exit. If no model was spawned this is silently ignored.

Wait at most timeoutInMs until the child exits. If the child did not exit by then, send a SIGINT and wait for timeoutInMsAfterSigInt until the child exits. If the child did not exit by then, send a SIGKILL and wait for timeoutInMsAfterSigKill until the child exits. If the child did not exit by then, an E\_not\_connected exception is thrown. If timeoutInMs is 0, do not wait and continue with SIGINT. If timeoutAfterSigInt is 0, do not issue a SIGINT and continue with SIGKILL. If timeoutAfterSigKill is 0, do not issue a SIGKILL and throw an E\_not\_connected exception. If any of the timeouts is < 0, wait indefinitely.

Return true if the child exited, else false.

### 8.9.2.6 getIrisInstance()

```
IrisInstance & iris::IrisClient::getIrisInstance ( ) [inline]
```

Get contained [IrisInstance](#). This can be used as a generic client instance to call Iris functions.

### 8.9.2.7 initServiceServer()

```
void iris::IrisClient::initServiceServer (
    impl::IrisTcpSocket * socket_ ) [inline]
```

Initialize as an IrisService server, only used in IRIS\_SERVICE\_SERVER mode. This function will store pointer to IrisTcpSocket created by IrisService and initialize adapter as a server. -socket\_ pointer to IrisTcpSocket created by IrisService when receiving new connection. (TODO safer memory management of this object) -return Nothing.

### 8.9.2.8 loadPlugin()

```
void iris::IrisClient::loadPlugin (
    const std::string & plugin_name ) [inline]
```

Load Plugin function, only used in IRIS\_SERVICE\_SERVER mode Only one plugin can be loaded at a time

### 8.9.2.9 processEvents()

```
virtual void iris::IrisClient::processEvents ( ) [inline], [override], [virtual]
```

Client main processing function.

- Check for incoming requests/responses and process them .
- Check for pending outgoing requests/responses and process them. This function is ideal for integrating the client into other processing environments in one of the following ways: (1) Thread-less: Requests are only executed from within [processEvents\(\)](#).
- pro: Iris request and responses are always synchronized with the rest of the code of the client. No explicit synchronization (mutexes etc.) necessary.

- con: No blocking Iris requests can be called from within received synchronous callbacks. (2) Asynchronous (handleRequestAsynchronously = true): Requests are executed in another thread
- pro: Blocking Iris requests can be called from within received synchronous callbacks transparently.
- con: Received Iris requests are called on another thread and they require explicit synchronization to be synchronized with the rest of the code of the client. It is harmless to call this function when there is nothing to do.

#### 8.9.2.10 setInstanceName()

```
void iris::IrisClient::setInstanceName (
    const std::string & instName ) [inline]
```

Set instance name of the contained Iris instance returned by getIrisInstance. This must be called before [connect\(\)](#).

#### 8.9.2.11 setSleepOnDestructionMs()

```
void iris::IrisClient::setSleepOnDestructionMs (
    uint64_t sleepOnDestructionMs_ ) [inline]
```

Sleep a short time on destruction to de-interleave output by different processes. This has not functional impact or purpose. It just beautifies the output on stdout.

#### 8.9.2.12 spawnAndConnect()

```
void iris::IrisClient::spawnAndConnect (
    const std::vector< std::string > & modelCommandLine,
    const std::string & additionalServerArgs = std::string(),
    const std::string & additionalClientArgs = std::string() ) [inline]
```

Spawn model and connect to it. All errors are reported via exceptions. additionalServerArgs are added to the models -iris-connect argument and ultimately passed to IrisTcpServer::startServer(), for example "verbose=1" to enable verbose messages. additionalClientArgs are added to the argument passed to [IrisClient::connect\(\)](#), for example "verbose=1,timeout=2000" to enable verbose messages and a 2 second timeout.

#### 8.9.2.13 stopWaitForEvent()

```
virtual void iris::IrisClient::stopWaitForEvent ( ) [inline], [override], [virtual]
```

Stop waiting in [waitForEvent\(\)](#). Return from [waitForEvent\(\)](#) as soon as possible even without a socket event.

#### 8.9.2.14 waitForEvent()

```
virtual void iris::IrisClient::waitForEvent ( ) [inline], [override], [virtual]
```

Wait for any event which would cause [processEvents\(\)](#) to do some work. This function intentionally blocks until there is something useful to do. This function can be interrupted by calling [stopWaitForEvent\(\)](#).

#### 8.9.2.15 waitpidWithTimeout()

```
bool iris::IrisClient::waitpidWithTimeout (
    pid_t pid,
    int * status,
    int options,
    double timeoutInMs ) [inline]
```

waitpid() with timeout. Throw exceptions on errors. Return true if the child exited within the timeout, else false.

### 8.9.3 Member Data Documentation

### 8.9.3.1 connectionHelpStr

```
const std::string iris::IrisClient::connectionHelpStr
```

**Initial value:**

```
=
    "Supported connection types:\n"
    "tcp[=HOST][,port=PORT][,timeout=T]\n"
    "    Connect to an Iris TCP server on HOST:PORT.\n"
    "    The default for HOST is 'localhost' and the default for PORT is 0 if HOST is 'localhost' and 7100
    otherwise. If PORT is 0 then a port scan on ports 7100 to 7109 is done.\n"
    "    T is the connection timeout in ms (defaults to 100 if PORT==0, else 1000).\n"
    "\n"
    "socketfd=FD[,timeout=T]\n"
    "    Use socket file descriptor FD as an established UNIX domain socket connection.\n"
    "    T is the timeout for the Iris handshake in ms.\n"
    "\n"
    "General parameters:\n"
    "    verbose=N: Increase verbose level of IrisClient to level N (0..3).\n"
```

Connection help string.

The documentation for this class was generated from the following file:

- [IrisClient.h](#)

## 8.10 iris::IrisCommandLineParser Class Reference

```
#include <IrisCommandLineParser.h>
```

### Classes

- struct [Option](#)  
*Option container.*

### Public Member Functions

- [Option](#) & [addOption](#) (char shortOption, const std::string &longOption, const std::string &help, const std::string &formalArgumentName=std::string(), const std::string &defaultValue=std::string())
- void [clear](#) ()
- double [getDbI](#) (const std::string &longOption) const
- std::string [getHelpMessage](#) () const
- int64\_t [getIntI](#) (const std::string &longOption) const
- std::vector< std::string > [getList](#) (const std::string &longOption) const  
*Get list of elements of a list option.*
- std::map< std::string, std::string > [getMap](#) (const std::string &longOption) const
- const std::vector< std::string > & [getNonOptionArguments](#) () const  
*Get non-option arguments.*
- std::string [getStr](#) (const std::string &longOption) const  
*Get string value.*
- uint64\_t [getSwitch](#) (const std::string &longOption) const  
*Check how many times an option switch (an option without an argument) was specified.*
- uint64\_t [getUInt](#) (const std::string &longOption) const
- [IrisCommandLineParser](#) (const std::string &programName\_, const std::string &usageHeader\_, const std::string &versionStr\_)  
*Constructor.*
- bool [isSpecified](#) (const std::string &longOption) const
- void [noNonOptionArguments](#) ()
- bool [operator\(\)](#) (const std::string &longOption) const  
*Check whether an option was specified.*
- int [parseCommandLine](#) (int argc, char \*\*argv)
- int [parseCommandLine](#) (int argc, const char \*\*argv)

- void [pleaseSpecifyOneOf](#) (const std::vector< std::string > &options, const std::vector< std::string > &formalNonOptionArguments=std::vector< std::string >())
- int [printError](#) (const std::string &message) const  
*Print error message (and do not exit).*
- int [printErrorAndExit](#) (const IrisErrorException &e) const
- int [printErrorAndExit](#) (const std::exception &e) const
- int [printErrorAndExit](#) (const std::string &message) const
- int [printMessage](#) (const std::string &message, int error=0, bool exit=false) const
- void [setMessageFunc](#) (const std::function< int(const std::string &message, int error, bool exit)> &messageFunc)
- void [setProgramName](#) (const std::string &programName\_, bool append=false)  
*Set/override program name.*
- void [setValue](#) (const std::string &longOption, const std::string &value, bool append=false)
- void [unsetValue](#) (const std::string &longOption)

## Static Public Member Functions

- static int [defaultMessageFunc](#) (const std::string &message, int error, bool exit)

### 8.10.1 Detailed Description

Generic command line parser.

This covers roughly all features supported by GNU getopt\_long() and provides -h/--help and --version.

Usage:

1. Declare options by calling [addOption\(\)](#) for each option.
2. Parse command line by calling [parseCommandLine\(\)](#).
3. Retrieve command line option values by calling the get...() functions.

Example:

### 8.10.2 Member Function Documentation

#### 8.10.2.1 addOption()

```
Option & iris::IrisCommandLineParser::addOption (
    char shortOption,
    const std::string & longOption,
    const std::string & help,
    const std::string & formalArgumentName = std::string(),
    const std::string & defaultValue = std::string() )
```

Add command line option. shortOption: Single character or 0 if no short option. longOption: Long option (mandatory, must be unique and non-empty). help: Description for --help. formalArgumentName: Empty means: This option has no argument (switch). Nonempty means: This option has an argument and this is named 'formalArgumentName' in the --help message. defaultValue: Default value of this option when not specified on the command line. When defaultValue is not specified: By default [getSwitch\(\)](#), [getInt\(\)](#) and [GetInt\(\)](#) return 0 and [getStr\(\)](#) returns an empty string.

#### 8.10.2.2 clear()

```
void iris::IrisCommandLineParser::clear ( )
```

Clear all values parsed by a previous parseCommandLine call. All options will be reset to their default values. All option definitions ([addOption\(\)](#)) will be preserved.



### 8.10.2.3 defaultMessageFunc()

```
static int iris::IrisCommandLineParser::defaultMessageFunc (
    const std::string & message,
    int error,
    bool exit ) [static]
```

Default message function. The default message function prints message on stdout and exits with "error" status if `exit==true`, else it returns error status.

### 8.10.2.4 getDb1()

```
double iris::IrisCommandLineParser::getDb1 (
    const std::string & longOption ) const
```

Get double value. (This will print an error and exit when there is a parse error.)

### 8.10.2.5 getHelpMessage()

```
std::string iris::IrisCommandLineParser::getHelpMessage ( ) const
```

Get help message. (`parserCommandLine()` automatically prints this on `-help` so there is usually no need to call this function.)

### 8.10.2.6 getInt()

```
int64_t iris::IrisCommandLineParser::getInt (
    const std::string & longOption ) const
```

Get integer value. (This will print an error and exit when there is a parse error.)

### 8.10.2.7 getMap()

```
std::map< std::string, std::string > iris::IrisCommandLineParser::getMap (
    const std::string & longOption ) const
```

Get NAME->VALUE map of elements of a list option. The elements are assumed to have the format "NAME=<VALUE" or "NAME". If "=VALUE" is missing then VALUE is the empty string.

### 8.10.2.8 getUInt()

```
uint64_t iris::IrisCommandLineParser::getUInt (
    const std::string & longOption ) const
```

Get unsigned integer value. (This will print an error and exit when there is a parse error.)

### 8.10.2.9 isSpecified()

```
bool iris::IrisCommandLineParser::isSpecified (
    const std::string & longOption ) const
```

Return true iff option is specified explicitly on the command line. (This can be used to detect whether an option was present on the command line even if it was just set to its default value.)

### 8.10.2.10 noNonOptionArguments()

```
void iris::IrisCommandLineParser::noNonOptionArguments ( )
```

Print an error for each non-option argument and exit if any non-option arguments are present. Call this after [parseCommandLine\(\)](#) for programs which do not support any non-option arguments as these are otherwise silently ignored.

### 8.10.2.11 parseCommandLine()

```
int iris::IrisCommandLineParser::parseCommandLine (
    int argc,
    const char ** argv )
```

Parse command line. After calling this function the named argument values can be retrieved by the `get...()` functions. All arguments after the first occurrence of a `--` argument are treated as non-option arguments. Also handles `-help` and `-version` and `exit()`s when these are specified.

`argv[0]` is ignored. The program name is passed in the constructor argument.

Calling `parseCommandLine()` again will add and/or override options as if they were in a single command line.

Return value: By default `parseCommandLine()` exits (and so does not return) when it detects an error or when `-help` or `-version` was specified, so the return value can safely (and should) be ignored.

When the exit behavior is overridden by calling `setMessageFunc()` with a non-exiting function, then `parseCommandLine()` returns the return value of the message function or 0 when the message function was not called (no error and no `-help/-version`).

Note that parse errors in integers or doubles are only identified by the respective `get*()` functions.

#### 8.10.2.12 pleaseSpecifyOneOf()

```
void iris::IrisCommandLineParser::pleaseSpecifyOneOf (
    const std::vector< std::string > & options,
    const std::vector< std::string > & formalNonOptionArguments = std::vector< std::string >() )
```

Check whether at least one of the options or non-option-arguments are specified and exit with an error message if not. Call this for programs which require at least one of these options or arguments to be set. If `formalNonOptionArguments` is empty only options are checked.

#### 8.10.2.13 printErrorAndExit() [1/3]

```
int iris::IrisCommandLineParser::printErrorAndExit (
    const IrisErrorException & e ) const [inline]
```

Print error message and exit. Note that custom message functions may decide not to exit even on errors. In this case `parseCommandLine()` returns the return value of the message function.

#### 8.10.2.14 printErrorAndExit() [2/3]

```
int iris::IrisCommandLineParser::printErrorAndExit (
    const std::exception & e ) const
```

Print error message and exit. Note that custom message functions may decide not to exit even on errors. In this case `parseCommandLine()` returns the return value of the message function.

#### 8.10.2.15 printErrorAndExit() [3/3]

```
int iris::IrisCommandLineParser::printErrorAndExit (
    const std::string & message ) const
```

Print error message and exit. Note that custom message functions may decide not to exit even on errors. In this case `parseCommandLine()` returns the return value of the message function.

#### 8.10.2.16 printMessage()

```
int iris::IrisCommandLineParser::printMessage (
    const std::string & message,
    int error = 0,
    bool exit = false ) const
```

Print message. This can be used by additional checks on the arguments to print warnings. This calls the message function set by `setMessageFunc()` or the `defaultMessageFunc()`.

#### 8.10.2.17 setMessageFunc()

```
void iris::IrisCommandLineParser::setMessageFunc (
    const std::function< int(const std::string &message, int error, bool exit)> &
    messageFunc )
```

Set custom message function which prints errors (`error!=0`), `-help` and `-version` messages (`error==0`) and which potentially also `exit()`s (`exit==true`).

The default message function prints message on stdout and exits with "error" status if `exit==true`, else it returns error status.

Custom message functions may either exit, or they may return a value which is then returned by `parserCommandLine()` for errors raised by `parseCommandLine()`. For errors in the `get*()` functions the return value is ignored.

### 8.10.2.18 setValue()

```
void iris::IrisCommandLineParser::setValue (
    const std::string & longOption,
    const std::string & value,
    bool append = false )
```

Set/override command line option. By default overwrite the entire list for list options. Set `append=true` for list options to append to list.

### 8.10.2.19 unsetValue()

```
void iris::IrisCommandLineParser::unsetValue (
    const std::string & longOption )
```

Unset command line option. Set value to default value and mark as not specified.

The documentation for this class was generated from the following file:

- [IrisCommandLineParser.h](#)

## 8.11 iris::IrisEventEmitter< ARGS > Class Template Reference

A helper class for generating Iris events.

```
#include <IrisEventEmitter.h>
```

Inherits `IrisEventEmitterBase`.

### Public Member Functions

- `IrisEventEmitter ()`  
*Construct an event emitter.*
- `void operator() (ARGS... args)`  
*Emit an event.*

#### 8.11.1 Detailed Description

```
template<typename... ARGS>
class iris::IrisEventEmitter< ARGS >
```

A helper class for generating Iris events.

#### Template Parameters

<i>ARGS</i>	Argument types corresponding to the fields in this event.
-------------	---

Use [IrisEventEmitter](#) with [IrisInstanceBuilder](#) to add events to your Iris instance:

```
// Declare an event emitter
iris::IrisEventEmitter<uint64_t, bool> my_event;
// Add it to an Iris instance
iris::IrisInstance my_instance(...);
my_instance->getBuilder()->addEventSource("MY_EVENT", my_event)
    .addField("FOO", "uint", 8, "A value")
    .addField("FLAG", "bool", 1, "A flag");
// Emit an event
my_event(0x1234, true);
```

## 8.11.2 Member Function Documentation

### 8.11.2.1 operator()

```
template<typename...  ARGS>
void iris::IrisEventEmitter< ARGS >::operator() (
    ARGS...  args ) [inline]
```

Emit an event.

The arguments to this function are the fields of the event source, in the same order that they appear in the template arguments to the [IrisEventEmitter](#) class.

The documentation for this class was generated from the following file:

- [IrisEventEmitter.h](#)

## 8.12 iris::IrisEventRegistry Class Reference

Class to register Iris event streams for an event.

```
#include <IrisInstanceEvent.h>
```

### Public Types

- typedef std::set< [EventStream](#) \* >::const\_iterator **iterator**

### Public Member Functions

- template<class T >  
void [addField](#) (const IrisU64StringConstant &field, const T &value) const  
*Add a field value.*
- template<class T >  
void [addFieldSlow](#) (const std::string &field, const T &value) const  
*Add a field value.*
- iterator [begin](#) () const  
*Get an iterator to the beginning of the event stream set.*
- void [emitEventBegin](#) (uint64\_t time, uint64\_t pc=IRIS\_UINT64\_MAX) const
- void [emitEventEnd](#) () const  
*Emit the callback.*
- bool [empty](#) () const  
*Return true if no event streams are registered.*
- iterator [end](#) () const  
*Get an iterator to the end of the event stream set.*
- template<class T , typename F >  
void [forEach](#) (F &&func) const  
*Call a function for each event stream.*
- bool [registerEventStream](#) ([EventStream](#) \*evStream)  
*Register an event stream.*
- bool [unregisterEventStream](#) ([EventStream](#) \*evStream)  
*Unregister an event stream.*

### 8.12.1 Detailed Description

Class to register Iris event streams for an event.

## 8.12.2 Member Function Documentation

### 8.12.2.1 addField()

```
template<class T >
void iris::IrisEventRegistry::addField (
    const IrisU64StringConstant & field,
    const T & value ) const [inline]
```

Add a field value.

This is supported for all types supported by IrisU64JsonWriter and IrisObjects.h. Fast variant for argument names up to 23 chars. Use this if you can.

#### Template Parameters

<i>T</i>	The type of <i>value</i> .
----------	----------------------------

#### Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

### 8.12.2.2 addFieldSlow()

```
template<class T >
void iris::IrisEventRegistry::addFieldSlow (
    const std::string & field,
    const T & value ) const [inline]
```

Add a field value.

This is supported for all types supported by IrisU64JsonWriter and IrisObjects.h. Slow variant for argument names with more than 23 chars. Do not use unless you have to.

#### Template Parameters

<i>T</i>	The type of <i>value</i> .
----------	----------------------------

#### Parameters

<i>field</i>	The name of the field whose value is set.
<i>value</i>	The value of the field.

### 8.12.2.3 begin()

```
iterator iris::IrisEventRegistry::begin ( ) const [inline]
```

Get an iterator to the beginning of the event stream set.

See also

[end](#)

**Returns**

An iterator to the beginning of the event stream set.

**8.12.2.4 emitEventEnd()**

```
void iris::IrisEventRegistry::emitEventEnd ( ) const
```

Emit the callback.

This also checks the ranges and maintains the counter.

**8.12.2.5 empty()**

```
bool iris::IrisEventRegistry::empty ( ) const [inline]
```

Return true if no event streams are registered.

**Returns**

true if no event streams are registered.

**8.12.2.6 end()**

```
iterator iris::IrisEventRegistry::end ( ) const [inline]
```

Get an iterator to the end of the event stream set.

**See also**

[begin](#)

**Returns**

An iterator to the end of the event stream set.

**8.12.2.7 forEach()**

```
template<class T , typename F >
void iris::IrisEventRegistry::forEach (
    F && func ) const [inline]
```

Call a function for each event stream.

This function can be used as an alternative to [addField\(\)](#)/[addFieldSlow\(\)](#), when each event stream needs to be handled individually, for example because the event stream has options or because only selected fields should be emitted.

The main use-case of this function is to emit the fields of all event streams.

Example of an event source which optionally allows inverting its data: `class MyEventStream : public iris::IrisEventStream {...} IrisEventRegistry evreg;` In the callback set with (`IrisInstanceBuilder.addSource().`) `set< EventStreamCreateDelegate()` create a new event stream with `new MyEventStream(evreg);`

`// Emit event. evreg.emitEventBegin(time, pc); // Start building the callback data. evreg.forEach<MyEventStream>([&](MyEventStream& es) { es.addField(ISTR("DATA"), es.invert ? ~data : data); }); evreg.emitEventEnd();`  
`// Emit the callback.`

**Template Parameters**

<i>T</i>	Class derived from <a href="#">IrisEventStream</a> .
<i>F</i>	Function to be called for each event stream (usually a lambda function).

### 8.12.2.8 registerEventStream()

```
bool iris::IrisEventRegistry::registerEventStream (
    EventStream * evStream )
```

Register an event stream.

#### Parameters

<i>evStream</i>	The stream to be registered.
-----------------	------------------------------

#### Returns

`true` if the stream was registered successfully.

### 8.12.2.9 unregisterEventStream()

```
bool iris::IrisEventRegistry::unregisterEventStream (
    EventStream * evStream )
```

Unregister an event stream.

#### Parameters

<i>evStream</i>	The stream to be unregistered.
-----------------	--------------------------------

#### Returns

`true` if the stream was unregistered successfully.

The documentation for this class was generated from the following file:

- [IrisInstanceEvent.h](#)

## 8.13 iris::IrisEventStream Class Reference

Event stream class for Iris-specific events.

#include <IrisInstanceEvent.h>

Inherits [iris::EventStream](#).

### Public Member Functions

- virtual IrisErrorCode [disable](#) () IRIS\_OVERRIDE  
*Disable this event stream.*
- virtual IrisErrorCode [enable](#) () IRIS\_OVERRIDE  
*Enable this event stream.*
- [IrisEventStream](#) ([IrisEventRegistry](#) \*registry\_)

### Additional Inherited Members

#### 8.13.1 Detailed Description

Event stream class for Iris-specific events.

#### 8.13.2 Member Function Documentation

### 8.13.2.1 disable()

```
virtual IrisErrorCode iris::IrisEventStream::disable ( ) [virtual]
```

Disable this event stream.

This function is only called when [isEnabled\(\)](#)/enabled == true. It is not necessary to verify this inside the [disable\(\)](#) method.

#### Returns

An error code indicating whether the event stream was successfully disabled. This should be E\_ok if it was disabled or E\_error\_disabling\_event\_stream if it could not be disabled.

Implements [iris::EventStream](#).

### 8.13.2.2 enable()

```
virtual IrisErrorCode iris::IrisEventStream::enable ( ) [virtual]
```

Enable this event stream.

This function is only called when [isEnabled\(\)](#)/enabled == false. It is not necessary to verify this inside the [enable\(\)](#) method.

#### Returns

An error code indicating whether the event stream was successfully enabled. This should be E\_ok if it was enabled or E\_error\_enabling\_event\_stream if it could not be enabled.

Implements [iris::EventStream](#).

The documentation for this class was generated from the following file:

- [IrisInstanceEvent.h](#)

## 8.14 iris::IrisGlobalInstance Class Reference

Inherits [IrisInterface](#), and [IrisConnectionInterface](#).

### Public Member Functions

- [IrisInstance](#) & [getIrisInstance](#) ()
- virtual [IrisInterface](#) \* [getIrisInterface](#) () override  
*Get the IrisInterface for this connection.*
- [IrisGlobalInstance](#) ()  
*Constructor.*
- virtual void [irisHandleMessage](#) (const uint64\_t \*message) override  
*Handle incoming Iris messages.*
- virtual [IrisErrorCode](#) [processAsyncMessages](#) (bool waitForAMessage) override
- uint64\_t [registerChannel](#) ([IrisC\\_CommunicationChannel](#) \*channel, const std::string &connection\_info="")
- virtual uint64\_t [registerIrisInterfaceChannel](#) ([IrisInterface](#) \*iris\_interface) override
- virtual void [setIrisProxyInterface](#) ([IrisProxyInterface](#) \*irisProxyInterface\_) override  
*Set proxy interface.*
- void [setLogLevel](#) (unsigned level)
- void [unregisterChannel](#) (uint64\_t channelId)  
*Unregister a channel.*
- virtual void [unregisterIrisInterfaceChannel](#) (uint64\_t channelId) override
- ~[IrisGlobalInstance](#) ()  
*Destructor.*

### 8.14.1 Member Function Documentation



### 8.14.1.1 `getIrisInstance()`

`IrisInstance` & `iris::IrisGlobalInstance::getIrisInstance ( ) [inline]`

Get contained `IrisInstance`. This can be used as a generic client instance to call Iris functions.

### 8.14.1.2 `registerChannel()`

```
uint64_t iris::IrisGlobalInstance::registerChannel (
    IrisC_CommunicationChannel * channel,
    const std::string & connection_info = "" )
```

Register a channel. Returns an associated channel id.

### 8.14.1.3 `registerIrisInterfaceChannel()`

```
virtual uint64_t iris::IrisGlobalInstance::registerIrisInterfaceChannel (
    IrisInterface * iris_interface ) [override], [virtual]
```

Register a local `IrisInterface` with the system. This allows it to receive messages (requests and responses). Returns the unique `channelId` used to identify this channel when registering instances.

### 8.14.1.4 `unregisterIrisInterfaceChannel()`

```
virtual void iris::IrisGlobalInstance::unregisterIrisInterfaceChannel (
    uint64_t channelId ) [inline], [override], [virtual]
```

Unregister a previously registered channel. This will automatically unregister all instances associated with that channel.

The documentation for this class was generated from the following file:

- [IrisGlobalInstance.h](#)

## 8.15 `iris::IrisInstance` Class Reference

### Public Types

- using `EventCallbackFunction` = `std::function< IrisErrorCode(EventStreamId, const IrisValueMap &, uint64_t, InstanceId, bool, std::string &)>`

### Public Member Functions

- void `addCallback_IRIS_INSTANCE_REGISTRY_CHANGED` (`EventCallbackFunction` f)
- void `clearCachedMetaInfo` ()  
*Clear cached meta-information including the list of InstanceInfos for all instances in the system.*
- void `disableEvent` (const std::string &eventSpec)  
*Disable all matching event callback(s).*
- void `enableEvent` (const std::string &eventSpec, std::function< void()> callback)  
*Enable event callback(s).*
- void `enableEvent` (const std::string &eventSpec, std::function< void(const EventStreamInfo &eventStreamInfo, IrisReceivedRequest &request)> callback)  
*Enable event callback(s).*
- std::vector< EventSourceInfo > `findEventSources` (const std::string &instancePathFilter="all")  
*Find all event sources in the system.*
- std::vector< EventStreamInfo > `findEventSourcesAndFields` (const std::string &spec, InstanceId defaultInstId=IRIS\_UINT64\_MAX)  
*Find specific event sources in the system.*
- void `findEventSourcesAndFields` (const std::string &spec, std::vector< EventStreamInfo > &eventStreamInfosOut, InstanceId defaultInstId=IRIS\_UINT64\_MAX)
- std::vector< InstanceInfo > `findInstanceInfos` (const std::string &instancePathFilter="all")  
*Find instance infos of all instances in the system.*

- [IrisInstanceBuilder](#) \* [getBuilder](#) ()  
*Get the [IrisInstanceBuilder](#) object for this instance. This can be used to set up metadata and callbacks for standard Iris functions.*
- InstanceId [getInstanceId](#) (const std::string &instName)  
*Get instance id for a specifid instance name.*
- InstanceInfo [getInstanceInfo](#) (const std::string &instancePathFilter)  
*Get instance info of a specific instance in the system.*
- const InstanceInfo & [getInstanceInfo](#) (InstanceId instId)  
*Get InstanceInfo including properties for a specific instId.*
- const std::vector< InstanceInfo > & [getInstanceList](#) ()  
*Get list of InstanceInfos of all instances in the system, including properties.*
- const std::string & [getInstanceName](#) () const  
*Get the instance name of this instance. This is valid after [registerInstance\(\)](#) returns.*
- std::string [getInstanceName](#) (InstanceId instId)  
*Get instance name for a specifid instId.*
- InstanceId [getInstId](#) () const  
*Get the instance id of this instance. This is valid after [registerInstance\(\)](#) returns.*
- IrisInterface \* [getLocalIrisInterface](#) ()  
*Get the local IrisInterface of this instance. This is the interface that other instances use to send their requests and responses to this instance.*
- MemorySpaceId [getMemorySpaceId](#) (InstanceId instId, const std::string &name)  
*Get memory space id of memory space by name.*
- MemorySpaceId [getMemorySpaceId](#) (InstanceId instId, uint64\_t canonicalMsn)  
*Get memory space id of memory space identified by its canonical memory space number (e.g. CanonicalMsnArm\_\* constant).*
- const MemorySpaceInfo & [getMemorySpaceInfo](#) (InstanceId instId, const std::string &name)  
*Get MemorySpaceInfo of memory space by name.*
- const MemorySpaceInfo & [getMemorySpaceInfo](#) (InstanceId instId, uint64\_t canonicalMsn)  
*Get MemorySpaceInfo of memory space identified by its canonical memory space number (e.g. CanonicalMsnArm\_\* constant).*
- const std::vector< MemorySpaceInfo > & [getMemorySpaceInfos](#) (InstanceId instId)  
*Get list of MemorySpaceInfos.*
- const PropertyMap & [getPropertyMap](#) () const  
*Get property map.*
- IrisInterface \* [getRemoteIrisInterface](#) ()  
*Get the remote Iris interface.*
- const std::vector< ResourceGroupInfo > & [getResourceGroups](#) (InstanceId instId)  
*Get list of resource groups.*
- ResourceId [getResourceId](#) (InstanceId instId, const std::string &resourceSpec)  
*Get resource id for a specific resource.*
- const ResourceInfo & [getResourceInfo](#) (InstanceId instId, const std::string &resourceSpec)  
*Get ResourceInfo for a specific resource.*
- const ResourceInfo & [getResourceInfo](#) (InstanceId instId, ResourceId resourceId)  
*Get ResourceInfo for a specific resource.*
- const std::vector< ResourceInfo > & [getResourceInfos](#) (InstanceId instId)  
*Get list of resource infos.*
- IrisCppAdapter & [irisCall](#) ()  
*Get an IrisCppAdapter to call an Iris function of any other instance.*
- IrisCppAdapter & [irisCallNoThrow](#) ()  
*Get an IrisCppAdapter to call an Iris function of any other instance.*
- IrisCppAdapter & [irisCallThrow](#) ()

Get an `IrisCppAdapter` to call an `Iris` function of any other instance. When an `Iris` function returns an error response, this adapter always throws an exception. Usage:

- `IrisInstance` (`IrisConnectionInterface` \*connection\_interface=nullptr, const std::string &instName=std::string(), uint64\_t flags=DEFAULT\_FLAGS)

Construct a new `Iris` instance.

- `IrisInstance` (`IrisInstantiationContext` \*context)

Construct a new `Iris` instance using an `IrisInstantiationContext`.

- bool `isAdapterInitialized` () const
- bool `isRegistered` () const
- bool `isValidEvBufId` (EventBufferId evBufId) const

Check whether event buffer id is valid.

- void `notifyStateChanged` ()

Notify client instances that the state of any resource/memory/table/disassembly etc changed.

- void `processAsyncRequests` ()

Process async requests. Use this to keep the `Iris` system running while a thread is blocked waiting for something.

- template<class T >

void `publishCppInterface` (const std::string &interfaceName, T \*pointer, const std::string &jsonDescription)

Publish a C++ interface XYZ through a new instance `_getCppInterfaceXYZ()` function.

- void `registerEventBufferCallback` (EventBufferCallbackDelegate delegate, const std::string &name, const std::string &description, const std::string &dlgInstanceTypeStr)

Register an event buffer callback using an `EventBufferCallbackDelegate`.

- template<typename T, IrisErrorCode(T::\*)(const EventBufferCallbackData &data) METHOD>

void `registerEventBufferCallback` (T \*instance, const std::string &name, const std::string &description, const std::string &dlgInstanceTypeStr)

Register an event buffer callback using an `EventBufferCallbackDelegate`.

- template<class T >

void `registerEventBufferCallback` (T \*instance, const std::string &name, const std::string &description, void(T::\*memberFunctionPtr)(IrisReceivedRequest &), const std::string &instanceTypeStr)

Register an event buffer callback function.

- void `registerEventCallback` (EventCallbackDelegate delegate, const std::string &name, const std::string &description, const std::string &dlgInstanceTypeStr)

Register a general event callback using an `EventCallbackDelegate`.

- template<typename T, IrisErrorCode(T::\*)(uint64\_t, const AttributeValueMap &, uint64\_t, uint64\_t, bool, std::string &) METHOD>

void `registerEventCallback` (T \*instance, const std::string &name, const std::string &description, const std::string &dlgInstanceTypeStr)

Register a general event callback using an `EventCallbackDelegate`.

- template<class T >

void `registerEventCallback` (T \*instance, const std::string &name, const std::string &description, void(T::\*memberFunctionPtr)(IrisReceivedRequest &), const std::string &instanceTypeStr)

Register a general event callback.

- template<class T >

void `registerFunction` (T \*instance, const std::string &name, void(T::\*memberFunctionPtr)(IrisReceivedRequest &), const std::string &functionInfoJson, const std::string &instanceTypeStr)

Register an `Iris` function implementation.

- IrisErrorCode `registerInstance` (const std::string &instName, uint64\_t flags=DEFAULT\_FLAGS)

Register this instance if it was not registered when constructed.

- uint64\_t `resourceRead` (InstanceId instId, const std::string &resourceSpec)

Read numeric resource and return its value.

- uint64\_t `resourceReadCrn` (InstanceId instId, uint64\_t canonicalRegisterNumber)

Read numeric resource and return its value (using the canonical register number aka DWARF register id).

- std::string `resourceReadStr` (InstanceId instId, const std::string &resourceSpec)

Read string resource, or read other resources as string.

- void `resourceWrite` (InstanceId instId, const std::string &resourceSpec, uint64\_t value)

- Write numeric resource.*

  - void [resourceWriteCrn](#) (Instanceld instId, uint64\_t canonicalRegisterNumber, uint64\_t value)

*Write numeric resource by canonical register number (aka DWARF register id).*
- void [resourceWriteStr](#) (Instanceld instId, const std::string &resourceSpec, const std::string &value)

*Write string resource, or write numeric resource from string.*
- bool [sendRequest](#) (IrisRequest &req)

*Send an Iris request or notification and potentially wait for a response.*
- void [sendResponse](#) (const uint64\_t \*response)

*Send a response to the remote Iris interface.*
- void [setAdapterInitialized](#) ()
- void [setCallback\\_IRIS\\_SHUTDOWN\\_LEAVE](#) (EventCallbackFunction f)
- void [setCallback\\_IRIS\\_SIMULATION\\_TIME\\_EVENT](#) (EventCallbackFunction f)
- void [setConnectionInterface](#) (IrisConnectionInterface \*connection\_interface)

*Set the remote connection interface.*
- void [setEventHandler](#) (IrisInstanceEvent \*handler)

*Set the event handler.*
- void [setInstId](#) (Instanceld instId)

*Internal function. Do not call. Set the instance id of this instance. The instId is automatically set after calling [instanceRegistry\\_registerInstance\(\)](#).*
- void [setPendingSyncStepResponse](#) (RequestId requestId, EventBufferId evBufId)

*Set pending response to a [step\\_syncStep\(\)](#) call.*
- template<class T >
  - void [setProperty](#) (const std::string &propertyName, const T &propertyValue)

*Set/add instance property.*
- void [setThrowOnError](#) (bool throw\_on\_error)

*Set default error behavior for [irisCall\(\)](#).*
- void [simulationTimeDisableEvents](#) ()

*Disable the internal reception of IRIS\_SIMULATION\_TIME\_EVENT events for performance reasons (e.g. during synchronous stepping).*
- bool [simulationTimeIsRunning](#) ()

*Return true iff simulation is currently running.*
- void [simulationTimeRun](#) ()

*Run simulation time and wait until simulation time started running.*
- void [simulationTimeRunUntilStop](#) (double timeoutInSeconds=0.0)

*Run simulation time and wait until simulation time stopped again or until timeout expired.*
- void [simulationTimeStop](#) ()

*Stop simulation time and wait until simulation time stopped.*
- bool [simulationTimeWaitForStop](#) (double timeoutInSeconds=0.0)

*Wait for simulation time to stop or timeout.*
- void [unpublishCpplInterface](#) (const std::string &interfaceName)

*Unpublish a previously published C++ interface.*
- void [unregisterEventBufferCallback](#) (const std::string &name)

*Unregister the named event buffer callback function.*
- void [unregisterEventCallback](#) (const std::string &name)

*Unregister the named event callback function.*
- void [unregisterFunction](#) (const std::string &name)

*Unregister a function that was previously registered with [registerFunction\(\)](#) or [irisRegisterFunction\(\)](#).*
- IrisErrorCode [unregisterInstance](#) ()

*Unregister this instance.*
- ~[IrisInstance](#) ()

*Destructor.*

## Static Public Attributes

- static const uint64\_t **DEFAULT\_FLAGS** = [THROW\\_ON\\_ERROR](#)  
*Default flags used if not otherwise specified.*
- static const uint64\_t **THROW\_ON\_ERROR** = (1 << 1)  
*Throw an exception when an Iris call returns an error response.*
- static const uint64\_t **UNQUIFY** = (1 << 0)  
*Uniquify instance name when registering.*

## Protected Attributes

- InstanceInfo **thisInstanceInfo** {}  
*InstanceInfo of this instance.*

## 8.15.1 Member Typedef Documentation

### 8.15.1.1 EventCallbackFunction

```
using iris::IrisInstance::EventCallbackFunction = std::function<IrisErrorCode(EventStreamId,
const IrisValueMap&, uint64_t, InstanceId, bool, std::string&)>
```

Event callback function type.

(Each [IrisInstance](#) can implicitly register two events which are used internally (IRIS\_SIMULATION\_TIME\_EVENT and IRIS\_SHUTDOWN\_LEAVE). Using the functions below clients can make use of these events without going through the effort of calling [irisRegisterEventCallback\(\)](#)/registerEventCallback(), event\_getEventSource() and eventStream\_create(), and it also reduces the number of callbacks being called at runtime.

## 8.15.2 Constructor & Destructor Documentation

### 8.15.2.1 IrisInstance() [1/2]

```
iris::IrisInstance::IrisInstance (
    IrisConnectionInterface * connection_interface = nullptr,
    const std::string & instName = std::string(),
    uint64_t flags = DEFAULT\_FLAGS )
```

Construct a new Iris instance.

#### Parameters

<i>connection_interface</i>	The IrisConnectionInterface that this instance should use to connect to the simulation.
<i>instName</i>	Name of the instance. This should be prefixed with one of the following, as appropriate: <ul style="list-style-type: none"> <li>"client."</li> <li>"component."</li> <li>"framework."</li> </ul>
<i>flags</i>	A bitwise OR of <a href="#">Instance Flags</a> . Client instances should usually set the flag <a href="#">iris::IrisInstance::UNQUIFY</a> .

### 8.15.2.2 IrisInstance() [2/2]

```
iris::IrisInstance::IrisInstance (
```

```
IrisInstantiationContext * context )
```

Construct a new Iris instance using an [IrisInstantiationContext](#).

#### Parameters

<i>context</i>	A context object that provides the necessary information to instantiate an instance.
----------------	--

## 8.15.3 Member Function Documentation

### 8.15.3.1 addCallback\_IRIS\_INSTANCE\_REGISTRY\_CHANGED()

```
void iris::IrisInstance::addCallback_IRIS_INSTANCE_REGISTRY_CHANGED (
    EventCallbackFunction f )
```

Add callback function for IRIS\_INSTANCE\_REGISTRY\_CHANGED.

### 8.15.3.2 disableEvent()

```
void iris::IrisInstance::disableEvent (
    const std::string & eventSpec )
```

Disable all matching event callback(s).

This disables all event callbacks which were previously enabled using [enableEvent\(\)](#) which match eventSpec. The eventSpec argument for [enableEvent\(\)](#) and [disableEvent\(\)](#) do not have to be the same string. In particular it is not necessary to specify event fields and it is not possible to selectively disable one specific event stream out of multiple created for the same event source.

[disableEvent\(\)](#) always iterates over all currently active event streams and disables all event streams which originate from the event sources specified in eventSpec.

Example: // Handle INST of cpu0 and cpu1 in different ways. `irisInstance.enableEvent("*.cpu0.INST", [&] (const EventStreamInfo& eventStreamInfo, IrisReceivedRequest& request) { ... }); irisInstance.enableEvent("*.cpu1.INST", [&] (const EventStreamInfo& eventStreamInfo, IrisReceivedRequest& request) { ... }); // Disable just the cpu1 events. irisInstance.disableEvent("*.cpu1.INST");`

### 8.15.3.3 enableEvent() [1/2]

```
void iris::IrisInstance::enableEvent (
    const std::string & eventSpec,
    std::function< void()> callback )
```

Enable event callback(s).

This is equivalent to [enableEvent\(\)](#) specified above except that the callback does not take any arguments which is useful for the global simulation phase events.

Example:

Initialize a plugin or client in the SystemC `end_of_elaboration()` phase. This is the phase when all other instances are initialized and can be inspected. `irisInstance.enableEvent("IRIS_SIM_PHASE_END_OF_ELABORATION", [&] { ... enable trace (using enableTrace()), inspect other instances, etc ... });`

### 8.15.3.4 enableEvent() [2/2]

```
void iris::IrisInstance::enableEvent (
    const std::string & eventSpec,
    std::function< void(const EventStreamInfo &eventStreamInfo, IrisReceivedRequest
&request)> callback )
```

Enable event callback(s).

Create one or more event streams and set up the callback function to be called for all events on the event streams. If no event stream is created because no event source matching spec is found, or if an error occurred when create an events stream, an error is thrown.

Calling this function multiple times matching the same event source is valid, but it results in multiple event streams being created which should usually be avoided for performance reasons.

A new unique callback function with the name `ec_i<instanceId>_<eventSourceName>[N]` is registered, where `N` is used to make the function name different from all other functions. This is name usually not of interest for the usage of this function.

#### Parameters

<i>eventSpec</i>	This specifies one or more event source names of one or more instances. See <a href="#">findEventSourcesAndFields()</a> for the syntax specification. When the instance part of an event source is omitted the global instance is assumed. Passing "help" will throw an <code>E_help_message</code> error with a help messages describing the syntax and listing all available event sources in the system.
------------------	---

#### Examples:

Initialize a plugin or client in the SystemC `end_of_elaboration()` phase. This is the phase when all other instances are initialized and can be inspected. Every plugin usually does this in its constructor to enable other traces in the `end_of_elaboration()` phase. `irisInstance.enableEvent("IRIS_SIM_PHASE_END_OF_ELABORATION", [&] { // Enable traces, inspect other instances. irisInstance.enableEvent("*.INST", [&] (const EventStreamInfo& eventStreamInfo, IrisReceivedRequest& request) { ... handle INST trace ... }); });`

Print all simulation phases as they happen: `irisInstance.enableEvent("IRIS_SIM_PHASE_*:IRIS_SHUTDOWN_*", [&](const iris::EventStreamInfo& eventStreamInfo, iris::IrisReceivedRequest&) { std::cout << eventStreamInfo.eventSourceInfo.name << "\n"; });`

Receive INST callbacks from all cores: `irisInstance.enableEvent("*.INST", [&] (const EventStreamInfo& eventStreamInfo, IrisReceivedRequest& request) { ... });`

See also `Examples/Plugin/SimpleTrace/main.cpp` and `Examples/Plugin/GenericTrace/main.cpp`.

This may throw:

- `E_syntax_error`: Syntax error in spec (like missing closing parenthesis).
- `E_unknown_event_source`: A pattern in `EVENT_SOURCE` in `eventSpec` did not match any instance and/or event source name.
- `E_unknown_event_field`: A pattern in `FIELD_OR_OPTION` in `eventSpec` did not match any field or option of its event source.

#### 8.15.3.5 findEventSources()

```
std::vector< EventSourceInfo > iris::IrisInstance::findEventSources (
    const std::string & instancePathFilter = "all" )
```

Find all event sources in the system.

See `filterInstanceInfos()` (`IrisObjects.h`) for `instancePathFilter` semantics.

#### 8.15.3.6 findEventSourcesAndFields()

```
std::vector< EventStreamInfo > iris::IrisInstance::findEventSourcesAndFields (
    const std::string & spec,
    InstanceId defaultInstId = IRIS_UINT64_MAX )
```

Find specific event sources in the system.

Find all event sources in the system and/or in the instance defined by `defaultInstId` matching wildcard patterns.

All matching event sources are added to `eventStreamInfosOut` which is not cleared beforehand.

The following fields in each `EventStreamInfo` element are set to the meta-info of the events source: `sInstId`, `evSrcId`, `evSrcName`, `fields`, `hasFields` and `eventSourceInfo`.

No event streams are created. The output is suitable as the `eventStreamInfos` argument for `eventBuffer_create()`. Alternatively, individual event streams can be created using `eventStream_create()` by looping over `eventStreamInfosOut`.

The set of returned event sources is defined by the filters specified in "spec" which has the following format:

- `[~]EVENT_SOURCE ["[" [FIELD_OR_OPTION ["+" FIELD_OR_OPTION] ...] "]" ] [":" ...]`

- `EVENT_SOURCE` is a wildcard pattern matching on strings of the form `<instance_path>.<event_source_name>` (for all instances in the system) and on strings `<event_source_name>` for event sources of default InstId.
- `FIELD_OR_OPTION` is either a wildcard pattern matching on field names of the selected event sources, or it is of the format `OPT=VAL` setting option `OPT` to value `VAL`. Use `(+OPT=VAL)` to set option and still emit all fields.
- Use `~EVENT_SOURCE` to remove any previously matched event sources. The adding and removing event sources is executed in the specified order, so usually removes should come at the end. This makes it easy to enable events using wildcards and then exclude certain events. Example: `*:~*UTLB`: Enable all events in the system except all UTLB related events.
- Likewise, use `~FIELD` to remove any previously selected fields. When the first `FIELD` is a negative field matching starts with all fields.

Examples:

- `INST` (Trace `INST` on the selected core.)  
" - \*.INST:\*.CORE\_STORES (Trace `INST` and `CORE_STORES` on all cores.)\n"
- `*.INST(PC+DISASS)` (Only trace PC and disassembly of `INST`.)  
" - \*.INST(~DISASS) (Trace all fields except disassembly of `INST`.)\n"
- `*:~*SEMIHOSTING*:~*UTLB*` (Enable all trace sources in the whole system except semihosting and UTLB related traces.)  
" - \*.TRACE\_DATA\_FMT\_V1\_1(+bufferSize=1048576) (Enable trace stream in FMT V1.1 format with buffer size 1MB and all fields.)\n\n";

This may throw:

- `E_syntax_error`: Syntax error in spec (like missing closing parenthesis).
- `E_unknown_event_source`: A pattern in `EVENT_SOURCE` in spec did not match any instance and/or event source name.
- `E_unknown_event_field`: A pattern in `FIELD_OR_OPTION` in spec did not match any field or option of its event source.

### 8.15.3.7 findInstanceInfos()

```
std::vector< InstanceInfo > iris::IrisInstance::findInstanceInfos (
    const std::string & instancePathFilter = "all" )
```

Find instance infos of all instances in the system.

This function uses instance info data cached in this instance. The cache can be cleared with [clearCachedMetaInfo\(\)](#). See [filterInstanceInfos\(\)](#) (`IrisObjects.h`) for `instancePathFilter` semantics.

### 8.15.3.8 getBuilder()

```
IrisInstanceBuilder * iris::IrisInstance::getBuilder ( )
```

Get the [IrisInstanceBuilder](#) object for this instance. This can be used to set up metadata and callbacks for standard Iris functions.

Returns

The [IrisInstanceBuilder](#) object for this instance.



### 8.15.3.9 getInstanceId()

```
InstanceId iris::IrisInstance::getInstanceId (
    const std::string & instName )
```

Get instance id for a specific instance name.

If no such instance is known `IrisErrorException(E_unknown_instance_name)` is thrown.

This information is cached in this instance. The cache can be cleared with [clearCachedMetaInfo\(\)](#).

#### Returns

Instance id.

### 8.15.3.10 getInstanceInfo() [1/2]

```
InstanceInfo iris::IrisInstance::getInstanceInfo (
    const std::string & instancePathFilter )
```

Get instance info of a specific instance in the system.

This function expects either a correct instance path or a pattern which just matches a single instance, for example "core" which always returns the first core, regardless of the number of cores in the system. If no instance is found or if more than one instances are found, `IrisErrorException(E_unknown_instance_name)` is thrown.

This function should only be used when the instance name is known upfront, or to get access to the first core only. Use [findInstanceInfos\(\)](#) to discover arbitrary instances.

This function uses instance info data cached in this instance. The cache can be cleared with [clearCachedMetaInfo\(\)](#). See `filterInstanceInfos()` (`IrisObjects.h`) for `instancePathFilter` semantics.

### 8.15.3.11 getInstanceInfo() [2/2]

```
const InstanceInfo & iris::IrisInstance::getInstanceInfo (
    InstanceId instId )
```

Get `InstanceInfo` including properties for a specific `instId`.

This information is cached in this instance. The cache can be cleared with [clearCachedMetaInfo\(\)](#).

#### Returns

`InstanceInfo` (including properties) for `instId`. Throws `IrisErrorException(E_unknown_instance_id)` if `instId` is unknown.

### 8.15.3.12 getInstanceList()

```
const std::vector< InstanceInfo > & iris::IrisInstance::getInstanceList ( )
```

Get list of `InstanceInfos` of all instances in the system, including properties.

Note that the index into the returned list is generally not the `InstanceId`. Use `getInstanceInfo(instId)` to get the `InstanceInfo` for a specific instance id.

This information is cached in this instance. The cache can be cleared with [clearCachedMetaInfo\(\)](#).

#### Returns

`InstanceInfos` (including properties) for all instances in the system.

### 8.15.3.13 getInstanceName() [1/2]

```
const std::string & iris::IrisInstance::getInstanceName ( ) const [inline]
```

Get the instance name of this instance. This is valid after [registerInstance\(\)](#) returns.

#### Returns

The instance name of this instance. This is the same as the name parameter passed to the constructor or [registerInstance\(\)](#) unless this instance was registered with the `UNIQUEIFY` flag set and the name was modified to make it unique.

**8.15.3.14 getInstanceName()** [2/2]

```
std::string iris::IrisInstance::getInstanceName (
    InstanceId instId )
```

Get instance name for a specifid instId.

This function does not throw. It returns "instance.<instId>" for unknown instIds.

This information is cached in this instance. The cache can be cleared with [clearCachedMetaInfo\(\)](#).

**Returns**

instance name or "instance.<instId>" instId is unknown.

**8.15.3.15 getInstId()**

```
InstanceId iris::IrisInstance::getInstId ( ) const [inline]
```

Get the instance id of this instance. This is valid after [registerInstance\(\)](#) returns.

**Returns**

The instId for this instance.

**8.15.3.16 getLocalIrisInterface()**

```
IrisInterface * iris::IrisInstance::getLocalIrisInterface ( ) [inline]
```

Get the local IrisInterface of this instance. This is the interface that other instances use to send their requests and responses to this instance.

**Returns**

IrisInterface to send messages to this instance.

**8.15.3.17 getMemorySpaceId()**

```
MemorySpaceId iris::IrisInstance::getMemorySpaceId (
    InstanceId instId,
    const std::string & name )
```

Get memory space id of memory space by name.

Note: Memory space names change over time and are not a stable method to identify memory spaces. If possible the canonical memory space number should be used instead to identify memory spaces.

**8.15.3.18 getMemorySpaceInfo()**

```
const MemorySpaceInfo & iris::IrisInstance::getMemorySpaceInfo (
    InstanceId instId,
    const std::string & name )
```

Get MemorySpaceInfo of memory space by name.

Note: Memory space names change over time and are not a stable method to identify memory spaces. If possible the canonical memory space number should be used instead to identify memory spaces.

**8.15.3.19 getPropertyMap()**

```
const PropertyMap & iris::IrisInstance::getPropertyMap ( ) const [inline]
```

Get property map.

This can be used to lookup properties: `getWithDefault(my_instance->getPropertyMap\(\), "myStringProperty", "").getAsString();`

### 8.15.3.20 getRemoteIrisInterface()

```
IrisInterface * iris::IrisInstance::getRemoteIrisInterface ( ) [inline]
```

Get the remote Iris interface.

#### Returns

Returns the IrisInterface that this instance sends requests and responses to.

### 8.15.3.21 getResourceId()

```
ResourceId iris::IrisInstance::getResourceId (
    InstanceId instId,
    const std::string & resourceSpec )
```

Get resource id for a specific resource.

See [resourceRead\(\)](#) for semantics of resourceSpec.

Throws an error when resource is not found.

#### Returns

Resource id.

### 8.15.3.22 irisCall()

```
IrisCppAdapter & iris::IrisInstance::irisCall ( ) [inline]
```

Get an IrisCppAdapter to call an Iris function of any other instance.

Usage:

```
irisCall\(\).resource_read(...);
```

for the Iris function `resource_read()`.

### 8.15.3.23 irisCallNoThrow()

```
IrisCppAdapter & iris::IrisInstance::irisCallNoThrow ( ) [inline]
```

Get an IrisCppAdapter to call an Iris function of any other instance.

When an Iris function returns an error response, this adapter returns the error code and does not throw an exception.

Usage:

```
iris::IrisErrorCode code = irisCallNoThrow\(\).resource_read(...);
```

### 8.15.3.24 irisCallThrow()

```
IrisCppAdapter & iris::IrisInstance::irisCallThrow ( ) [inline]
```

Get an IrisCppAdapter to call an Iris function of any other instance. When an Iris function returns an error response, this adapter always throws an exception. Usage:

```
try
{
    irisCall\(\).resource_read(...);
}
catch (iris::IrisErrorException &e)
{
    ...
}
```

### 8.15.3.25 isRegistered()

```
bool iris::IrisInstance::isRegistered ( ) const [inline]
```

Return true iff we are registered as an instance (= we have a valid instance id).

**8.15.3.26 isValidEvBufId()**

```
bool iris::IrisInstance::isValidEvBufId (
    EventBufferId evBufId ) const
```

Check whether event buffer id is valid.

This function is use to validate event buffer ids.

**Returns**

Returns true iff evBufId is a valid event buffer id.

**8.15.3.27 notifyStateChanged()**

```
void iris::IrisInstance::notifyStateChanged ( )
```

Notify client instances that the state of any resource/memory/table/disassembly etc changed.

This should only ever be called when the value of anything changes spontaneously, e.g. through a private GUI of an instance. This must not be called when the state changes because of normal simulation operations.

Calling this function is very exotic. Normal component instances and client instances will never want to call this.

**8.15.3.28 publishCppInterface()**

```
template<class T >
void iris::IrisInstance::publishCppInterface (
    const std::string & interfaceName,
    T * pointer,
    const std::string & jsonDescription ) [inline]
```

Publish a C++ interface XYZ through a new instance `_getCppInterfaceXYZ()` function.

Null pointers are silently ignored. An interface previously registered under the same name is silently overwritten.

**Parameters**

<i>interfaceName</i>	Class name or interface name of the interface to be published. This must be a C identifier without namespaces etc. The interface can be retrieved with "instance_getCppInterface<interfaceName>()".
<i>pointer</i>	Pointer to the C++ class instance implementing this interface.
<i>jsonDescription</i>	Text for FunctionInfo.description. This must be a valid JSON string without enclosing quotes. This text is amended by generic notes about the compatibility of C++ pointers which are valid for every C++ interface.

**8.15.3.29 registerEventBufferCallback() [1/3]**

```
void iris::IrisInstance::registerEventBufferCallback (
    EventBufferCallbackDelegate delegate,
    const std::string & name,
    const std::string & description,
    const std::string & dlgInstanceTypeStr ) [inline]
```

Register an event buffer callback using an EventBufferCallbackDelegate.

**Parameters**

<i>delegate</i>	EventBufferCallbackDelegate to call to handle the function.
<i>name</i>	Name of the function as it will be published.
<i>description</i>	Description of this event callback function.
<i>dlgInstanceTypeStr</i>	The name of the delegate type. This is only used for logging purposes.

**8.15.3.30 registerEventBufferCallback() [2/3]**

```
template<typename T , IrisErrorCode(T::*)(const EventBufferCallbackData &data) METHOD>
void iris::IrisInstance::registerEventBufferCallback (
    T * instance,
    const std::string & name,
    const std::string & description,
    const std::string & dlgInstanceTypeStr ) [inline]
```

Register an event buffer callback using an EventBufferCallbackDelegate.

**Parameters**

<i>instance</i>	An instance of class T on which to call the delegate T::METHOD().
<i>name</i>	Name of the function as it will be published.
<i>description</i>	Description of this event callback function.
<i>dlgInstanceTypeStr</i>	The name of the delegate type. This is only used for logging purposes.

**8.15.3.31 registerEventBufferCallback() [3/3]**

```
template<class T >
void iris::IrisInstance::registerEventBufferCallback (
    T * instance,
    const std::string & name,
    const std::string & description,
    void(T::*)(IrisReceivedRequest &) memberFunctionPtr,
    const std::string & instanceTypeStr ) [inline]
```

Register an event buffer callback function.

Event buffer callbacks have the same signature, only the description is different.

**Parameters**

<i>instance</i>	An instance of class T on which to call the member function.
<i>name</i>	Name of the function as it will be published.
<i>description</i>	Description of this event callback function.
<i>memberFunctionPtr</i>	Pointer to the C++ implementation of the function.
<i>instanceTypeStr</i>	The name of class T. This is only used for logging purposes.

**8.15.3.32 registerEventCallback() [1/3]**

```
void iris::IrisInstance::registerEventCallback (
    EventCallbackDelegate delegate,
    const std::string & name,
    const std::string & description,
    const std::string & dlgInstanceTypeStr ) [inline]
```

Register a general event callback using an EventCallbackDelegate.

**Parameters**

<i>delegate</i>	EventCallbackDelegate to call to handle the function.
<i>name</i>	Name of the function as it will be published.
<i>description</i>	Description of this event callback function.

## Parameters

<i>dlgInstanceTypeStr</i>	The name of the delegate type. This is only used for logging purposes.
---------------------------	--

**8.15.3.33 registerEventCallback() [2/3]**

```
template<typename T , IrisErrorCode(T::*)(uint64_t, const AttributeValueMap &, uint64_t, uint64_t, bool, std::string &) METHOD>
```

```
void iris::IrisInstance::registerEventCallback (
    T * instance,
    const std::string & name,
    const std::string & description,
    const std::string & dlgInstanceTypeStr ) [inline]
```

Register a general event callback using an EventCallbackDelegate.

## Parameters

<i>instance</i>	An instance of class T on which to call the delegate T::METHOD().
<i>name</i>	Name of the function as it will be published.
<i>description</i>	Description of this event callback function.
<i>dlgInstanceTypeStr</i>	The name of the delegate type. This is only used for logging purposes.

**8.15.3.34 registerEventCallback() [3/3]**

```
template<class T >
void iris::IrisInstance::registerEventCallback (
    T * instance,
    const std::string & name,
    const std::string & description,
    void(T::*)(IrisReceivedRequest &) memberFunctionPtr,
    const std::string & instanceTypeStr ) [inline]
```

Register a general event callback.

Event callbacks have the same signature, only the description is different.

## Parameters

<i>instance</i>	An instance of class T on which to call the member function.
<i>name</i>	Name of the function as it will be published.
<i>description</i>	Description of this event callback function.
<i>memberFunctionPtr</i>	Pointer to the C++ implementation of the function.
<i>instanceTypeStr</i>	The name of class T. This is only used for logging purposes.

**8.15.3.35 registerFunction()**

```
template<class T >
void iris::IrisInstance::registerFunction (
    T * instance,
    const std::string & name,
    void(T::*)(IrisReceivedRequest &) memberFunctionPtr,
    const std::string & functionInfoJson,
```

```
const std::string & instanceTypeStr ) [inline]
```

Register an Iris function implementation.

The following macro can be used instead of calling this function to avoid specifying the function name twice↔  
: [irisRegisterFunction\(instancePtr, instanceType, functionName, implFunctionName, functionInfoJson\)](#)

#### Parameters

<i>instance</i>	An instance of class T on which to call the member function.
<i>name</i>	Name of the function as it will be published.
<i>memberFunctionPtr</i>	Pointer to the C++ implementation of the function.
<i>functionInfoJson</i>	A string containing the JSON-encoded FunctionInfo object for this function.
<i>instanceTypeStr</i>	The name of class T. This is only used for logging purposes.

#### 8.15.3.36 registerInstance()

```
IrisErrorCode iris::IrisInstance::registerInstance (
    const std::string & instName,
    uint64_t flags = DEFAULT\_FLAGS )
```

Register this instance if it was not registered when constructed.

#### Parameters

<i>instName</i>	Name of the instance. This should be prefixed with one of the following, as appropriate: <ul style="list-style-type: none"> <li>• "client."</li> <li>• "component."</li> <li>• "framework."</li> </ul>
<i>flags</i>	A bitwise OR of <a href="#">Instance Flags</a> . Client instances should usually set the flag <a href="#">iris::IrisInstance::UNIQUEIFY</a> .

#### 8.15.3.37 resourceRead()

```
uint64_t iris::IrisInstance::resourceRead (
    InstanceId instId,
    const std::string & resourceSpec )
```

Read numeric resource and return its value.

Resource spec may be:

- <resource\_name>[.<child\_name>...]
- <resource\_group>.<resource\_name>[.<child\_name>...]
- tag:<tag> (e.g. "tag:isInstructionCounter" or "tag:isPc")
- crn:<canonical\_register\_number\_in\_decimal> (usage: resourceRead(instId, "crn:" + std::to\_string(iris::Elf↔ Dwarf::ARM\_R0)), see [iris/IrisElfDwarfArm.h](#), consider using [resourceReadCrn\(\)](#) instead)
- rscl:<resourceId> (fallback in case resourceId is already known, consider using [irisCallThrow\(\)](#)->resource\_read() instead)

If the resource is not found or could not be read the appropriate error is thrown. If the resource is not a numeric resource `E_type_mismatch` is thrown.

This is a convenience function, intended to make reading well-known registers easy (e.g. PC, instruction counter). This intentionally does not handle the generic case (string registers, wide registers) to keep the usage simple. Use `resource_read()` to read any register which does not fit this function.

The resource meta-information is cached in this instance, but the value is not. The cache can be cleared with [clearCachedMetaInfo\(\)](#).

#### Returns

Resource value.

#### 8.15.3.38 resourceReadCrn()

```
uint64_t iris::IrisInstance::resourceReadCrn (
    InstanceId instId,
    uint64_t canonicalRegisterNumber ) [inline]
```

Read numeric resource and return its value (using the canonical register number aka DWARF register id).

See [resourceRead\(\)](#) and the "crn:" case within.

#### Returns

Resource value.

#### 8.15.3.39 resourceReadStr()

```
std::string iris::IrisInstance::resourceReadStr (
    InstanceId instId,
    const std::string & resourceSpec )
```

Read string resource, or read other resources as string.

Numeric resource values get converted to a string according to the type and bitWidth. Errors in the result.error fields are returned as string. noValue resources return an empty string.

See [resourceRead\(\)](#) for semantics of resourceSpec, errors and limitations.

#### 8.15.3.40 resourceWrite()

```
void iris::IrisInstance::resourceWrite (
    InstanceId instId,
    const std::string & resourceSpec,
    uint64_t value )
```

Write numeric resource.

If the resource is not a numeric resource `E_type_mismatch` is thrown.

See [resourceRead\(\)](#) for semantics of resourceSpec, errors and limitations.

#### 8.15.3.41 resourceWriteCrn()

```
void iris::IrisInstance::resourceWriteCrn (
    InstanceId instId,
    uint64_t canonicalRegisterNumber,
    uint64_t value ) [inline]
```

Write numeric resource by canonical register number (aka DWARF register id).

See [resourceWrite\(\)](#) for semantics.

#### 8.15.3.42 resourceWriteStr()

```
void iris::IrisInstance::resourceWriteStr (
    InstanceId instId,
    const std::string & resourceSpec,
    const std::string & value )
```



Write string resource, or write numeric resource from string.

If the resource is not a string the value is converted to a numeric value according to the resource type.

See [resourceRead\(\)](#) for semantics of resourceSpec, errors and limitations.

#### 8.15.3.43 sendRequest()

```
bool iris::IrisInstance::sendRequest (
    IrisRequest & req ) [inline]
```

Send an Iris request or notification and potentially wait for a response.

##### Parameters

<i>req</i>	Iris request to send.
------------	-----------------------

##### Returns

Returns true iff a non-error response was received, and therefore the result values must be decoded.

Use this to manually call functions implemented in the called target but not implemented in IrisCppAdapter.

#### 8.15.3.44 sendResponse()

```
void iris::IrisInstance::sendResponse (
    const uint64_t * response ) [inline]
```

Send a response to the remote Iris interface.

Call this from the function implementations registered with [registerFunction\(\)](#) or [irisRegisterFunction\(\)](#).

##### Parameters

<i>response</i>	The Iris response message to send.
-----------------	------------------------------------

#### 8.15.3.45 setCallback\_IRIS\_SHUTDOWN\_LEAVE()

```
void iris::IrisInstance::setCallback_IRIS_SHUTDOWN_LEAVE (
    EventCallbackFunction f )
```

Set callback function for IRIS\_SHUTDOWN\_LEAVE.

#### 8.15.3.46 setCallback\_IRIS\_SIMULATION\_TIME\_EVENT()

```
void iris::IrisInstance::setCallback_IRIS_SIMULATION_TIME_EVENT (
    EventCallbackFunction f )
```

Set callback function for IRIS\_SIMULATION\_TIME\_EVENT.

#### 8.15.3.47 setConnectionInterface()

```
void iris::IrisInstance::setConnectionInterface (
    IrisConnectionInterface * connection_interface )
```

Set the remote connection interface.

Used to set the IrisConnectionInterface if it was not set in the constructor.

##### Parameters

<i>connection_interface</i>	The interface used to connect to an Iris simulation.
-----------------------------	--

**8.15.3.48 setPendingSyncStepResponse()**

```
void iris::IrisInstance::setPendingSyncStepResponse (
    RequestId requestId,
    EventBufferId evBufId )
```

Set pending response to a `step_syncStep()` call.

This function is called when the `step_syncStep()` function is called and the response is delivered when the simulation time stopped.

**8.15.3.49 setProperty()**

```
template<class T >
void iris::IrisInstance::setProperty (
    const std::string & propertyName,
    const T & propertyValue ) [inline]
```

Set/add instance property.

This creates a new property or overwrites an existing one.

Properties (name and value) are defined by the instance that has them. Properties are not to be confused with parameters, whose values are defined by clients or by parent components and some parameters might change at runtime.

Properties are exposed by the function `instance_getProperties()`. This should only ever be called upon initialization, before other components have a chance to call `instance_getProperties()`. Properties are constant and should not be changed at runtime. T can be `bool`, `uint64_t`, `int64_t`, or `std::string`.

**Parameters**

<i>propertyName</i>	Name of the property.
<i>propertyValue</i>	Value of the property.

**8.15.3.50 setThrowOnError()**

```
void iris::IrisInstance::setThrowOnError (
    bool throw_on_error ) [inline]
```

Set default error behavior for [irisCall\(\)](#).

**Parameters**

<i>throw_on_error</i>	If true, calls made using <a href="#">irisCall()</a> that respond with an error response will throw an exception. This is the same behavior as <a href="#">irisCallThrow()</a> . If false, calls made using <a href="#">irisCall()</a> that respond with an error response will return the error code and not throw an exception. This is the same behavior as <a href="#">irisCallNoThrow()</a> .
-----------------------	--

**8.15.3.51 simulationTimeDisableEvents()**

```
void iris::IrisInstance::simulationTimeDisableEvents ( )
```

Disable the internal reception of `IRIS_SIMULATION_TIME_EVENT` events for performance reasons (e.g. during synchronous stepping).

The callback set with [setCallback\\_IRIS\\_SIMULATION\\_TIME\\_EVENT\(\)](#) will no longer be called.

Internal `IRIS_SIMULATION_TIME_EVENTS` will automatically be re-enabled as soon as one of the other `simulationTime*()` functions is called.

This function throws Iris errors.

**8.15.3.52 simulationTimeIsRunning()**

```
bool iris::IrisInstance::simulationTimeIsRunning ( )
```

Return true iff simulation is currently running.

Note that this information is always out of date if there is another simulation controller.

This function throws Iris errors.

#### 8.15.3.53 simulationTimeRun()

```
void iris::IrisInstance::simulationTimeRun ( )
```

Run simulation time and wait until simulation time started running.

Does not wait until model stopped again. See [simulationTimeRunUntilStop\(\)](#).

This function throws Iris errors.

#### 8.15.3.54 simulationTimeRunUntilStop()

```
void iris::IrisInstance::simulationTimeRunUntilStop (
    double timeoutInSeconds = 0.0 )
```

Run simulation time and wait until simulation time stopped again or until timeout expired.

This function throws Iris errors.

#### 8.15.3.55 simulationTimeStop()

```
void iris::IrisInstance::simulationTimeStop ( )
```

Stop simulation time and wait until simulation time stopped.

This function throws Iris errors.

#### 8.15.3.56 simulationTimeWaitForStop()

```
bool iris::IrisInstance::simulationTimeWaitForStop (
    double timeoutInSeconds = 0.0 )
```

Wait for simulation time to stop or timeout.

This function only works after [simulationTimeRun\(\)](#) has been called. When the simulation time already stopped after [simulationTimeRun\(\)](#) then this function exits immediately.

This function throws Iris errors.

##### Parameters

<i>timeoutInSeconds</i>	Stop waiting after the specified timeout and return false on timeout. 0.0 means to wait indefinitely.
-------------------------	---

##### Returns

true if simulation time stopped, false on timeout. When timeoutInSeconds is 0.0 (= no timeout) this always returns true.

#### 8.15.3.57 unublishCppInterface()

```
void iris::IrisInstance::unublishCppInterface (
    const std::string & interfaceName ) [inline]
```

Unpublish a previously published C++ interface.

After calling this function the corresponding instance\_getCppInterface...() function is no longer available. This is silently ignored If the interface was not previously published.

##### Parameters

<i>interfaceName</i>	Class name or interface name of the interface to be unpublished.
----------------------	--

### 8.15.3.58 unregisterInstance()

`IrisErrorCode iris::IrisInstance::unregisterInstance ( )`

Unregister this instance.

Iris calls must not be made after the instance has been unregistered.

The documentation for this class was generated from the following file:

- [IrisInstance.h](#)

## 8.16 iris::IrisInstanceBreakpoint Class Reference

Breakpoint add-on for [IrisInstance](#).

```
#include <IrisInstanceBreakpoint.h>
```

### Public Member Functions

- void [addCondition](#) (const std::string &name, const std::string &type, const std::string &description, const std::vector< std::string > bpt\_types=std::vector< std::string >())  
*Add an optional component-specific condition that can be configured by clients.*
- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- const BreakpointInfo \* [getBreakpointInfo](#) (BreakpointId bptId) const  
*Get BreakpointInfo for a breakpoint id.*
- void [handleBreakpointHit](#) (const [BreakpointHitInfo](#) &bptHitInfo)  
*Handle breakpoint hit.*
- **IrisInstanceBreakpoint** ([IrisInstance](#) \*irisInstance=nullptr)
- void [notifyBreakpointHit](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId)  
*Notify clients that a code breakpoint was hit.*
- void [notifyBreakpointHitData](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId, uint64\_t accessAddr, uint64\_t accessSize, const std::string &accessRw, const std::vector< uint64\_t > &data)  
*Notify clients that a data breakpoint was hit.*
- void [notifyBreakpointHitRegister](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId, const std::string &accessRw, const std::vector< uint64\_t > &data)  
*Notify clients that a register breakpoint was hit.*
- void [setBreakpointDeleteDelegate](#) ([BreakpointDeleteDelegate](#) delegate)  
*Set breakpoint delete delegate for all breakpoints deleted by this instance.*
- void [setBreakpointSetDelegate](#) ([BreakpointSetDelegate](#) delegate)  
*Set breakpoint set delegate for all breakpoints set by this instance.*
- void [setEventHandler](#) ([IrisInstanceEvent](#) \*handler)  
*Set the event handler used to notify the clients that enable the IRIS\_BREAKPOINT\_HIT event.*
- void [setHandleBreakpointHitDelegate](#) ([HandleBreakpointHitDelegate](#) delegate)  
*Set a delegate for handling breakpoint hit in this instance.*

### 8.16.1 Detailed Description

Breakpoint add-on for [IrisInstance](#).

Instances use this class to support breakpoint functionality.

It implements all Iris breakpoint\*() functions and maintains the breakpoint information that is set by breakpoint\_set() and is exposed by breakpoint\_getList().

Example usage:

```
irisInstanceBpt = new iris::IrisInstanceBreakpoint(irisInstance);
irisInstanceBpt->setBreakpointSetDelegate(bptSetDel);           // Use this delegate for breakpoint set.
irisInstanceBpt->setBreakpointDeleteDelegate(bptDeleteDel);     // Use this delegate for breakpoint delete.
// When a breakpoint is hit, notify the instances that enable the IRIS_BREAKPOINT_HIT event.
irisInstanceBpt->setEventHandler(irisInstanceEvent);
```

See DummyComponent.h for a working example.

## 8.16.2 Member Function Documentation

### 8.16.2.1 addCondition()

```
void iris::IrisInstanceBreakpoint::addCondition (
    const std::string & name,
    const std::string & type,
    const std::string & description,
    const std::vector< std::string > bpt_types = std::vector< std::string >() )
```

Add an optional component-specific condition that can be configured by clients.

#### Parameters

<i>name</i>	The name of the condition.
<i>type</i>	The type of the value that clients set to configure the condition.
<i>description</i>	A description of the condition.
<i>bpt_types</i>	A list of breakpoint types that this condition can be applied to. An empty list indicates all types.

### 8.16.2.2 attachTo()

```
void iris::IrisInstanceBreakpoint::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

Only use this method if nullptr was passed to the constructor.

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

### 8.16.2.3 getBreakpointInfo()

```
const BreakpointInfo * iris::IrisInstanceBreakpoint::getBreakpointInfo (
    BreakpointId bptId ) const
```

Get BreakpointInfo for a breakpoint id.

#### Parameters

<i>bptId</i>	The breakpoint id for which the BreakpointInfo is requested.
--------------	--

#### Returns

A pointer to the BreakpointInfo for the requested breakpoint or nullptr if *bptId* is not a valid breakpoint id.

### 8.16.2.4 handleBreakpointHit()

```
void iris::IrisInstanceBreakpoint::handleBreakpointHit (
    const BreakpointHitInfo & bptHitInfo )
```

Handle breakpoint hit.

## Parameters

<i>bptHitInfo</i>	The information of the breakpoint that is hit. Calls a delegate method in the model.
-------------------	--

**8.16.2.5 notifyBreakpointHit()**

```
void iris::IrisInstanceBreakpoint::notifyBreakpointHit (
    BreakpointId bptId,
    uint64_t time,
    uint64_t pc,
    MemorySpaceId pcSpaceId )
```

Notify clients that a code breakpoint was hit.

It notifies clients by emitting an IRIS\_BREAKPOINT\_HIT event.

## Parameters

<i>bptId</i>	Breakpoint id for the breakpoint that was hit.
<i>time</i>	Simulation time at which the breakpoint hit.
<i>pc</i>	Value of the relevant program counter when the event hit.
<i>pc</i> ↔ <i>SpaceId</i>	Memory space Id for the memory space that the PC address corresponds to.

**8.16.2.6 notifyBreakpointHitData()**

```
void iris::IrisInstanceBreakpoint::notifyBreakpointHitData (
    BreakpointId bptId,
    uint64_t time,
    uint64_t pc,
    MemorySpaceId pcSpaceId,
    uint64_t accessAddr,
    uint64_t accessSize,
    const std::string & accessRw,
    const std::vector< uint64_t > & data )
```

Notify clients that a data breakpoint was hit.

It notifies clients by emitting an IRIS\_BREAKPOINT\_HIT event.

## Parameters

<i>bptId</i>	Breakpoint id for the breakpoint that was hit.
<i>time</i>	Simulation time at which the breakpoint hit.
<i>pc</i>	Value of the relevant program counter when the event hit.
<i>pcSpaceId</i>	Memory space Id for the memory space that the PC address corresponds to.
<i>accessAddr</i>	The address of the data access that triggered the breakpoint.
<i>accessSize</i>	The size of the data access that triggered the breakpoint.
<i>accessRw</i>	Indicates the direction of the access. "r" = read access or "w" = write access.
<i>data</i>	The data that was written or read during the access that triggered the breakpoint.

**8.16.2.7 notifyBreakpointHitRegister()**

```
void iris::IrisInstanceBreakpoint::notifyBreakpointHitRegister (
```

```

BreakpointId bptId,
uint64_t time,
uint64_t pc,
MemorySpaceId pcSpaceId,
const std::string & accessRw,
const std::vector< uint64_t > & data )

```

Notify clients that a register breakpoint was hit.

It notifies clients by emitting an IRIS\_BREAKPOINT\_HIT event.

#### Parameters

<i>bptId</i>	Breakpoint id for the breakpoint that was hit.
<i>time</i>	Simulation time at which the breakpoint hit.
<i>pc</i>	Value of the relevant program counter when the event hit.
<i>pc</i> ↔ <i>SpaceId</i>	Memory space Id for the memory space that the PC address corresponds to.
<i>accessRw</i>	Indicates the direction of the access. "r" = read access or "w" = write access.
<i>data</i>	The data that was written or read during the access that triggered the breakpoint.

#### 8.16.2.8 setBreakpointDeleteDelegate()

```

void iris::IrisInstanceBreakpoint::setBreakpointDeleteDelegate (
    BreakpointDeleteDelegate delegate )

```

Set breakpoint delete delegate for all breakpoints deleted by this instance.

#### Parameters

<i>delegate</i>	A BreakpointDeleteDelegate to call when a breakpoint is deleted.
-----------------	--

#### 8.16.2.9 setBreakpointSetDelegate()

```

void iris::IrisInstanceBreakpoint::setBreakpointSetDelegate (
    BreakpointSetDelegate delegate )

```

Set breakpoint set delegate for all breakpoints set by this instance.

#### Parameters

<i>delegate</i>	A BreakpointSetDelegate to call when a breakpoint is set.
-----------------	---

#### 8.16.2.10 setEventHandler()

```

void iris::IrisInstanceBreakpoint::setEventHandler (
    IrisInstanceEvent * handler )

```

Set the event handler used to notify the clients that enable the IRIS\_BREAKPOINT\_HIT event.

All breakpoint events are normal events and are handled through the same mechanism as other events.

#### 8.16.2.11 setHandleBreakpointHitDelegate()

```

void iris::IrisInstanceBreakpoint::setHandleBreakpointHitDelegate (
    HandleBreakpointHitDelegate delegate )

```

Set a delegate for handling breakpoint hit in this instance.

## Parameters

<i>delegate</i>	A HandleBreakpointHitDelegate to call when a breakpoint is hit.
-----------------	---

The documentation for this class was generated from the following file:

- [IrisInstanceBreakpoint.h](#)

## 8.17 iris::IrisInstanceBuilder Class Reference

Builder interface to populate an [IrisInstance](#) with registers, memory etc.

```
#include <IrisInstanceBuilder.h>
```

### Classes

- class [AddressTranslationBuilder](#)  
*Used to set metadata for an address translation.*
- class [EventSourceBuilder](#)  
*Used to set metadata on an EventSource.*
- class [FieldBuilder](#)  
*Used to set metadata on a register field resource.*
- class [MemorySpaceBuilder](#)  
*Used to set metadata for a memory space.*
- class [ParameterBuilder](#)  
*Used to set metadata on a parameter.*
- class [RegisterBuilder](#)  
*Used to set metadata on a register resource.*
- class [SemihostingManager](#)  
*semihosting\_apis [IrisInstanceBuilder](#) semihosting APIs*
- class [TableBuilder](#)  
*Used to set metadata for a table.*
- class [TableColumnBuilder](#)  
*Used to set metadata for a table column.*

### Public Member Functions

- [AddressTranslationBuilder addAddressTranslation](#) (MemorySpaceId inSpaceId, MemorySpaceId outSpaceId, const std::string &description)  
*Add an address translation.*
- void **addBreakpointCondition** (const std::string &name, const std::string &type, const std::string &description, const std::vector< std::string > bpt\_types=std::vector< std::string >())  
*Add an optional component-specific condition.*
- [EventSourceBuilder addEventSource](#) (const std::string &name, bool isHidden=false)  
*Add metadata for an event source.*
- [EventSourceBuilder addEventSource](#) (const std::string &name, IrisEventEmitterBase &event\_emitter, bool isHidden=false)  
*Add metadata for an event source that uses an [IrisEventEmitter](#).*
- [MemorySpaceBuilder addMemorySpace](#) (const std::string &name)  
*Add metadata for one memory space.*
- [RegisterBuilder addNoValueRegister](#) (const std::string &name, const std::string &description, const std::string &format)  
*Add metadata for one noValue resource.*
- [ParameterBuilder addParameter](#) (const std::string &name, uint64\_t bitWidth, const std::string &description)



- Add numeric parameter.*

  - [RegisterBuilder addRegister](#) (const std::string &name, uint64\_t bitWidth, const std::string &description, uint64\_t addressOffset=IRIS\_UINT64\_MAX, uint64\_t canonicalRn=IRIS\_UINT64\_MAX)

*Add metadata for one numeric register resource.*
- [ParameterBuilder addStringParameter](#) (const std::string &name, const std::string &description)

*Add string parameter.*
- [RegisterBuilder addStringRegister](#) (const std::string &name, const std::string &description)

*Add metadata for one string register resource.*
- [TableBuilder addTable](#) (const std::string &name)

*Add metadata for one table.*
- void [beginResourceGroup](#) (const std::string &name, const std::string &description, uint64\_t subRscld←Start=IRIS\_UINT64\_MAX, const std::string &cname=std::string())

*Begin a new resource group.*
- void [deleteEventSource](#) (const std::string &name)

*Delete event source.*
- [EventSourceBuilder enhanceEventSource](#) (const std::string &name)

*Enhance existing event source.*
- [ParameterBuilder enhanceParameter](#) (ResourceId rscld)

*Get [ParameterBuilder](#) to enhance a parameter.*
- [RegisterBuilder enhanceRegister](#) (ResourceId rscld)

*Get [RegisterBuilder](#) to enhance register.*
- void [finalizeRegisterReadEvent](#) ()
- void [finalizeRegisterUpdateEvent](#) ()

*Finalize set up of an [IrisEventEmitter](#).*
- const BreakpointInfo \* [getBreakpointInfo](#) (BreakpointId bptId)

*Get the breakpoint information for a given breakpoint.*
- [IrisInstanceEvent](#) \* [getIrisInstanceEvent](#) ()
- const ResourceInfo & [getResourceInfo](#) (ResourceId rscld)

*Get ResourceInfo of a previously added register.*
- bool [hasEventSource](#) (const std::string &name)

*Check whether event source already exists.*
- [IrisInstanceBuilder](#) ([IrisInstance](#) \*iris\_instance)

*Construct an [IrisInstanceBuilder](#) for an Iris instance.*
- void [notifyBreakpointHit](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId)

*Notify clients that a code breakpoint was hit.*
- void [notifyBreakpointHitData](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpace←Id, uint64\_t accessAddr, uint64\_t accessSize, const std::string &accessRw, const std::vector< uint64\_t > &data)

*Notify clients that a data breakpoint was hit (IRIS\_BREAKPOINT\_HIT).*
- void [notifyBreakpointHitRegister](#) (BreakpointId bptId, uint64\_t time, uint64\_t pc, MemorySpaceId pcSpaceId, const std::string &accessRw, const std::vector< uint64\_t > &data)

*Notify clients that a register breakpoint was hit (IRIS\_BREAKPOINT\_HIT).*
- uint64\_t [openImage](#) (const std::string &filename)

*Open an image to be read using [image\\_loadDataPull\(\)](#) or [image\\_loadDataRead\(\)](#).*
- void [resetRegisterReadEvent](#) ()

*Reset the active register read event.*
- void [resetRegisterUpdateEvent](#) ()

*Reset the active register update event.*
- template<IrisErrorCode(\*)>(const BreakpointInfo &) FUNC<>  
void [setBreakpointDeleteDelegate](#) ()

*Set the delegate that is called when a breakpoint is deleted.*
- void [setBreakpointDeleteDelegate](#) ([BreakpointDeleteDelegate](#) delegate)

- Set the delegate that is called when a breakpoint is deleted.*

  - `template<typename T , IrisErrorCode(T::*)(const BreakpointInfo &) METHOD>`  
`void setBreakpointDeleteDelegate (T *instance)`
- Set the delegate that is called when a breakpoint is deleted.*

  - `template<IrisErrorCode(*)(BreakpointInfo &) FUNC>`  
`void setBreakpointSetDelegate ()`
- Set the delegate that is called when a breakpoint is set.*

  - `void setBreakpointSetDelegate (BreakpointSetDelegate delegate)`
- Set the delegate that is called when a breakpoint is set.*

  - `template<typename T , IrisErrorCode(T::*)(BreakpointInfo &) METHOD>`  
`void setBreakpointSetDelegate (T *instance)`
- Set the delegate that is called when a breakpoint is set.*

  - `template<IrisErrorCode(*)(uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &) FUNC>`  
`void setDefaultAddressTranslateDelegate ()`
- Set the default address translation function for all subsequently added memory spaces.*

  - `void setDefaultAddressTranslateDelegate (MemoryAddressTranslateDelegate delegate=MemoryAddressTranslateDelegate())`
- Set the default address translation function for all subsequently added memory spaces.*

  - `template<typename T , IrisErrorCode(T::*)(uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult &) METHOD>`  
`void setDefaultAddressTranslateDelegate (T *instance)`
- Set the default address translation function for all subsequently added memory spaces.*

  - `template<IrisErrorCode(*)(EventStream *&, const EventSourceInfo &, const std::vector< std::string > &) FUNC>`  
`void setDefaultEsCreateDelegate ()`
- Set the delegate that helps to create a new event stream for the simulation-specific event.*

  - `void setDefaultEsCreateDelegate (EventStreamCreateDelegate delegate)`
- Set the delegate that helps to create a new event stream for the simulation-specific event.*

  - `template<typename T , IrisErrorCode(T::*)(EventStream *&, const EventSourceInfo &, const std::vector< std::string > &) METHOD>`  
`void setDefaultEsCreateDelegate (T *instance)`
- Set the delegate that helps to create a new event stream for the simulation-specific event.*

  - `template<IrisErrorCode(*)(const MemorySpaceInfo &, uint64_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) FUNC>`  
`void setDefaultGetMemorySidebandInfoDelegate ()`
- Set the default sideband info function for all subsequently added memory spaces.*

  - `void setDefaultGetMemorySidebandInfoDelegate (MemoryGetSidebandInfoDelegate delegate)`
- Set the default sideband info function for all subsequently added memory spaces.*

  - `template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) METHOD>`  
`void setDefaultGetMemorySidebandInfoDelegate (T *instance)`
- Set the default sideband info function for all subsequently added memory spaces.*

  - `template<IrisErrorCode(*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, MemoryReadResult &) FUNC>`  
`void setDefaultMemoryReadDelegate ()`
- Set the default read function for all subsequently added memory spaces.*

  - `void setDefaultMemoryReadDelegate (MemoryReadDelegate delegate=MemoryReadDelegate())`
- Set the default read function for all subsequently added memory spaces.*

  - `template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, MemoryReadResult &) METHOD>`  
`void setDefaultMemoryReadDelegate (T *instance)`
- Set the default read function for all subsequently added memory spaces.*

  - `template<IrisErrorCode(*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) FUNC>`  
`void setDefaultMemoryWriteDelegate ()`
- Set default write function for all subsequently added memory spaces.*

  - `void setDefaultMemoryWriteDelegate (MemoryWriteDelegate delegate=MemoryWriteDelegate())`

*Set the default write function for all subsequently added memory spaces.*

- `template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) METHOD>`  
void `setDefaultMemoryWriteDelegate` (T \*instance)

*Set the default write function for all subsequently added memory spaces.*

- `template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) READER, IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &) WRITER>`  
void `setDefaultResourceDelegates` (T \*instance)

*Set both read and write resource delegates if they are defined in the same class.*

- `template<IrisErrorCode(*) (const ResourceInfo &, ResourceReadResult &) FUNC>`  
void `setDefaultResourceReadDelegate` ()

*Set default read access function for all subsequently added resources.*

- void `setDefaultResourceReadDelegate` (ResourceReadDelegate delegate=ResourceReadDelegate())

*Set default read access function for all subsequently added resources.*

- `template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) METHOD>`  
void `setDefaultResourceReadDelegate` (T \*instance)

*Set default read access function for all subsequently added resources.*

- `template<IrisErrorCode(*) (const ResourceInfo &, const ResourceWriteValue &) FUNC>`  
void `setDefaultResourceWriteDelegate` ()

*Set default write access function for all subsequently added resources.*

- void `setDefaultResourceWriteDelegate` (ResourceWriteDelegate delegate=ResourceWriteDelegate())

*Set default write access function for all subsequently added resources.*

- `template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &) METHOD>`  
void `setDefaultResourceWriteDelegate` (T \*instance)

*Set default write access function for all subsequently added resources.*

- `template<IrisErrorCode(*) (const TableInfo &, uint64_t, uint64_t, TableReadResult &) FUNC>`  
void `setDefaultTableReadDelegate` ()

*Set the default table read function for all subsequently added tables.*

- `template<typename T , IrisErrorCode(T::*)(const TableInfo &, uint64_t, uint64_t, TableReadResult &) METHOD>`  
void `setDefaultTableReadDelegate` (T \*instance)

*Set the default table read function for all subsequently added tables.*

- void `setDefaultTableReadDelegate` (TableReadDelegate delegate=TableReadDelegate())

*Set the default table read function for all subsequently added tables.*

- `template<IrisErrorCode(*) (const TableInfo &, const TableRecords &, TableWriteResult &) FUNC>`  
void `setDefaultTableWriteDelegate` ()

*Set the default table write function for all subsequently added tables.*

- `template<typename T , IrisErrorCode(T::*)(const TableInfo &, const TableRecords &, TableWriteResult &) METHOD>`  
void `setDefaultTableWriteDelegate` (T \*instance)

*Set the default table write function for all subsequently added tables.*

- void `setDefaultTableWriteDelegate` (TableWriteDelegate delegate=TableWriteDelegate())

*Set the default table write function for all subsequently added tables.*

- `template<IrisErrorCode(*) (bool &) FUNC>`  
void `setExecutionStateGetDelegate` ()

*Set the delegate to get the execution state for this instance.*

- void `setExecutionStateGetDelegate` (PerInstanceExecutionStateGetDelegate delegate)

*Set the delegate to get the execution state for this instance.*

- `template<typename T , IrisErrorCode(T::*)(bool &) METHOD>`  
void `setExecutionStateGetDelegate` (T \*instance)

*Set the delegate to get the execution state for this instance.*

- `template<IrisErrorCode(*) (bool) FUNC>`  
void `setExecutionStateSetDelegate` ()

*Set the delegate to set the execution state for this instance.*

- void `setExecutionStateSetDelegate` (PerInstanceExecutionStateSetDelegate delegate=PerInstanceExecutionStateSetDelegate)

- Set the delegate to set the execution state for this instance.*

  - `template<typename T , IrisErrorCode(T::*)(bool) METHOD>`  
`void setExecutionStateSetDelegate (T *instance)`
- Set the delegate to set the execution state for this instance.*

  - `template<IrisErrorCode(*)(const BreakpointHitInfo &) FUNC>`  
`void setHandleBreakpointHitDelegate ()`
- Set the delegate that is called when a breakpoint is hit.*

  - `void setHandleBreakpointHitDelegate (HandleBreakpointHitDelegate delegate)`
- Set the delegate that is called when a breakpoint is hit.*

  - `template<typename T , IrisErrorCode(T::*)(const BreakpointHitInfo &) METHOD>`  
`void setHandleBreakpointHitDelegate (T *instance)`
- Set the delegate that is called when a breakpoint is hit.*

  - `template<IrisErrorCode(*)(const std::vector< uint8_t > &) FUNC>`  
`void setLoadImageDataDelegate ()`
- Set the delegate to load an image from the data provided.*

  - `void setLoadImageDataDelegate (ImageLoadDataDelegate delegate=ImageLoadDataDelegate())`
- Set the delegate to load an image from the data provided.*

  - `template<typename T , IrisErrorCode(T::*)(const std::vector< uint8_t > &) METHOD>`  
`void setLoadImageDataDelegate (T *instance)`
- Set the delegate to load an image from the data provided.*

  - `template<IrisErrorCode(*)(const std::string &) FUNC>`  
`void setLoadImageFileDelegate ()`
- Set the delegate to load an image from a file.*

  - `void setLoadImageFileDelegate (ImageLoadFileDelegate delegate=ImageLoadFileDelegate())`
- Set the delegate to load an image from a file.*

  - `template<typename T , IrisErrorCode(T::*)(const std::string &) METHOD>`  
`void setLoadImageFileDelegate (T *instance)`
- Set the delegate to load an image from a file.*

  - `void setNextSubRsclId (uint64_t nextSubRsclId)`
- Set the rscl that will be used for the next resource to be added.*

  - `void setPropertyCanonicalMsnScheme (const std::string &canonicalMsnScheme)`
- Set the memory.canonicalMsnScheme instance property.*

  - `void setPropertyCanonicalRnScheme (const std::string &canonicalRnScheme)`
- Set the register.canonicalRnScheme instance property.*

  - `EventSourceBuilder setRegisterReadEvent (const std::string &name, const std::string &description=std::string())`
- Add a new register read event source.*

  - `EventSourceBuilder setRegisterReadEvent (const std::string &name, IrisRegisterEventEmitterBase &event_emitter)`
- Add a new register read event source.*

  - `EventSourceBuilder setRegisterUpdateEvent (const std::string &name, const std::string &description=std::string())`
- Add a new register update event source.*

  - `EventSourceBuilder setRegisterUpdateEvent (const std::string &name, IrisRegisterEventEmitterBase &event_emitter)`
- Add a new register update event source.*

  - `template<IrisErrorCode(*)(uint64_t &, const std::string &) FUNC>`  
`void setRemainingStepGetDelegate ()`
- Set the delegate to get the remaining steps for this instance.*

  - `void setRemainingStepGetDelegate (RemainingStepGetDelegate delegate)`
- Set the delegate to get the remaining steps for this instance.*

  - `template<typename T , IrisErrorCode(T::*)(uint64_t &, const std::string &) METHOD>`  
`void setRemainingStepGetDelegate (T *instance)`

- Set the delegate to get the remaining steps for this instance.*

  - template<IrisErrorCode(\*)>(uint64\_t, const std::string &) FUNC>  
void **setRemainingStepSetDelegate** ()
  - Set the delegate to set the remaining steps for this instance.*

    - void **setRemainingStepSetDelegate** (RemainingStepSetDelegate delegate=RemainingStepSetDelegate())
    - Set the delegate to set the remaining steps for this instance.*

      - template<typename T , IrisErrorCode(T::\*)(uint64\_t, const std::string &) METHOD>  
void **setRemainingStepSetDelegate** (T \*instance)
      - Set the delegate to set the remaining steps for this instance.*

        - template<IrisErrorCode(\*)>(uint64\_t &, const std::string &) FUNC>  
void **setStepCountGetDelegate** ()
        - Set the delegate to get the step count for this instance.*

          - void **setStepCountGetDelegate** (StepCountGetDelegate delegate=StepCountGetDelegate())
          - Set the delegate to get the step count for this instance.*

            - template<typename T , IrisErrorCode(T::\*)(uint64\_t &, const std::string &) METHOD>  
void **setStepCountGetDelegate** (T \*instance)
            - Set the delegate to get the step count for this instance.*

              - void **setTag** (ResourceId rscl, const std::string &tag)
              - Set a tag for a specific resource.*
    - void **setGetCurrentDisassemblyModeDelegate** (GetCurrentDisassemblyModeDelegate delegate)
      - disass\_apis IrisInstanceBuilder disassembler APIs*

        - template<typename T , IrisErrorCode(T::\*)(std::string &) METHOD>  
void **setGetCurrentDisassemblyModeDelegate** (T \*instance)
        - void **setGetDisassemblyDelegate** (GetDisassemblyDelegate delegate)
        - Set the delegate to get the disassembly of a chunk of memory.*

          - template<typename T , IrisErrorCode(T::\*)(uint64\_t, const std::string &, MemoryReadResult &, uint64\_t, uint64\_t, std::vector< DisassemblyLine > &) METHOD>  
void **setGetDisassemblyDelegate** (T \*instance)
          - template<IrisErrorCode(\*)>(uint64\_t, const std::string &, MemoryReadResult &, uint64\_t, uint64\_t, std::vector< DisassemblyLine > &) FUNC>  
void **setGetDisassemblyDelegate** ()
          - void **setDisassembleOpcodeDelegate** (DisassembleOpcodeDelegate delegate)
          - Set the delegate to get the disassembly of Opcode.*

            - template<typename T , IrisErrorCode(T::\*)(const std::vector< uint64\_t > &, uint64\_t, const std::string &, DisassembleContext &, DisassemblyLine &) METHOD>  
void **setDisassembleOpcodeDelegate** (T \*instance)
            - template<IrisErrorCode(\*)>(const std::vector< uint64\_t > &, uint64\_t, const std::string &, DisassembleContext &, DisassemblyLine &) FUNC>  
void **setDisassembleOpcodeDelegate** ()
            - void **addDisassemblyMode** (const std::string &name, const std::string &description)
            - Add a disassembly mode.*
      - void **setDbgStateSetRequestDelegate** (DebuggableStateSetRequestDelegate delegate=DebuggableStateSetRequestDelegate)
        - debuggable\_state\_apis IrisInstanceBuilder debuggable state APIs*

          - template<typename T , IrisErrorCode(T::\*)(bool) METHOD>  
void **setDbgStateSetRequestDelegate** (T \*instance)
          - Set the delegate to set the debuggable state request flag for this instance.*

            - template<IrisErrorCode(\*)>(bool) FUNC>  
void **setDbgStateSetRequestDelegate** ()
            - Set the delegate to set the debuggable state request flag for this instance.*

- void [setDbgStateGetAcknowledgeDelegate](#) ([DebuggableStateGetAcknowledgeDelegate](#) delegate=[DebuggableStateGetAcknowledgeDelegate](#))  
Set the delegate to get the debuggable state acknowledge flag for this instance.
- template<typename T , [IrisErrorCode](#)(T::\*)(bool &) METHOD>  
void [setDbgStateGetAcknowledgeDelegate](#) (T \*instance)  
Set the delegate to get the debuggable state acknowledge flag for this instance.
- template<[IrisErrorCode](#)(\*)(bool &) FUNC>  
void [setDbgStateGetAcknowledgeDelegate](#) ()  
Set the delegate to get the debuggable state acknowledge flag for this instance.
- template<typename T , [IrisErrorCode](#)(T::\*)(bool) SET\_REQUEST, [IrisErrorCode](#)(T::\*)(bool &) GET\_ACKNOWLEDGE>  
void [setDbgStateDelegates](#) (T \*instance)  
Set both the debuggable state delegates.
- void [setCheckpointSaveDelegate](#) ([CheckpointSaveDelegate](#) delegate=[CheckpointSaveDelegate](#)())  
Delegates for checkpointing.
- template<typename T , [IrisErrorCode](#)(T::\*)(const std::string &) METHOD>  
void [setCheckpointSaveDelegate](#) (T \*instance)
- void [setCheckpointRestoreDelegate](#) ([CheckpointRestoreDelegate](#) delegate=[CheckpointRestoreDelegate](#)())
- template<typename T , [IrisErrorCode](#)(T::\*)(const std::string &) METHOD>  
void [setCheckpointRestoreDelegate](#) (T \*instance)
- [SemihostingManager](#) [enableSemihostingAndGetManager](#) ()  
Enable semihosting functionality for this instance and get a manager object to make use of it.

### 8.17.1 Detailed Description

Builder interface to populate an [IrisInstance](#) with registers, memory etc.  
See DummyComponent.h for a working example.

### 8.17.2 Constructor & Destructor Documentation

#### 8.17.2.1 IrisInstanceBuilder()

```
iris::IrisInstanceBuilder::IrisInstanceBuilder (
    IrisInstance * iris_instance )
```

Construct an [IrisInstanceBuilder](#) for an Iris instance.

Parameters

<i>iris_instance</i>	The instance to build.
----------------------	------------------------

### 8.17.3 Member Function Documentation

#### 8.17.3.1 addTable()

```
TableBuilder iris::IrisInstanceBuilder::addTable (
    const std::string & name ) [inline]
```

Add metadata for one table.

Typical use pattern:

```
addTableInfo("name")
    .setDescription("description")
    .setMinIndex(...)
    .setMaxIndex(...)
```

```

.setIndexFormatHint (...)
.setFormatShort (...)
.setFormatLong (...)
.setReadDelegate (...)
.setWriteDelegate (...)
.addColumnInfo (...)
.addColumnInfo (...)
...

```

#### Parameters

<i>name</i>	Name of the new table.
-------------	------------------------

#### Returns

A [TableBuilder](#) object than can be used to set metadata for the new table.

### 8.17.3.2 enableSemihostingAndGetManager()

[SemihostingManager](#) `iris::IrisInstanceBuilder::enableSemihostingAndGetManager ( ) [inline]`  
 Enable semihosting functionality for this instance and get a manager object to make use of it.

#### Returns

A [SemihostingManager](#) object to manage semihosting functionality for this instance.

### 8.17.3.3 setDbgStateDelegates()

```

template<typename T , IrisErrorCode(T::*)(bool) SET_REQUEST, IrisErrorCode(T::*)(bool &) GET↔
_ACKNOWLEDGE>
void iris::IrisInstanceBuilder::setDbgStateDelegates (
    T * instance ) [inline]

```

Set both the debuggable state delegates.

#### Usage:

```

class MyClass
{
    ...
    iris::IrisErrorCode setRequestFlag(bool request_debuggable_state);
    iris::IrisErrorCode getAcknowledgeFlag(bool &debuggable_state_acknowledge);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateDelegates<MyClass,
    &MyClass::setRequest,
    &MyClass::getAcknowledgeFlag>(&myInstanceOfMyClass);

```

#### Template Parameters

<i>T</i>	Class that defines both a debuggable state request set and a get acknowledge delegate method.
<i>SET_REQUEST</i>	A method of class T which is a debuggable state request set delegate.
<i>GET_ACKNOWLEDGE</i>	A method of class T which is a debuggable state get acknowledge delegate.

#### Parameters

<i>instance</i>	An instance of class T on which SET_REQUEST and GET_ACKNOWLEDGE should be called.
-----------------	---

**8.17.3.4 setDbgStateGetAcknowledgeDelegate() [1/3]**

```
template<IrisErrorCode(*) (bool &) FUNC>
void iris::IrisInstanceBuilder::setDbgStateGetAcknowledgeDelegate ( ) [inline]
```

Set the delegate to get the debuggable state acknowledge flag for this instance.

Usage:

```
iris::IrisErrorCode getAcknowledgeFlag(bool &debuggable_state_acknowledge);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateGetAcknowledgeDelegate(&getAcknowledgeFlag());
```

**Template Parameters**

<i>FUNC</i>	Global function to call to get the debuggable state acknowledge flag.
-------------	---

**8.17.3.5 setDbgStateGetAcknowledgeDelegate() [2/3]**

```
void iris::IrisInstanceBuilder::setDbgStateGetAcknowledgeDelegate (
    DebuggableStateGetAcknowledgeDelegate delegate = DebuggableStateGetAcknowledgeDelegate()
) [inline]
```

Set the delegate to get the debuggable state acknowledge flag for this instance.

Passing an empty delegate (the default argument) restores the default implementation which always returns E\_↔ not\_implemented for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getAcknowledgeFlag(bool &debuggable_state_acknowledge);
};
MyClass myInstanceOfMyClass;
iris::DebuggableStateGetAcknowledgeDelegate delegate =
    iris::DebuggableStateGetAcknowledgeDelegate::make<MyClass,
    &MyClass::getAcknowledgeFlag>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateGetAcknowledgeDelegate(delegate);
```

**Parameters**

<i>delegate</i>	Delegate object to call to get the debuggable state acknowledge flag.
-----------------	---

**8.17.3.6 setDbgStateGetAcknowledgeDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*)(bool &) METHOD>
void iris::IrisInstanceBuilder::setDbgStateGetAcknowledgeDelegate (
    T * instance ) [inline]
```

Set the delegate to get the debuggable state acknowledge flag for this instance.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getAcknowledgeFlag(bool &debuggable_state_acknowledge);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateGetAcknowledgeDelegate<MyClass, &MyClass::getAcknowledgeFlag>(&myInstanceOfMyClass);
```

**Template Parameters**

<i>T</i>	Class that defines a debuggable state get acknowledge delegate method.
<i>METHOD</i>	A method of class T which is a debuggable state get acknowledge delegate.



## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

**8.17.3.7 setDbgStateSetRequestDelegate() [1/3]**

```
template<IrisErrorCode(*) (bool) FUNC>
void iris::IrisInstanceBuilder::setDbgStateSetRequestDelegate ( ) [inline]
Set the delegate to set the debuggable state request flag for this instance.
Usage:
iris::IrisErrorCode setRequestFlag(bool request_debuggable_state);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateSetRequestDelegate<&setRequestFlag>();
```

## Template Parameters

<i>FUNC</i>	Global function to call to set the debuggable state request flag.
-------------	---

**8.17.3.8 setDbgStateSetRequestDelegate() [2/3]**

```
void iris::IrisInstanceBuilder::setDbgStateSetRequestDelegate (
    DebuggableStateSetRequestDelegate delegate = DebuggableStateSetRequestDelegate()
) [inline]
debuggable_state_apis IrisInstanceBuilder debuggable state APIs
Set the delegate to set the debuggable state request flag for this instance.
Passing an empty delegate (the default argument) restores the default implementation which always returns E_↔
not_implemented for all requests.
Usage:
class MyClass
{
    ...
    iris::IrisErrorCode setRequestFlag(bool request_debuggable_state);
};
MyClass myInstanceOfMyClass;
iris::DebuggableStateSetRequestDelegate delegate =
    iris::DebuggableStateSetRequestDelegate::make<MyClass, &MyClass::setRequestFlag>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateSetRequestDelegate(delegate);
```

## Parameters

<i>delegate</i>	Delegate object to call to set the debuggable state request flag.
-----------------	---

**8.17.3.9 setDbgStateSetRequestDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*)(bool) METHOD>
void iris::IrisInstanceBuilder::setDbgStateSetRequestDelegate (
    T * instance ) [inline]
Set the delegate to set the debuggable state request flag for this instance.
Usage:
class MyClass
{
    ...
    iris::IrisErrorCode setRequestFlag(bool request_debuggable_state);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDbgStateSetRequestDelegate<MyClass, &MyClass::setRequestFlag>(&myInstanceOfMyClass);
```

## Template Parameters

<i>T</i>	Class that defines a debuggable state request set delegate method.
<i>METHOD</i>	A method of class T which is a debuggable state request set delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 8.17.3.10 setDefaultTableReadDelegate() [1/3]

```
template<IrisErrorCode(*) (const TableInfo &, uint64_t, uint64_t, TableReadResult &) FUNC>
void iris::IrisInstanceBuilder::setDefaultTableReadDelegate ( ) [inline]
```

Set the default table read function for all subsequently added tables.

Tables that do not explicitly override the access function using

```
addTable(...).setReadDelegate(...)
```

will use this delegate.

Usage:

```
iris::IrisErrorCode readTable(const iris::TableInfo &tableInfo, uint64_t index,
                             uint64_t count, iris::TableReadResult &result);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultTableReadDelegate(&readTable);
builder->addTable(...); // Uses readTable
```

## Template Parameters

<i>FUNC</i>	Global function to call to read a table.
-------------	--

## 8.17.3.11 setDefaultTableReadDelegate() [2/3]

```
template<typename T , IrisErrorCode(T::*)(const TableInfo &, uint64_t, uint64_t, TableReadResult &) METHOD>
```

```
void iris::IrisInstanceBuilder::setDefaultTableReadDelegate (
    T * instance ) [inline]
```

Set the default table read function for all subsequently added tables.

Tables that do not explicitly override the access function using

```
addTable(...).setReadDelegate(...)
```

will use this delegate.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode readTable(const iris::TableInfo &tableInfo, uint64_t index,
                                 uint64_t count, iris::TableReadResult &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultTableReadDelegate<MyClass, &MyClass::readTable>(&myInstanceOfMyClass);
builder->addTable(...); // Uses readTable
```

## Template Parameters

<i>T</i>	Class that defines a table read delegate method.
<i>METHOD</i>	A method of class T which is a table read delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

### 8.17.3.12 setDefaultTableReadDelegate() [3/3]

```
void iris::IrisInstanceBuilder::setDefaultTableReadDelegate (
    TableReadDelegate delegate = TableReadDelegate() ) [inline]
```

Set the default table read function for all subsequently added tables.

Tables that do not explicitly override the access function using

```
addTable(...).setReadDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` not\_implemented for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode readTable(const iris::TableInfo &tableInfo, uint64_t index,
                                uint64_t count, iris::TableReadResult &result);
};
MyClass myInstanceOfMyClass;
iris::TableReadDelegate delegate =
    iris::TableReadDelegate::make<MyClass, &MyClass::readTable>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultTableReadDelegate(delegate);
builder->addTable(...); // Uses readTable
```

#### Parameters

<i>delegate</i>	Delegate object to call to read a table.
-----------------	--

### 8.17.3.13 setDefaultTableWriteDelegate() [1/3]

```
template<IrisErrorCode(*)>(const TableInfo &, const TableRecords &, TableWriteResult &) FUNC>
void iris::IrisInstanceBuilder::setDefaultTableWriteDelegate ( ) [inline]
```

Set the default table write function for all subsequently added tables.

Tables that do not explicitly override the access function using

```
addTable(...).setWriteDelegate(...)
```

will use this delegate.

Usage:

```
iris::IrisErrorCode writeTable(const iris::TableInfo &tableInfo,
                              const iris::TableRecords &records,
                              iris::TableWriteResult &result);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultTableWriteDelegate(&writeTable);
builder->addTable(...); // Uses writeTable
```

#### Template Parameters

<i>FUNC</i>	Global function to call to write a table.
-------------	---

### 8.17.3.14 setDefaultTableWriteDelegate() [2/3]

```
template<typename T , IrisErrorCode(T::*)(const TableInfo &, const TableRecords &, Table↵
WriteResult &) METHOD>
```

```
void iris::IrisInstanceBuilder::setDefaultTableWriteDelegate (
    T * instance ) [inline]
```

Set the default table write function for all subsequently added tables.

Tables that do not explicitly override the access function using

```
addTable(...).setWriteDelegate(...)
```

will use this delegate.

Usage:

```
class MyClass
```

```

{
    ...
    iris::IrisErrorCode writeTable(const iris::TableInfo &tableInfo,
                                   const iris::TableRecords &records,
                                   iris::TableWriteResult &result);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultTableWriteDelegate<MyClass, &MyClass::writeTable>(&myInstanceOfMyClass);
builder->addTable(...); // Uses writeTable

```

#### Template Parameters

<i>T</i>	Class that defines a table write delegate method.
<i>METHOD</i>	A method of class T which is a table write delegate.

#### Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

#### 8.17.3.15 setDefaultTableWriteDelegate() [3/3]

```

void iris::IrisInstanceBuilder::setDefaultTableWriteDelegate (
    TableWriteDelegate delegate = TableWriteDelegate() ) [inline]

```

Set the default table write function for all subsequently added tables.

Tables that do not explicitly override the access function using

```
addTable(...).setWriteDelegate(...)
```

will use this delegate.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔ not_implemented` for all requests.

Usage:

```

class MyClass
{
    ...
    iris::IrisErrorCode writeTable(const iris::TableInfo &tableInfo,
                                   const iris::TableRecords &records,
                                   iris::TableWriteResult &result);
};
MyClass myInstanceOfMyClass;
iris::TableWriteDelegate delegate =
    iris::TableWriteDelegate::make<MyClass, &MyClass::writeTable>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setDefaultTableWriteDelegate(delegate);
builder->addTable(...); // Uses writeTable

```

#### Parameters

<i>delegate</i>	Delegate object to call to write a table.
-----------------	---

#### 8.17.3.16 setExecutionStateGetDelegate() [1/3]

```

template<IrisErrorCode(*) (bool &) FUNC>
void iris::IrisInstanceBuilder::setExecutionStateGetDelegate ( ) [inline]

```

Set the delegate to get the execution state for this instance.

Usage:

```

iris::IrisErrorCode getState(bool &execution_enabled);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setExecutionStateGetDelegate<&getState>();

```

#### Template Parameters

<i>FUNC</i>	Global function to call to get the execution state.
-------------	---

**8.17.3.17 setExecutionStateGetDelegate() [2/3]**

```
void iris::IrisInstanceBuilder::setExecutionStateGetDelegate (
    PerInstanceExecutionStateGetDelegate delegate ) [inline]
```

Set the delegate to get the execution state for this instance.

Passing an empty delegate (the default argument) restores the default implementation which always returns `E_↔` `not_implemented` for all requests.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getState(bool &execution_enabled);
};
MyClass myInstanceOfMyClass;
iris::PerInstanceExecutionStateGetDelegate delegate =
    iris::PerInstanceExecutionStateGetDelegate::make<MyClass, &MyClass::getState>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setExecutionStateGetDelegate(delegate);
```

Parameters

<i>delegate</i>	Delegate object to call to get the execution state.
-----------------	---

**8.17.3.18 setExecutionStateGetDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*)(bool &) METHOD>
void iris::IrisInstanceBuilder::setExecutionStateGetDelegate (
    T * instance ) [inline]
```

Set the delegate to get the execution state for this instance.

Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode getState(bool &execution_enabled);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setExecutionStateGetDelegate<MyClass, &MyClass::getState>(&myInstanceOfMyClass);
```

Template Parameters

<i>T</i>	Class that defines a get execution state delegate method.
<i>METHOD</i>	A method of class T which is a get execution state delegate.

Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

**8.17.3.19 setExecutionStateSetDelegate() [1/3]**

```
template<IrisErrorCode(*) (bool) FUNC>
void iris::IrisInstanceBuilder::setExecutionStateSetDelegate ( ) [inline]
```

Set the delegate to set the execution state for this instance.

Usage:

```
iris::IrisErrorCode setState(bool enable_execution);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setExecutionStateSetDelegate<&setState>();
```

## Template Parameters

<i>FUNC</i>	Global function to call to set the execution state.
-------------	---

## 8.17.3.20 setExecutionStateSetDelegate() [2/3]

```
void iris::IrisInstanceBuilder::setExecutionStateSetDelegate (
    PerInstanceExecutionStateSetDelegate delegate = PerInstanceExecutionStateSetDelegate()
) [inline]
```

Set the delegate to set the execution state for this instance.

Passing an empty delegate (the default argument) restores the default implementation which always returns E\_↔ not\_implemented for all requests.

## Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode setState(bool enable_execution);
};
MyClass myInstanceOfMyClass;
iris::PerInstanceExecutionStateSetDelegate delegate =
    iris::PerInstanceExecutionStateSetDelegate::make<MyClass, &MyClass::setState>(&myInstanceOfMyClass);
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setExecutionStateSetDelegate(delegate);
```

## Parameters

<i>delegate</i>	Delegate object to call to set the execution state.
-----------------	---

## 8.17.3.21 setExecutionStateSetDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(bool) METHOD>
void iris::IrisInstanceBuilder::setExecutionStateSetDelegate (
    T * instance ) [inline]
```

Set the delegate to set the execution state for this instance.

## Usage:

```
class MyClass
{
    ...
    iris::IrisErrorCode setState(bool enable_execution);
};
MyClass myInstanceOfMyClass;
iris::IrisInstanceBuilder *builder = myIrisInstance.getBuilder();
builder->setExecutionStateSetDelegate<MyClass, &MyClass::setState>(&myInstanceOfMyClass);
```

## Template Parameters

<i>T</i>	Class that defines a set execution state delegate method.
<i>METHOD</i>	A method of class T which is a set execution state delegate.

## Parameters

<i>instance</i>	An instance of class T on which METHOD should be called.
-----------------	--

## 8.17.3.22 setGetCurrentDisassemblyModeDelegate()

```
void iris::IrisInstanceBuilder::setGetCurrentDisassemblyModeDelegate (
    GetCurrentDisassemblyModeDelegate delegate ) [inline]
```

disass\_apis [IrisInstanceBuilder](#) disassembler APIs  
 Set the delegates to get the current disassembly mode  
 The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.18 iris::IrisInstanceCheckpoint Class Reference

Checkpoint add-on for [IrisInstance](#).

```
#include <IrisInstanceCheckpoint.h>
```

### Public Member Functions

- void [attachTo](#) ([IrisInstance](#) \*iris\_instance\_)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceCheckpoint](#) ([IrisInstance](#) \*iris\_instance=nullptr)
- void [setCheckpointRestoreDelegate](#) ([CheckpointRestoreDelegate](#) delegate)  
*Set checkpoint restore delegate for all checkpoints related to this instance.*
- void [setCheckpointSaveDelegate](#) ([CheckpointSaveDelegate](#) delegate)  
*Set checkpoint save delegate for all checkpoints related to this instance.*

#### 8.18.1 Detailed Description

Checkpoint add-on for [IrisInstance](#).

#### 8.18.2 Member Function Documentation

##### 8.18.2.1 attachTo()

```
void iris::IrisInstanceCheckpoint::attachTo (
    IrisInstance * iris_instance_ )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

Only use this method if nullptr was passed to the constructor.

##### Parameters

<i>iris_↔ instance_</i>	The <a href="#">IrisInstance</a> to attach to.
-----------------------------	--

##### 8.18.2.2 setCheckpointRestoreDelegate()

```
void iris::IrisInstanceCheckpoint::setCheckpointRestoreDelegate (
    CheckpointRestoreDelegate delegate )
```

Set checkpoint restore delegate for all checkpoints related to this instance.

##### Parameters

<i>delegate</i>	A <a href="#">CheckpointRestoreDelegate</a> to call when restoring a checkpoint.
-----------------	--

### 8.18.2.3 setCheckpointSaveDelegate()

```
void iris::IrisInstanceCheckpoint::setCheckpointSaveDelegate (
    CheckpointSaveDelegate delegate )
```

Set checkpoint save delegate for all checkpoints related to this instance.

#### Parameters

<i>delegate</i>	A CheckpointSaveDelegate to call when saving a checkpoint.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstanceCheckpoint.h](#)

## 8.19 iris::IrisInstanceDebuggableState Class Reference

Debuggable-state add-on for [IrisInstance](#).

```
#include <IrisInstanceDebuggableState.h>
```

### Public Member Functions

- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceDebuggableState](#) ([IrisInstance](#) \*iris\_instance=nullptr)
- void [setGetAcknowledgeDelegate](#) ([DebuggableStateGetAcknowledgeDelegate](#) delegate)  
*Set the get acknowledge flag delegate.*
- void [setSetRequestDelegate](#) ([DebuggableStateSetRequestDelegate](#) delegate)  
*Set the set request flag delegate.*

### 8.19.1 Detailed Description

Debuggable-state add-on for [IrisInstance](#).

### 8.19.2 Member Function Documentation

#### 8.19.2.1 attachTo()

```
void iris::IrisInstanceDebuggableState::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

#### 8.19.2.2 setGetAcknowledgeDelegate()

```
void iris::IrisInstanceDebuggableState::setGetAcknowledgeDelegate (
    DebuggableStateGetAcknowledgeDelegate delegate ) [inline]
```

Set the get acknowledge flag delegate.

#### Parameters

<i>delegate</i>	Delegate that will be called to get the debuggable-state acknowledge flag.
-----------------	--



### 8.19.2.3 setSetRequestDelegate()

```
void iris::IrisInstanceDebuggableState::setSetRequestDelegate (
    DebuggableStateSetRequestDelegate delegate ) [inline]
```

Set the set request flag delegate.

#### Parameters

<i>delegate</i>	Delegate that will be called to set or clear the debuggable-state request flag.
-----------------	---

The documentation for this class was generated from the following file:

- [IrisInstanceDebuggableState.h](#)

## 8.20 iris::IrisInstanceDisassembler Class Reference

Disassembler add-on for [IrisInstance](#).

```
#include <IrisInstanceDisassembler.h>
```

### Public Member Functions

- void [addDisassemblyMode](#) (const std::string &name, const std::string &description)  
*Add a disassembly mode.*
- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceDisassembler](#) ([IrisInstance](#) \*irisInstance=nullptr)  
*Construct an [IrisInstanceDisassembler](#).*
- void [setDisassembleOpcodeDelegate](#) ([DisassembleOpcodeDelegate](#) delegate)  
*Set the delegate to get the disassembly of Opcode.*
- void [setGetCurrentModeDelegate](#) ([GetCurrentDisassemblyModeDelegate](#) delegate)  
*Set the delegate to get the current disassembly mode.*
- void [setGetDisassemblyDelegate](#) ([GetDisassemblyDelegate](#) delegate)  
*Set the delegate to get the disassembly of a chunk of memory.*

### 8.20.1 Detailed Description

Disassembler add-on for [IrisInstance](#).

This class is used by instances that want to support disassembly functionality.

It implements all [Iris](#) [disassembler\\*\(\)](#) functions.

Example usage:

```
irisInstanceDisassembler = new iris::IrisInstanceDisassembler(irisInstance);
irisInstanceDisassembler->setGetCurrentModeDelegate(dasmCurrentModeGetDel); // Get the current disassembly
mode
irisInstanceDisassembler->setGetDisassemblyDelegate(dasmDisassemblyGetDel); // Get the disassembly of a
chunk of memory
irisInstanceDisassembler->setDisassembleOpcodeDelegate(dasmOpcodeDasmGetDel); // Disassemble specific
opcode
```

See [DummyComponent.h](#) for a working example.

The documentation for this class was generated from the following file:

- [IrisInstanceDisassembler.h](#)

## 8.21 iris::IrisInstanceEvent Class Reference

Event add-on for [IrisInstance](#).

```
#include <IrisInstanceEvent.h>
```

## Classes

- struct [EventSourceInfoAndDelegate](#)  
*Contains the metadata and delegates for a single EventSource.*
- struct [ProxyEventInfo](#)  
*Contains information for a single proxy EventSource.*

## Public Member Functions

- uint64\_t [addEventSource](#) (const [EventSourceInfoAndDelegate](#) &info)  
*Add metadata for an event source.*
- [EventSourceInfoAndDelegate](#) & [addEventSource](#) (const std::string &name, bool isHidden=false)  
*Add metadata for an event source.*
- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstanceEvent](#) add-on to a specific [IrisInstance](#).*
- void [deleteEventSource](#) (const std::string &eventName)  
*Delete metadata for an event source.*
- [EventSourceInfoAndDelegate](#) & [enhanceEventSource](#) (const std::string &name)  
*Enhance existing event source.*
- void [eventBufferClear](#) (EventBufferId evBufId)  
*Clear event buffer.*
- const uint64\_t \* [eventBufferGetSyncStepResponse](#) (EventBufferId evBufId, RequestId requestId)  
*Get response to step\_syncStep(), containing event data.*
- bool [hasEventSource](#) (const std::string &eventName)  
*Check if event source already exists.*
- [IrisInstanceEvent](#) ([IrisInstance](#) \*irisInstance=nullptr)  
*Construct an [IrisInstanceEvent](#) add-on.*
- bool [isValidEvBufId](#) (EventBufferId evBufId) const  
*Check whether event buffer id is valid.*
- void [setDefaultEsCreateDelegate](#) ([EventStreamCreateDelegate](#) delegate)  
*Set the default delegate for creating EventStreams for the attached instance.*

## Friends

- struct [EventBuffer](#)

### 8.21.1 Detailed Description

Event add-on for [IrisInstance](#).

This class is used by instances to support event functionality. Generally, there are two kinds of event sources:

- Iris-specific event sources. These are defined in the Iris spec, for example `IRIS_BREAKPOINT_HIT` and `IRIS_SIMULATION_TIME_EVENT`.
- Simulation-specific event sources. These are not defined in the Iris spec. They could be quite different for different simulations or instances. For example `INST` (every instruction executed).

This class implements all Iris `event*()` functions. It maintains event source information that is added by [addEventSource\(\)](#) and exposed by `event_getEventSources()` or `event_getEventSource()`. This class maintains all event streams. Iris-specific event streams are created by this add-on. Simulation-specific event streams are created by a delegate, which could be different for different simulations or instances.

### 8.21.2 Constructor & Destructor Documentation

### 8.21.2.1 IrisInstanceEvent()

```
iris::IrisInstanceEvent::IrisInstanceEvent (
    IrisInstance * irisInstance = nullptr )
```

Construct an [IrisInstanceEvent](#) add-on.

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to which to attach this add-on.
---------------------	--

## 8.21.3 Member Function Documentation

### 8.21.3.1 addEventSource() [1/2]

```
uint64_t iris::IrisInstanceEvent::addEventSource (
    const EventSourceInfoAndDelegate & info )
```

Add metadata for an event source.

#### Parameters

<i>info</i>	The metadata and event-specific delegates (if applicable) for a new event to add.
-------------	---

#### Returns

The evSrcId of the newly added event source.

### 8.21.3.2 addEventSource() [2/2]

```
EventSourceInfoAndDelegate & iris::IrisInstanceEvent::addEventSource (
    const std::string & name,
    bool isHidden = false )
```

Add metadata for an event source.

#### Parameters

<i>name</i>	The name of the event source.
<i>isHidden</i>	If true, this event source is hidden. The EventSourceInfo is not included in the list of event sources returned by <code>event_getEventSources()</code> but can still be accessed by <code>event_getEventSource()</code> if the client knows the name of the hidden event.

#### Returns

A reference to an object which keeps the metadata and event-specific delegates (if applicable) for this event. The reference is valid until the next call to [addEventSource\(\)](#).

### 8.21.3.3 attachTo()

```
void iris::IrisInstanceEvent::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstanceEvent](#) add-on to a specific [IrisInstance](#).

This should only be used if no instance was attached when this object was constructed.

## Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to which to attach this add-on.
---------------------	--

**8.21.3.4 deleteEventSource()**

```
void iris::IrisInstanceEvent::deleteEventSource (
    const std::string & eventName )
```

Delete metadata for an event source.

## Parameters

<i>eventName</i>	The name of the event source.
------------------	-------------------------------

**8.21.3.5 enhanceEventSource()**

```
EventSourceInfoAndDelegate & iris::IrisInstanceEvent::enhanceEventSource (
    const std::string & name )
```

Enhance existing event source.

## Parameters

<i>name</i>	The name of the event source.
-------------	-------------------------------

## Returns

A reference to an object which keeps the metadata and event-specific delegates (if applicable) for this event. The reference is valid until the next call to [addEventSource\(\)](#).

**8.21.3.6 eventBufferClear()**

```
void iris::IrisInstanceEvent::eventBufferClear (
    EventBufferId evBufId )
```

Clear event buffer.

This is separate from [eventBufferGetSyncStepResponse\(\)](#) so the message writer can be used to send the message without taking an unnecessary copy.

## Parameters

<i>ev↔ BufId</i>	The event buffer which is to be cleared.
----------------------	--

**8.21.3.7 eventBufferGetSyncStepResponse()**

```
const uint64_t * iris::IrisInstanceEvent::eventBufferGetSyncStepResponse (
    EventBufferId evBufId,
    RequestId requestId )
```

Get response to `step_syncStep()`, containing event data.

## Parameters

<i>evBufId</i>	The data of this event buffer is returned. This is set beforehand with <code>step_syncStepSetup()</code> .
<i>requestId</i>	This is the request id of the original <code>step_syncStep()</code> for which this function generates the answer.

## Returns

Response message to `step_syncStep()` call, containing the event data.

**8.21.3.8 hasEventSource()**

```
bool iris::IrisInstanceEvent::hasEventSource (
    const std::string & eventName )
```

Check if event source already exists.

## Parameters

<i>eventName</i>	The name of the event source.
------------------	-------------------------------

## Returns

True iff event source already exists.

**8.21.3.9 isValidEvBufId()**

```
bool iris::IrisInstanceEvent::isValidEvBufId (
    EventBufferId evBufId ) const
```

Check whether event buffer id is valid.

This function is use to validate event buffer ids.

## Returns

Returns true iff `evBufId` is a valid event buffer id.

**8.21.3.10 setDefaultEsCreateDelegate()**

```
void iris::IrisInstanceEvent::setDefaultEsCreateDelegate (
    EventStreamCreateDelegate delegate )
```

Set the default delegate for creating EventStreams for the attached instance.

## Parameters

<i>delegate</i>	A delegate that will be called to create an event stream for event sources in the attached instance that have not set an event source-specific delegate.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstanceEvent.h](#)

**8.22 iris::IrisInstanceFactoryBuilder Class Reference**

A builder class to construct instantiation parameter metadata.

#include <IrisInstanceFactoryBuilder.h>  
 Inherited by [iris::IrisPluginFactoryBuilder](#).

## Public Member Functions

- [IrisParameterBuilder addBooleanParameter](#) (const std::string &name, const std::string &description)  
*Add a new boolean parameter.*
- [IrisParameterBuilder addHiddenBooleanParameter](#) (const std::string &name, const std::string &description)  
*Add a new hidden boolean parameter.*
- [IrisParameterBuilder addHiddenParameter](#) (const std::string &name, uint64\_t bitWidth, const std::string &description)  
*Add a new hidden numeric parameter.*
- [IrisParameterBuilder addHiddenStringParameter](#) (const std::string &name, const std::string &description)  
*Add a new hidden string parameter.*
- [IrisParameterBuilder addParameter](#) (const std::string &name, uint64\_t bitWidth, const std::string &description)  
*Add a new numeric parameter.*
- [IrisParameterBuilder addStringParameter](#) (const std::string &name, const std::string &description)  
*Add a new string parameter.*
- const std::vector< ResourceInfo > &[getHiddenParameterInfo](#) () const  
*Get all ResourceInfo for hidden parameters.*
- const std::vector< ResourceInfo > &[getParameterInfo](#) () const  
*Get all ResourceInfo for non-hidden parameters.*
- [IrisInstanceFactoryBuilder](#) (const std::string &prefix)  
*Construct an [IrisInstanceFactoryBuilder](#).*

### 8.22.1 Detailed Description

A builder class to construct instantiation parameter metadata.

### 8.22.2 Constructor & Destructor Documentation

#### 8.22.2.1 IrisInstanceFactoryBuilder()

```
iris::IrisInstanceFactoryBuilder::IrisInstanceFactoryBuilder (
    const std::string & prefix ) [inline]
```

Construct an [IrisInstanceFactoryBuilder](#).

#### Parameters

<i>prefix</i>	All parameters added to this builder are prefixed with this string.
---------------	---

### 8.22.3 Member Function Documentation

#### 8.22.3.1 addBooleanParameter()

```
IrisParameterBuilder iris::IrisInstanceFactoryBuilder::addBooleanParameter (
    const std::string & name,
    const std::string & description ) [inline]
```

Add a new boolean parameter.

Boolean parameters are numeric parameters with a bitWidth of 1 and "true" and "false" enum symbols.

## Parameters

<i>name</i>	Name of the parameter.
<i>description</i>	Description of the parameter.

## Returns

An [IrisParameterBuilder](#) object which can be used to set further metadata for this parameter. The object is valid until another parameter is added.

**8.22.3.2 addHiddenBooleanParameter()**

```
IrisParameterBuilder iris::IrisInstanceFactoryBuilder::addHiddenBooleanParameter (
    const std::string & name,
    const std::string & description ) [inline]
```

Add a new hidden boolean parameter.

Boolean parameters are numeric parameters with a bitWidth of 1 and "true" and "false" enum symbols.

## Parameters

<i>name</i>	Name of the parameter.
<i>description</i>	Description of the parameter.

## Returns

An [IrisParameterBuilder](#) object which can be used to set further metadata for this parameter. The object is valid until another parameter is added.

**8.22.3.3 addHiddenParameter()**

```
IrisParameterBuilder iris::IrisInstanceFactoryBuilder::addHiddenParameter (
    const std::string & name,
    uint64_t bitWidth,
    const std::string & description ) [inline]
```

Add a new hidden numeric parameter.

## Parameters

<i>name</i>	Name of the parameter.
<i>bitWidth</i>	Width of the parameter in bits.
<i>description</i>	Description of the parameter.

## Returns

An [IrisParameterBuilder](#) object which can be used to set further metadata for this parameter. The object is valid until another parameter is added.

**8.22.3.4 addHiddenStringParameter()**

```
IrisParameterBuilder iris::IrisInstanceFactoryBuilder::addHiddenStringParameter (
    const std::string & name,
    const std::string & description ) [inline]
```



Add a new hidden string parameter.

## Parameters

<i>name</i>	Name of the parameter.
<i>description</i>	Description of the parameter.

## Returns

An [IrisParameterBuilder](#) object which can be used to set further metadata for this parameter. The object is valid until another parameter is added.

**8.22.3.5 addParameter()**

```
IrisParameterBuilder iris::IrisInstanceFactoryBuilder::addParameter (
    const std::string & name,
    uint64_t bitWidth,
    const std::string & description ) [inline]
```

Add a new numeric parameter.

## Parameters

<i>name</i>	Name of the parameter.
<i>bitWidth</i>	Width of the parameter in bits.
<i>description</i>	Description of the parameter.

## Returns

An [IrisParameterBuilder](#) object which can be used to set further metadata for this parameter. The object is valid until another parameter is added.

**8.22.3.6 addStringParameter()**

```
IrisParameterBuilder iris::IrisInstanceFactoryBuilder::addStringParameter (
    const std::string & name,
    const std::string & description ) [inline]
```

Add a new string parameter.

## Parameters

<i>name</i>	Name of the parameter.
<i>description</i>	Description of the parameter.

## Returns

An [IrisParameterBuilder](#) object which can be used to set further metadata for this parameter. The object is valid until another parameter is added.

**8.22.3.7 getHiddenParameterInfo()**

```
const std::vector< ResourceInfo > & iris::IrisInstanceFactoryBuilder::getHiddenParameterInfo (
) const [inline]
```

Get all ResourceInfo for hidden parameters.

**Returns**

A vector of ResourceInfo. Iterators for this vector are invalidated if a new hidden parameter is added.

**8.22.3.8 getParameterInfo()**

```
const std::vector< ResourceInfo > & iris::IrisInstanceFactoryBuilder::getParameterInfo ( )
const [inline]
```

Get all ResourceInfo for non-hidden parameters.

**Returns**

A vector of ResourceInfo. Iterators for this vector are invalidated if a new non-hidden parameter is added.

The documentation for this class was generated from the following file:

- [IrisInstanceFactoryBuilder.h](#)

**8.23 iris::IrisInstanceImage Class Reference**

Image loading add-on for [IrisInstance](#).

```
#include <IrisInstanceImage.h>
```

**Public Member Functions**

- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceImage](#) ([IrisInstance](#) \*irisInstance=0)  
*Construct a new [IrisInstanceImage](#).*
- void [setLoadImageDataDelegate](#) ([ImageLoadDataDelegate](#) delegate)  
*Set image loading from (pushed/pulled) data delegate.*
- void [setLoadImageFileDelegate](#) ([ImageLoadFileDelegate](#) delegate)  
*Set image loading from file delegate.*

**Static Public Member Functions**

- static IrisErrorCode [readFileData](#) (const std::string &fileName, std::vector< uint8\_t > &data)  
*Read file data into a uint8\_t array.*

**8.23.1 Detailed Description**

Image loading add-on for [IrisInstance](#).

This class is used by instances to support image loading. It is also used by instances that want to use [image\\_loadDataPull\(\)](#) to implement the [image\\_loadDataRead\(\)](#) callback.

This class implements the [Iris image\\*\(\)](#) functions. It maintains or implements two main things:

- Functions to load images:
  - From a file, by [image\\_loadFile\(\)](#), or from a data buffer, by [image\\_loadData\(\)](#) or [image\\_loadDataPull\(\)](#).
  - As raw data, by specifying [rawAddr](#) and [rawSpaceId](#).
- Image meta information, which is exposed by [image\\_getMetaInfoList\(\)](#) or cleared by [image\\_clearMetaInfoList\(\)](#).

See DummyComponent.h for a working example.

**8.23.2 Constructor & Destructor Documentation**

### 8.23.2.1 IrisInstanceImage()

```
iris::IrisInstanceImage::IrisInstanceImage (
    IrisInstance * irisInstance = 0 )
```

Construct a new [IrisInstanceImage](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

## 8.23.3 Member Function Documentation

### 8.23.3.1 attachTo()

```
void iris::IrisInstanceImage::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

### 8.23.3.2 readFileData()

```
static IrisErrorCode iris::IrisInstanceImage::readFileData (
    const std::string & fileName,
    std::vector< uint8_t > & data ) [static]
```

Read file data into a `uint8_t` array.

#### Parameters

<i>fileName</i>	Name of the file to read.
<i>data</i>	A reference to a vector which is populated with the file contents.

#### Returns

An error code indicating success or failure.

### 8.23.3.3 setLoadImageDataDelegate()

```
void iris::IrisInstanceImage::setLoadImageDataDelegate (
    ImageLoadDataDelegate delegate )
```

Set image loading from (pushed/pulled) data delegate.

#### Parameters

<i>delegate</i>	The delegate that will be called to load an image from a data buffer.
-----------------	---

### 8.23.3.4 setLoadImageFileDelegate()

```
void iris::IrisInstanceImage::setLoadImageFileDelegate (
    ImageLoadFileDelegate delegate )
```

Set image loading from file delegate.

#### Parameters

<i>delegate</i>	The delegate that will be called to load an image from a file.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstancelImage.h](#)

## 8.24 iris::IrisInstancelImage\_Callback Class Reference

Image loading add-on for [IrisInstance](#) clients implementing `image_loadDataRead()`.

```
#include <IrisInstanceImage.h>
```

### Public Member Functions

- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstancelImage\\_Callback](#) ([IrisInstance](#) \*irisInstance=0)  
*Construct an [IrisInstancelImage\\_Callback](#) add-on.*
- uint64\_t [openImage](#) (const std::string &fileName)  
*Open an image for reading.*

### Protected Member Functions

- void [impl\\_image\\_loadDataRead](#) (IrisReceivedRequest &request)  
*Implementation of the [Iris](#) function [image\\_loadDataRead\(\)](#).*

### 8.24.1 Detailed Description

Image loading add-on for [IrisInstance](#) clients implementing `image_loadDataRead()`.

This is used by instances that call the instances supporting `image_loadDataPull()`.

This class maintains/implements:

- [Iris](#) `image_loadDataRead()` function.
- Image opening, data reading.
- Tags of images.

### 8.24.2 Constructor & Destructor Documentation

#### 8.24.2.1 IrisInstancelImage\_Callback()

```
iris::IrisInstanceImage_Callback::IrisInstanceImage_Callback (
    IrisInstance * irisInstance = 0 )
```

Construct an [IrisInstancelImage\\_Callback](#) add-on.

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

### 8.24.3 Member Function Documentation

#### 8.24.3.1 attachTo()

```
void iris::IrisInstanceImage_Callback::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

##### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

#### 8.24.3.2 openImage()

```
uint64_t iris::IrisInstanceImage_Callback::openImage (
    const std::string & fileName )
```

Open an image for reading.

##### Parameters

<i>fileName</i>	File name of the image file to read.
-----------------	--------------------------------------

##### Returns

An opaque tag number that is passed to `image_loadDataRead()` to identify the file to read from. This returns `iris::IRIS_UINT64_MAX` on failure to open the image.

The documentation for this class was generated from the following file:

- [IrisInstanceImage.h](#)

## 8.25 iris::IrisInstanceMemory Class Reference

Memory add-on for [IrisInstance](#).

```
#include <IrisInstanceMemory.h>
```

### Classes

- struct [AddressTranslationInfoAndAccess](#)  
*Contains static address translation information.*
- struct [SpaceInfoAndAccess](#)  
*Entry in 'spaceInfos'.*

### Public Member Functions

- [AddressTranslationInfoAndAccess](#) & [addAddressTranslation](#) (MemorySpaceId inSpaceId, MemorySpaceId outSpaceId, const std::string &description)  
*Add one memory address translation as well as the translate interface.*
- [SpaceInfoAndAccess](#) & [addMemorySpace](#) (const std::string &name)  
*Add meta information for one memory space.*
- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceMemory](#) ([IrisInstance](#) \*irisInstance=0)

Construct an [IrisInstanceMemory](#).

- void [setDefaultGetSidebandInfoDelegate](#) ([MemoryGetSidebandInfoDelegate](#) delegate=[MemoryGetSidebandInfoDelegate](#)())  
Set the default delegate to retrieve sideband information.
- void [setDefaultReadDelegate](#) ([MemoryReadDelegate](#) delegate=[MemoryReadDelegate](#)())  
Set default read function for all subsequently added memory spaces.
- void [setDefaultTranslateDelegate](#) ([MemoryAddressTranslateDelegate](#) delegate=[MemoryAddressTranslateDelegate](#)())  
Set the default memory translation delegate.
- void [setDefaultWriteDelegate](#) ([MemoryWriteDelegate](#) delegate=[MemoryWriteDelegate](#)())  
Set default write function for all subsequently added memory spaces.

### 8.25.1 Detailed Description

Memory add-on for [IrisInstance](#).

This class is used by instances to expose their own memory.

It implements all `Iris memory*()` functions. It maintains/implements two main things:

- Memory space meta information (exposed by `memory_getMemorySpaces()`).
- Forwarding memory read/write and address translate accesses to functions with a simple prototype which is easy to implement by components, hiding a lot of the complexity of `memory_read()`, `memory_write()`, and `memory_translateAddress()`.

Example usage:

```
irisInstance = new iris::IrisInstance(irisInterface, instanceName);
irisInstanceMemory = new iris::IrisInstanceMemory(irisInstance);
// Use these delegates for read/write for all following memory spaces.
irisInstanceMemory->setDefaultReadDelegate<DummyComponent, &DummyComponent::readMemory>(this);
irisInstanceMemory->setDefaultWriteDelegate<DummyComponent, &DummyComponent::writeMemory>(this);
irisInstanceMemory->addMemorySpace("Memory"); // Add a memory address space.
```

See [setDefaultReadDelegate\(\)](#) for an example of read/write delegates.

See `DummyComponent.h` for a working example.

See also

[IrisInstanceBuilder](#) memory APIs

## 8.25.2 Constructor & Destructor Documentation

### 8.25.2.1 IrisInstanceMemory()

```
iris::IrisInstanceMemory::IrisInstanceMemory (
    IrisInstance * irisInstance = 0 )
```

Construct an [IrisInstanceMemory](#).

Optionally attaches to an [IrisInstance](#).

Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

## 8.25.3 Member Function Documentation

### 8.25.3.1 addAddressTranslation()

```
AddressTranslationInfoAndAccess & iris::IrisInstanceMemory::addAddressTranslation (
    MemorySpaceId inSpaceId,
```

```
MemorySpaceId outSpaceId,
const std::string & description )
```

Add one memory address translation as well as the translate interface.

#### Parameters

<i>inSpaceId</i>	Memory space id for the input memory space of this translation.
<i>out↔SpaceId</i>	Memory space id for the output memory space of this translation.
<i>description</i>	A human-readable description of this translation.

#### Returns

A reference to an [AddressTranslationInfoAndAccess](#) object for the new translation. This reference is valid until the next time [addAddressTranslation\(\)](#) is called.

### 8.25.3.2 addMemorySpace()

```
SpaceInfoAndAccess & iris::IrisInstanceMemory::addMemorySpace (
    const std::string & name )
```

Add meta information for one memory space.

#### Parameters

<i>name</i>	Name of the memory space.
-------------	---------------------------

#### Returns

A reference to a [SpaceInfoAndAccess](#) object for this new memory space. This reference is valid until the next time [addMemorySpace\(\)](#) is called.

### 8.25.3.3 attachTo()

```
void iris::IrisInstanceMemory::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

### 8.25.3.4 setDefaultGetSidebandInfoDelegate()

```
void iris::IrisInstanceMemory::setDefaultGetSidebandInfoDelegate (
    MemoryGetSidebandInfoDelegate delegate = MemoryGetSidebandInfoDelegate() ) [inline]
```

Set the default delegate to retrieve sideband information.

#### Parameters

<i>delegate</i>	Delegate object which will be called to get sideband information for a memory space.
-----------------	--



### 8.25.3.5 setDefaultReadDelegate()

```
void iris::IrisInstanceMemory::setDefaultReadDelegate (
    MemoryReadDelegate delegate = MemoryReadDelegate() ) [inline]
```

Set default read function for all subsequently added memory spaces.

#### Parameters

<i>delegate</i>	Delegate object which will be called to read memory.
-----------------	--

### 8.25.3.6 setDefaultTranslateDelegate()

```
void iris::IrisInstanceMemory::setDefaultTranslateDelegate (
    MemoryAddressTranslateDelegate delegate = MemoryAddressTranslateDelegate() )
[inline]
```

Set the default memory translation delegate.

#### Parameters

<i>delegate</i>	Delegate object which will be called to translate addresses.
-----------------	--

### 8.25.3.7 setDefaultWriteDelegate()

```
void iris::IrisInstanceMemory::setDefaultWriteDelegate (
    MemoryWriteDelegate delegate = MemoryWriteDelegate() ) [inline]
```

Set default write function for all subsequently added memory spaces.

#### Parameters

<i>delegate</i>	Delegate object which will be called to write memory.
-----------------	---

The documentation for this class was generated from the following file:

- [IrisInstanceMemory.h](#)

## 8.26 iris::IrisInstancePerInstanceExecution Class Reference

Per-instance execution control add-on for [IrisInstance](#).

```
#include <IrisInstancePerInstanceExecution.h>
```

### Public Member Functions

- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
Attach this [IrisInstancePerInstanceExecution](#) add-on to a specific [IrisInstance](#).
- [IrisInstancePerInstanceExecution](#) ([IrisInstance](#) \*irisInstance=nullptr)  
Construct an [IrisInstancePerInstanceExecution](#) add-on.
- void [setExecutionStateGetDelegate](#) ([PerInstanceExecutionStateGetDelegate](#) delegate)  
Set the delegate for getting execution state.
- void [setExecutionStateSetDelegate](#) ([PerInstanceExecutionStateSetDelegate](#) delegate)  
Set the delegate for setting execution state.

### 8.26.1 Detailed Description

Per-instance execution control add-on for [IrisInstance](#).

This class is used by instances to support per-instance execution control functionality.

This class implements all `Iris perInstanceExecution*()` functions.

### 8.26.2 Constructor & Destructor Documentation

#### 8.26.2.1 IrisInstancePerInstanceExecution()

```
iris::IrisInstancePerInstanceExecution::IrisInstancePerInstanceExecution (
    IrisInstance * irisInstance = nullptr )
```

Construct an [IrisInstancePerInstanceExecution](#) add-on.

Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

### 8.26.3 Member Function Documentation

#### 8.26.3.1 attachTo()

```
void iris::IrisInstancePerInstanceExecution::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstancePerInstanceExecution](#) add-on to a specific [IrisInstance](#).

This should only be used if no instance was attached when this object was constructed.

Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

#### 8.26.3.2 setExecutionStateGetDelegate()

```
void iris::IrisInstancePerInstanceExecution::setExecutionStateGetDelegate (
    PerInstanceExecutionStateGetDelegate delegate )
```

Set the delegate for getting execution state.

Parameters

<i>delegate</i>	A delegate object which will be called to get the current execution state for the attached instance.
-----------------	--

#### 8.26.3.3 setExecutionStateSetDelegate()

```
void iris::IrisInstancePerInstanceExecution::setExecutionStateSetDelegate (
    PerInstanceExecutionStateSetDelegate delegate )
```

Set the delegate for setting execution state.

Parameters

<i>delegate</i>	A delegate object which will be called to set execution state for the attached instance.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstancePerInstanceExecution.h](#)

## 8.27 iris::IrisInstanceResource Class Reference

Resource add-on for [IrisInstance](#).

```
#include <IrisInstanceResource.h>
```

### Classes

- struct [ResourceInfoAndAccess](#)  
*Entry in 'resourceInfos'.*

### Public Member Functions

- [ResourceInfoAndAccess](#) & [addResource](#) (const std::string &type, const std::string &name, const std::string &description)  
*Add a new resource.*
- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- void [beginResourceGroup](#) (const std::string &name, const std::string &description, uint64\_t startSubRscId=IRIS\_UINT64\_MAX, const std::string &cname=std::string())  
*Begin a new resource group.*
- [ResourceInfoAndAccess](#) \* [getResourceInfo](#) (ResourceId rscId)  
*Get the resource info for a resource that was already added.*
- [IrisInstanceResource](#) ([IrisInstance](#) \*irisInstance=0)  
*Construct an [IrisInstanceResource](#).*
- void [setNextSubRscId](#) (ResourceId nextSubRscId\_)  
*Set next subRscId.*
- void [setTag](#) (ResourceId rscId, const std::string &tag)  
*Set a tag for a specific resource.*

### Static Public Member Functions

- static void [calcHierarchicalNames](#) (std::vector< ResourceInfo > &resourceInfos)  
*Calculate hierarchicalName and hierarchicalCName for all RegisterInfos.*
- static void [makeNamesHierarchical](#) (std::vector< ResourceInfo > &resourceInfos)  
*Make name and cname of RegisterInfos hierarchical.*

### Protected Member Functions

- void [impl\\_resource\\_getList](#) (IrisReceivedRequest &request)
- void [impl\\_resource\\_getListOfResourceGroups](#) (IrisReceivedRequest &request)
- void [impl\\_resource\\_getResourceInfo](#) (IrisReceivedRequest &request)
- void [impl\\_resource\\_read](#) (IrisReceivedRequest &request)
- void [impl\\_resource\\_write](#) (IrisReceivedRequest &request)

#### 8.27.1 Detailed Description

Resource add-on for [IrisInstance](#).

This class implements all Iris resource\*() functions. It maintains/implements two main things:

- Resource meta information that is exposed by [resource\\_getList\(\)](#) and [resource\\_getListOfResourceGroups\(\)](#).
- Forwarding resource read/write accesses to functions with a simple prototype which is easy to implement by components, hiding a lot of the complexity of [resource\\_read\(\)](#) and [resource\\_write\(\)](#).

In most cases, an instance should not use [IrisInstanceResource](#) directly but should use [IrisInstanceBuilder](#) instead.

## 8.27.2 Constructor & Destructor Documentation

### 8.27.2.1 IrisInstanceResource()

```
iris::IrisInstanceResource::IrisInstanceResource (
    IrisInstance * irisInstance = 0 )
```

Construct an [IrisInstanceResource](#).

Optionally attaches to an [IrisInstance](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

## 8.27.3 Member Function Documentation

### 8.27.3.1 addResource()

```
ResourceInfoAndAccess & iris::IrisInstanceResource::addResource (
    const std::string & type,
    const std::string & name,
    const std::string & description )
```

Add a new resource.

#### Parameters

<i>type</i>	The type of the resource. This should be one of: <ul style="list-style-type: none"> <li>• "numeric"</li> <li>• "numericFp"</li> <li>• "String"</li> <li>• "noValue"</li> </ul>
<i>name</i>	The name of the resource.
<i>description</i>	A human-readable description of the resource.

#### Returns

A reference to a [ResourceInfoAndAccess](#) object for this new resource. This reference is valid until the next time [addResource\(\)](#) is called.

### 8.27.3.2 attachTo()

```
void iris::IrisInstanceResource::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach to.
---------------------	--

### 8.27.3.3 beginResourceGroup()

```
void iris::IrisInstanceResource::beginResourceGroup (
    const std::string & name,
    const std::string & description,
    uint64_t startSubRscId = IRIS_UINT64_MAX,
    const std::string & cname = std::string() )
```

Begin a new resource group.

This method has these effects:

- Add a resource group (only if it does not yet exist).
- Assign all resources that are added through [addResource\(\)](#) calls to this group.

#### Parameters

<i>name</i>	The name of the resource group.
<i>description</i>	A description of this resource group.
<i>startSubRscId</i>	If not IRIS_UINT64_MAX start counting from this subRscId when new resources are added.
<i>cname</i>	A C identifier version of the resource name if different from <i>name</i> .

### 8.27.3.4 calcHierarchicalNames()

```
static void iris::IrisInstanceResource::calcHierarchicalNames (
    std::vector< ResourceInfo > & resourceInfos ) [static]
```

Calculate hierarchicalName and hierarchicalCName for all RegisterInfos.

RegisterInfo.hierarchicalName and RegisterInfo.hierarchicalCName are set to the hierarchical name for each resource such that a child register X of parent FLAGS gets hierarchicalName=FLAGS.X and hierarchicalCName=FLAGS\_X, similarly also for deeper nesting levels.

This functionality is not an Iris interface but just a convenience function for simple clients. The ResourceInfos returned by [IrisInstance::getResourceInfo\\*](#)() have already hierarchical names.

No errors are generated for missing parent resources. parentRscId links to missing parent resources are silently ignored. The intended usage is to call this function on a list containing all resources or all registers of an instance, so that all parent links can be resolved.

#### Parameters

<i>resourceInfos</i>	Array of all ResourceInfos of an instance.
----------------------	--

### 8.27.3.5 getResourceInfo()

```
ResourceInfoAndAccess * iris::IrisInstanceResource::getResourceInfo (
    ResourceId rscId )
```

Get the resource info for a resource that was already added.

#### Parameters

<i>rscId</i>	A resource id for a resource that was already added.
--------------	--

**Returns**

A pointer to the [ResourceInfoAndAccess](#) object for the requested resource. This pointer is valid until the next call to [addResource\(\)](#). If *rscId* is not a valid id, this function returns nullptr.

**8.27.3.6 makeNamesHierarchical()**

```
static void iris::IrisInstanceResource::makeNamesHierarchical (
    std::vector< ResourceInfo > & resourceInfos ) [static]
```

Make name and cname of RegisterInfos hierarchical.

Legacy function overwriting ResourceInfo.name/cname.

This function calculates the hierarchical names using [calcHierarchicalNames\(\)](#) and then copies ResourceInfo.↔ hierarchicalName/hierarchicalCName into ResourceInfo.name/cname info, respectively.

Consider using [calcHierarchicalNames\(\)](#) which does not alter the original resource information.

**Parameters**

<i>resourceInfos</i>	Array of all ResourceInfos of an instance.
----------------------	--

**8.27.3.7 setNextSubRscId()**

```
void iris::IrisInstanceResource::setNextSubRscId (
    ResourceId nextSubRscId_ ) [inline]
```

Set next subRscId.

Resources that are added following this call are assigned subRscIds starting at nextSubRscId unless nextSubRscId is IRIS\_UINT64\_MAX, in which case all further resources are assigned IRIS\_UINT64\_MAX as the subRscId

**Parameters**

<i>nextSubRsc↔ Id_</i>	Next subRscId
----------------------------	------------------

**8.27.3.8 setTag()**

```
void iris::IrisInstanceResource::setTag (
    ResourceId rscId,
    const std::string & tag )
```

Set a tag for a specific resource.

**Parameters**

<i>rsc↔ Id</i>	Resource Id for the resource that will have this tag set.
<i>tag</i>	Name of the boolean tag which will be set to true.

**See also**

[IrisInstanceBuilder::setTag](#)

The documentation for this class was generated from the following file:

- [IrisInstanceResource.h](#)

## 8.28 iris::IrisInstanceSemihosting Class Reference

### Public Member Functions

- void [attachTo](#) ([IrisInstance](#) \*iris\_instance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- void [enableExtensions](#) ()  
*Instances that support semihosting extensions should call this method to enable the `IRIS_SEMIHOSTING_CALL_EXTENSION` event.*
- [IrisInstanceSemihosting](#) ([IrisInstance](#) \*iris\_instance=nullptr, [IrisInstanceEvent](#) \*inst\_event=nullptr)
- std::vector< uint8\_t > [readData](#) (uint64\_t fDes, uint64\_t max\_size=0, uint64\_t flags=semihost::DEFAULT)  
*Read data for a given file descriptor.*
- std::pair< bool, uint64\_t > [semihostedCall](#) (uint64\_t operation, uint64\_t parameter)  
*Allow a client to perform a semihosting extension defined by operation and parameter.*
- void [setEventHandler](#) ([IrisInstanceEvent](#) \*handler)  
*Set the corresponding [IrisInstanceEvent](#) object to use to manage semihosting events.*
- void [unblock](#) ()  
*Request premature exit from any blocking requests that are currently blocked.*
- bool [writeData](#) (uint64\_t fDes, const uint8\_t \*data, uint64\_t size)

### 8.28.1 Member Function Documentation

#### 8.28.1.1 attachTo()

```
void iris::IrisInstanceSemihosting::attachTo (
    IrisInstance * iris_instance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

##### Parameters

<i>iris_instance</i>	The instance to attach to.
----------------------	----------------------------

#### 8.28.1.2 readData()

```
std::vector< uint8_t > iris::IrisInstanceSemihosting::readData (
    uint64_t fDes,
    uint64_t max_size = 0,
    uint64_t flags = semihost::DEFAULT )
```

Read data for a given file descriptor.

The exact behavior of this method depends on the value of the max\_size and flags parameters. If the NONBLOCK flag is set, the method returns immediately with whatever data is already buffered, if any. If NONBLOCK is not set, the method blocks until data is available. Iris messages continue to be processed while this methods blocks. If max\_size is not zero, then at most max\_size bytes will be returned.

##### Parameters

<i>fDes</i>	File descriptor to read from. Usually semihost::STDIN.
<i>max_size</i>	The maximum amount of bytes to read or zero for no limit.
<i>flags</i>	A bitwise OR of <a href="#">Semihosting data request flag constants</a>

**Returns**

A vector of data that was read.

**8.28.1.3 semihostedCall()**

```
std::pair< bool, uint64_t > iris::IrisInstanceSemihosting::semihostedCall (
    uint64_t operation,
    uint64_t parameter )
```

Allow a client to perform a semihosting extension defined by *operation* and *parameter*.

This might implement a user-defined operation or override the default implementation for a predefined operation.

**Parameters**

<i>operation</i>	A number indicating the operation to perform. This is defined by the semihosting standard for standard operations or by the client for user-defined operations.
<i>parameter</i>	A parameter to the operation. This meaning of this parameter is defined by the operation.

**Returns**

A pair of (bool success, uint64\_t result). If status is true, a client performed the function and returned the value in result. If status is false, no client performed the function and result is 0.

**8.28.1.4 setEventHandler()**

```
void iris::IrisInstanceSemihosting::setEventHandler (
    IrisInstanceEvent * handler )
```

Set the corresponding [IrisInstanceEvent](#) object to use to manage semihosting events.

This must not be called more than once and must be called with an Event add-on that is attached to the same [IrisInstance](#) as this semihosting add-on.

**Parameters**

<i>handler</i>	The event add-on for this Iris instance.
----------------	--

The documentation for this class was generated from the following file:

- [IrisInstanceSemihosting.h](#)

**8.29 iris::IrisInstanceSimulation Class Reference**

An [IrisInstance](#) add-on that adds simulation functions for the SimulationEngine instance.

```
#include <IrisInstanceSimulation.h>
```

**Public Member Functions**

- void [attachTo](#) ([IrisInstance](#) \*iris\_instance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- void [enterPostInstantiationPhase](#) ()  
*Move from the pre-instantiation to the post-instantiation phase.*
- [IrisInstanceSimulation](#) ([IrisInstance](#) \*iris\_instance=nullptr, [IrisConnectionInterface](#) \*connection\_↔ interface=nullptr)  
*Construct an [IrisInstanceSimulation](#) add-on.*
- void [notifySimPhase](#) (uint64\_t time, [IrisSimulationPhase](#) phase)



- Emit an IRIS\_SIM\_PHASE\* event for the supplied phase.*

  - void [registerSimEventsOnGlobalInstance](#) ()

*Register all simulation engine events as proxy events on the global iris instance.*
- void [setConnectionInterface](#) (IrisConnectionInterface \*connection\_interface\_)

*Set the IrisConnectionInterface to use for the instantiation.*
- void [setEventHandler](#) (IrisInstanceEvent \*handler)

*Set up IRIS\_SIM\_PHASE\* events.*
- template<IrisErrorCode(\*)>(std::vector< ResourceInfo > &) FUNC<>  
void [setGetParameterInfoDelegate](#) (bool cache\_result=true)

*Set the getParameterInfo() delegate.*
- void [setGetParameterInfoDelegate](#) (SimulationGetParameterInfoDelegate delegate, bool cache\_result=true)

*Set the getParameterInfo() delegate.*
- template<typename T , IrisErrorCode(T::\*)>(std::vector< ResourceInfo > &) METHOD<>  
void [setGetParameterInfoDelegate](#) (T \*instance, bool cache\_result=true)

*Set the getParameterInfo() delegate.*
- template<IrisErrorCode(\*)>(InstantiationResult &) FUNC<>  
void [setInstantiateDelegate](#) ()

*Set the instantiate() delegate.*
- void [setInstantiateDelegate](#) (SimulationInstantiateDelegate delegate)

*Set the instantiate() delegate.*
- template<typename T , IrisErrorCode(T::\*)>(InstantiationResult &) METHOD<>  
void [setInstantiateDelegate](#) (T \*instance)

*Set the instantiate() delegate.*
- void [setLogLevel](#) (unsigned logLevel\_)

*Set log level (0-1).*
- template<IrisErrorCode(\*)>() FUNC<>  
void [setRequestShutdownDelegate](#) ()

*Set the requestShutdown() delegate.*
- void [setRequestShutdownDelegate](#) (SimulationRequestShutdownDelegate delegate)

*Set the requestShutdown() delegate.*
- template<typename T , IrisErrorCode(T::\*)>() METHOD<>  
void [setRequestShutdownDelegate](#) (T \*instance)

*Set the requestShutdown() delegate.*
- template<IrisErrorCode(\*)>(const IrisSimulationResetContext &) FUNC<>  
void [setResetDelegate](#) ()

*Set the reset() delegate.*
- void [setResetDelegate](#) (SimulationResetDelegate delegate)

*Set the reset() delegate.*
- template<typename T , IrisErrorCode(T::\*)>(const IrisSimulationResetContext &) METHOD<>  
void [setResetDelegate](#) (T \*instance)

*Set the reset() delegate.*
- template<IrisErrorCode(\*)>(const InstantiationParameterValue &) FUNC<>  
void [setSetParameterValueDelegate](#) ()

*Set the setParameterValue() delegate.*
- void [setSetParameterValueDelegate](#) (SimulationSetParameterValueDelegate delegate)

*Set the setParameterValue() delegate.*
- template<typename T , IrisErrorCode(T::\*)>(const InstantiationParameterValue &) METHOD<>  
void [setSetParameterValueDelegate](#) (T \*instance)

*Set the setParameterValue() delegate.*

## Static Public Member Functions

- static std::string [getSimulationPhaseDescription](#) ([IrisSimulationPhase](#) phase)  
*Get dexcription string for a simulation phase.*
- static std::string [getSimulationPhaseName](#) ([IrisSimulationPhase](#) phase)  
*Get name of the enum symbol for name.*

### 8.29.1 Detailed Description

An [IrisInstance](#) add-on that adds simulation functions for the SimulationEngine instance.

### 8.29.2 Constructor & Destructor Documentation

#### 8.29.2.1 IrisInstanceSimulation()

```
iris::IrisInstanceSimulation::IrisInstanceSimulation (
    IrisInstance * iris_instance = nullptr,
    IrisConnectionInterface * connection_interface = nullptr )
```

Construct an [IrisInstanceSimulation](#) add-on.

##### Parameters

<i>iris_instance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
<i>connection_interface</i>	The connection interface that will be used when the simulation is instantiated.

### 8.29.3 Member Function Documentation

#### 8.29.3.1 attachTo()

```
void iris::IrisInstanceSimulation::attachTo (
    IrisInstance * iris_instance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

##### Parameters

<i>iris_instance</i>	The <a href="#">IrisInstance</a> to attach to.
----------------------	--

#### 8.29.3.2 enterPostInstantiationPhase()

```
void iris::IrisInstanceSimulation::enterPostInstantiationPhase ( )
```

Move from the pre-instantiation to the post-instantiation phase.

This effects which functions are published. Only call this function if the simulation is instantiated outside of Iris. This object automatically enters post-instantiation phase when the simulation is successfully instantiated by an Iris call to `simulation_instantiate()`.

#### 8.29.3.3 getSimulationPhaseDescription()

```
static std::string iris::IrisInstanceSimulation::getSimulationPhaseDescription (
    IrisSimulationPhase phase ) [static]
```

Get dexcription string for a simulation phase.

This is a free form single line text ending with a dot.

#### 8.29.3.4 getSimulationPhaseName()

```
static std::string iris::IrisInstanceSimulation::getSimulationPhaseName (
    IrisSimulationPhase phase ) [static]
```

Get name of the enum symbol for name.

Example: getSimulationPhaseName(IRIS\_SIM\_PHASE\_INIT) returns "IRIS\_SIM\_PHASE\_INIT".

#### 8.29.3.5 notifySimPhase()

```
void iris::IrisInstanceSimulation::notifySimPhase (
    uint64_t time,
    IrisSimulationPhase phase )
```

Emit an IRIS\_SIM\_PHASE\* event for the supplied phase.

##### Parameters

<i>time</i>	The simulation time at which the event occurred.
<i>phase</i>	The simulation phase that was reached.

#### 8.29.3.6 registerSimEventsOnGlobalInstance()

```
void iris::IrisInstanceSimulation::registerSimEventsOnGlobalInstance ( )
```

Register all simulation engine events as proxy events on the global iris instance.

This function should be called after an iris instance has been attached to [IrisInstanceSimulation](#) object ([IrisInstanceSimulation::attachTo](#)). This will ensure that the simulation engine iris instance i.e. `iris_instance` is available to call the register API. This function should be called after event handler has been set for [IrisInstanceSimulation](#) object ([IrisInstanceSimulation::setEventHandler](#)). This will ensure that all simulation engine events are available in simulation engine event handler. This function should be called after an `IrisInstanceEvent` has been attached to `iris_instance` ([IrisInstanceEvent::attachTo](#)). This will ensure that event functions have been registered on simulation engine iris instance.

#### 8.29.3.7 setConnectionInterface()

```
void iris::IrisInstanceSimulation::setConnectionInterface (
    IrisConnectionInterface * connection_interface_ ) [inline]
```

Set the `IrisConnectionInterface` to use for the instantiation.

This will be passed to the `instantiate()` delegate when the simulation is instantiated.

#### 8.29.3.8 setEventHandler()

```
void iris::IrisInstanceSimulation::setEventHandler (
    IrisInstanceEvent * handler )
```

Set up IRIS\_SIM\_PHASE\* events.

##### Parameters

<i>handler</i>	An <a href="#">IrisInstanceEvent</a> add-on that is attached to the same instance as this add-on.
----------------	---

#### 8.29.3.9 setGetParameterInfoDelegate() [1/3]

```
template<IrisErrorCode(*) (std::vector< ResourceInfo > &) FUNC>
void iris::IrisInstanceSimulation::setGetParameterInfoDelegate (
    bool cache_result = true ) [inline]
```

Set the `getParameterInfo()` delegate.

Set the delegate to a global function.

## Template Parameters

<i>FUNC</i>	A function that is a <code>getParameterInfo</code> delegate.
-------------	--

## Parameters

<i>cache_result</i>	If true, the delegate is only called once and the result is cached and used for subsequent calls to <code>simulation_getInstantiationParameterInfo()</code> . If false, the result is not cached and the delegate is called every time.
---------------------	---

8.29.3.10 `setGetParameterInfoDelegate()` [2/3]

```
void iris::IrisInstanceSimulation::setGetParameterInfoDelegate (
    SimulationGetParameterInfoDelegate delegate,
    bool cache_result = true ) [inline]
```

Set the `getParameterInfo()` delegate.

## Parameters

<i>delegate</i>	A delegate object that is called to get instantiation parameter information for the simulation.
<i>cache_result</i>	If true, the delegate is only called once and the result is cached and used for subsequent calls to <code>simulation_getInstantiationParameterInfo()</code> . If false, the result is not cached and the delegate is called every time.

8.29.3.11 `setGetParameterInfoDelegate()` [3/3]

```
template<typename T , IrisErrorCode(T::*)(std::vector< ResourceInfo > &) METHOD>
void iris::IrisInstanceSimulation::setGetParameterInfoDelegate (
    T * instance,
    bool cache_result = true ) [inline]
```

Set the `getParameterInfo()` delegate.

Set the delegate to call a method in class `T`.

## Template Parameters

<i>T</i>	Class that defines a <code>getParameterInfo</code> delegate method.
<i>METHOD</i>	A method of class <code>T</code> that is a <code>getParameterInfo</code> delegate.

## Parameters

<i>instance</i>	An instance of class <code>T</code> on which <code>METHOD</code> should be called.
<i>cache_result</i>	If true, the delegate is called once and the result is cached and used for subsequent calls to <code>simulation_getInstantiationParameterInfo()</code> . If false, the result is not cached and the delegate is called every time.

8.29.3.12 `setInstantiateDelegate()` [1/3]

```
template<IrisErrorCode(*) (InstantiationResult &) FUNC>
void iris::IrisInstanceSimulation::setInstantiateDelegate ( ) [inline]
```

Set the instantiate() delegate.  
Set the delegate to a global function.

#### Template Parameters

<i>FUNC</i>	A function that is an instantiate delegate.
-------------	---

#### 8.29.3.13 setInstantiateDelegate() [2/3]

```
void iris::IrisInstanceSimulation::setInstantiateDelegate (
    SimulationInstantiateDelegate delegate ) [inline]
```

Set the instantiate() delegate.

#### Parameters

<i>delegate</i>	A delegate object that will be called to instantiate the simulation.
-----------------	--

#### 8.29.3.14 setInstantiateDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(InstantiationResult &) METHOD>
void iris::IrisInstanceSimulation::setInstantiateDelegate (
    T * instance ) [inline]
```

Set the instantiate() delegate.  
Set the delegate to call a method in class T.

#### Template Parameters

<i>T</i>	Class that defines an instantiate delegate method.
<i>METHOD</i>	A method of class <i>T</i> that is an instantiate delegate.

#### Parameters

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

#### 8.29.3.15 setLogLevel()

```
void iris::IrisInstanceSimulation::setLogLevel (
    unsigned logLevel_ ) [inline]
```

Set log level (0-1).  
Set log level (0-1).

#### 8.29.3.16 setRequestShutdownDelegate() [1/3]

```
template<IrisErrorCode(*)() FUNC>
void iris::IrisInstanceSimulation::setRequestShutdownDelegate ( ) [inline]
```

Set the requestShutdown() delegate.  
Set the delegate to a global function.

#### Template Parameters

<i>FUNC</i>	A function that is a requestShutdown delegate.
-------------	--

**8.29.3.17 setRequestShutdownDelegate()** [2/3]

```
void iris::IrisInstanceSimulation::setRequestShutdownDelegate (
    SimulationRequestShutdownDelegate delegate ) [inline]
```

Set the requestShutdown() delegate.

**Parameters**

<i>delegate</i>	A delegate object that will be called to request that the simulation be shut down.
-----------------	--

**8.29.3.18 setRequestShutdownDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)() METHOD>
void iris::IrisInstanceSimulation::setRequestShutdownDelegate (
    T * instance ) [inline]
```

Set the requestShutdown() delegate.

Set the delegate to call a method in class T.

**Template Parameters**

<i>T</i>	Class that defines a requestShutdown delegate method.
<i>METHOD</i>	A method of class <i>T</i> that is a requestShutdown delegate.

**Parameters**

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

**8.29.3.19 setResetDelegate()** [1/3]

```
template<IrisErrorCode(*) (const IrisSimulationResetContext &) FUNC>
void iris::IrisInstanceSimulation::setResetDelegate ( ) [inline]
```

Set the reset() delegate.

Set the delegate to a global function.

**Template Parameters**

<i>FUNC</i>	A function that is a reset delegate.
-------------	--------------------------------------

**8.29.3.20 setResetDelegate()** [2/3]

```
void iris::IrisInstanceSimulation::setResetDelegate (
    SimulationResetDelegate delegate ) [inline]
```

Set the reset() delegate.

**Parameters**

<i>delegate</i>	A delegate object which will be called to reset the simulation.
-----------------	---

**8.29.3.21 setResetDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(const IrisSimulationResetContext &) METHOD>
void iris::IrisInstanceSimulation::setResetDelegate (
    T * instance ) [inline]
```

Set the reset() delegate.

Set the delegate to call a method in class T.

**Template Parameters**

<i>T</i>	Class that defines a reset delegate method.
<i>METHOD</i>	A method of class <i>T</i> that is a reset delegate.

**Parameters**

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

**8.29.3.22 setSetParameterValueDelegate()** [1/3]

```
template<IrisErrorCode(*) (const InstantiationParameterValue &) FUNC>
void iris::IrisInstanceSimulation::setSetParameterValueDelegate ( ) [inline]
```

Set the setParameterValue() delegate.

Set the delegate to a global function.

**Template Parameters**

<i>FUNC</i>	A function that is a setParameterValue delegate.
-------------	--

**8.29.3.23 setSetParameterValueDelegate()** [2/3]

```
void iris::IrisInstanceSimulation::setSetParameterValueDelegate (
    SimulationSetParameterValueDelegate delegate ) [inline]
```

Set the setParameterValue() delegate.

**Parameters**

<i>delegate</i>	A delegate object that is called to set instantiation parameter values before instantiation.
-----------------	--

**8.29.3.24 setSetParameterValueDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(const InstantiationParameterValue &) METHOD>
void iris::IrisInstanceSimulation::setSetParameterValueDelegate (
    T * instance ) [inline]
```

Set the setParameterValue() delegate.

Set the delegate to call a method in class T.

**Template Parameters**

<i>T</i>	Class that defines a setParameterValue delegate method.
----------	---

## Template Parameters

<i>METHOD</i>	A method of class <i>T</i> that is a setParameterValue delegate.
---------------	--

## Parameters

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstanceSimulation.h](#)

## 8.30 iris::IrisInstanceSimulationTime Class Reference

Simulation time add-on for [IrisInstance](#).

```
#include <IrisInstanceSimulationTime.h>
```

### Public Member Functions

- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceSimulationTime](#) ([IrisInstance](#) \*iris\_instance=nullptr, [IrisInstanceEvent](#) \*inst\_event=nullptr)  
*Construct an [IrisInstanceSimulationTime](#) add-on.*
- void [notifySimulationTimeEvent](#) (uint64\_t reason=TIME\_EVENT\_UNKNOWN)  
*Generate the IRIS\_SIMULATION\_TIME\_EVENT event callback.*
- void [registerSimTimeEventsOnGlobalInstance](#) ()  
*Register all simulation time events as proxy events on the global iris instance.*
- void [setEventHandler](#) ([IrisInstanceEvent](#) \*handler)  
*Set the event handler to use to send simulation time-related events.*
- template<IrisErrorCode(\*)>(uint64\_t &, uint64\_t &, bool &) FUNC<  
void [setSimTimeGetDelegate](#) ()  
*Set the getTime() delegate.*
- void [setSimTimeGetDelegate](#) ([SimulationTimeGetDelegate](#) delegate)  
*Set the getTime() delegate.*
- template<typename T, IrisErrorCode(T::\*)(uint64\_t &, uint64\_t &, bool &) METHOD>  
void [setSimTimeGetDelegate](#) (T \*instance)  
*Set the getTime() delegate.*
- void [setSimTimeNotifyStateChanged](#) (std::function< void()> func)  
*Set the notifyStateChanged() delegate.*
- template<IrisErrorCode(\*)>() FUNC<  
void [setSimTimeRunDelegate](#) ()  
*Set the run() delegate.*
- void [setSimTimeRunDelegate](#) ([SimulationTimeRunDelegate](#) delegate)  
*Set the run() delegate.*
- template<typename T, IrisErrorCode(T::\*)>() METHOD>  
void [setSimTimeRunDelegate](#) (T \*instance)  
*Set the run() delegate.*
- template<IrisErrorCode(\*)>() FUNC<  
void [setSimTimeStopDelegate](#) ()  
*Set the stop() delegate.*
- void [setSimTimeStopDelegate](#) ([SimulationTimeStopDelegate](#) delegate)  
*Set the stop() delegate.*



- `template<typename T, IrisErrorCode(T::*)() METHOD>`  
`void setSimTimeStopDelegate (T *instance)`  
*Set the stop() delegate.*

### 8.30.1 Detailed Description

Simulation time add-on for [IrisInstance](#).

### 8.30.2 Constructor & Destructor Documentation

#### 8.30.2.1 IrisInstanceSimulationTime()

```
iris::IrisInstanceSimulationTime::IrisInstanceSimulationTime (
    IrisInstance * iris_instance = nullptr,
    IrisInstanceEvent * inst_event = nullptr )
```

Construct an [IrisInstanceSimulationTime](#) add-on.

##### Parameters

<i>iris_instance</i>	An <a href="#">IrisInstance</a> to attach this add-on to.
<i>inst_event</i>	An <a href="#">IrisInstanceEvent</a> add-on that is already attached to <a href="#">IrisInstance</a> . This is used to set up simulation time events.

### 8.30.3 Member Function Documentation

#### 8.30.3.1 attachTo()

```
void iris::IrisInstanceSimulationTime::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstance](#) add-on to a specific [IrisInstance](#).

##### Parameters

<i>irisInstance</i>	An <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	---

#### 8.30.3.2 registerSimTimeEventsOnGlobalInstance()

```
void iris::IrisInstanceSimulationTime::registerSimTimeEventsOnGlobalInstance ( )
```

Register all simulation time events as proxy events on the global iris instance.

This function should be called after an iris instance has been attached to [IrisInstanceSimulationTime](#) object ([IrisInstanceSimulationTime::attachTo](#)). This will ensure that the simulation time iris instance i.e. `iris_↵` instance is available to call the register API. This function should be called after event handler has been set for [IrisInstanceSimulationTime](#) object ([IrisInstanceSimulationTime::setEventHandler](#)). This will ensure that all simulation time events are available in simulation time event handler. This function should be called after an `IrisInstance↵` Event has been attached to `iris_instance` ([IrisInstanceEvent::attachTo](#)). This will ensure that event functions have been registered on simulation time iris instance.

#### 8.30.3.3 setEventHandler()

```
void iris::IrisInstanceSimulationTime::setEventHandler (
    IrisInstanceEvent * handler )
```

Set the event handler to use to send simulation time-related events.

#### Parameters

<i>handler</i>	An <a href="#">IrisInstanceEvent</a> add-on that is already attached to <a href="#">IrisInstance</a> . This is used to set up simulation time events.
----------------	---

#### 8.30.3.4 setSimTimeGetDelegate() [1/3]

```
template<IrisErrorCode(*) (uint64_t &, uint64_t &, bool &) FUNC>
void iris::IrisInstanceSimulationTime::setSimTimeGetDelegate ( ) [inline]
```

Set the getTime() delegate.

Set the delegate to a global function.

#### Template Parameters

<i>FUNC</i>	A function that is a getTime delegate.
-------------	--

#### 8.30.3.5 setSimTimeGetDelegate() [2/3]

```
void iris::IrisInstanceSimulationTime::setSimTimeGetDelegate (
    SimulationTimeGetDelegate delegate ) [inline]
```

Set the getTime() delegate.

#### Parameters

<i>delegate</i>	A delegate that is called to get the current simulation time.
-----------------	---

#### 8.30.3.6 setSimTimeGetDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(uint64_t &, uint64_t &, bool &) METHOD>
void iris::IrisInstanceSimulationTime::setSimTimeGetDelegate (
    T * instance ) [inline]
```

Set the getTime() delegate.

#### Template Parameters

<i>T</i>	Class that defines a getTime delegate method.
<i>METHOD</i>	A method of class <i>T</i> that is a getTime delegate.

#### Parameters

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

#### 8.30.3.7 setSimTimeNotifyStateChanged()

```
void iris::IrisInstanceSimulationTime::setSimTimeNotifyStateChanged (
    std::function< void()> func ) [inline]
```

Set the notifyStateChanged() delegate.

The semantics of this delegate is to emit a IRIS\_SIMULATION\_TIME\_EVENT(REASON=STATE\_CHANGED) event, usually by calling notifySimulationTimeEvent(TIME\_EVENT\_STATE\_CHANGED). Ideally this is done with a small delay so that multiple successive calls to simulationTime\_notifyStateChanged() cause only one IRIS\_SIMULATION\_TIME\_EVENT(REASON=STATE\_CHANGED) event. In other words multiple calls to simulationTime\_notifyStateChanged() should be aggregated into one IRIS\_SIMULATION\_TIME\_EVENT(REASON=STATE\_CHANGED) event. The delay from the first call to simulationTime\_notifyStateChanged() to the IRIS\_SIMULATION\_TIME\_EVENT(REASON=STATE\_CHANGED) event should be approximately 500 ms. The default implementation of this delegate immediately emits a IRIS\_SIMULATION\_TIME\_EVENT(REASON=STATE\_CHANGED) event and does not aggregate multiple calls to simulationTime\_notifyStateChanged().

#### Parameters

<i>func</i>	A function which calls <a href="#">notifySimulationTimeEvent()</a> within the next 500 ms.
-------------	--

### 8.30.3.8 setSimTimeRunDelegate() [1/3]

```
template<IrisErrorCode(*)() FUNC>
void iris::IrisInstanceSimulationTime::setSimTimeRunDelegate ( ) [inline]
```

Set the run() delegate.

Set the delegate to a global function.

#### Template Parameters

<i>FUNC</i>	A function that is a run delegate.
-------------	------------------------------------

### 8.30.3.9 setSimTimeRunDelegate() [2/3]

```
void iris::IrisInstanceSimulationTime::setSimTimeRunDelegate (
    SimulationTimeRunDelegate delegate ) [inline]
```

Set the run() delegate.

#### Parameters

<i>delegate</i>	A delegate that is called to start/resume progress of simulation time.
-----------------	--

### 8.30.3.10 setSimTimeRunDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)() METHOD>
void iris::IrisInstanceSimulationTime::setSimTimeRunDelegate (
    T * instance ) [inline]
```

Set the run() delegate.

#### Template Parameters

<i>T</i>	Class that defines a run delegate method.
<i>METHOD</i>	A method of class <i>T</i> that is a run delegate.

#### Parameters

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

**8.30.3.11 setSimTimeStopDelegate() [1/3]**

```
template<IrisErrorCode(*)() FUNC>
void iris::IrisInstanceSimulationTime::setSimTimeStopDelegate ( ) [inline]
```

Set the stop() delegate.  
Set the delegate to a global function.

**Template Parameters**

<i>FUNC</i>	A function that is a stop delegate.
-------------	-------------------------------------

**8.30.3.12 setSimTimeStopDelegate() [2/3]**

```
void iris::IrisInstanceSimulationTime::setSimTimeStopDelegate (
    SimulationTimeStopDelegate delegate ) [inline]
```

Set the stop() delegate.

**Parameters**

<i>delegate</i>	A delegate that is called to stop the progress of simulation time.
-----------------	--

**8.30.3.13 setSimTimeStopDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*)() METHOD>
void iris::IrisInstanceSimulationTime::setSimTimeStopDelegate (
    T * instance ) [inline]
```

Set the stop() delegate.

**Template Parameters**

<i>T</i>	Class that defines a stop delegate method.
<i>METHOD</i>	A method of class <i>T</i> that is a stop delegate.

**Parameters**

<i>instance</i>	An instance of class <i>T</i> on which <i>METHOD</i> should be called.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstanceSimulationTime.h](#)

**8.31 iris::IrisInstanceStep Class Reference**

Step add-on for [IrisInstance](#).

```
#include <IrisInstanceStep.h>
```

**Public Member Functions**

- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
Attach this [IrisInstanceStep](#) add-on to a specific [IrisInstance](#).

- [IrisInstanceStep](#) ([IrisInstance](#) \*irisInstance=nullptr)  
*Construct an [IrisInstanceStep](#) add-on.*
- void [setRemainingStepGetDelegate](#) ([RemainingStepGetDelegate](#) delegate)  
*Set the delegate for getting the remaining steps.*
- void [setRemainingStepSetDelegate](#) ([RemainingStepSetDelegate](#) delegate)  
*Set the delegate for setting the remaining steps.*
- void [setStepCountGetDelegate](#) ([StepCountGetDelegate](#) delegate)  
*Set the delegate for getting the step count.*

### 8.31.1 Detailed Description

Step add-on for [IrisInstance](#).

This is used by instances to support stepping functionality.

This class implements all Iris step\*() functions.

### 8.31.2 Constructor & Destructor Documentation

#### 8.31.2.1 IrisInstanceStep()

```
iris::IrisInstanceStep::IrisInstanceStep (
    IrisInstance * irisInstance = nullptr )
```

Construct an [IrisInstanceStep](#) add-on.

##### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

### 8.31.3 Member Function Documentation

#### 8.31.3.1 attachTo()

```
void iris::IrisInstanceStep::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstanceStep](#) add-on to a specific [IrisInstance](#).

This should only be used if no instance was attached when this object was constructed.

##### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

#### 8.31.3.2 setRemainingStepGetDelegate()

```
void iris::IrisInstanceStep::setRemainingStepGetDelegate (
    RemainingStepGetDelegate delegate )
```

Set the delegate for getting the remaining steps.

##### Parameters

<i>delegate</i>	A delegate object that is called to get the remaining steps for the attached instance.
-----------------	--

### 8.31.3.3 setRemainingStepSetDelegate()

```
void iris::IrisInstanceStep::setRemainingStepSetDelegate (
    RemainingStepSetDelegate delegate )
```

Set the delegate for setting the remaining steps.

#### Parameters

<i>delegate</i>	A delegate object that is called to set the remaining steps for the attached instance.
-----------------	--

### 8.31.3.4 setStepCountGetDelegate()

```
void iris::IrisInstanceStep::setStepCountGetDelegate (
    StepCountGetDelegate delegate )
```

Set the delegate for getting the step count.

#### Parameters

<i>delegate</i>	A delegate object that is called to get the step count for the attached instance.
-----------------	---

The documentation for this class was generated from the following file:

- [IrisInstanceStep.h](#)

## 8.32 iris::IrisInstanceTable Class Reference

Table add-on for [IrisInstance](#).

```
#include <IrisInstanceTable.h>
```

### Classes

- struct [TableInfoAndAccess](#)  
*Entry in 'tableInfos'.*

### Public Member Functions

- [TableInfoAndAccess](#) & [addTableInfo](#) (const std::string &name)  
*Add metadata for one table.*
- void [attachTo](#) ([IrisInstance](#) \*irisInstance)  
*Attach this [IrisInstanceTable](#) add-on to a specific [IrisInstance](#).*
- [IrisInstanceTable](#) ([IrisInstance](#) \*irisInstance=nullptr)  
*Construct an [IrisInstanceTable](#) add-on.*
- void [setDefaultReadDelegate](#) ([TableReadDelegate](#) delegate=[TableReadDelegate](#)())  
*Set the default delegate for reading table data.*
- void [setDefaultWriteDelegate](#) ([TableWriteDelegate](#) delegate=[TableWriteDelegate](#)())  
*Set the default delegate for writing table data.*

### 8.32.1 Detailed Description

Table add-on for [IrisInstance](#).

This is used by instances to support table functionality.

## 8.32.2 Constructor & Destructor Documentation

### 8.32.2.1 IrisInstanceTable()

```
iris::IrisInstanceTable::IrisInstanceTable (
    IrisInstance * irisInstance = nullptr )
```

Construct an [IrisInstanceTable](#) add-on.

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

## 8.32.3 Member Function Documentation

### 8.32.3.1 addTableInfo()

```
TableInfoAndAccess & iris::IrisInstanceTable::addTableInfo (
    const std::string & name )
```

Add metadata for one table.

#### Parameters

<i>name</i>	The name of this table.
-------------	-------------------------

#### Returns

A reference to a [TableInfoAndAccess](#) object that can be used to set metadata and access delegates for this table.

### 8.32.3.2 attachTo()

```
void iris::IrisInstanceTable::attachTo (
    IrisInstance * irisInstance )
```

Attach this [IrisInstanceTable](#) add-on to a specific [IrisInstance](#).

This should only be used if no instance was attached when this object was constructed.

#### Parameters

<i>irisInstance</i>	The <a href="#">IrisInstance</a> to attach this add-on to.
---------------------	--

### 8.32.3.3 setDefaultReadDelegate()

```
void iris::IrisInstanceTable::setDefaultReadDelegate (
    TableReadDelegate delegate = TableReadDelegate() ) [inline]
```

Set the default delegate for reading table data.

#### Parameters

<i>delegate</i>	A delegate object that is called to read table data for tables in the attached instance that did not set a table-specific delegate.
-----------------	---

### 8.32.3.4 setDefaultWriteDelegate()

```
void iris::IrisInstanceTable::setDefaultWriteDelegate (
    TableWriteDelegate delegate = TableWriteDelegate() ) [inline]
```

Set the default delegate for writing table data.

#### Parameters

<i>delegate</i>	A delegate object that is called to write table data for tables in the attached instance that did not set a table-specific delegate.
-----------------	--

The documentation for this class was generated from the following file:

- [IrisInstanceTable.h](#)

## 8.33 iris::IrisInstantiationContext Class Reference

Provides context when instantiating an Iris instance from a factory.

```
#include <IrisInstantiationContext.h>
```

### Public Member Functions

- void void void [error](#) (const std::string &code, const char \*format,...) INTERNAL\_IRIS\_PRINTF(3)  
*Add an error to the InstantiationResult.*
- bool [getBoolParameter](#) (const std::string &name)  
*Get the value of an instantiation parameter as boolean.*
- IrisConnectionInterface \* [getConnectionInterface](#) () const  
*Get the connection interface to use to register the instance being instantiated.*
- std::string [getInstanceName](#) () const  
*Get the instance name to use when registering the instance being instantiated.*
- const IrisValue & [getParameter](#) (const std::string &name)  
*Get the value of an instantiation parameter as IrisValue.*
- void [getParameter](#) (const std::string &name, std::vector< uint64\_t > &value)  
*Get the value of a large numeric instantiation parameter.*
- template<typename T >  
void [getParameter](#) (const std::string &name, T &value)  
*Get the value of an instantiation parameter.*
- uint64\_t [getRecommendedInstanceFlags](#) () const  
*Get the flags to use when registering the instance being instantiated.*
- int64\_t [getS64Parameter](#) (const std::string &name)  
*Get the value of an instantiation parameter as int64\_t.*
- std::string [getStringParameter](#) (const std::string &name)  
*Get the value of an instantiation parameter as string.*
- [IrisInstantiationContext](#) \* [getSubcomponentContext](#) (const std::string &child\_name)  
*Get an IrisInstanceContext pointer for a subcomponent instance.*
- uint64\_t [getU64Parameter](#) (const std::string &name)  
*Get the value of an instantiation parameter as uint64\_t.*
- **IrisInstantiationContext** (IrisConnectionInterface \*connection\_interface\_, InstantiationResult &result\_  
, const std::vector< ResourceInfo > &param\_info\_, const std::vector< InstantiationParameterValue >  
&param\_values\_, const std::string &prefix\_, const std::string &component\_name\_, uint64\_t instance\_flags\_  
)



- void void void void [parameterError](#) (const std::string &code, const std::string &parameterName, const char \*format,...) INTERNAL\_IRIS\_PRINTF(4)  
Add an error to the *InstantiationResult*.
- void void [parameterWarning](#) (const std::string &code, const std::string &parameterName, const char \*format,...) INTERNAL\_IRIS\_PRINTF(4)  
Add a warning to the *InstantiationResult*.
- void [warning](#) (const std::string &code, const char \*format,...) INTERNAL\_IRIS\_PRINTF(3)  
Add a warning to the *InstantiationResult*.

### 8.33.1 Detailed Description

Provides context when instantiating an Iris instance from a factory.

### 8.33.2 Member Function Documentation

#### 8.33.2.1 error()

```
void void void iris::IrisInstantiationContext::error (
    const std::string & code,
    const char * format,
    ... )
```

Add an error to the *InstantiationResult*.

See also

[parameterError](#)

#### Parameters

<i>code</i>	An error code symbol. This should be one of the codes specified for the <i>InstantiationError</i> object.
<i>format</i>	A printf-style format string.
...	Printf substitution arguments.

#### 8.33.2.2 getBoolParameter()

```
bool iris::IrisInstantiationContext::getBoolParameter (
    const std::string & name ) [inline]
```

Get the value of an instantiation parameter as boolean.

#### Parameters

<i>name</i>	The name of the parameter.
-------------	----------------------------

#### Returns

Boolean value.

#### 8.33.2.3 getConnectionInterface()

```
IrisConnectionInterface * iris::IrisInstantiationContext::getConnectionInterface ( ) const
[inline]
```

Get the connection interface to use to register the instance being instantiated.

**Returns**

A value to use for the `connection_interface` argument of [IrisInstance::IrisInstance\(\)](#).

**8.33.2.4 getInstanceName()**

```
std::string iris::IrisInstantiationContext::getInstanceName ( ) const [inline]
```

Get the instance name to use when registering the instance being instantiated.

**Returns**

A value to use for the `instName` argument of [IrisInstance::IrisInstance\(\)](#) or [IrisInstance::registerInstance\(\)](#).

**8.33.2.5 getParameter() [1/3]**

```
const IrisValue & iris::IrisInstantiationContext::getParameter (
    const std::string & name ) [inline]
```

Get the value of an instantiation parameter as `IrisValue`.

This can be used as a fallback for all types not supported by the `get<type>Parameter()` functions below.

**Parameters**

<i>name</i>	The name of the parameter.
-------------	----------------------------

**Returns**

`IrisValue` of the parameter.

**8.33.2.6 getParameter() [2/3]**

```
void iris::IrisInstantiationContext::getParameter (
    const std::string & name,
    std::vector< uint64_t > & value )
```

Get the value of a large numeric instantiation parameter.

This is used for numeric parameters that are outside the range of `uint64_t/int64_t`.

**Parameters**

<i>name</i>	The name of the parameter.
<i>value</i>	A reference to a value of type <i>T</i> that receives the value of the named parameter.

**8.33.2.7 getParameter() [3/3]**

```
template<typename T >
void iris::IrisInstantiationContext::getParameter (
    const std::string & name,
    T & value ) [inline]
```

Get the value of an instantiation parameter.

**Template Parameters**

<i>T</i>	The type of the <i>value</i> . This must be a type that is appropriate to receive the value of this parameter.
----------	--

## Parameters

<i>name</i>	The name of the parameter.
<i>value</i>	A reference to a value of type <i>T</i> that receives the value of the named parameter.

**8.33.2.8 getRecommendedInstanceFlags()**

```
uint64_t iris::IrisInstantiationContext::getRecommendedInstanceFlags ( ) const [inline]
```

Get the flags to use when registering the instance being instantiated.

## Returns

A value to use for the flags argument of [IrisInstance::IrisInstance\(\)](#) or [IrisInstance::registerInstance\(\)](#).

**8.33.2.9 getS64Parameter()**

```
int64_t iris::IrisInstantiationContext::getS64Parameter (
    const std::string & name ) [inline]
```

Get the value of an instantiation parameter as int64\_t.

## Parameters

<i>name</i>	The name of the parameter.
-------------	----------------------------

## Returns

S64 value.

**8.33.2.10 getStringParameter()**

```
std::string iris::IrisInstantiationContext::getStringParameter (
    const std::string & name ) [inline]
```

Get the value of an instantiation parameter as string.

## Parameters

<i>name</i>	The name of the parameter.
-------------	----------------------------

## Returns

String value.

**8.33.2.11 getSubcomponentContext()**

```
IrisInstantiationContext * iris::IrisInstantiationContext::getSubcomponentContext (
    const std::string & child_name )
```

Get an IrisInstanceContext pointer for a subcomponent instance.

For example, you might call `getSubcomponentContext("cpu0")` on the context "component.cluster0" to get the context to instantiate "component.cluster0.cpu0". The object pointed to by the return value is owned by its parent context and has the same lifetime as the parent context.

## Parameters

<i>child_name</i>	The name of a child instance.
-------------------	-------------------------------

## Returns

A pointer to an [IrisInstantiationContext](#) object for the named child.

**8.33.2.12 getU64Parameter()**

```
uint64_t iris::IrisInstantiationContext::getU64Parameter (
    const std::string & name ) [inline]
```

Get the value of an instantiation parameter as uint64\_t.

## Parameters

<i>name</i>	The name of the parameter.
-------------	----------------------------

## Returns

U64 value.

**8.33.2.13 parameterError()**

```
void void void void iris::IrisInstantiationContext::parameterError (
    const std::string & code,
    const std::string & parameterName,
    const char * format,
    ... )
```

Add an error to the InstantiationResult.

## See also

[error](#)

## Parameters

<i>code</i>	An error code symbol. This should be one of the codes specified for the InstantiationError object.
<i>parameterName</i>	The name of the parameter this error relates to.
<i>format</i>	A printf-style format string.
...	Printf substitution arguments.

**8.33.2.14 parameterWarning()**

```
void void iris::IrisInstantiationContext::parameterWarning (
    const std::string & code,
    const std::string & parameterName,
    const char * format,
    ... )
```

Add a warning to the InstantiationResult.

See also

[warning](#)

#### Parameters

<i>code</i>	An error code symbol. This should be one of the codes specified for the <code>InstantiationError</code> object.
<i>parameterName</i>	The name of the parameter this warning relates to.
<i>format</i>	A printf-style format string.
...	Printf substitution arguments.

#### 8.33.2.15 `warning()`

```
void iris::IrisInstantiationContext::warning (
    const std::string & code,
    const char * format,
    ... )
```

Add a warning to the `InstantiationResult`.

See also

[parameterWarning](#)

#### Parameters

<i>code</i>	An error code symbol. This should be one of the codes specified for the <code>InstantiationError</code> object.
<i>format</i>	A printf-style format string.
...	Printf substitution arguments.

The documentation for this class was generated from the following file:

- [IrisInstantiationContext.h](#)

## 8.34 `iris::IrisNonFactoryPlugin< PLUGIN_CLASS >` Class Template Reference

Wrapper to instantiate a non-factory plugin.

```
#include <IrisPluginFactory.h>
```

### Public Member Functions

- **`IrisNonFactoryPlugin`** (`IrisC_Funcions *functions`, `const std::string &pluginName`)

### Static Public Member Functions

- `static int64_t initPlugin` (`IrisC_Funcions *functions`, `const std::string &pluginName`)

#### 8.34.1 Detailed Description

```
template<class PLUGIN_CLASS>
class iris::IrisNonFactoryPlugin< PLUGIN_CLASS >
```

Wrapper to instantiate a non-factory plugin.

Do not use this directly. Use the IRIS\_NON\_FACTORY\_PLUGIN macro instead.

## Template Parameters

<code>PLUGIN_CLASS</code>	Plugin class.
---------------------------	---------------

The documentation for this class was generated from the following file:

- [IrisPluginFactory.h](#)

## 8.35 iris::IrisParameterBuilder Class Reference

Helper class to construct instantiation parameters.

```
#include <IrisParameterBuilder.h>
```

### Public Member Functions

- [IrisParameterBuilder](#) & [addEnum](#) (const std::string &symbol, const IrisValue &value, const std::string &description=std::string())  
*Add an enum symbol for this parameter.*
- [IrisParameterBuilder](#) & [addStringEnum](#) (const std::string &value, const std::string &description=std::string())  
*Add a string enum symbol for this parameter.*
- [IrisParameterBuilder](#) (ResourceInfo &info\_)  
*Construct a parameter builder for a given parameter resource.*
- [IrisParameterBuilder](#) & [setBitWidth](#) (uint64\_t bitWidth)  
*Set the `bitWidth` field.*
- [IrisParameterBuilder](#) & [setDefault](#) (const std::string &value)  
*Set the default value for a string parameter.*
- [IrisParameterBuilder](#) & [setDefault](#) (const std::vector< uint64\_t > &value)  
*Set the default value for a numeric parameter.*
- [IrisParameterBuilder](#) & [setDefault](#) (uint64\_t value)  
*Set the default value for a numeric parameter.*
- [IrisParameterBuilder](#) & [setDefaultFloat](#) (double value)  
*Set the default value for a numericFp parameter.*
- [IrisParameterBuilder](#) & [setDefaultSigned](#) (const std::vector< uint64\_t > &value)  
*Set the default value for a numericSigned parameter.*
- [IrisParameterBuilder](#) & [setDefaultSigned](#) (int64\_t value)  
*Set the default value for a numericSigned parameter.*
- [IrisParameterBuilder](#) & [setDescr](#) (const std::string &description)  
*Set the `description` field.*
- [IrisParameterBuilder](#) & [setFormat](#) (const std::string &format)  
*Set the `format` field.*
- [IrisParameterBuilder](#) & [setHidden](#) (bool hidden)  
*Set the resource to hidden !*
- [IrisParameterBuilder](#) & [setInitOnly](#) (bool value=true)  
*Set the `initOnly` field.*
- [IrisParameterBuilder](#) & [setMax](#) (const std::vector< uint64\_t > &max)  
*Set the `max` field.*
- [IrisParameterBuilder](#) & [setMax](#) (uint64\_t max)  
*Set the `max` field.*
- [IrisParameterBuilder](#) & [setMaxFloat](#) (double max)  
*Set the `max` field for floating-point parameters.*
- [IrisParameterBuilder](#) & [setMaxSigned](#) (const std::vector< uint64\_t > &max)  
*Set the `max` field.*

- [IrisParameterBuilder](#) & [setMaxSigned](#) (int64\_t max)  
*Set the `max` field.*
- [IrisParameterBuilder](#) & [setMin](#) (const std::vector< uint64\_t > &min)  
*Set the `min` field.*
- [IrisParameterBuilder](#) & [setMin](#) (uint64\_t min)  
*Set the `min` field.*
- [IrisParameterBuilder](#) & [setMinFloat](#) (double min)  
*Set the `min` field for floating-point parameters.*
- [IrisParameterBuilder](#) & [setMinSigned](#) (const std::vector< uint64\_t > &min)  
*Set the `min` field.*
- [IrisParameterBuilder](#) & [setMinSigned](#) (int64\_t min)  
*Set the `min` field.*
- [IrisParameterBuilder](#) & [setName](#) (const std::string &name)  
*Set the `name` field.*
- [IrisParameterBuilder](#) & [setRange](#) (const std::vector< uint64\_t > &min, const std::vector< uint64\_t > &max)  
*Set both the `min` field and the `max` field.*
- [IrisParameterBuilder](#) & [setRange](#) (uint64\_t min, uint64\_t max)  
*Set both the `min` field and the `max` field.*
- [IrisParameterBuilder](#) & [setRangeFloat](#) (double min, double max)  
*Set both the `min` field and the `max` field.*
- [IrisParameterBuilder](#) & [setRangeSigned](#) (const std::vector< uint64\_t > &min, const std::vector< uint64\_t > &max)  
*Set both the `min` field and the `max` field.*
- [IrisParameterBuilder](#) & [setRangeSigned](#) (int64\_t min, int64\_t max)  
*Set both the `min` field and the `max` field.*
- [IrisParameterBuilder](#) & [setRwMode](#) (const std::string &rwMode)  
*Set the `rwMode` field.*
- [IrisParameterBuilder](#) & [setSubRscId](#) (uint64\_t subRscId)  
*Set the `subRscId` field.*
- [IrisParameterBuilder](#) & [setTag](#) (const std::string &tag)  
*Set a boolean tag for this parameter resource.*
- [IrisParameterBuilder](#) & [setTag](#) (const std::string &tag, const IrisValue &value)  
*Set a tag for this parameter resource.*
- [IrisParameterBuilder](#) & [setTopology](#) (bool value=true)  
*Set the `topology` field.*
- [IrisParameterBuilder](#) & [setType](#) (const std::string &type)  
*Set the type of this parameter.*

### 8.35.1 Detailed Description

Helper class to construct instantiation parameters.

### 8.35.2 Constructor & Destructor Documentation

#### 8.35.2.1 IrisParameterBuilder()

```
iris::IrisParameterBuilder::IrisParameterBuilder (
    ResourceInfo & info_ ) [inline]
```

Construct a parameter builder for a given parameter resource.



## Parameters

<i>info</i> ↔	The resource info object for the parameter being built.
—	

### 8.35.3 Member Function Documentation

#### 8.35.3.1 addEnum()

```
IrisParameterBuilder & iris::IrisParameterBuilder::addEnum (
    const std::string & symbol,
    const IrisValue & value,
    const std::string & description = std::string() ) [inline]
```

Add an enum symbol for this parameter.

## Parameters

<i>symbol</i>	The enum symbol that is being added.
<i>value</i>	The value associated with the symbol.
<i>description</i>	A description explaining the meaning of the symbol.

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

#### 8.35.3.2 addStringEnum()

```
IrisParameterBuilder & iris::IrisParameterBuilder::addStringEnum (
    const std::string & value,
    const std::string & description = std::string() ) [inline]
```

Add a string enum symbol for this parameter.

For string enums, the symbol and value are the same.

## Parameters

<i>value</i>	The value associated with the symbol.
<i>description</i>	A description explaining the meaning of the symbol.

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

#### 8.35.3.3 setBitWidth()

```
IrisParameterBuilder & iris::IrisParameterBuilder::setBitWidth (
    uint64_t bitWidth ) [inline]
```

Set the `bitWidth` field.

## Parameters

<i>bitWidth</i>	The <code>bitWidth</code> field of the <code>ResourceInfo</code> object.
-----------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.4 setDefault() [1/3]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDefault (
    const std::string & value ) [inline]
```

Set the default value for a string parameter.

**Parameters**

<i>value</i>	The defaultString field of the ParameterInfo object.
--------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.5 setDefault() [2/3]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDefault (
    const std::vector< uint64_t > & value ) [inline]
```

Set the default value for a numeric parameter.

Use this variant for values that are  $\geq 2^{64}$ .

**Parameters**

<i>value</i>	The defaultData field of the ParameterInfo object.
--------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.6 setDefault() [3/3]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDefault (
    uint64_t value ) [inline]
```

Set the default value for a numeric parameter.

**Parameters**

<i>value</i>	The defaultData field of the ParameterInfo object.
--------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.7 setDefaultFloat()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDefaultFloat (
    double value ) [inline]
```

Set the default value for a numericFp parameter.

## Parameters

<i>value</i>	The defaultData field of the ParameterInfo object.
--------------	--

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.8 setDefaultSigned() [1/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDefaultSigned (
    const std::vector< uint64_t > & value ) [inline]
```

Set the default value for a numericSigned parameter.

Use this variant for values that are out of range for int64\_t.

## Parameters

<i>value</i>	The defaultData field of the ParameterInfo object.
--------------	--

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.9 setDefaultSigned() [2/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDefaultSigned (
    int64_t value ) [inline]
```

Set the default value for a numericSigned parameter.

## Parameters

<i>value</i>	The defaultData field of the ParameterInfo object.
--------------	--

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.10 setDescr()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setDescr (
    const std::string & description ) [inline]
```

Set the description field.

## Parameters

<i>description</i>	The description field of the ResourceInfo object.
--------------------	---

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.11 setFormat()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setFormat (
    const std::string & format ) [inline]
```

Set the `format` field.

**Parameters**

<i>format</i>	The <code>format</code> field of the <code>ResourceInfo</code> object.
---------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.12 setHidden()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setHidden (
    bool hidden ) [inline]
```

Set the resource to hidden !

**Parameters**

<i>hidden</i>	If true, this event source is not listed in <code>resource_getList()</code> calls but can still be accessed by <code>resource_getResourceInfo()</code> for clients that know the resource name. !
---------------	---

**Returns**

A reference to this TYPE object allowing calls to be chained together.

**8.35.3.13 setInitOnly()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setInitOnly (
    bool value = true ) [inline]
```

Set the `initOnly` field.

**Parameters**

<i>value</i>	The <code>initOnly</code> field of the <code>ParameterInfo</code> object.
--------------	---

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.14 setMax() [1/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMax (
    const std::vector< uint64_t > & max ) [inline]
```

Set the `max` field.

Use this variant to set values that are  $\geq 2^{64}$ .

**Parameters**

<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.15 setMax() [2/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMax (
    uint64_t max ) [inline]
```

Set the `max` field.

**Parameters**

<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.16 setMaxFloat()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMaxFloat (
    double max ) [inline]
```

Set the `max` field for floating-point parameters.

This implies that the parameter type is "numericFp".

**Parameters**

<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.17 setMaxSigned() [1/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMaxSigned (
    const std::vector< uint64_t > & max ) [inline]
```

Set the `max` field.

This implies that the parameter type is "numericSigned". Use this variant for signed values that are out of range for `int64_t`.

**Parameters**

<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.18 setMaxSigned() [2/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMaxSigned (
    int64_t max ) [inline]
```

Set the `max` field.

This implies that the parameter type is "numericSigned".

#### Parameters

<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.
------------	--

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

### 8.35.3.19 setMin() [1/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMin (
    const std::vector< uint64_t > & min ) [inline]
```

Set the `min` field.

Use this variant to set values that are  $\geq 2^{64}$ .

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
------------	--

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

### 8.35.3.20 setMin() [2/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMin (
    uint64_t min ) [inline]
```

Set the `min` field.

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
------------	--

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

### 8.35.3.21 setMinFloat()

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMinFloat (
    double min ) [inline]
```

Set the `min` field for floating-point parameters.

This implies that the parameter type is "numericFp".

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.22 setMinSigned() [1/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMinSigned (
    const std::vector< uint64_t > & min ) [inline]
```

Set the `min` field.

This implies that the parameter type is "numericSigned". Use this variant for signed values that are out of range for `int64_t`.

**Parameters**

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.23 setMinSigned() [2/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setMinSigned (
    int64_t min ) [inline]
```

Set the `min` field.

This implies that the parameter type is "numericSigned".

**Parameters**

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.24 setName()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setName (
    const std::string & name ) [inline]
```

Set the `name` field.

**Parameters**

<i>name</i>	The <code>name</code> field of the <code>ResourceInfo</code> object.
-------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.25 setRange() [1/2]**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setRange (
```

```
const std::vector< uint64_t > & min,
const std::vector< uint64_t > & max ) [inline]
```

Set both the `min` field and the `max` field.

Use this variant to set values that are  $\geq 2^{64}$ .

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

#### 8.35.3.26 setRange() [2/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setRange (
    uint64_t min,
    uint64_t max ) [inline]
```

Set both the `min` field and the `max` field.

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

#### 8.35.3.27 setRangeFloat()

```
IrisParameterBuilder & iris::IrisParameterBuilder::setRangeFloat (
    double min,
    double max ) [inline]
```

Set both the `min` field and the `max` field.

This implies that the parameter type is "numericFp".

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

#### 8.35.3.28 setRangeSigned() [1/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setRangeSigned (
    const std::vector< uint64_t > & min,
    const std::vector< uint64_t > & max ) [inline]
```



Set both the `min` field and the `max` field.

This implies that the parameter type is "numericSigned". Use this variant for signed values that are out of range for `int64_t`.

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

### 8.35.3.29 `setRangeSigned()` [2/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setRangeSigned (
    int64_t min,
    int64_t max ) [inline]
```

Set both the `min` field and the `max` field.

This implies that the parameter type is "numericSigned".

#### Parameters

<i>min</i>	The <code>min</code> field of the <code>ParameterInfo</code> object.
<i>max</i>	The <code>max</code> field of the <code>ParameterInfo</code> object.

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

### 8.35.3.30 `setRwMode()`

```
IrisParameterBuilder & iris::IrisParameterBuilder::setRwMode (
    const std::string & rwMode ) [inline]
```

Set the `rwMode` field.

#### Parameters

<i>rwMode</i>	The <code>rwMode</code> field of the <code>ResourceInfo</code> object.
---------------	--

#### Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

### 8.35.3.31 `setSubRscId()`

```
IrisParameterBuilder & iris::IrisParameterBuilder::setSubRscId (
    uint64_t subRscId ) [inline]
```

Set the `subRscId` field.

## Parameters

<i>sub↔ RscId</i>	The <code>subRscId</code> field of the <code>ResourceInfo</code> object.
-----------------------	--

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.32 setTag()** [1/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setTag (  
    const std::string & tag ) [inline]
```

Set a boolean tag for this parameter resource.

## Parameters

<i>tag</i>	The name of the tag to set.
------------	-----------------------------

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.33 setTag()** [2/2]

```
IrisParameterBuilder & iris::IrisParameterBuilder::setTag (  
    const std::string & tag,  
    const IrisValue & value ) [inline]
```

Set a tag for this parameter resource.

## Parameters

<i>tag</i>	The name of the tag to set.
<i>value</i>	The value to set for this tag.

## Returns

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.34 setTopology()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setTopology (  
    bool value = true ) [inline]
```

Set the `topology` field.

## Parameters

<i>value</i>	The <code>topology</code> field of the <code>ParameterInfo</code> object.
--------------	---

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

**8.35.3.35 setType()**

```
IrisParameterBuilder & iris::IrisParameterBuilder::setType (
    const std::string & type ) [inline]
```

Set the type of this parameter.

The bitWidth field must be set before setting the type.

**Parameters**

<i>type</i>	The type field of the ResourceInfo object.
-------------	--

**Returns**

A reference to this [IrisParameterBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisParameterBuilder.h](#)

## 8.36 iris::IrisPluginFactory< PLUGIN\_CLASS > Class Template Reference

**Public Member Functions**

- **IrisPluginFactory** (IrisC\_Funcions \*iris\_c\_functions, const std::string &plugin\_name)
- IrisErrorCode **unregisterInstance** ()

**Static Public Member Functions**

- static int64\_t **initPlugin** (IrisC\_Funcions \*functions, const std::string &plugin\_name)

The documentation for this class was generated from the following file:

- [IrisPluginFactory.h](#)

## 8.37 iris::IrisPluginFactoryBuilder Class Reference

Set meta data for instantiating a plug-in instance.

```
#include <IrisPluginFactory.h>
```

Inherits [iris::IrisInstanceFactoryBuilder](#).

**Public Member Functions**

- const std::string & **getDefaultInstanceName** () const  
*Get the default name to use for plug-in instances.*
- const std::string & **getInstanceNamePrefix** () const  
*Get the prefix to use for instances of this plug-in.*
- const std::string & **getPluginName** () const  
*Get the plug-in name.*
- [IrisPluginFactoryBuilder](#) (const std::string &name)
- void **setDefaultInstanceName** (const std::string &name)

*Override the default instance name for plug-in instances.*

- void [setInstanceNamePrefix](#) (const std::string &prefix)

*Override the instance name prefix. The default is "client.plugin".*

- void [setPluginName](#) (const std::string &name)

*Override the plug-in name.*

### 8.37.1 Detailed Description

Set meta data for instantiating a plug-in instance.

### 8.37.2 Constructor & Destructor Documentation

#### 8.37.2.1 IrisPluginFactoryBuilder()

```
iris::IrisPluginFactoryBuilder::IrisPluginFactoryBuilder (
    const std::string & name ) [inline]
```

Parameters

<i>name</i>	The name of the plug-in to build.
-------------	-----------------------------------

### 8.37.3 Member Function Documentation

#### 8.37.3.1 getDefaultInstanceName()

```
const std::string & iris::IrisPluginFactoryBuilder::getDefaultInstanceName ( ) const [inline]
```

Get the default name to use for plug-in instances.

Returns

The default name for plug-in instances.

#### 8.37.3.2 getInstanceNamePrefix()

```
const std::string & iris::IrisPluginFactoryBuilder::getInstanceNamePrefix ( ) const [inline]
```

Get the prefix to use for instances of this plug-in.

Returns

The prefix to use for instances of this plug-in.

#### 8.37.3.3 getPluginName()

```
const std::string & iris::IrisPluginFactoryBuilder::getPluginName ( ) const [inline]
```

Get the plug-in name.

Returns

The name of the plug-in.

#### 8.37.3.4 setDefaultInstanceName()

```
void iris::IrisPluginFactoryBuilder::setDefaultInstanceName (
    const std::string & name ) [inline]
```

Override the default instance name for plug-in instances.

The factory provides a sensible default for this name so it should only be overridden if there is a good reason to do so.

##### Parameters

<i>name</i>	The default name for plug-in instances.
-------------	---

#### 8.37.3.5 setInstanceNamePrefix()

```
void iris::IrisPluginFactoryBuilder::setInstanceNamePrefix (
    const std::string & prefix ) [inline]
```

Override the instance name prefix. The default is "client.plugin".

The factory provides a sensible default for this prefix so it should only be overridden if there is a good reason to do so.

##### Parameters

<i>prefix</i>	The prefix that will be used for instances of this plug-in.
---------------	---

#### 8.37.3.6 setPluginName()

```
void iris::IrisPluginFactoryBuilder::setPluginName (
    const std::string & name ) [inline]
```

Override the plug-in name.

The factory provides a sensible default for this name so it should only be overridden if there is a good reason to do so.

##### Parameters

<i>name</i>	The name of the plug-in.
-------------	--------------------------

The documentation for this class was generated from the following file:

- [IrisPluginFactory.h](#)

## 8.38 iris::IrisRegisterReadEventEmitter< REG\_T, ARGS > Class Template Reference

An EventEmitter class for register read events.

```
#include <IrisRegisterEventEmitter.h>
```

Inherits IrisRegisterEventEmitterBase.

### Public Member Functions

- void [operator\(\)](#) (ResourceId rscId, bool debug, REG\_T value, ARGS... args)  
*Emit an event.*

#### 8.38.1 Detailed Description

```
template<typename REG_T, typename... ARGS>
class iris::IrisRegisterReadEventEmitter< REG_T, ARGS >
```

An EventEmitter class for register read events.

#### Template Parameters

<i>REG_T</i>	The type of the register being read.
<i>ARGS</i>	The types of any custom fields that this event source defines, in addition to the standard fields defined for register read events.

Use [IrisRegisterReadEventEmitter](#) with [IrisInstanceBuilder](#) to add register read events to your Iris instance:

```
// Declare an event emitter
iris::IrisRegisterReadEventEmitter<uint64_t> reg_read_event;
// Add it to an Iris instance
iris::IrisInstance my_instance(...);
iris::IrisInstanceBuilder *builder = my_instance->getBuilder();
builder->setRegisterReadEvent("READ_REG", reg_read_event);
// Add some registers that will be traced by this event
builder->setNextRscId(0x1000);
builder->addRegister("X0", 64, "Register X0");
builder->addRegister("X1", 64, "Register X1");
builder->addRegister("X2", 64, "Register X2");
builder->addRegister("X3", 64, "Register X3");
// Now that the Instance builder has the metadata for the registers, we need
// to finalize the register read event to populate the event metadata.
builder->finalizeRegisterReadEvent();
uint64_t readRegister(unsigned reg_index, bool is_debug)
{
    uint64_t value = readRegValue(reg_index);
    // Emit an event
    reg_read_event(0x1000 | reg_index, is_debug, value);
    return value;
}
```

## 8.38.2 Member Function Documentation

### 8.38.2.1 operator()

```
template<typename REG_T , typename... ARGS>
void iris::IrisRegisterReadEventEmitter< REG_T, ARGS >::operator() (
    ResourceId rscId,
    bool debug,
    REG_T value,
    ARGS... args ) [inline]
```

Emit an event.

#### Parameters

<i>rscId</i>	Resource id for the register that was accessed.
<i>debug</i>	True if this access originated from a debug access.
<i>value</i>	The register value that was read during this event.
<i>args</i>	Any additional custom fields for this event.

The documentation for this class was generated from the following file:

- [IrisRegisterEventEmitter.h](#)

## 8.39 iris::IrisRegisterUpdateEventEmitter< REG\_T, ARGS > Class Template Reference

An EventEmitter class for register update events.

#include <IrisRegisterUpdateEventEmitter.h>

Inherits IrisRegisterEventEmitterBase.

### Public Member Functions

- void [operator\(\)](#) (ResourceId rscId, bool debug, REG\_T old\_value, REG\_T new\_value, ARGS... args)  
*Emit an event.*

#### 8.39.1 Detailed Description

```
template<typename REG_T, typename... ARGS>
```

```
class iris::IrisRegisterUpdateEventEmitter< REG_T, ARGS >
```

An EventEmitter class for register update events.

#### Template Parameters

<i>REG_T</i>	The type of the register being read.
<i>ARGS</i>	Types of any custom fields that this event source defines, in addition to the standard fields defined for register update events.

Use [IrisRegisterUpdateEventEmitter](#) with [IrisInstanceBuilder](#) to add register update events to your Iris instance:

```
// Declare an event emitter
iris::IrisRegisterUpdateEventEmitter<uint64_t> reg_update_event;
// Add it to an Iris instance
iris::IrisInstance my_instance(...);
iris::IrisInstanceBuilder *builder = my_instance->getBuilder();
builder->setRegisterUpdateEvent("WRITE_REG", reg_update_event);
// Add some registers that will be traced by this event
builder->setNextRscId(0x1000);
builder->addRegister("X0", 64, "Register X0");
builder->addRegister("X1", 64, "Register X1");
builder->addRegister("X2", 64, "Register X2");
builder->addRegister("X3", 64, "Register X3");
// Now that the Instance builder has the metadata for the registers, we need
// to finalize the register update event to populate the event metadata.
builder->finalizeRegisterUpdateEvent();
void writeRegister(unsigned reg_index, bool is_debug, uint64_t new_value)
{
    uint64_t old_value = readRegValue(reg_index);
    writeRegValue(reg_index, new_value);
    // Emit an event
    reg_update_event(0x1000 | reg_index, is_debug, old_value, new_value);
}
```

#### 8.39.2 Member Function Documentation

##### 8.39.2.1 operator()

```
template<typename REG_T , typename... ARGS>
```

```
void iris::IrisRegisterUpdateEventEmitter< REG_T, ARGS >::operator() (
    ResourceId rscId,
    bool debug,
    REG_T old_value,
    REG_T new_value,
    ARGS... args ) [inline]
```

Emit an event.

## Parameters

<i>rsclId</i>	Resource id for the register that was accessed.
<i>debug</i>	True if this access originated from a debug access.
<i>old_value</i>	The register value before the event.
<i>new_value</i>	The register value after the event.
<i>args</i>	Any additional custom fields for this event.

The documentation for this class was generated from the following file:

- [IrisRegisterEventEmitter.h](#)

## 8.40 iris::IrisSimulationResetContext Class Reference

Provides context to a reset delegate call.

```
#include <IrisInstanceSimulation.h>
```

### Public Member Functions

- bool [getAllowPartialReset](#) () const  
*Get the allowPartialReset flag.*
- void [setAllowPartialReset](#) (bool value=true)

#### 8.40.1 Detailed Description

Provides context to a reset delegate call.

#### 8.40.2 Member Function Documentation

##### 8.40.2.1 getAllowPartialReset()

```
bool iris::IrisSimulationResetContext::getAllowPartialReset ( ) const [inline]
```

Get the allowPartialReset flag.

##### Returns

Returns true if simulation\_reset() was called with allowPartialReset=true.

The documentation for this class was generated from the following file:

- [IrisInstanceSimulation.h](#)

## 8.41 iris::IrisInstanceBuilder::MemorySpaceBuilder Class Reference

Used to set metadata for a memory space.

```
#include <IrisInstanceBuilder.h>
```

### Public Member Functions

- [MemorySpaceBuilder](#) & [addAttribute](#) (const std::string &name, AttributeInfo attrib)  
*Add an attribute to the attrib field.*
- MemorySpaceId [getSpaceId](#) () const  
*Get the memory space id for this memory space.*
- [MemorySpaceBuilder](#) ([IrisInstanceMemory::SpaceInfoAndAccess](#) &info\_)
- [MemorySpaceBuilder](#) & [setAttributeDefault](#) (const std::string &name, IrisValue value)



- Set the default value for an attribute in the `attrib` field.*

  - [MemorySpaceBuilder](#) & [setCanonicalMsn](#) (uint64\_t canonicalMsn)

*Set the `canonicalMsn` field.*
- [MemorySpaceBuilder](#) & [setDescription](#) (const std::string &description)

*Set the `description` field.*
- [MemorySpaceBuilder](#) & [setEndianness](#) (const std::string &endianness)

*Set the `endianness` field.*
- [MemorySpaceBuilder](#) & [setMaxAddr](#) (uint64\_t maxAddr)

*Set the `maxAddr` field.*
- [MemorySpaceBuilder](#) & [setMinAddr](#) (uint64\_t minAddr)

*Set the `minAddr` field.*
- [MemorySpaceBuilder](#) & [setName](#) (const std::string &name)

*Set the `name` field.*
- template<IrisErrorCode(\*)>(const MemorySpaceInfo &, uint64\_t, uint64\_t, uint64\_t, const AttributeValueMap &, MemoryReadResult &) FUNC>  
[MemorySpaceBuilder](#) & [setReadDelegate](#) ()

*Set the delegate to read this memory space.*
- [MemorySpaceBuilder](#) & [setReadDelegate](#) (MemoryReadDelegate delegate)

*Set the delegate to read this memory space.*
- template<typename T , IrisErrorCode(T::\*)>(const MemorySpaceInfo &, uint64\_t, uint64\_t, uint64\_t, const AttributeValueMap &, MemoryReadResult &) METHOD>  
[MemorySpaceBuilder](#) & [setReadDelegate](#) (T \*instance)

*Set the delegate to read this memory space.*
- template<IrisErrorCode(\*)>(const MemorySpaceInfo &, uint64\_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) FUNC>  
[MemorySpaceBuilder](#) & [setSidebandDelegate](#) ()

*Set the delegate to read sideband information.*
- [MemorySpaceBuilder](#) & [setSidebandDelegate](#) (MemoryGetSidebandInfoDelegate delegate)

*Set the delegate to read sideband information.*
- template<typename T , IrisErrorCode(T::\*)>(const MemorySpaceInfo &, uint64\_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) METHOD>  
[MemorySpaceBuilder](#) & [setSidebandDelegate](#) (T \*instance)

*Set the delegate to read sideband information.*
- [MemorySpaceBuilder](#) & [setSupportedByteWidths](#) (uint64\_t supportedByteWidths)

*Set the `supportedByteWidths` field.*
- template<IrisErrorCode(\*)>(const MemorySpaceInfo &, uint64\_t, uint64\_t, uint64\_t, const AttributeValueMap &, const uint64\_t \*, MemoryWriteResult &) FUNC>  
[MemorySpaceBuilder](#) & [setWriteDelegate](#) ()

*Set the delegate to write to this memory space.*
- [MemorySpaceBuilder](#) & [setWriteDelegate](#) (MemoryWriteDelegate delegate)

*Set the delegate to write to this memory space.*
- template<typename T , IrisErrorCode(T::\*)>(const MemorySpaceInfo &, uint64\_t, uint64\_t, uint64\_t, const AttributeValueMap &, const uint64\_t \*, MemoryWriteResult &) METHOD>  
[MemorySpaceBuilder](#) & [setWriteDelegate](#) (T \*instance)

*Set the delegate to write to this memory space.*

### 8.41.1 Detailed Description

Used to set metadata for a memory space.

### 8.41.2 Member Function Documentation

### 8.41.2.1 addAttribute()

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::addAttribute (
    const std::string & name,
    AttributeInfo attrib ) [inline]
```

Add an attribute to the `attrib` field.

#### Parameters

<i>name</i>	The name of this attribute.
<i>attrib</i>	AttributeInfo for this attribute.

#### Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

### 8.41.2.2 getSpaceId()

```
MemorySpaceId iris::IrisInstanceBuilder::MemorySpaceBuilder::getSpaceId ( ) const [inline]
```

Get the memory space id for this memory space.

This can be useful for setting up address translations and to map access requests to the correct memory space in memory access delegates.

#### Returns

The memory space id for this memory space.

### 8.41.2.3 setAttributeDefault()

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setAttributeDefault (
    const std::string & name,
    IrisValue value ) [inline]
```

Set the default value for an attribute in the `attrib` field.

#### Parameters

<i>name</i>	The name of this attribute.
<i>value</i>	Default value of the named attribute.

#### Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

### 8.41.2.4 setCanonicalMsn()

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setCanonicalMsn (
    uint64_t canonicalMsn ) [inline]
```

Set the `canonicalMsn` field.

#### Parameters

<i>canonicalMsn</i>	The <code>canonicalMsn</code> field of the <code>MemorySpaceInfo</code> object.
---------------------	---

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.5 setDescription()**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setDescription (
    const std::string & description ) [inline]
```

Set the description field.

**Parameters**

<i>description</i>	The description field of the MemorySpaceInfo object.
--------------------	--

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.6 setEndianness()**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setEndianness (
    const std::string & endianness ) [inline]
```

Set the endianness field.

**Parameters**

<i>endianness</i>	The endianness field of the MemorySpaceInfo object.
-------------------	---

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.7 setMaxAddr()**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setMaxAddr (
    uint64_t maxAddr ) [inline]
```

Set the maxAddr field.

**Parameters**

<i>maxAddr</i>	The maxAddr field of the MemorySpaceInfo object.
----------------	--

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.8 setMinAddr()**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setMinAddr (
    uint64_t minAddr ) [inline]
```

Set the minAddr field.

## Parameters

<i>minAddr</i>	The minAddr field of the MemorySpaceInfo object.
----------------	--

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.9 setName()**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setName (
    const std::string & name ) [inline]
```

Set the name field.

## Parameters

<i>name</i>	The name field of the MemorySpaceInfo object.
-------------	---

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.10 setReadDelegate() [1/3]**

```
template<IrisErrorCode(*) (const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const Attribute↔
ValueMap &, MemoryReadResult &) FUNC>
```

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setReadDelegate ( ) [inline]
```

Set the delegate to read this memory space.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultMemoryReadDelegate](#)

## Template Parameters

<i>FUNC</i>	A memory read delegate function.
-------------	----------------------------------

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.11 setReadDelegate() [2/3]**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setReadDelegate (
    MemoryReadDelegate delegate ) [inline]
```

Set the delegate to read this memory space.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultMemoryReadDelegate](#)

## Parameters

<i>delegate</i>	MemoryReadDelegate object.
-----------------	----------------------------

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.12 setReadDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, MemoryReadResult &) METHOD>
```

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setReadDelegate (
    T * instance ) [inline]
```

Set the delegate to read this memory space.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultMemoryReadDelegate](#)

## Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a memory read delegate.
<i>METHOD</i>	A memory read delegate method in class T.

## Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.13 setSidebandDelegate()** [1/3]

```
template<IrisErrorCode(*) (const MemorySpaceInfo &, uint64_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap &) FUNC>
```

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setSidebandDelegate ( )
[inline]
```

Set the delegate to read sideband information.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate](#)

## Template Parameters

<i>FUNC</i>	A memory sideband information delegate function.
-------------	--

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.14 setSidebandDelegate() [2/3]**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setSidebandDelegate (
    MemoryGetSidebandInfoDelegate delegate ) [inline]
```

Set the delegate to read sideband information.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate](#)

**Parameters**

<i>delegate</i>	MemoryGetSidebandInfoDelegate object.
-----------------	---------------------------------------

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.15 setSidebandDelegate() [3/3]**

```
template<typename T , IrisErrorCode(T::*) (const MemorySpaceInfo &, uint64_t, const IrisValue↵
Map &, const std::vector< std::string > &, IrisValueMap &) METHOD>
```

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setSidebandDelegate (
    T * instance ) [inline]
```

Set the delegate to read sideband information.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultGetMemorySidebandInfoDelegate](#)

**Template Parameters**

<i>T</i>	A class that defines a method with the right signature to be a memory sideband information delegate.
<i>METHOD</i>	A memory sideband information delegate method in class T.

**Parameters**

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

**Returns**

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

**8.41.2.16 setSupportedByteWidths()**

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setSupportedByteWidths (
    uint64_t supportedByteWidths ) [inline]
```

Set the `supportedByteWidths` field.

Usage:

`setSupportedByteWidths(1+2+4+8+16);` // Indicate support for byteWidth 1, 2, 4, 8, and 16.

#### Parameters

<i>supportedByteWidths</i>	Outer envelope of all supported byteWidth values Bit mask: Bit N==1 means byteWidth 1 << N is supported.
----------------------------	--

#### Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

#### 8.41.2.17 setWriteDelegate() [1/3]

```
template<IrisErrorCode(*) (const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeMap &, const uint64_t *, MemoryWriteResult &) FUNC>
```

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setWriteDelegate ( ) [inline]
```

Set the delegate to write to this memory space.

If this is not set, the default delegate is used.

#### See also

[IrisInstanceBuilder::setDefaultMemoryWriteDelegate](#)

#### Template Parameters

<i>FUNC</i>	A memory write delegate function.
-------------	-----------------------------------

#### Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

#### 8.41.2.18 setWriteDelegate() [2/3]

```
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setWriteDelegate (
    MemoryWriteDelegate delegate ) [inline]
```

Set the delegate to write to this memory space.

If this is not set, the default delegate is used.

#### See also

[IrisInstanceBuilder::setDefaultMemoryWriteDelegate](#)

#### Parameters

<i>delegate</i>	MemoryWriteDelegate object.
-----------------	-----------------------------

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

## 8.41.2.19 setWriteDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const MemorySpaceInfo &, uint64_t, uint64_t, uint64_t, const AttributeValueMap &, const uint64_t *, MemoryWriteResult &) METHOD>
MemorySpaceBuilder & iris::IrisInstanceBuilder::MemorySpaceBuilder::setWriteDelegate (
    T * instance ) [inline]
```

Set the delegate to write to this memory space.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultMemoryWriteDelegate](#)

## Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a memory write delegate.
<i>METHOD</i>	A memory write delegate method in class T.

## Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

## Returns

A reference to this [MemorySpaceBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.42 iris::IrisCommandLineParser::Option Struct Reference

[Option](#) container.

```
#include <IrisCommandLineParser.h>
```

## Public Member Functions

- [Option](#) & [setList](#) (char sep=',')

## Friends

- class [IrisCommandLineParser](#)

## 8.42.1 Detailed Description

[Option](#) container.

## 8.42.2 Member Function Documentation



### 8.42.2.1 setList()

```
Option & iris::IrisCommandLineParser::Option::setList (
    char sep = ',' ) [inline]
```

Make this option a "list" option which can be specified multiple times. The value is stored as a single string and the elements are separated by "sep". Use [getList\(\)](#) or [getMap\(\)](#) to extract the elements.

The documentation for this struct was generated from the following file:

- [IrisCommandLineParser.h](#)

## 8.43 iris::IrisInstanceBuilder::ParameterBuilder Class Reference

Used to set metadata on a parameter.

```
#include <IrisInstanceBuilder.h>
```

### Public Member Functions

- [ParameterBuilder](#) & [addEnum](#) (const std::string &symbol, const IrisValue &value, const std::string &description=std::string())  
*Add a symbol to the enums field for numeric resources.*
- [ParameterBuilder](#) & [addStringEnum](#) (const std::string &stringValue, const std::string &description=std::string())  
*Add a symbol to the enums field for string resources.*
- ResourceId [getRsclId](#) () const  
*Return the rsclId that was allocated for this resource.*
- [ParameterBuilder](#) & [getRsclId](#) (ResourceId &rsclIdOut)  
*Get the rsclId that was allocated for this resource.*
- [ParameterBuilder](#) ([IrisInstanceResource::ResourceInfoAndAccess](#) &info\_)
- [ParameterBuilder](#) & [setBitWidth](#) (uint64\_t bitWidth)  
*Set the bitWidth field.*
- [ParameterBuilder](#) & [setName](#) (const std::string &cname)  
*Set the cname field.*
- template<typename T >  
[ParameterBuilder](#) & [setDefaultData](#) (std::initializer\_list< T > &&t)  
*Set the default value for wide numeric parameters.*
- [ParameterBuilder](#) & [setDefaultData](#) (uint64\_t value)  
*Set the default value for numeric parameter to a value <= 64 bit.*
- template<typename Container >  
[ParameterBuilder](#) & [setDefaultDataFromContainer](#) (const Container &container)  
*Set the default value for wide numeric parameters.*
- [ParameterBuilder](#) & [setDefaultString](#) (const std::string &defaultString)  
*Set the defaultData field for wide numeric parameters (bitWidth > 64 bit).*
- [ParameterBuilder](#) & [setDescription](#) (const std::string &description)  
*Obsolete alias for [setDescription\(\)](#). Do not use.*
- [ParameterBuilder](#) & [setDescription](#) (const std::string &description)  
*Set the description field.*
- [ParameterBuilder](#) & [setFormat](#) (const std::string &format)  
*Set the format field.*
- [ParameterBuilder](#) & [setHidden](#) (bool hidden=true)  
*Set the resource to hidden.*
- [ParameterBuilder](#) & [setInitOnly](#) (bool initOnly=true)  
*Set the initOnly flag of a parameter.*
- template<typename T >  
[ParameterBuilder](#) & [setMax](#) (std::initializer\_list< T > &&t)

- Set the `max` field for wide numeric parameters.*

  - [ParameterBuilder & setMax](#) (uint64\_t value)

*Set the `max` field to a value  $\leq 64$  bit.*
- template<typename Container >

  - [ParameterBuilder & setMaxFromContainer](#) (const Container &container)

*Set the `max` field for wide numeric parameters.*
- template<typename T >

  - [ParameterBuilder & setMin](#) (std::initializer\_list< T > &&t)

*Set the `min` field for wide numeric parameters.*
- [ParameterBuilder & setMin](#) (uint64\_t value)

*Set the `min` field to a value  $\leq 64$  bit.*
- template<typename Container >

  - [ParameterBuilder & setMinFromContainer](#) (const Container &container)

*Set the `min` field for wide numeric parameters.*
- [ParameterBuilder & setName](#) (const std::string &name)

*Set the `name` field.*
- [ParameterBuilder & setParentRscId](#) (ResourceId parentRscId)

*Set the `parentRscId` field.*
- template<IrisErrorCode(\*)>(const ResourceInfo &, ResourceReadResult &) FUNC>

  - [ParameterBuilder & setReadDelegate](#) ()

*Set the delegate to read the resource.*
- [ParameterBuilder & setReadDelegate](#) (ResourceReadDelegate readDelegate)

*Set the delegate to read the resource.*
- template<typename T , IrisErrorCode(T::\*)(const ResourceInfo &, ResourceReadResult &) METHOD>

  - [ParameterBuilder & setReadDelegate](#) (T \*instance)

*Set the delegate to read the resource.*
- [ParameterBuilder & setRwMode](#) (const std::string &rwMode)

*Set the `rwMode` field.*
- [ParameterBuilder & setSubRscId](#) (uint64\_t subRscId)

*Set the `subRscId` field.*
- [ParameterBuilder & setTag](#) (const std::string &tag)

*Set the named boolean tag to true (e.g. `isPc`)*
- [ParameterBuilder & setTag](#) (const std::string &tag, const IrisValue &value)

*Set a tag to the specified value.*
- [ParameterBuilder & setType](#) (const std::string &type)

*Set the `type` field.*
- template<IrisErrorCode(\*)>(const ResourceInfo &, const ResourceWriteValue &) FUNC>

  - [ParameterBuilder & setWriteDelegate](#) ()

*Set the delegate to write the resource.*
- [ParameterBuilder & setWriteDelegate](#) (ResourceWriteDelegate writeDelegate)

*Set the delegate to write the resource.*
- template<typename T , IrisErrorCode(T::\*)(const ResourceInfo &, const ResourceWriteValue &) METHOD>

  - [ParameterBuilder & setWriteDelegate](#) (T \*instance)

*Set the delegate to write the resource.*

### 8.43.1 Detailed Description

Used to set metadata on a parameter.

### 8.43.2 Member Function Documentation

### 8.43.2.1 addEnum()

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::addEnum (
    const std::string & symbol,
    const IrisValue & value,
    const std::string & description = std::string() ) [inline]
```

Add a symbol to the enums field for numeric resources.

This should be called multiple times to add multiple symbols.

#### Parameters

<i>symbol</i>	The symbol string to be associated with the specified value.
<i>value</i>	The value of this symbol.
<i>description</i>	A description of this symbol.

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

### 8.43.2.2 addStringEnum()

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::addStringEnum (
    const std::string & stringValue,
    const std::string & description = std::string() ) [inline]
```

Add a symbol to the enums field for string resources.

This should be called multiple times to add multiple symbols.

#### Parameters

<i>value</i>	The string value of this symbol. This is also used as the symbols string.
<i>description</i>	A description of this symbol.

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

### 8.43.2.3 getRscId() [1/2]

```
ResourceId iris::IrisInstanceBuilder::ParameterBuilder::getRscId ( ) const [inline]
```

Return the rscId that was allocated for this resource.

#### Returns

The rscId that was allocated for this resource.

### 8.43.2.4 getRscId() [2/2]

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::getRscId (
    ResourceId & rscIdOut ) [inline]
```

Get the rscId that was allocated for this resource.

This variant is useful to get the ResourceId of fields added in a chained call where return values are not practical.

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.5 setBitWidth()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setBitWidth (
    uint64_t bitWidth ) [inline]
```

Set the `bitWidth` field.

**Parameters**

<i>bitWidth</i>	The <code>bitWidth</code> field of the <code>ResourceInfo</code> object.
-----------------	--

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.6 setCname()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setCname (
    const std::string & cname ) [inline]
```

Set the `cname` field.

**Parameters**

<i>cname</i>	The <code>cname</code> field of the <code>ResourceInfo</code> object.
--------------	---

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.7 setDefaultData() [1/2]**

```
template<typename T >
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setDefaultData (
    std::initializer_list< T > && t ) [inline]
```

Set the default value for wide numeric parameters.

This function accepts a braced initializer-list and is otherwise identical to [setDefaultDataFromContainer\(\)](#).

Each element will be promoted/narrowed to `uint64_t`.

**Parameters**

<i>t</i>	Braced initializer-list.
----------	--------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.8 setDefaultData() [2/2]**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setDefaultData (
```

```
uint64_t value ) [inline]
```

Set the default value for numeric parameter to a value  $\leq 64$  bit.

If the parameter is wider than the passed value the value is zero extended.

If the parameter is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>value</i>	The defaultData field of the ParameterInfo object.
--------------	--

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

### 8.43.2.9 setDefaultDataFromContainer()

```
template<typename Container >
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setDefaultDataFromContainer (
    const Container & container ) [inline]
```

Set the default value for wide numeric parameters.

Container must be a type which allows to iterate over uint64\_t bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to uint64\_t.

If the parameter is wider than the passed value the value is zero extended.

If the parameter is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

### 8.43.2.10 setDefaultString()

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setDefaultString (
    const std::string & defaultString ) [inline]
```

Set the defaultData field for wide numeric parameters (bitWidth > 64 bit).

Set the default value for string parameters.

#### Parameters

<i>defaultString</i>	The defaultString field of the ParameterInfo object.
----------------------	--

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

### 8.43.2.11 setDescription()

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setDescription (
    const std::string & description ) [inline]
```

Set the description field.

## Parameters

<i>description</i>	The description field of the ResourceInfo object.
--------------------	---

## Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.12 setFormat()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setFormat (
    const std::string & format ) [inline]
```

Set the `format` field.

## Parameters

<i>format</i>	The format field of the ResourceInfo object.
---------------	--

## Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.13 setHidden()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setHidden (
    bool hidden = true ) [inline]
```

Set the resource to hidden.

## Parameters

<i>hidden</i>	If true, this resource is not listed in <code>resource_getList()</code> calls
---------------	---

## Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.14 setInitOnly()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setInitOnly (
    bool initOnly = true ) [inline]
```

Set the `initOnly` flag of a parameter.

This also implicitly sets the parameter to read-only.

## Parameters

<i>initOnly</i>	The <code>initOnly</code> flag of a parameter.
-----------------	--

## Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.15 setMax()** [1/2]

```
template<typename T >
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setMax (
    std::initializer_list< T > && t ) [inline]
```

Set the `max` field for wide numeric parameters.

This function accepts a braced initializer-list and is otherwise identical to [setMaxFromContainer\(\)](#).

Each element will be promoted/narrowed to `uint64_t`.

**Parameters**

<i>t</i>	Braced initializer-list.
----------	--------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.16 setMax()** [2/2]

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setMax (
    uint64_t value ) [inline]
```

Set the `max` field to a value  $\leq 64$  bit.

If the parameter is wider than the passed value the value is zero extended.

If the parameter is narrower than the passed value the superfluous bits are ignored.

**Parameters**

<i>value</i>	Max value of the parameter.
--------------	-----------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.17 setMaxFromContainer()**

```
template<typename Container >
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setMaxFromContainer (
    const Container & container ) [inline]
```

Set the `max` field for wide numeric parameters.

Container must be a type which allows to iterate over `uint64_t` bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to `uint64_t`.

If the parameter is wider than the passed value the value is zero extended.

If the parameter is narrower than the passed value the superfluous bits are ignored.

**Parameters**

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.18 setMin()** [1/2]

```
template<typename T >
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setMin (
    std::initializer_list< T > && t ) [inline]
```

Set the `min` field for wide numeric parameters.

This function accepts a braced initializer-list and is otherwise identical to [setMinFromContainer\(\)](#).

Each element will be promoted/narrowed to `uint64_t`.

**Parameters**

<i>t</i>	Braced initializer-list.
----------	--------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.19 setMin()** [2/2]

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setMin (
    uint64_t value ) [inline]
```

Set the `min` field to a value  $\leq 64$  bit.

If the parameter is wider than the passed value the value is zero extended.

If the parameter is narrower than the passed value the superfluous bits are ignored.

**Parameters**

<i>value</i>	min value of the parameter.
--------------	-----------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.20 setMinFromContainer()**

```
template<typename Container >
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setMinFromContainer (
    const Container & container ) [inline]
```

Set the `min` field for wide numeric parameters.

Container must be a type which allows to iterate over `uint64_t` bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to `uint64_t`.

If the parameter is wider than the passed value the value is zero extended.

If the parameter is narrower than the passed value the superfluous bits are ignored.

**Parameters**

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.



**8.43.2.21 setName()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setName (
    const std::string & name ) [inline]
```

Set the name field.

**Parameters**

<i>name</i>	The name field of the ResourceInfo object.
-------------	--

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.22 setParentRscId()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setParentRscId (
    ResourceId parentRscId ) [inline]
```

Set the parentRscId field.

This function makes this register a child of the specified parent. It is not necessary to call this function when adding child registers using the addField() function.

**Parameters**

<i>parent↔ RscId</i>	The rscId of the parent register.
--------------------------	-----------------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.23 setReadDelegate() [1/3]**

```
template<IrisErrorCode(*)>(const ResourceInfo &, ResourceReadResult &) FUNC>
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setReadDelegate ( ) [inline]
```

Set the delegate to read the resource.

Set a delegate which calls function FUNC().

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

**Template Parameters**

<i>FUNC</i>	A resource read delegate function.
-------------	------------------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.24 setReadDelegate() [2/3]**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setReadDelegate (
```

```
ResourceReadDelegate readDelegate ) [inline]
```

Set the delegate to read the resource.

If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

#### Parameters

<i>readDelegate</i>	ResourceReadDelegate object.
---------------------	------------------------------

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

#### 8.43.2.25 setReadDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) METHOD>
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setReadDelegate (
    T * instance ) [inline]
```

Set the delegate to read the resource.

Set a delegate which calls METHOD() on an instance of class T.

If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

#### Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a resource read delegate.
<i>METHOD</i>	A resource read delegate method in class T.

#### Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

#### 8.43.2.26 setRwMode()

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setRwMode (
    const std::string & rwMode ) [inline]
```

Set the `rwMode` field.

#### Parameters

<i>rwMode</i>	The <code>rwMode</code> field of the ResourceInfo object.
---------------	---

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.27 setSubRscId()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setSubRscId (
    uint64_t subRscId ) [inline]
```

Set the subRscId field.

**Parameters**

<i>sub↔ RscId</i>	The subRscId field of the ResourceInfo object.
-----------------------	--

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.28 setTag() [1/2]**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setTag (
    const std::string & tag ) [inline]
```

Set the named boolean tag to true (e.g. isPc)

**Parameters**

<i>tag</i>	The name of the tag to set.
------------	-----------------------------

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.29 setTag() [2/2]**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setTag (
    const std::string & tag,
    const IrisValue & value ) [inline]
```

Set a tag to the specified value.

**Parameters**

<i>tag</i>	The name of the tag to set.
<i>value</i>	The value to set the tag to.

**Returns**

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

**8.43.2.30 setType()**

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setType (
    const std::string & type ) [inline]
```

Set the `type` field.

#### Parameters

<i>type</i>	The type field of the ResourceInfo object.
-------------	--

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

#### 8.43.2.31 setWriteDelegate() [1/3]

```
template<IrisErrorCode(*) (const ResourceInfo &, const ResourceWriteValue &) FUNC>
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setWriteDelegate ( ) [inline]
```

Set the delegate to write the resource.

Set a delegate which calls function FUNC().

If this is not set, the default delegate is used.

#### See also

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

#### Template Parameters

<i>FUNC</i>	A resource write delegate function.
-------------	-------------------------------------

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

#### 8.43.2.32 setWriteDelegate() [2/3]

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setWriteDelegate (
    ResourceWriteDelegate writeDelegate ) [inline]
```

Set the delegate to write the resource.

If this is not set, the default delegate is used.

#### See also

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

#### Parameters

<i>writeDelegate</i>	ResourceWriteDelegate object.
----------------------	-------------------------------

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

#### 8.43.2.33 setWriteDelegate() [3/3]

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &)
METHOD>
```

```
ParameterBuilder & iris::IrisInstanceBuilder::ParameterBuilder::setWriteDelegate (
    T * instance ) [inline]
```

Set the delegate to write the resource.

Set a delegate which calls METHOD() on an instance of class T.

If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

#### Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a resource write delegate.
<i>METHOD</i>	A resource write delegate method in class T.

#### Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

#### Returns

A reference to this [ParameterBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.44 iris::IrisInstanceEvent::ProxyEventInfo Struct Reference

Contains information for a single proxy EventSource.

```
#include <IrisInstanceEvent.h>
```

### Public Attributes

- `std::vector< EventStreamId > evStreamIds`
- EventSourceId **targetEvSrcId** {}
- InstanceId **targetInstId** {}

#### 8.44.1 Detailed Description

Contains information for a single proxy EventSource.

The documentation for this struct was generated from the following file:

- [IrisInstanceEvent.h](#)

## 8.45 iris::IrisInstanceBuilder::RegisterBuilder Class Reference

Used to set metadata on a register resource.

```
#include <IrisInstanceBuilder.h>
```

### Public Member Functions

- [RegisterBuilder](#) & [addEnum](#) (const std::string &symbol, const IrisValue &value, const std::string &description=std::string())

*Add a symbol to the enums field for numeric resources.*

- **FieldBuilder addField** (const std::string &name, uint64\_t lsbOffset, uint64\_t bitWidth, const std::string &description)  
*Add a subregister field to this register. By default, the field copies attributes from its parent register, but any field can be overridden.*
- **FieldBuilder addLogicalField** (const std::string &name, uint64\_t bitWidth, const std::string &description)  
*Add a logical subregister field to this register. A logical field is a field which has a bitwidth, but which does not have an lsbOffset. It is usually used to represent non-contiguous fields which are distributed across multiple chunks in the parent register as a single contiguous register. This allows to attach enums to such a field.*
- **RegisterBuilder & addStringEnum** (const std::string &stringValue, const std::string &description=std::string())  
*Add a symbol to the enums field for string resources.*
- **ResourceId getRsclId** () const  
*Return the rsclId that was allocated for this resource.*
- **RegisterBuilder & getRsclId** (ResourceId &rsclIdOut)  
*Get the rsclId that was allocated for this resource.*
- **RegisterBuilder** (IrisInstanceResource::ResourceInfoAndAccess &info\_, IrisInstanceResource \*inst\_ ↵ resource\_, IrisInstanceBuilder \*instance\_builder\_)
- **RegisterBuilder & setAddressOffset** (uint64\_t addressOffset)  
*Set the addressOffset field.*
- **RegisterBuilder & setBitWidth** (uint64\_t bitWidth)  
*Set the bitWidth field.*
- **RegisterBuilder & setCanonicalRn** (uint64\_t canonicalRn\_)  
*Set the canonicalRn field.*
- **RegisterBuilder & setCanonicalRnElfDwarf** (uint16\_t architecture, uint16\_t dwarfRegNum)  
*Set the canonicalRn field for "ElfDwarf" scheme.*
- **RegisterBuilder & setCname** (const std::string &cname)  
*Set the cname field.*
- **RegisterBuilder & setDescr** (const std::string &description)  
*Obsolete alias for setDescription(). Do not use.*
- **RegisterBuilder & setDescription** (const std::string &description)  
*Set the description field.*
- **RegisterBuilder & setFormat** (const std::string &format)  
*Set the format field.*
- **RegisterBuilder & setLsbOffset** (uint64\_t lsbOffset)  
*Set the lsbOffset field.*
- **RegisterBuilder & setName** (const std::string &name)  
*Set the name field.*
- **RegisterBuilder & setParentRsclId** (ResourceId parentRsclId)  
*Set the parentRsclId field.*
- **template<IrisErrorCode(\*)>(const ResourceInfo &, ResourceReadResult &) FUNC>**  
**RegisterBuilder & setReadDelegate** ()  
*Set the delegate to read the resource.*
- **RegisterBuilder & setReadDelegate** (ResourceReadDelegate readDelegate)  
*Set the delegate to read the resource.*
- **template<typename T, IrisErrorCode(T::\*)(const ResourceInfo &, ResourceReadResult &) METHOD>**  
**RegisterBuilder & setReadDelegate** (T \*instance)  
*Set the delegate to read the resource.*
- **template<typename T>**  
**RegisterBuilder & setResetData** (std::initializer\_list< T > &&t)  
*Set the resetData field for wide registers.*
- **RegisterBuilder & setResetData** (uint64\_t value)  
*Set the resetData field to a value <= 64 bit.*

- `template<typename Container >`  
[RegisterBuilder](#) & [setResetDataFromContainer](#) (const Container &container)  
*Set the `resetData` field for wide registers.*
- [RegisterBuilder](#) & [setResetString](#) (const std::string &resetString)  
*Set the `resetString` field.*
- [RegisterBuilder](#) & [setRwMode](#) (const std::string &rwMode)  
*Set the `rwMode` field.*
- [RegisterBuilder](#) & [setSubRscId](#) (uint64\_t subRscId)  
*Set the `subRscId` field.*
- [RegisterBuilder](#) & [setTag](#) (const std::string &tag)  
*Set the named boolean tag to true (e.g. `isPc`)*
- [RegisterBuilder](#) & [setTag](#) (const std::string &tag, const IrisValue &value)  
*Set a tag to the specified value.*
- [RegisterBuilder](#) & [setType](#) (const std::string &type)  
*Set the `type` field.*
- `template<IrisErrorCode(*)>(const ResourceInfo &, const ResourceWriteValue &) FUNC>`  
[RegisterBuilder](#) & [setWriteDelegate](#) ()  
*Set the delegate to write the resource.*
- [RegisterBuilder](#) & [setWriteDelegate](#) ([ResourceWriteDelegate](#) writeDelegate)  
*Set the delegate to write the resource.*
- `template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &) METHOD>`  
[RegisterBuilder](#) & [setWriteDelegate](#) (T \*instance)  
*Set the delegate to write the resource.*
- `template<typename T >`  
[RegisterBuilder](#) & [setWriteMask](#) (std::initializer\_list< T > &&t)  
*Set the `writeMask` field for wide registers.*
- [RegisterBuilder](#) & [setWriteMask](#) (uint64\_t value)  
*Set the `writeMask` field to a value  $\leq 64$  bit.*
- `template<typename Container >`  
[RegisterBuilder](#) & [setWriteMaskFromContainer](#) (const Container &container)  
*Set the `writeMask` field for wide registers.*

### 8.45.1 Detailed Description

Used to set metadata on a register resource.

### 8.45.2 Member Function Documentation

#### 8.45.2.1 addEnum()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::addEnum (
    const std::string & symbol,
    const IrisValue & value,
    const std::string & description = std::string() ) [inline]
```

Add a symbol to the enums field for numeric resources.

This should be called multiple times to add multiple symbols.

#### Parameters

<i>symbol</i>	The symbol string to be associated with the specified value.
<i>value</i>	The value of this symbol.
<i>description</i>	A description of this symbol.

### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.2 addField()

```
FieldBuilder iris::IrisInstanceBuilder::RegisterBuilder::addField (
    const std::string & name,
    uint64_t lsbOffset,
    uint64_t bitWidth,
    const std::string & description )
```

Add a subregister field to this register. By default, the field copies attributes from its parent register, but any field can be overridden.

### Parameters

<i>name</i>	Name of the register field.
<i>lsbOffset</i>	The bit offset of this field inside its parent register.
<i>bitWidth</i>	The size of the field.
<i>description</i>	Description of this field.

### Returns

A [FieldBuilder](#) object that allows the caller to set attributes for this field.

#### 8.45.2.3 addLogicalField()

```
FieldBuilder iris::IrisInstanceBuilder::RegisterBuilder::addLogicalField (
    const std::string & name,
    uint64_t bitWidth,
    const std::string & description )
```

Add a logical subregister field to this register. A logical field is a field which has a bitwidth, but which does not have an lsbOffset. It is usually used to represent non-contiguous fields which are distributed across multiple chunks in the parent register as a single contiguous register. This allows to attach enums to such a field. By default, the field copies attributes from its parent register, but any field can be overridden.

### Parameters

<i>name</i>	Name of the register field.
<i>bitWidth</i>	The size of the field.
<i>description</i>	Description of this field.

### Returns

A [FieldBuilder](#) object that allows the caller to set attributes for this field.

#### 8.45.2.4 addStringEnum()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::addStringEnum (
    const std::string & stringValue,
    const std::string & description = std::string() ) [inline]
```

Add a symbol to the enums field for string resources. This should be called multiple times to add multiple symbols.



## Parameters

<i>value</i>	The string value of this symbol. This is also used as the symbols string.
<i>description</i>	A description of this symbol.

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.5 getRscId() [1/2]**

```
ResourceId iris::IrisInstanceBuilder::RegisterBuilder::getRscId ( ) const [inline]
```

Return the rscId that was allocated for this resource.

## Returns

The rscId that was allocated for this resource.

**8.45.2.6 getRscId() [2/2]**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::getRscId (
    ResourceId & rscIdOut ) [inline]
```

Get the rscId that was allocated for this resource.

This variant is useful to get the ResourceId of fields added in a chained call where return values are not practical.

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.7 setAddressOffset()**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setAddressOffset (
    uint64_t addressOffset ) [inline]
```

Set the addressOffset field.

## Parameters

<i>addressOffset</i>	The addressOffset field of the RegisterInfo object.
----------------------	---

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.8 setBitWidth()**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setBitWidth (
    uint64_t bitWidth ) [inline]
```

Set the bitWidth field.

## Parameters

<i>bitWidth</i>	The bitWidth field of the ResourceInfo object.
-----------------	--

### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.9 setCanonicalRn()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setCanonicalRn (
    uint64_t canonicalRn_ ) [inline]
```

Set the `canonicalRn` field.

Note: Use [setCanonicalRnElfDwarf\(\)](#) when using the "ElfDwarf" scheme.

### Parameters

<i>canonicalRn</i>	The canonicalRn field of the RegisterInfo object.
--------------------	---

### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.10 setCanonicalRnElfDwarf()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setCanonicalRnElfDwarf (
    uint16_t architecture,
    uint16_t dwarfRegNum ) [inline]
```

Set the `canonicalRn` field for "ElfDwarf" scheme.

### Parameters

<i>architecture</i>	ELF EM_* constant for architecture.
<i>dwarfRegNum</i>	DWARF register number for architecture.

### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.11 setCname()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setCname (
    const std::string & cname ) [inline]
```

Set the `cname` field.

### Parameters

<i>cname</i>	The cname field of the ResourceInfo object.
--------------	---

### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.12 setDescription()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setDescription (
    const std::string & description ) [inline]
```

Set the `description` field.

#### Parameters

<i>description</i>	The description field of the ResourceInfo object.
--------------------	---

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.13 setFormat()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setFormat (
    const std::string & format ) [inline]
```

Set the `format` field.

#### Parameters

<i>format</i>	The format field of the ResourceInfo object.
---------------	--

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.14 setLsbOffset()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setLsbOffset (
    uint64_t lsbOffset ) [inline]
```

Set the `lsbOffset` field.

#### Parameters

<i>lsbOffset</i>	The lsbOffset field of the RegisterInfo object.
------------------	---

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.15 setName()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setName (
    const std::string & name ) [inline]
```

Set the `name` field.

#### Parameters

<i>name</i>	The name field of the ResourceInfo object.
-------------	--

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.16 setParentRscId()**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setParentRscId (
    ResourceId parentRscId ) [inline]
```

Set the `parentRscId` field.

This function makes this register a child of the specified parent. It is not necessary to call this function when adding child registers using the [addField\(\)](#) function.

**Parameters**

<i>parentRscId</i>	The rscId of the parent register.
--------------------	-----------------------------------

**Returns**

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.17 setReadDelegate() [1/3]**

```
template<IrisErrorCode(*)>(const ResourceInfo &, ResourceReadResult &) FUNC>
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setReadDelegate ( ) [inline]
```

Set the delegate to read the resource.

Set a delegate which calls function `FUNC()`.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

**Template Parameters**

<i>FUNC</i>	A resource read delegate function.
-------------	------------------------------------

**Returns**

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.18 setReadDelegate() [2/3]**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setReadDelegate (
    ResourceReadDelegate readDelegate ) [inline]
```

Set the delegate to read the resource.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

**Parameters**

<i>readDelegate</i>	ResourceReadDelegate object.
---------------------	------------------------------

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.19 setReadDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, ResourceReadResult &) METHOD>
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setReadDelegate (
    T * instance ) [inline]
```

Set the delegate to read the resource.

Set a delegate which calls METHOD() on an instance of class T.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultResourceReadDelegate](#)

## Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a resource read delegate.
<i>METHOD</i>	A resource read delegate method in class T.

## Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.20 setResetData()** [1/2]

```
template<typename T >
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setResetData (
    std::initializer_list< T > && t ) [inline]
```

Set the `resetData` field for wide registers.

This function accepts a braced initializer-list and is otherwise identical to [setResetDataFromContainer\(\)](#).

Each element will be promoted/narrowed to `uint64_t`.

## Parameters

<i>t</i>	Braced initializer-list.
----------	--------------------------

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.21 setResetData()** [2/2]

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setResetData (
    uint64_t value ) [inline]
```

Set the `resetData` field to a value  $\leq 64$  bit.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>value</i>	resetData value of the register.
--------------	----------------------------------

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.22 setResetDataFromContainer()

```
template<typename Container >
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setResetDataFromContainer (
    const Container & container ) [inline]
```

Set the `resetData` field for wide registers.

Container must be a type which allows to iterate over `uint64_t` bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to `uint64_t`.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.23 setResetString()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setResetString (
    const std::string & resetString ) [inline]
```

Set the `resetString` field.

Set the reset value for string registers.

#### Parameters

<i>resetString</i>	The <code>resetString</code> field of the <code>RegisterInfo</code> object.
--------------------	---

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.24 setRwMode()

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setRwMode (
    const std::string & rwMode ) [inline]
```

Set the `rwMode` field.

## Parameters

<i>rwMode</i>	The rwMode field of the ResourceInfo object.
---------------	--

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.25 setSubRscId()**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setSubRscId (
    uint64_t subRscId ) [inline]
```

Set the subRscId field.

## Parameters

<i>sub↔ RscId</i>	The subRscId field of the ResourceInfo object.
-----------------------	--

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.26 setTag() [1/2]**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setTag (
    const std::string & tag ) [inline]
```

Set the named boolean tag to true (e.g. isPc)

## Parameters

<i>tag</i>	The name of the tag to set.
------------	-----------------------------

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.27 setTag() [2/2]**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setTag (
    const std::string & tag,
    const IrisValue & value ) [inline]
```

Set a tag to the specified value.

## Parameters

<i>tag</i>	The name of the tag to set.
<i>value</i>	The value to set the tag to.

**Returns**

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.28 setType()**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setType (
    const std::string & type ) [inline]
```

Set the type field.

**Parameters**

<i>type</i>	The type field of the ResourceInfo object.
-------------	--

**Returns**

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.29 setWriteDelegate() [1/3]**

```
template<IrisErrorCode(*) (const ResourceInfo &, const ResourceWriteValue &) FUNC>
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setWriteDelegate ( ) [inline]
```

Set the delegate to write the resource.

Set a delegate which calls function FUNC().

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

**Template Parameters**

<i>FUNC</i>	A resource write delegate function.
-------------	-------------------------------------

**Returns**

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.30 setWriteDelegate() [2/3]**

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setWriteDelegate (
    ResourceWriteDelegate writeDelegate ) [inline]
```

Set the delegate to write the resource.

If this is not set, the default delegate is used.

**See also**

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

**Parameters**

<i>writeDelegate</i>	ResourceWriteDelegate object.
----------------------	-------------------------------



## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.31 setWriteDelegate()** [3/3]

```
template<typename T , IrisErrorCode(T::*)(const ResourceInfo &, const ResourceWriteValue &)
METHOD>
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setWriteDelegate (
    T * instance ) [inline]
```

Set the delegate to write the resource.

Set a delegate which calls METHOD() on an instance of class T.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultResourceWriteDelegate](#)

## Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a resource write delegate.
<i>METHOD</i>	A resource write delegate method in class T.

## Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.32 setWriteMask()** [1/2]

```
template<typename T >
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setWriteMask (
    std::initializer_list< T > && t ) [inline]
```

Set the writeMask field for wide registers.

This function accepts a braced initializer-list and is otherwise identical to

[setWriteMaskFromContainer\(\)](#).

Each element will be promoted/narrowed to uint64\_t.

## Parameters

<i>t</i>	Braced initializer-list.
----------	--------------------------

## Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

**8.45.2.33 setWriteMask()** [2/2]

```
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setWriteMask (
    uint64_t value ) [inline]
```

Set the `writeMask` field to a value  $\leq 64$  bit.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>value</i>	writeMask value of the register.
--------------	----------------------------------

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

#### 8.45.2.34 setWriteMaskFromContainer()

```
template<typename Container >
RegisterBuilder & iris::IrisInstanceBuilder::RegisterBuilder::setWriteMaskFromContainer (
    const Container & container ) [inline]
```

Set the `writeMask` field for wide registers.

Container must be a type which allows to iterate over `uint64_t` bit chunks of the value, least significant bits first, for example `std::array<uint64_t>` or `std::vector<uint64_t>`.

Each element of the container will be promoted/narrowed to `uint64_t`.

If the register is wider than the passed value the value is zero extended.

If the register is narrower than the passed value the superfluous bits are ignored.

#### Parameters

<i>container</i>	Container containing the value in 64-bit chunks.
------------------	--

#### Returns

A reference to this [RegisterBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.46 iris::IrisInstanceResource::ResourceInfoAndAccess Struct Reference

Entry in 'resourceInfos'.

```
#include <IrisInstanceResource.h>
```

### Public Attributes

- [ResourceReadDelegate](#) `readDelegate`
- ResourceInfo `resourceInfo`
- [ResourceWriteDelegate](#) `writeDelegate`

### 8.46.1 Detailed Description

Entry in 'resourceInfos'.

Contains static resource information and information on how to access the resource.

The documentation for this struct was generated from the following file:

- [IrisInstanceResource.h](#)

## 8.47 iris::ResourceWriteValue Struct Reference

```
#include <IrisInstanceResource.h>
```

### Public Attributes

- const uint64\_t \* **data** {}
  - const std::string \* **str** {}
- Non-null for non-string resources.*

### 8.47.1 Detailed Description

Write value for ResourceWriteDelegate. This struct is used as a union. At most one of the two pointers is non-null when ResourceWriteDelegate is invoked.

The documentation for this struct was generated from the following file:

- [IrisInstanceResource.h](#)

## 8.48 iris::IrisInstanceBuilder::SemihostingManager Class Reference

semihosting\_apis [IrisInstanceBuilder](#) semihosting APIs

```
#include <IrisInstanceBuilder.h>
```

### Public Member Functions

- void **enableExtensions** ()  
*Instances that support semihosting extensions should call this function to enable the `IRIS_SEMIHOSTING_CALL_EXTENSION` event.*
- std::vector< uint8\_t > **readData** (uint64\_t fDes, size\_t max\_size=0, uint64\_t flags=semihost::DEFAULT)  
*Read data for a given file descriptor.*
- std::pair< bool, uint64\_t > **semihostedCall** (uint64\_t operation, uint64\_t parameter)  
*Allow a client to perform a semihosting extension defined by operation and parameter.*
- **SemihostingManager** ([IrisInstanceSemihosting](#) \*inst\_semihost\_)
- void **unblock** ()
- bool **writeData** (uint64\_t fDes, const std::vector< uint8\_t > &data)
- bool **writeData** (uint64\_t fDes, const uint8\_t \*data, size\_t size)

### 8.48.1 Detailed Description

semihosting\_apis [IrisInstanceBuilder](#) semihosting APIs

Manage semihosting functionality

### 8.48.2 Member Function Documentation

#### 8.48.2.1 readData()

```
std::vector< uint8_t > iris::IrisInstanceBuilder::SemihostingManager::readData (
    uint64_t fDes,
    size_t max_size = 0,
    uint64_t flags = semihost::DEFAULT ) [inline]
```

Read data for a given file descriptor.

The exact behavior of this method depends on the value of the max\_size and flags parameters. If the NONBLOCK flag is set, the method returns immediately with whatever data is already buffered, if any. If NONBLOCK is not set, the method blocks until data is available. Iris messages continue to be processed while this methods blocks. If max\_size is not zero, then at most max\_size bytes will be returned.

## Parameters

<i>fDes</i>	File descriptor to read from. Usually semihost::STDIN.
<i>max_size</i>	The maximum amount of bytes to read or zero for no limit.
<i>flags</i>	A bitwise OR of <a href="#">Semihosting data request flag constants</a> .

## Returns

A vector of data that was read.

## 8.48.2.2 semihostedCall()

```
std::pair< bool, uint64_t > iris::IrisInstanceBuilder::SemihostingManager::semihostedCall (
    uint64_t operation,
    uint64_t parameter ) [inline]
```

Allow a client to perform a semihosting extension defined by *operation* and *parameter*.

This might implement a user-defined operation or override the default implementation for a predefined operation.

## Parameters

<i>operation</i>	A number indicating the operation to perform. This is defined by the semihosting standard for standard operations or by the client for user-defined operations.
<i>parameter</i>	A parameter to the operation. The meaning of this parameter is defined by the operation.

## Returns

A pair of (bool success, uint64\_t result). If success is true, a client performed the function and returned the value in result. If success is false, no client performed the function and result is 0.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

## 8.49 iris::IrisInstanceMemory::SpaceInfoAndAccess Struct Reference

Entry in 'spaceInfos'.

```
#include <IrisInstanceMemory.h>
```

## Public Attributes

- [MemoryReadDelegate](#) **readDelegate**
- [MemoryGetSidebandInfoDelegate](#) **sidebandDelegate**
- MemorySpaceInfo **spaceInfo**
- [MemoryWriteDelegate](#) **writeDelegate**

## 8.49.1 Detailed Description

Entry in 'spaceInfos'.

Contains static memory space information and information on how to access the space.

The documentation for this struct was generated from the following file:

- [IrisInstanceMemory.h](#)

## 8.50 iris::IrisInstanceBuilder::TableBuilder Class Reference

Used to set metadata for a table.

```
#include <IrisInstanceBuilder.h>
```

## Public Member Functions

- [TableColumnBuilder addColumn](#) (const std::string &name)  
*Add a new column.*
- [TableBuilder & addColumnInfo](#) (const TableColumnInfo &columnInfo)  
*Add a column with a preconstructed TableColumnInfo.*
- [TableBuilder & setDescription](#) (const std::string &description)  
*Set the description field.*
- [TableBuilder & setFormatLong](#) (const std::string &format)  
*Set the formatLong field.*
- [TableBuilder & setFormatShort](#) (const std::string &format)  
*Set the formatShort field.*
- [TableBuilder & setIndexFormatHint](#) (const std::string &hint)  
*Set the indexFormatHint field.*
- [TableBuilder & setMaxIndex](#) (uint64\_t maxIndex)  
*Set the maxIndex field.*
- [TableBuilder & setMinIndex](#) (uint64\_t minIndex)  
*Set the minIndex field.*
- [TableBuilder & setName](#) (const std::string &name)  
*Set the name field.*
- [template<IrisErrorCode\(\\*\)>\(const TableInfo &, uint64\\_t, uint64\\_t, TableReadResult &\) FUNC>](#)  
[TableBuilder & setReadDelegate](#) ()  
*Set the delegate to read the table.*
- [template<typename T , IrisErrorCode\(T::\\*\)\(const TableInfo &, uint64\\_t, uint64\\_t, TableReadResult &\) METHOD>](#)  
[TableBuilder & setReadDelegate](#) (T \*instance)  
*Set the delegate to read the table.*
- [TableBuilder & setReadDelegate](#) (TableReadDelegate delegate)  
*Set the delegate to read the table.*
- [template<IrisErrorCode\(\\*\)>\(const TableInfo &, const TableRecords &, TableWriteResult &\) FUNC>](#)  
[TableBuilder & setWriteDelegate](#) ()  
*Set the delegate to write to the table.*
- [template<typename T , IrisErrorCode\(T::\\*\)\(const TableInfo &, const TableRecords &, TableWriteResult &\) METHOD>](#)  
[TableBuilder & setWriteDelegate](#) (T \*instance)  
*Set the delegate to write to the table.*
- [TableBuilder & setWriteDelegate](#) (TableWriteDelegate delegate)  
*Set the delegate to write to the table.*
- [TableBuilder](#) ([IrisInstanceTable::TableInfoAndAccess](#) &info\_)

### 8.50.1 Detailed Description

Used to set metadata for a table.

### 8.50.2 Member Function Documentation

#### 8.50.2.1 addColumn()

```
IrisInstanceBuilder::TableColumnBuilder iris::IrisInstanceBuilder::TableBuilder::addColumn (
    const std::string & name ) [inline]
```

Add a new column.

Call this multiple times for multiple columns

See also

[AddColumnInfo](#)

## Parameters

<i>name</i>	The name of the new column.
-------------	-----------------------------

## Returns

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

**8.50.2.2 addColumnInfo()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::addColumnInfo (
    const TableColumnInfo & columnInfo ) [inline]
```

Add a column with a preconstructed TableColumnInfo.

Call this multiple times for multiple columns.

## See also

[addColumn](#)

## Parameters

<i>columnInfo</i>	A preconstructed TableColumnInfo object for the new column.
-------------------	---

## Returns

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.3 setDescription()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setDescription (
    const std::string & description ) [inline]
```

Set the description field.

## Parameters

<i>description</i>	The description field of the TableInfo object.
--------------------	--

## Returns

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.4 setFormatLong()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setFormatLong (
    const std::string & format ) [inline]
```

Set the formatLong field.

## Parameters

<i>format</i>	The formatLong field of the TableInfo object.
---------------	---

**Returns**

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.5 setFormatShort()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setFormatShort (
    const std::string & format ) [inline]
```

Set the `formatShort` field.

**Parameters**

<i>format</i>	The <code>formatShort</code> field of the <code>TableInfo</code> object.
---------------	--

**Returns**

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.6 setIndexFormatHint()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setIndexFormatHint (
    const std::string & hint ) [inline]
```

Set the `indexFormatHint` field.

**Parameters**

<i>hint</i>	The <code>indexFormatHint</code> field of the <code>TableInfo</code> object.
-------------	--

**Returns**

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.7 setMaxIndex()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setMaxIndex (
    uint64_t maxIndex ) [inline]
```

Set the `maxIndex` field.

**Parameters**

<i>maxIndex</i>	The <code>maxIndex</code> field of the <code>TableInfo</code> object.
-----------------	---

**Returns**

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.8 setMinIndex()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setMinIndex (
    uint64_t minIndex ) [inline]
```

Set the `minIndex` field.

## Parameters

<i>minIndex</i>	The minIndex field of the TableInfo object.
-----------------	---

## Returns

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.9 setName()**

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setName (
    const std::string & name ) [inline]
```

Set the name field.

## Parameters

<i>name</i>	The name field of the TableInfo object.
-------------	---

## Returns

A reference to this [TableBuilder](#) allowing calls to be chained together.

**8.50.2.10 setReadDelegate() [1/3]**

```
template<IrisErrorCode(*) (const TableInfo &, uint64_t, uint64_t, TableReadResult &) FUNC>
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setReadDelegate ( ) [inline]
```

Set the delegate to read the table.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultTableReadDelegate](#)

## Template Parameters

<i>FUNC</i>	A table read delegate function.
-------------	---------------------------------

## Returns

A reference to this [TableBuilder](#) object allowing calls to be chained together.

**8.50.2.11 setReadDelegate() [2/3]**

```
template<typename T , IrisErrorCode(T::*)(const TableInfo &, uint64_t, uint64_t, TableReadResult &) METHOD>
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setReadDelegate (
    T * instance ) [inline]
```

Set the delegate to read the table.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultTableReadDelegate](#)



## Template Parameters

<i>T</i>	A class that defines a method with the right signature to be a table read delegate.
<i>METHOD</i>	A table read delegate method in class T.

## Parameters

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

## Returns

A reference to this [TableBuilder](#) object allowing calls to be chained together.

**8.50.2.12 setReadDelegate()** [3/3]

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setReadDelegate (
    TableReadDelegate delegate ) [inline]
```

Set the delegate to read the table.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultTableReadDelegate](#)

## Parameters

<i>delegate</i>	TableReadDelegate object.
-----------------	---------------------------

## Returns

A reference to this [TableBuilder](#) object allowing calls to be chained together.

**8.50.2.13 setWriteDelegate()** [1/3]

```
template<IrisErrorCode(*)>(const TableInfo &, const TableRecords &, TableWriteResult &) FUNC>
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setWriteDelegate ( ) [inline]
```

Set the delegate to write to the table.

If this is not set, the default delegate is used.

## See also

[IrisInstanceBuilder::setDefaultTableWriteDelegate](#)

## Template Parameters

<i>FUNC</i>	A table write delegate function.
-------------	----------------------------------

## Returns

A reference to this [TableBuilder](#) object allowing calls to be chained together.

**8.50.2.14 setWriteDelegate()** [2/3]

```
template<typename T , IrisErrorCode(T::*)(const TableInfo &, const TableRecords &, Table←
WriteResult &) METHOD>
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setWriteDelegate (
    T * instance ) [inline]
```

Set the delegate to write to the table.

If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultTableWriteDelegate](#)

**Template Parameters**

<i>T</i>	A class that defines a method with the right signature to be a table write delegate.
<i>METHOD</i>	A table write delegate method in class T.

**Parameters**

<i>instance</i>	The instance of class T on which to call METHOD.
-----------------	--

**Returns**

A reference to this [TableBuilder](#) object allowing calls to be chained together.

**8.50.2.15 setWriteDelegate()** [3/3]

```
TableBuilder & iris::IrisInstanceBuilder::TableBuilder::setWriteDelegate (
    TableWriteDelegate delegate ) [inline]
```

Set the delegate to write to the table.

If this is not set, the default delegate is used.

See also

[IrisInstanceBuilder::setDefaultTableWriteDelegate](#)

**Parameters**

<i>delegate</i>	TableWriteDelegate object.
-----------------	----------------------------

**Returns**

A reference to this [TableBuilder](#) object allowing calls to be chained together.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

**8.51 iris::IrisInstanceBuilder::TableColumnBuilder Class Reference**

Used to set metadata for a table column.

```
#include <IrisInstanceBuilder.h>
```

## Public Member Functions

- [TableColumnBuilder](#) [addColumn](#) (const std::string &name)  
*Add another new column.*
- [TableBuilder](#) & [addColumnInfo](#) (const TableColumnInfo &columnInfo)  
*Add another column with a preconstructed TableColumnInfo.*
- [TableBuilder](#) & [endColumn](#) ()  
*Stop building this column and go back to the parent table.*
- [TableColumnBuilder](#) & [setBitWidth](#) (uint64\_t bitWidth)  
*Set the `bitWidth` field.*
- [TableColumnBuilder](#) & [setDescription](#) (const std::string &description)  
*Set the `description` field.*
- [TableColumnBuilder](#) & [setFormat](#) (const std::string &format)  
*Set the `format` field.*
- [TableColumnBuilder](#) & [setFormatLong](#) (const std::string &format)  
*Set the `formatLong` field.*
- [TableColumnBuilder](#) & [setFormatShort](#) (const std::string &format)  
*Set the `formatShort` field.*
- [TableColumnBuilder](#) & [setName](#) (const std::string &name)  
*Set the `name` field.*
- [TableColumnBuilder](#) & [setRwMode](#) (const std::string &rwMode)  
*Set the `rwMode` field.*
- [TableColumnBuilder](#) & [setType](#) (const std::string &type)  
*Set the `type` field.*
- **TableColumnBuilder** ([TableBuilder](#) &parent\_, TableColumnInfo &info\_)

### 8.51.1 Detailed Description

Used to set metadata for a table column.

### 8.51.2 Member Function Documentation

#### 8.51.2.1 addColumn()

```
TableColumnBuilder iris::IrisInstanceBuilder::TableColumnBuilder::addColumn (
    const std::string & name ) [inline]
```

Add another new column.

Call this multiple times for multiple columns

See also

[TableBuilder::addColumn](#)

#### Parameters

<i>name</i>	The name of the new column.
-------------	-----------------------------

**Returns**

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

**8.51.2.2 addColumnInfo()**

```
TableBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::addColumnInfo (
    const TableColumnInfo & columnInfo ) [inline]
```

Add another column with a preconstructed TableColumnInfo.

**See also**

[TableBuilder::addColumnInfo](#)  
[addColumn](#)

**Parameters**

<i>columnInfo</i>	A preconstructed TableColumnInfo object for the new column.
-------------------	---

**Returns**

A reference to the parent [TableBuilder](#) for this table.

**8.51.2.3 endColumn()**

```
TableBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::endColumn ( ) [inline]
```

Stop building this column and go back to the parent table.

**See also**

[addColumn](#)  
[addColumnInfo](#)

**Returns**

The parent [TableBuilder](#) for this table.

**8.51.2.4 setBitWidth()**

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setBitWidth (
    uint64_t bitWidth ) [inline]
```

Set the bitWidth field.

**Parameters**

<i>bitWidth</i>	The bitWidth field of the TableColumnInfo object.
-----------------	---

**Returns**

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

**8.51.2.5 setDescription()**

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setDescription (
```

```
const std::string & description ) [inline]
```

Set the `description` field.

#### Parameters

<i>description</i>	The description field of the <code>TableColumnInfo</code> object.
--------------------	---

#### Returns

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

#### 8.51.2.6 setFormat()

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setFormat (
```

```
const std::string & format ) [inline]
```

Set the `format` field.

#### Parameters

<i>format</i>	The format field of the <code>TableColumnInfo</code> object.
---------------	--

#### Returns

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

#### 8.51.2.7 setFormatLong()

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setFormatLong (
```

```
const std::string & format ) [inline]
```

Set the `formatLong` field.

#### Parameters

<i>format</i>	The <code>formatLong</code> field of the <code>TableColumnInfo</code> object.
---------------	---

#### Returns

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

#### 8.51.2.8 setFormatShort()

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setFormatShort (
```

```
const std::string & format ) [inline]
```

Set the `formatShort` field.

#### Parameters

<i>format</i>	The <code>formatShort</code> field of the <code>TableColumnInfo</code> object.
---------------	--

**Returns**

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

**8.51.2.9 setName()**

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setName (
    const std::string & name ) [inline]
```

Set the name field.

**Parameters**

<i>name</i>	The name field of the TableColumnInfo object.
-------------	---

**Returns**

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

**8.51.2.10 setRwMode()**

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setRwMode (
    const std::string & rwMode ) [inline]
```

Set the rwMode field.

**Parameters**

<i>rwMode</i>	The rwMode field of the TableColumnInfo object.
---------------	---

**Returns**

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

**8.51.2.11 setType()**

```
TableColumnBuilder & iris::IrisInstanceBuilder::TableColumnBuilder::setType (
    const std::string & type ) [inline]
```

Set the type field.

**Parameters**

<i>type</i>	The type field of the TableColumnInfo object.
-------------	---

**Returns**

A [TableColumnBuilder](#) object that can be used to add metadata for the new column.

The documentation for this class was generated from the following file:

- [IrisInstanceBuilder.h](#)

**8.52 iris::IrisInstanceTable::TableInfoAndAccess Struct Reference**

Entry in 'tableInfos'.

```
#include <IrisInstanceTable.h>
```

## Public Attributes

- [TableReadDelegate](#) **readDelegate**  
*Can be empty, in which case defaultReadDelegate is used.*
- TableInfo **tableInfo**
- [TableWriteDelegate](#) **writeDelegate**  
*Can be empty, in which case defaultWriteDelegate is used.*

### 8.52.1 Detailed Description

Entry in 'tableInfos'.

Contains static table information and information on how to access the table.

The documentation for this struct was generated from the following file:

- [IrisInstanceTable.h](#)

## Chapter 9

# File Documentation

### 9.1 IrisCanonicalMsnArm.h File Reference

Constants for the memory.canonicalMsnScheme arm.com/memoryspaces.

```
#include "iris/detail/IrisInterface.h"
#include "iris/detail/IrisCommon.h"
```

#### Enumerations

- enum **CanonicalMsnArm** : uint64\_t {  
    **CanonicalMsnArm\_SecureMonitor** = 0x1000 , **CanonicalMsnArm\_Secure** = 0x1000 , **CanonicalMsnArm\_Guest** = 0x1001 , **CanonicalMsnArm\_Normal** = 0x1001 ,  
    **CanonicalMsnArm\_NSHyp** = 0x1002 , **CanonicalMsnArm\_Memory** = 0x1003 , **CanonicalMsnArm\_HypApp** = 0x1004 , **CanonicalMsnArm\_Host** = 0x1005 ,  
    **CanonicalMsnArm\_Current** = 0x10ff , **CanonicalMsnArm\_IPA** = 0x1100 , **CanonicalMsnArm\_PhysicalMemorySecure** = 0x1200 , **CanonicalMsnArm\_PhysicalMemoryNonSecure** = 0x1201 ,  
    **CanonicalMsnArm\_PhysicalMemory** = 0x1202 , **CanonicalMsnArm\_PhysicalMemoryRoot** = 0x1203 ,  
    **CanonicalMsnArm\_PhysicalMemoryRealm** = 0x1204 }

#### 9.1.1 Detailed Description

Constants for the memory.canonicalMsnScheme arm.com/memoryspaces.

Date

Copyright ARM Limited 2022. All Rights Reserved.

### 9.2 IrisCanonicalMsnArm.h

[Go to the documentation of this file.](#)

```
1
2
3 #ifndef ARM_INCLUDE_IrisCanonicalMsnArm_h
4 #define ARM_INCLUDE_IrisCanonicalMsnArm_h
5
6 #include "iris/detail/IrisInterface.h" // uint64_t
7 #include "iris/detail/IrisCommon.h"   // namespace iris
8
9 NAMESPACE_IRIS_START
10
11 enum CanonicalMsnArm: uint64_t
12 {
13     CanonicalMsnArm_SecureMonitor = 0x1000,    CanonicalMsnArm_Secure           = 0x1000,
14     CanonicalMsnArm_Guest         = 0x1001,    CanonicalMsnArm_Normal          = 0x1001,
15     CanonicalMsnArm_NSHyp         = 0x1002,
16     CanonicalMsnArm_Memory        = 0x1003,    // Virtual memory for cores which do not have TrustZone.
17     CanonicalMsnArm_HypApp        = 0x1004,
18     CanonicalMsnArm_Host          = 0x1005,
19
20     CanonicalMsnArm_Current       = 0x10ff,
21 }
```



```

27     CanonicalMsnArm_IPA           = 0x1100,
28
29     CanonicalMsnArm_PhysicalMemorySecure = 0x1200,
30     CanonicalMsnArm_PhysicalMemoryNonSecure = 0x1201,
31     CanonicalMsnArm_PhysicalMemory      = 0x1202,
32     CanonicalMsnArm_PhysicalMemoryRoot  = 0x1203,
33     CanonicalMsnArm_PhysicalMemoryRealm  = 0x1204
34 }; // enum CanonicalMsnArm
35
36 NAMESPACE_IRIS_END
37
38 #endif // ARM_INCLUDE_IrisCanonicalMsnArm_h
39

```

## 9.3 IrisCConnection.h File Reference

IrisConnectionInterface implementation based on IrisC.

```

#include "iris/detail/IrisC.h"
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisErrorException.h"
#include "iris/detail/IrisInterface.h"
#include "iris/detail/IrisJsonProducer.h"
#include <string>

```

### Classes

- class [iris::IrisCConnection](#)

*Provide an IrisConnectionInterface which loads an IrisC library.*

### 9.3.1 Detailed Description

IrisConnectionInterface implementation based on IrisC.

#### Copyright

Copyright (C) 2017-2023 Arm Limited. All rights reserved.

## 9.4 IrisCConnection.h

[Go to the documentation of this file.](#)

```

1
7 #ifndef ARM_INCLUDE_IrisCConnection_h
8 #define ARM_INCLUDE_IrisCConnection_h
9
10 #include "iris/detail/IrisC.h"
11 #include "iris/detail/IrisCommon.h"
12 #include "iris/detail/IrisErrorException.h"
13 #include "iris/detail/IrisInterface.h"
14 #include "iris/detail/IrisJsonProducer.h"
15
16 #include <string>
17
18 NAMESPACE_IRIS_START
19
25 class IrisCConnection : public IrisConnectionInterface
26 {
27 private:
28     IrisC_HandleMessageFunction    handleMessage_function;
29
30     IrisC_RegisterChannelFunction   registerChannel_function;
31     IrisC_UnregisterChannelFunction unregisterChannel_function;
32
33     IrisC_ProcessAsyncMessagesFunction processAsyncMessages_function;
34
35     class RemoteInterface : public IrisInterface
36     {
37     private:
38         IrisCConnection* irisc;
39
40     public:
41         RemoteInterface(IrisCConnection* irisc_)
42

```

```

43         : irisc(irisc_)
44     {
45     }
46
47     public: // IrisInterface
48         virtual void irisHandleMessage(const uint64_t* message) IRIS_OVERRIDE
49     {
50         // Forward to the IrisC library
51         int64_t status = irisc->IrisC_handleMessage(message);
52
53         if (status != E_ok)
54         {
55             throw IrisErrorException(IrisErrorCode(status));
56         }
57     }
58     } remote_interface;
59
60     // Helper function to bridge IrisC_HandleMessageFunction to IrisInterface::irisHandleMessage
61     static int64_t handleMessageToIrisInterface(void* context, const uint64_t* message)
62     {
63         if (context == nullptr)
64         {
65             return E_invalid_context;
66         }
67         try
68         {
69             static_cast<IrisInterface*>(context)->irisHandleMessage(message);
70         }
71         catch (std::exception& e)
72         {
73             // Catch and print all exceptions here as they usually get silently dropped when going
74             // back through the C function.
75             // These are always programming errors (e.g. in plugin event callbacks) and not
76             // valid error return values of Iris functions.
77             std::cout << "Caught exception on plugin C boundary: " << e.what() << "\n";
78             std::cout << "Call was: " << messageToString(message) << "\n";
79
80             // Some compilers can transport exceptions through C functions, some not.
81             // Do whatever the compiler can do.
82             throw;
83         }
84
85         return E_ok;
86     }
87
88 protected:
89     void* iris_c_context;
90
91     IrisCConnection()
92     : handleMessage_function(nullptr)
93     , registerChannel_function(nullptr)
94     , unregisterChannel_function(nullptr)
95     , processAsyncMessages_function(nullptr)
96     , remote_interface(this)
97     , iris_c_context(nullptr)
98     {
99     }
100
101     int64_t IrisC_handleMessage(const uint64_t* message)
102     {
103         return (*handleMessage_function)(iris_c_context, message);
104     }
105
106     int64_t IrisC_registerChannel(IrisC_CommunicationChannel* channel, uint64_t* channel_id_out)
107     {
108         return (*registerChannel_function)(iris_c_context, channel, channel_id_out);
109     }
110
111     int64_t IrisC_unregisterChannel(uint64_t channel_id)
112     {
113         return (*unregisterChannel_function)(iris_c_context, channel_id);
114     }
115
116     int64_t IrisC_processAsyncMessages(bool waitForAMessage)
117     {
118         return (*processAsyncMessages_function)(iris_c_context, waitForAMessage);
119     }
120
121 public:
122     IrisCConnection(IrisC_Functions* functions)
123     : handleMessage_function(functions->handleMessage_function)
124     , registerChannel_function(functions->registerChannel_function)
125     , unregisterChannel_function(functions->unregisterChannel_function)
126     , processAsyncMessages_function(functions->processAsyncMessages_function)
127     , remote_interface(this)
128     , iris_c_context(functions->iris_c_context)

```

```

133     {
134     }
135
136 public: // IrisConnectionInterface
141     virtual uint64_t registerIrisInterfaceChannel(IrisInterface* iris_interface) IRIS_OVERRIDE
142     {
143         IrisC_CommunicationChannel channel;
144
145         channel.CommunicationChannel_version = 0;
146         channel.handleMessage_function      = &IrisCConnection::handleMessageToIrisInterface;
147         channel.handleMessage_context       = static_cast<void*>(iris_interface);
148
149         uint64_t channelId = IRIS_UINT64_MAX;
150
151         IrisErrorCode status = static_cast<IrisErrorCode>(IrisC_registerChannel(&channel, &channelId));
152
153         if (status != E_ok)
154         {
155             throw IrisErrorException(status);
156         }
157
158         return channelId;
159     }
160
161     virtual void unregisterIrisInterfaceChannel(uint64_t channelId) IRIS_OVERRIDE
162     {
163         IrisErrorCode status = static_cast<IrisErrorCode>(IrisC_unregisterChannel(channelId));
164
165         if (status != E_ok)
166         {
167             throw IrisErrorException(status);
168         }
169     }
170
171     virtual IrisErrorCode processAsyncMessages(bool waitForAMessage) IRIS_OVERRIDE
172     {
173         return static_cast<IrisErrorCode>(IrisC_processAsyncMessages(waitForAMessage));
174     }
175
176     virtual IrisInterface* getIrisInterface() IRIS_OVERRIDE
177     {
178         return &remote_interface;
179     }
180 };
181
182 namespace IRIS_END
183
184 #endif // ARM_INCLUDE_IrisCConnection_h

```

## 9.5 IrisClient.h File Reference

Iris client which supports multiple methods to connect to other Iris executables.

```

#include "iris/IrisInstance.h"
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisErrorCode.h"
#include "iris/detail/IrisInterface.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisUtils.h"
#include "iris/detail/IrisCommaSeparatedParameters.h"
#include "iris/impl/IrisChannelRegistry.h"
#include "iris/impl/IrisMessageQueue.h"
#include "iris/impl/IrisPlugin.h"
#include "iris/impl/IrisProcessEventThread.h"
#include "iris/impl/IrisRpcAdapterTcp.h"
#include "iris/impl/IrisTcpSocket.h"
#include <map>
#include <memory>
#include <mutex>
#include <queue>
#include <thread>
#include <vector>

```

## Classes

- class [iris::IrisClient](#)

## Functions

- `NAMESPACE_IRIS_INTERNAL_START` (service) class IrisServiceTcpServer

### 9.5.1 Detailed Description

Iris client which supports multiple methods to connect to other Iris executables.

#### Date

Copyright ARM Limited 2015-2022 All Rights Reserved.

## 9.6 IrisClient.h

[Go to the documentation of this file.](#)

```

1
2
3
4
5
6
7 #ifndef ARM_INCLUDE_IrisClient_h
8 #define ARM_INCLUDE_IrisClient_h
9
10 #include "iris/IrisInstance.h"
11
12 #include "iris/detail/IrisCommon.h"
13 #include "iris/detail/IrisErrorCode.h"
14 #include "iris/detail/IrisInterface.h"
15 #include "iris/detail/IrisLogger.h"
16 #include "iris/detail/IrisUtils.h"
17 #include "iris/detail/IrisCommaSeparatedParameters.h"
18
19 #include "iris/impl/IrisChannelRegistry.h"
20 #include "iris/impl/IrisMessageQueue.h"
21 #include "iris/impl/IrisPlugin.h"
22 #include "iris/impl/IrisProcessEventsThread.h"
23 #include "iris/impl/IrisRpcAdapterTcp.h"
24 #include "iris/impl/IrisTcpSocket.h"
25 #include "iris/IrisInstance.h"
26
27 #include <map>
28 #include <memory>
29 #include <mutex>
30 #include <queue>
31 #include <thread>
32 #include <vector>
33 #if defined(__linux__) || defined(__APPLE__)
34 #include <csignal>
35 #include <sys/types.h>
36 #include <sys/wait.h>
37 #endif
38 #if defined(__linux__)
39 #include <sys/prctl.h>
40 #endif
41
42 NAMESPACE_IRIS_INTERNAL_START(service)
43 class IrisServiceTcpServer;
44 NAMESPACE_IRIS_INTERNAL_END
45
46 NAMESPACE_IRIS_START
47
48 class IrisClient
49 : public IrisInterface
50 , public impl::IrisProcessEventsInterface
51 , public IrisConnectionInterface
52 {
53 public:
54     IrisClient(const std::string& instName = std::string(), const std::string& connectionSpec =
55         std::string())
56     {
57         init(IRIS_TCP_CLIENT, instName);
58         if (!connectionSpec.empty())
59         {
60             connect(connectionSpec);
61         }
62     }
63
64     IrisClient(const service::IrisServiceTcpServer*, const std::string& instName = std::string())
65     {
66 
```

```

67     init(IRIS_SERVICE_SERVER, instName);
68 }
69
80 IrisClient(const std::string& hostname, uint16_t port, const std::string& instName = std::string())
81 {
82     init(IRIS_TCP_CLIENT, instName);
83     std::string ignored_error;
84     IrisErrorCode status = connect(hostname, port, port ? 1000 : 100, ignored_error);
85     if (status != E_ok)
86     {
87         throw IrisErrorExceptionString(status, "Failed to connect to Iris TCP server");
88     }
89 }
90
92 virtual ~IrisClient()
93 {
94     disconnect();
95
96     // Do not rely on destructor order. The socket_thread expects this
97     // object to be fully alive.
98     if (socket_thread)
99     {
100         socket_thread->terminate();
101     }
102
103     switch (mode)
104     {
105     case IRIS_TCP_CLIENT:
106         socketSet.removeSocket(&sock);
107         break;
108
109     case IRIS_SERVICE_SERVER:
110         socketSet.removeSocket(service_socket);
111         // remove service_socket TODO safer memory management
112         delete service_socket;
113         break;
114     }
115
116     iris::sleepMs(sleepOnDestructionMs);
117 }
118
123 void spawnAndConnect(const std::vector<std::string>& modelCommandLine, const std::string&
additionalServerArgs = std::string(), const std::string& additionalClientArgs = std::string())
124 {
125 #ifdef _WIN32
126     (void)modelCommandLine;
127     (void)additionalServerArgs;
128     (void)additionalClientArgs;
129     if (modelCommandLine.size() < 1000000) // Hack: Disable spurious "unreachable code" warning in
code calling spawnAndConnect() on Windows while we have not implemented this.
130     {
131         throw IrisErrorExceptionString(E_not_connected, "socketpair() connections not yet supported
on Windows");
132     }
133 #else
134     // Increase verbose level? (connect() below does this, but is too late)
135     IrisCommaSeparatedParameters clientArgs(additionalClientArgs, "1");
136     setVerbose(unsigned(clientArgs.getUint("verbose", 0)), /*increaseOnly=*/true);
137
138     if (isConnected() || (childPid > 0))
139     {
140         disconnectAndWaitForChildToExit();
141     }
142
143     // Create socket pair.
144     int socketfd[2]; // We arbitrarily choose: 0=parent/client, 1=child/server
145     enum { CLIENT, SERVER };
146     if (socketpair(PF_LOCAL, SOCK_STREAM, 0, socketfd))
147     {
148         throw IrisErrorExceptionString(E_socket_error, "socketpair() failed");
149     }
150
151     lastExitStatus = -1;
152
153     // Fork.
154     childPid = fork();
155     if (childPid == 0)
156     {
157         // Child == server/model.
158         close(socketfd[CLIENT]);
159
160 #if defined(__linux__)
161         // Ask the kernel to kill us with SIGINT on parent thread termination.
162         // NOTE: Cleared on fork, but not on exec.
163         prctl(PR_SET_PDEATHSIG, SIGINT);
164 #endif
165

```

```

166         // Prepare args.
167         std::vector<std::string> args = modelCommandLine;
168         args.push_back("--iris-connect");
169         args.push_back("socketfd=" + std::to_string(socketfd[SERVER]) + "," + additionalServerArgs);
170         std::vector<const char *> cargs;
171         for (const std::string& s: args)
172         {
173             cargs.push_back(s.c_str());
174         }
175         cargs.push_back(nullptr);
176
177         // Start model. Replaces the currently running executable. Does not return on success.
178         execve(cargs[0], (char * const *)cargs.data(), environ);
179
180         // execve() only returns on error.
181         close(socketfd[SERVER]);
182         throw IrisErrorExceptionString(E_not_connected, "execve() failed. Error launching model
(command line: " + iris::joinString(args, " ") + ").");
183     }
184     else if (childPid < 0)
185     {
186         close(socketfd[CLIENT]);
187         close(socketfd[SERVER]);
188         childPid = 0;
189         throw IrisErrorExceptionString(E_not_connected, "fork() failed with errno=" +
std::to_string(errno) + ".");
190     }
191     else
192     {
193         if (verbose)
194         {
195             log.info("IrisClient::spawnAndConnect(): Spawned child process %d.\n", int(childPid));
196         }
197
198         // Parent == client/debugger.
199         close(socketfd[SERVER]);
200
201         try
202         {
203             // Connect to model.
204             connect("socketfd=" + std::to_string(socketfd[CLIENT]) + "," + additionalClientArgs);
205         }
206         catch (...)
207         {
208             // connect() already closed the socket on error.
209
210             // Issue SIGINT and then SIGKILL to terminate child.
211             disconnectAndWaitForChildToExit(0);
212             throw;
213         }
214     }
215 #endif
216 }
217
218 bool disconnectAndWaitForChildToExit(double timeoutInMs = 5000, double timeoutInMsAfterSigInt =
5000, double timeoutInMsAfterSigKill = 5000)
219 {
220     if (verbose)
221     {
222         log.info("IrisClient::disconnectAndWaitForChildToExit(timeoutInMs=%0f,
timeoutInMsAfterSigInt=%0f, timeoutInMsAfterSigKill=%0f)\n", timeoutInMs, timeoutInMsAfterSigInt,
timeoutInMsAfterSigKill);
223     }
224
225     // Disconnect.
226     IrisErrorCode error = disconnect();
227     if (error)
228     {
229         throw IrisErrorExceptionString(E_not_connected, "disconnect() failed.");
230     }
231
232 #ifdef _WIN32
233     (void)timeoutInMs;
234     (void)timeoutInMsAfterSigInt;
235     (void)timeoutInMsAfterSigKill;
236     throw IrisErrorExceptionString(E_not_implemented, "socketpair() connections not yet supported on
Windows.");
237 #else
238     if (childPid == 0)
239     {
240         return true;
241     }
242
243     if (!floatEqual(timeoutInMs, 0.0))
244     {
245         // Wait for child process to exit for timeoutInMs.
246         if (waitpidWithTimeout(childPid, &lastExitStatus, 0, timeoutInMs))

```

```

260         {
261             childPid = 0;
262             return true;
263         }
264     }
265
266     if (!floatEqual(timeoutInMsAfterSigInt, 0.0))
267     {
268         // Send SIGINT and wait for timeoutInMsAfterSigInt.
269         if (verbose)
270         {
271             log.info("IrisClient::disconnectAndWaitForChildToExit(): Sending SIGINT to child %d.\n",
272 int(childPid));
273         }
274         if (kill(childPid, SIGINT) < 0)
275         {
276             throw IrisErrorExceptionString(E_not_connected, "kill(SIGINT) failed with errno=" +
277 std::to_string(errno) + ".");
278         }
279         if (waitpidWithTimeout(childPid, &lastExitStatus, 0, timeoutInMsAfterSigInt))
280         {
281             childPid = 0;
282             return true;
283         }
284     }
285
286     if (!floatEqual(timeoutInMsAfterSigKill, 0.0))
287     {
288         // Send SIGKILL and wait for timeoutInMsAfterSigKill.
289         if (verbose)
290         {
291             log.info("IrisClient::disconnectAndWaitForChildToExit(): Sending SIGKILL to child
292 %d.\n", int(childPid));
293         }
294         if (kill(childPid, SIGKILL) < 0)
295         {
296             throw IrisErrorExceptionString(E_not_connected, "kill(SIGKILL) failed with errno=" +
297 std::to_string(errno) + ".");
298         }
299         if (waitpidWithTimeout(childPid, &lastExitStatus, 0, timeoutInMsAfterSigKill))
300         {
301             childPid = 0;
302             return true;
303         }
304     }
305
306     // Child did not exit so far.
307     if (verbose)
308     {
309         log.info("IrisClient::disconnectAndWaitForChildToExit(): Child %d did not exit.\n",
310 int(childPid));
311     }
312     return false;
313 #endif
314 }
315
316 #ifndef _WIN32
317 bool waitpidWithTimeout(pid_t pid, int* status, int options, double timeoutInMs)
318 {
319     if (verbose)
320     {
321         log.info("IrisClient::waitpidWithTimeout(): Waiting %.1f ms for child %d to exit ...\n",
322 timeoutInMs, int(pid));
323     }
324
325     double endTime = getTimeInSec() + timeoutInMs / 1000.0;
326     if (timeoutInMs < 0)
327     {
328         endTime += 1e100;
329     }
330
331     // Wait for child to exit.
332     while (getTimeInSec() < endTime)
333     {
334         pid_t ret = waitpid(pid, status, options | WNOHANG);
335         if (ret == pid)
336         {
337             if (verbose)
338             {
339                 log.info("IrisClient::waitpidWithTimeout(): Child %d exited with exit status %d
340 after waiting for %.3fs.\n", int(pid), status ? *status : 0, getTimeInSec() - endTime + (timeoutInMs
341 / 1000.0));
342             }
343             return true; // Child exited.
344         }
345     }
346     if (ret < 0)
347     {

```

```

342         throw IrisErrorExceptionString(E_not_connected, "waitpid() failed with errno=" +
std::to_string(errno) + ".");
343     }
344     if (ret > 0)
345     {
346         throw IrisErrorExceptionString(E_not_connected, "waitpid() returned unexpected pid=" +
std::to_string(pid) + ".");
347     }
348     assert(ret == 0);
349
350     sleepMs(20);
351 }
352
353     return false; // Timeout.
354 }
355 #endif
356
357 #ifndef _WIN32
358     pid_t getChildPid() const
359     {
360         return childPid;
361     }
362 }
363 #endif
364
365 int getLastExitStatus() const { return lastExitStatus; }
366
367 const std::string connectionHelpStr =
368     "Supported connection types:\n"
369     "tcp[=HOST][,port=PORT][,timeout=T]\n"
370     "    Connect to an Iris TCP server on HOST:PORT.\n"
371     "    The default for HOST is 'localhost' and the default for PORT is 0 if HOST is 'localhost' and
7100 otherwise. If PORT is 0 then a port scan on ports 7100 to 7109 is done.\n"
372     "    T is the connection timeout in ms (defaults to 100 if PORT==0, else 1000).\n"
373     "\n"
374     "socketfd=FD[,timeout=T]\n"
375     "    Use socket file descriptor FD as an established UNIX domain socket connection.\n"
376     "    T is the timeout for the Iris handshake in ms.\n"
377     "\n"
378     "General parameters:\n"
379     "    verbose=N: Increase verbose level of IrisClient to level N (0..3).\n";
380
381 void connect(const std::string& connectionSpec)
382 {
383     if (verbose)
384     {
385         log.info("IrisClient::connect(%s)\n", connectionSpec.c_str());
386     }
387
388     IrisCommaSeparatedParameters params(connectionSpec, "1");
389
390     // Emit help message?
391     if (params.have("help"))
392     {
393         throw IrisErrorExceptionString(E_help_message, connectionHelpStr);
394     }
395
396     // Increase verbose level?
397     setVerbose(unsigned(params.getUint("verbose", 0)), /*increaseOnly=*/true);
398
399     // Validate connection type.
400     if (unsigned(params.have("tcp")) + unsigned(params.have("socketfd"))) != 1)
401     {
402         throw IrisErrorExceptionString(E_not_connected, "Exactly one out of \"tcp\", \"socketfd\"
and \"help\" must be specified (got \"" + connectionSpec + "\"). Specify \"help\" to get a list of
all supported connection types.");
403     }
404
405     if (params.have("tcp"))
406     {
407         std::string hostname = params.getStr("tcp");
408         if (hostname == "1")
409         {
410             hostname = "localhost";
411         }
412         uint16_t port = uint16_t(params.getUint("port", hostname == "localhost" ? 0 : 7100));
413         unsigned timeoutInMs = unsigned(params.getUint("timeout", port == 0 ? 100 : 1000));
414         if (params.haveUnusedParameters())
415         {
416             throw IrisErrorExceptionString(E_not_connected, params.getUnusedParametersMessage("Error
in 'tcp' connection parameters: "));
417         }
418         std::string errorResponse;
419         IrisErrorCode status = connect(hostname, port, timeoutInMs, errorResponse);
420         if (status != E_ok)
421         {
422             throw IrisErrorExceptionString(status, errorResponse);
423         }
424     }
425 }

```



```

434     }
435
436     if (params.have("socketfd"))
437     {
438         SocketFd socketfd = SocketFd(params.getUint("socketfd"));
439         unsigned timeoutInMs = unsigned(params.getUint("timeout", 1000));
440         if (params.haveUnusedParameters())
441         {
442             throw IrisErrorExceptionString(E_not_connected, params.getUnusedParametersMessage("Error
in 'socketfd' connection parameters: "));
443         }
444         connectSocketFd(socketfd, timeoutInMs);
445     }
446 }
447
448 IrisErrorCode connect(const std::string& hostname, uint16_t port, unsigned timeoutInMs, std::string&
errorResponseOut)
449 {
450     assert(mode == IRIS_TCP_CLIENT);
451
452     if (verbose)
453         log.info("IrisClient::connect(hostname=%s, port=%u, timeout=%u) enter\n", hostname.c_str(),
port, timeoutInMs);
454
455     // Already connected?
456     IrisErrorCode error = E_ok;
457     if (adapter.isConnected() || sock.isConnected())
458     {
459         error = E_already_connected;
460         goto done;
461     }
462
463     // hostname==localhost and port==0 means port scan.
464     if ((hostname == "localhost") && (port == 0))
465     {
466         const uint16_t startport = 7100;
467         const uint16_t endport = 7109;
468         for (port = startport; port <= endport; port++)
469         {
470             std::string errorMessage;
471             if (connect(hostname, port, timeoutInMs, errorResponseOut) == iris::E_ok)
472                 return E_ok;
473         }
474         errorResponseOut = "No Iris TCP server found on ports " + std::to_string(startport) + ".." +
std::to_string(endport) + "\n";
475         error = E_not_connected;
476         goto done;
477     }
478
479     if (!sock.isCreated())
480     {
481         sock.create();
482         sock.setNonBlocking();
483
484         // Unblock a potentially blocked worker thread which so far is waiting indefinitely
485         // on 'no socket'. This thread will block again on the socket we just created.
486         socketSet.stopWaitForEvent();
487     }
488
489     // Connect to server.
490     error = sock.connect(hostname, port, timeoutInMs);
491     if (error != E_ok)
492     {
493         errorResponseOut = "Error connecting to " + hostname + ":" + std::to_string(port);
494         sock.close();
495         goto done;
496     }
497
498     // Initialize client.
499     error = initClient(timeoutInMs, errorResponseOut);
500     if (error == E_ok)
501     {
502         connectionStr = hostname + ":" + std::to_string(port);
503     }
504     else
505     {
506         disconnect();
507     }
508
509     // Return error code (if any).
510 done:
511     if (verbose)
512         log.info("IrisClient::connect() leave (%s)\n", irisErrorCodeCStr(error));
513     return error;
514 }
515
516 void connectSocketFd(SocketFd socketfd, unsigned timeoutInMs = 1000)

```

```

524     {
525         assert(mode == IRIS_TCP_CLIENT);
526
527         if (verbose)
528             log.info("IrisClient::connectSocketFd(socketfd=%llu, timeout=%u)\n", (long long)socketfd,
                    timeoutInMs);
529
530         // Already connected?
531         std::string errorResponse;
532         IrisErrorCode error = E_ok;
533         if (adapter.isConnected() || sock.isConnected())
534         {
535             throw IrisErrorExceptionString(E_already_connected, "Already connected.");
536         }
537
538         sock.setSocketFd(socketfd);
539         sock.setNonBlocking();
540
541         // Unblock a potentially blocked worker thread which so far is waiting indefinitely
542         // on 'no socket'. This thread will block again on the socket we just created.
543         socketSet.stopWaitForEvent();
544
545         // Initialize client.
546         error = initClient(timeoutInMs, errorResponse);
547         if (error != E_ok)
548         {
549             disconnect();
550             throw IrisErrorExceptionString(error, errorResponse);
551         }
552
553         connectionStr = "(connected via socketfd)";
554     }
555
556     IrisErrorCode disconnect()
557     {
558         if (verbose)
559         {
560             log.info("IrisClient::disconnect()\n");
561         }
562
563         // Tell IrisInstance to stop sending requests to us.
564         // All Iris calls (including the inevitable final
565         // instanceRegistry_unregisterInstance()) will return
566         // E_not_connected from now on.
567         irisInstance.setConnectionInterface(nullptr);
568
569         connectionStr = "(not connected)";
570
571         if (mode != IRIS_TCP_CLIENT)
572         {
573             return E_ok;
574         }
575
576         // We just close the TCP connection. This is a first-class operation which always must be
577         // handled gracefully by the server.
578         // The server needs to do all cleanup automatically.
579         IrisErrorCode errorCode = E_ok;
580         if (adapter.isConnected())
581             errorCode = adapter.closeConnection();
582         if (sock.isConnected())
583         {
584             if (errorCode != E_ok)
585                 sock.close();
586             else
587                 errorCode = sock.close();
588         }
589
590         // Wake up processing thread since there is no point to wait on a closed socket.
591         socketSet.stopWaitForEvent();
592
593         return errorCode;
594     }
595
596     bool isConnected() const
597     {
598         return adapter.isConnected();
599     }
600
601     IrisInterface* getSendingInterface()
602     {
603         return this;
604     }
605
606     void setInstanceName(const std::string& instName)
607     {
608         if (irisInstance.isRegistered())
609         {

```

```

616         throw IrisErrorExceptionString(E_instance_already_registered, "IrisClient::setInstanceName()
must be called before connect().");
617     }
618     irisInstanceInstName = instName;
619 }
620
623 IrisInstance& getIrisInstance() { return irisInstance; }
624
627 void setSleepOnDestructionMs(uint64_t sleepOnDestructionMs_)
628 {
629     sleepOnDestructionMs = sleepOnDestructionMs_;
630 }
631
632
633 // --- IrisProcessEventsInterface implementation ---
634
651 virtual void processEvents() override
652 {
653     if (verbose >= 2)
654         log.info("IrisClient::processEvents() enter\n");
655
656     // in IRIS_SERVICE_SERVER mode, the adapter should work as server and hence call
657     // function processEventsServer()
658     switch (mode)
659     {
660     case IRIS_TCP_CLIENT:
661         adapter.processEventsClient();
662         break;
663     case IRIS_SERVICE_SERVER:
664         adapter.processEventsServer();
665         break;
666     }
667
668     if (verbose >= 2)
669         log.info("IrisClient::processEvents() leave\n");
670 }
671
675 virtual void waitForEvent() override
676 {
677     if (verbose >= 2)
678         log.info("IrisClient::waitForEvent() enter\n");
679     socketSet.waitForEvent(1000);
680     if (verbose >= 2)
681         log.info("IrisClient::waitForEvent() leave\n");
682 }
683
686 virtual void stopWaitForEvent() override
687 {
688     if (verbose)
689         log.info("IrisClient::stopWaitForEvent()\n");
690     socketSet.stopWaitForEvent();
691 }
692
694 void setPreferredSendingFormat(impl::IrisRpcAdapterTcp::Format p)
695 {
696     adapter.setPreferredSendingFormat(p);
697 }
698
700 impl::IrisRpcAdapterTcp::Format getEffectiveSendingFormat() const
701 {
702     return adapter.getEffectiveSendingFormat();
703 }
704
706 void setVerbose(unsigned level, bool increaseOnly = false)
707 {
708     if (increaseOnly && (level < verbose))
709     {
710         return;
711     }
712
713     verbose = level;
714     if (verbose)
715         log.info("IrisClient: verbose logging enabled (level %d)\n", verbose);
716     if (mode == IRIS_TCP_CLIENT)
717     {
718         sock.setVerbose(verbose);
719     }
720     socketSet.setVerbose(verbose);
721     if (verbose)
722     {
723         log.setIrisMessageLogLevelFlags(IrisLogger::TIMESTAMP);
724     }
725 }
726
728 void setIrisMessageLogLevel(unsigned level) { irisMessageLogLevel = level;
log.setIrisMessageLogLevel(irisMessageLogLevel); }
729

```

```

731     std::string getConnectionStr() const { return connectionStr; }
732
733 private:
734     enum Mode
735     {
736         IRIS_TCP_CLIENT,
737         IRIS_SERVICE_SERVER
738     };
739
740     // Shared code for constructors in client mode.
741     void init(Mode mode_, const std::string& instName)
742     {
743         log.setLogContext("IrisTC");
744         mode = mode_;
745
746         // Set instance name of contained IrisInstance.
747         if (instName.empty())
748         {
749             setInstanceName("client.IrisClient");
750         }
751         else
752         {
753             setInstanceName(instName);
754         }
755
756         // Enable verbose logging?
757         setVerbose(static_cast<unsigned>(getEnvU64("IRIS_TCP_CLIENT_VERBOSE")), true);
758         irisMessageLogLevel = unsigned(getEnvU64("IRIS_TCP_CLIENT_LOG_MESSAGES"));
759         log.setIrisMessageLogLevel(irisMessageLogLevel);
760         log.setIrisMessageGetInstNameFunc([&](InstanceId instId) { return getInstName(instId); });
761
762         if (mode == IRIS_TCP_CLIENT)
763         {
764             socketSet.addSocket(&sock);
765         }
766         sendingInterface = adapter.getSendingInterface();
767
768         // Intercept all calls to the global instance since we must modify
769         instanceRegistry_registerInstance() and
770         // instanceRegistry_unregisterInstance() and their responses.
771         instIdToInterface.push_back(&globalInstanceSendingInterface); // This must be index 0 in the
772         vector (instId 0 == global instance).
773
774         if (mode == IRIS_SERVICE_SERVER)
775         {
776             socket_thread = std::unique_ptr<impl::IrisProcessEventsThread>(new
777             impl::IrisProcessEventsThread(this, "TcpSocket"));
778         }
779
780         IrisErrorCode initClient(unsigned timeoutInMs, std::string& errorResponseOut)
781         {
782             assert(mode == IRIS_TCP_CLIENT);
783
784             // Initialize IrisRpcAdapterTcp.
785             try
786             {
787                 adapter.initClient(&sock, &socketSet, &receivingInterface, verbose);
788             }
789             catch (const IrisErrorException& e)
790             {
791                 if (e.getMessage().empty())
792                 {
793                     throw IrisErrorExceptionString(e.getErrorCode(), "Client: Error connecting to server
794 socket.");
795                 }
796                 else
797                 {
798                     throw;
799                 }
800             }
801
802             // Handshake.
803             IrisErrorCode error = adapter.handshakeClient(errorResponseOut, timeoutInMs);
804
805             // Start a thread to process incoming data in the background.
806             socket_thread = std::unique_ptr<impl::IrisProcessEventsThread>(new
807             impl::IrisProcessEventsThread(this, "TcpSocket"));
808
809             // Initialize IrisInstance.
810             irisInstance.setConnectionInterface(this);
811             irisInstance.registerInstance(irisInstanceInstName, iris::IrisInstance::UNIQUEIFY |
812             iris::IrisInstance::THROW_ON_ERROR);
813
814             return error;
815         }
816     }

```

```

817     virtual void irisHandleMessage(const uint64_t* message) override
818     {
819         // Log message?
820         if (irisMessageLogLevel)
821         {
822             log.irisMessage(message);
823         }
824
825         // This calls one of these:
826         // - this->globalInstanceSendingInterface_irisHandleMessage(); (for requests, instId == 0)
827         // - Iris interface of a local instance (if a local instance talks to a local instance)
828         // - sendingInterface (to send message to server using TCP)
829         findInterface(IrisU64JsonReader::getInstId(message)) -> irisHandleMessage(message);
830     }
831
832     void globalInstanceSendingInterface_irisHandleMessage(const uint64_t* message)
833     {
834         // This is only ever called for instId == 0.
835         assert(IrisU64JsonReader::getInstId(message) == 0);
836         assert(IrisU64JsonReader::isRequestOrNotification(message));
837
838         // Decode request.
839         IrisU64JsonReader r(message);
840         IrisU64JsonReader::Request req = r.openRequest();
841         std::string method = req.getMethod();
842
843         if (method == "instanceRegistry_registerInstance")
844         {
845             RequestId requestId = req.getRequestId();
846
847             // We received an instanceRegistry_registerInstance() request from a local instance:
848             // - Create a new request id which is unique to this request for this TCP channel. (This is
849             //   not required to be globally unique.)
850             // - Allocate an ongoingInstanceRegistryCalls slot for this new request id and remember the
851             //   original request id and params.channelId in it.
852             // - Modify request id of request to the new request id so we can recognize the response
853             //   later.
854             // - Send modified request.
855
856             // Create a new request id which is unique to this request for this TCP channel. (This is
857             //   not required to be globally unique.)
858             RequestId newRequestId = generateNewRequestIdForRegisterInstanceCall();
859
860             // Get channelId.
861             uint64_t channelId = IRIS_UINT64_MAX;
862             if (!req.paramOptional(ISTR("channelId"), channelId))
863             {
864                 // Strange. 'params.channelId' is missing. This should never happen.
865                 log.error(
866                     "IrisClient::receivingInterface_irisHandleMessage(): "
867                     "Received instanceRegistry_registerInstance() request without channelId
868                     parameter:\n%s\n",
869                     messageToString(message).c_str());
870                 goto send;
871             }
872
873             {
874                 std::lock_guard<std::mutex> lock(ongoingInstanceRegistryCallsMutex);
875                 // Allocate an ongoingInstanceRegistryCalls slot for this new request id and remember
876                 // the
877                 // original request id and params.channelId in it.
878                 ongoingInstanceRegistryCalls[newRequestId] = OngoingInstanceRegistryCallEntry(method,
879                                                                                               requestId,
880                                                                                               channelId);
881             }
882
883             // Create a modified request that:
884             // - sets the new request id so we can recognize the response later.
885             // - removes the channelId parameter (it only has meaning in-process)
886             IrisU64JsonReader original_req = original_message.openRequest();
887             IrisU64JsonWriter modified_message;
888             {
889                 IrisU64JsonReader::Request new_req =
890                     modified_message.openRequest(original_req.getMethod(),
891                     original_req.getInstId());
892                 new_req.setRequestId(newRequestId);
893
894                 std::string param;
895                 while (original_req.readNextParam(param))
896                 {
897                     if ((param == "channelId") || (param == "instId"))
898                     {

```

```

897         // Skip the params we want to remove (channelId)
898         // and skip instId too because that will have already been filled in.
899         // skip over the value to the next parameter
900         original_message.skip();
901     }
902     else
903     {
904         new_req.paramSlow(param);
905
906         // Pass through the original value
907         IrisValue value;
908         persist(original_message, value);
909         persist(modified_message, value);
910     }
911 }
912 }
913
914 // Send modified request.
915 sendingInterface->irisHandleMessage(modified_message.getMessage());
916 return;
917 }
918 else if (method == "instanceRegistry_unregisterInstance")
919 {
920     // We received an instanceRegistry_unregisterInstance() request from a local instance:
921     // - Allocate an ongoingInstanceRegistryCalls slot for the request id and remember the
922     //   instId of the unregistered instance in it.
923     // - Send request unmodified.
924
925     // Get params.aInstId.
926     InstanceId aInstId = IRIS_UINT64_MAX;
927     if (!req.paramOptional(ISTR("aInstId"), aInstId))
928     {
929         // Strange. 'params.aInstId' is missing. This should never happen.
930         log.error(
931             "IrisClient::receivingInterface_irisHandleMessage():"
932             " Received instanceRegistry_unregisterInstance() request without aInstId
933 parameter:\n%s\n",
934             messageToString(message).c_str());
935         goto send;
936     }
937
938     if (!req.isNotification())
939     {
940         RequestId requestId = req.getRequestId();
941
942         if (aInstId == getCallerInstId(requestId))
943         {
944             std::lock_guard<std::mutex> lock(ongoingInstanceRegistryCallsMutex);
945             // There will be a response to this request so we need to remember the interface to
946             // send it to.
947             // Allocate an ongoingInstanceRegistryCalls slot for the request id and remember the
948             // instId of the unregistered instance in it.
949             ongoingInstanceRegistryCalls[requestId] = OngoingInstanceRegistryCallEntry(method,
950 aInstId);
951             goto send;
952         }
953     }
954
955     // There will be no more communication to the instance being unregistered.
956     // Remove instance from instIdToInterface.
957     assert(aInstId < InstanceId(instIdToInterface.size()));
958     // sendingInterface: Forward messages to unknown instIds to the server. The global instance
959     // may have reassigned the same instId to some other instance behind the server which exists.
960     instIdToInterface[aInstId] = sendingInterface;
961
962     // Intended fallthrough to send original request.
963 }
964 else if (method == "instanceRegistry_getList")
965 {
966     // We received an instanceRegistry_getList() request from a local instance:
967     // - We want to remember/snoop all returned instance names we get in the response (for
968     //   logging).
969     // - Allocate an ongoingInstanceRegistryCalls slot for the request id in order to recognize
970     //   the response.
971     // - Send request unmodified.
972
973     if (!req.isNotification())
974     {
975         RequestId requestId = req.getRequestId();
976         std::lock_guard<std::mutex> lock(ongoingInstanceRegistryCallsMutex);
977         ongoingInstanceRegistryCalls[requestId] = OngoingInstanceRegistryCallEntry(method);
978     }
979
980     // Intended fallthrough to send original request.
981 }
982
983 send:

```

```

976         // Send original message.
977         sendingInterface->irisHandleMessage(message);
978     }
979
980 void receivingInterface_irisHandleResponse(const uint64_t* message)
981 {
982     {
983         std::lock_guard<std::mutex> lock(ongoingInstanceRegistryCallsMutex);
984
985         if (!ongoingInstanceRegistryCalls.empty())
986         {
987             // Slow path is only used while a instanceRegistry_registerInstance() or
988             // instanceRegistry_unregisterInstance()
989             // call is ongoing. This is usually only the case at startup and shutdown.
990
991             // We need to check whether this is the response to either
992             // instanceRegistry_registerInstance() or
993             // instanceRegistry_unregisterInstance() or
994             // any other response.
995
996             // Decode response.
997             IrisU64JsonReader r(message);
998             IrisU64JsonReader::Response resp = r.openResponse();
999             RequestId requestId = resp.getRequestId();
1000
1001             // Check whether this is a response to one of our pending requests.
1002             OngoingInstanceRegistryCallMap::iterator i =
1003             ongoingInstanceRegistryCalls.find(requestId);
1004             if (i == ongoingInstanceRegistryCalls.end())
1005             {
1006                 goto send; // None of the pending responses. Handle in the normal way.
1007             }
1008
1009             if (i->second.method == "instanceRegistry_registerInstance")
1010             {
1011                 // This is a response to a previous instanceRegistry_registerInstance() call:
1012
1013                 IrisInterface* responseIfPtr = channel_registry.getChannel(i->second.channelId);
1014
1015                 if (resp.isError())
1016                 {
1017                     // The call failed, pass on the message.
1018                     responseIfPtr->irisHandleMessage(message);
1019                 }
1020                 else
1021                 {
1022                     // The call succeeded:
1023                     // - add new instId to our local instance registry
1024                     // - translate request id back to the original request id
1025                     // - send this modified response to the caller
1026                     // - erase this entry in ongoingInstanceRegistryCalls
1027
1028                     // Add instance to instIdToInterface.
1029                     InstanceId newInstId;
1030                     if (!resp.getResultReader().openObject().memberOptional(ISTR("instId"),
1031                     newInstId))
1032                     {
1033                         // Strange. 'result.instId' is missing. This should never happen.
1034                         log.error(
1035                             "IrisClient::receivingInterface_irisHandleResponse(): "
1036                             "Received instanceRegistry_registerInstance() response without
1037                             result.instId:\n%s\n",
1038                             messageToString(message).c_str());
1039                     }
1040                     else
1041                     {
1042                         // This is a valid response for instanceRegistry_registerInstance(): Enter
1043                         // newInstId into instIdToInterface.
1044                         findInterface(newInstId);
1045                         instIdToInterface[newInstId] = responseIfPtr;
1046                     }
1047
1048                     // Remember instance name.
1049                     std::string newInstName;
1050                     if (resp.getResultReader().openObject().memberOptional(ISTR("instName"),
1051                     newInstName))
1052                     {
1053                         setInstName(newInstId, newInstName);
1054                     }
1055
1056                     // Translate the id back to the id of the original request and use the
1057                     // responseIfPtr to send the response.
1058                     IrisU64JsonWriter modifiedMessageWriter;
1059                     modifiedMessageWriter.copyMessageAndModifyId(message, i->second.id);
1060
1061                     // Log message?
1062                     if (irisMessageLogLevel)

```

```

1059         {
1060             log.irisMessage(modifiedMessageWriter.getMessage());
1061         }
1062
1063         responseIfPtr->irisHandleMessage(modifiedMessageWriter.getMessage());
1064     }
1065
1066     // Remove ongoingInstanceRegistryCalls entry now that we have seen the response.
1067     ongoingInstanceRegistryCalls.erase(i);
1068     return;
1069 }
1070 else if (i->second.method == "instanceRegistry_unregisterInstance")
1071 {
1072     // This is a response to a previous instanceRegistry_unregisterInstance() call:
1073     // - remove this instId from our local instance registry
1074     // - remove this entry from ongoingInstanceRegistryCalls
1075     // - send response to caller
1076
1077     InstanceId aInstId = i->second.id;
1078
1079     // Remeber the old response interface in case we need it after we override it
1080     IrisInterface* aInst_responseIf = instIdToInterface[aInstId];
1081
1082     // Remove instance from instIdToInterface.
1083     assert(aInstId < InstanceId(instIdToInterface.size()));
1084     // sendingInterface: Forward messages to unknown instIds to the server. The global
instance may have reassigned the same instId to some other instance behind the server which exists.
1085     instIdToInterface[aInstId] = sendingInterface;
1086     setInstName(aInstId, ""); // IrisLogger will generate a default name for unknown
instance ids.
1087
1088     // Remove ongoingInstanceRegistryCalls entry.
1089     ongoingInstanceRegistryCalls.erase(i);
1090
1091     if (aInstId == resp.getInstId())
1092     {
1093         // An instance unregistered itself so we need to call it directly rather than
1094         // go through the normal message handler because we just set that to forward
1095         // messages to this instId to the server.
1096         aInst_responseIf->irisHandleMessage(message);
1097         return;
1098     }
1099
1100     // Intended fallthrough to irisHandleMessage(message).
1101 }
1102 else if (i->second.method == "instanceRegistry_getList")
1103 {
1104     // This is a response to a previous instanceRegistry_getList() call:
1105     // - remember all instance names (for logging)
1106     // - send response to caller
1107
1108     // Remove ongoingInstanceRegistryCalls entry.
1109     ongoingInstanceRegistryCalls.erase(i);
1110     try
1111     {
1112         // Peek into instance list. We do not care whether this is just
1113         // a subset of all instances or not. We take what we can get.
1114         std::vector<InstanceInfo> instanceInfoList;
1115         resp.getResult(instanceInfoList);
1116         for (const auto& instanceInfo: instanceInfoList)
1117         {
1118             setInstName(instanceInfo.instId, instanceInfo.instName);
1119         }
1120     }
1121     catch(const IrisErrorException&)
1122     {
1123         // Silently ignore bogus responses. The caller will handle the error.
1124     }
1125     // Intended fallthrough to irisHandleMessage(message).
1126 }
1127 }
1128
1129 send:
1130     // Handle response in the normal way.
1131     irisHandleMessage(message);
1132 }
1133
1134 RequestId generateNewRequestIdForRegisterInstanceCall()
1135 {
1136     return nextInstIdForRegisterInstanceCall++;
1137 }
1138
1139 IrisInterface* findInterface(InstanceId instId)
1140 {
1141     if (instId >= IrisMaxTotalInstances)
1142     {
1143         log.error("IrisClient::findInterface(instId=0x%08x): got ridiculously high instId",
1144

```



```

    int(instId));
1153         return sendingInterface;
1154     }
1155     if (instId >= InstanceId(instIdToInterface.size()))
1156     {
1157         instIdToInterface.resize(instId + 100, sendingInterface);
1158     }
1159     return instIdToInterface[instId];
1160 }
1161
1162 class GlobalInstanceSendingInterface : public IrisInterface
1163 {
1164 public:
1165     GlobalInstanceSendingInterface(IrisClient* parent_)
1166         : parent(parent_)
1167     {
1168     }
1169
1170     virtual void irisHandleMessage(const uint64_t* message) override
1171     {
1172         if (IrisU64JsonReader::isRequestOrNotification(message))
1173         {
1174             // Intercept requests to the global instance so we can snoop on
1175             // calls to instanceRegistry_registerInstance()
1176             parent->globalInstanceSendingInterface_irisHandleMessage(message);
1177         }
1178         else
1179         {
1180             // This is called for responses sent from clients to the global instance.
1181             // Simply forward them as usual. Nothing to intercept.
1182             parent->sendingInterface->irisHandleMessage(message);
1183         }
1184     }
1185
1186 private:
1187     IrisClient* const parent;
1188 };
1189
1190 class ReceivingInterface : public IrisInterface
1191 {
1192 public:
1193     ReceivingInterface(IrisLogger& log_, IrisClient* parent_)
1194         : parent(parent_)
1195         , log(log_)
1196     {
1197     }
1198
1199     virtual void irisHandleMessage(const uint64_t* message) override
1200     {
1201         InstanceId instId = IrisU64JsonReader::getInstId(message);
1202
1203         if (instId >= InstanceId(instId_to_thread_id.size()))
1204         {
1205             // We do not have an entry for this instance therefore
1206             // we have not been asked to marshal requests to a specific
1207             // thread and should use the default.
1208             // Todo: Remove once IrisMessageQueue and IrisProcessEventsThread are gone
1209             setHandlerThread(instId, getDefaultThreadId());
1210         }
1211
1212         // Todo: Refactor once IrisMessageQueue and IrisProcessEventsThread are gone
1213         std::thread::id thread_id = instId_to_thread_id[instId];
1214         if (thread_id == std::thread::id())
1215         {
1216             // Message has already been marshalled, forward on
1217             if (IrisU64JsonReader::isRequestOrNotification(message))
1218             {
1219                 parent->irisHandleMessage(message);
1220             }
1221             else
1222             {
1223                 parent->receivingInterface_irisHandleResponse(message);
1224             }
1225         }
1226         else
1227         {
1228             message_queue.push(message, thread_id);
1229         }
1230     }
1231
1232 void setHandlerThread(InstanceId instId, std::thread::id thread_id)
1233 {
1234     if (instId >= IrisMaxTotalInstances)
1235     {
1236         log.error(
1237             "IrisClient::ReceivingInterface::setHandlerThread(instId=0x%08x):"
1238             " got ridiculously high instId",
1239

```

```

1245         int(instId));
1246     }
1247     else if (instId >= InstanceId(instId_to_thread_id.size()))
1248     {
1249         instId_to_thread_id.resize(instId + 100, getDefaultThreadId());
1250     }
1251
1252     instId_to_thread_id[instId] = thread_id;
1253 }
1254
1255 IrisErrorCode processMessagesForCurrentThread(bool waitForAMessage)
1256 {
1257     if (waitForAMessage)
1258     {
1259         IrisErrorCode code = message_queue.waitForMessageForCurrentThread();
1260         if (code != E_ok)
1261         {
1262             return code;
1263         }
1264     }
1265     message_queue.processRequestsForCurrentThread();
1266
1267     return E_ok;
1268 }
1269
1270 private:
1271     std::thread::id getDefaultThreadId()
1272     {
1273         return process_events_thread.getThreadId();
1274     }
1275
1276     IrisClient* const parent;
1277
1278     impl::IrisMessageQueue message_queue{this};
1279
1280     std::vector<std::thread::id> instId_to_thread_id;
1281
1282     IrisLogger& log;
1283
1284     impl::IrisProcessEventsThread process_events_thread{&message_queue, "ClientMsgHandler"};
1285 };
1286
1287 public: // IrisConnectionInterface
1288     virtual uint64_t registerIrisInterfaceChannel(IrisInterface* iris_interface) override
1289     {
1290         return channel_registry.registerChannel(iris_interface);
1291     }
1292
1293     virtual void unregisterIrisInterfaceChannel(uint64_t channelId) override
1294     {
1295         IrisInterface* if_to_remove = channel_registry.getChannel(channelId);
1296
1297         std::vector<InstanceId> instIds_for_channel;
1298
1299         for (size_t i = 0; i < instIdToInterface.size(); i++)
1300         {
1301             if (instIdToInterface[i] == if_to_remove)
1302             {
1303                 InstanceId instId = InstanceId(i);
1304                 instIds_for_channel.push_back(instId);
1305             }
1306         }
1307
1308         if (instIds_for_channel.size() > 0)
1309         {
1310             // Create an instance to call instanceRegistry_unregisterInstance() with.
1311             IrisInstance instance_killer(this, "framework.IrisClient.instance_killer",
1312                                         IrisInstance::UNIQUEIFY);
1313             for (InstanceId instId : instIds_for_channel)
1314             {
1315                 instance_killer.irisCall().instanceRegistry_unregisterInstance(instId);
1316             }
1317         }
1318
1319         channel_registry.unregisterChannel(channelId);
1320     }
1321
1322     virtual IrisErrorCode processAsyncMessages(bool waitForAMessage) override
1323     {
1324         return receivingInterface.processMessagesForCurrentThread(waitForAMessage);
1325     }
1326
1327     virtual IrisInterface* getIrisInterface() override
1328     {
1329         return this;
1330     }
1331
1332     uint64_t registerChannel(IrisC_CommunicationChannel* channel)

```

```

1337     {
1338         return channel_registry.registerChannel(channel);
1339     }
1340
1341     void unregisterChannel(uint64_t channelId)
1342     {
1343         channel_registry.unregisterChannel(channelId);
1344     }
1345
1346     // function called by class IrisPlugin
1347     uint64_t registerChannel(IrisC_CommunicationChannel* channel, const ::std::string& path)
1348     {
1349         (void) path;
1350         return channel_registry.registerChannel(channel);
1351     }
1352
1353 public:
1354     void loadPlugin(const std::string& plugin_name)
1355     {
1356         assert(mode == IRIS_SERVICE_SERVER);
1357         assert(plugin == nullptr);
1358         plugin = std::unique_ptr<impl::IrisPlugin<IrisClient>>(new impl::IrisPlugin<IrisClient>(this,
1359 plugin_name));
1360     }
1361
1362     void unloadPlugin()
1363     {
1364         assert(mode == IRIS_SERVICE_SERVER);
1365         plugin = nullptr;
1366     }
1367
1368     void initServiceServer(impl::IrisTcpSocket* socket_)
1369     {
1370         assert(mode == IRIS_SERVICE_SERVER);
1371         service_socket = socket_;
1372         socketSet.addSocket(service_socket);
1373         adapter.initServiceServer(service_socket, &socketSet, &receivingInterface, verbose);
1374     }
1375
1376 private:
1377     std::string getInstName(InstanceId instId)
1378     {
1379         // IrisLogger will generate a default name for unknown instances (empty string).
1380         return instId < instIdToInstName.size() ? instIdToInstName[instId] : std::string();
1381     }
1382
1383     void setInstName(InstanceId instId, const std::string& instName)
1384     {
1385         // Ignore ridiculously high instIds (programming errors).
1386         if (instId >= IrisMaxTotalInstances)
1387         {
1388             return;
1389         }
1390
1391         if (instId >= instIdToInstName.size())
1392         {
1393             instIdToInstName.resize(instId + 1, "");
1394         }
1395
1396         instIdToInstName[instId] = instName;
1397     }
1398
1399     // --- Private data. ---
1400
1401     IrisLogger log;
1402
1403     IrisInstance irisInstance;
1404
1405     std::string irisInstanceInstName;
1406
1407     GlobalInstanceSendingInterface globalInstanceSendingInterface{this};
1408
1409     ReceivingInterface receivingInterface{log, this};
1410
1411     impl::IrisTcpSocket sock{log, 0};
1412
1413     impl::IrisTcpSocket* service_socket{nullptr};
1414
1415     impl::IrisTcpSocketSet socketSet{log, 0};
1416
1417     std::vector<IrisInterface*> instIdToInterface;
1418
1419     std::vector<std::string> instIdToInstName;
1420
1421     impl::IrisChannelRegistry channel_registry{log};
1422
1423     IrisInterface* sendingInterface{nullptr};

```

```

1445
1448     uint32_t nextInstIdForRegisterInstanceCall{0};
1449
1451     struct OngoingInstanceRegistryCallEntry
1452     {
1453         OngoingInstanceRegistryCallEntry()
1454         {
1455         }
1456
1457         OngoingInstanceRegistryCallEntry(const std::string& method_, uint64_t id_ = IRIS_UINT64_MAX,
1458                                         uint64_t channelId_ = IRIS_UINT64_MAX)
1459             : method(method_)
1460             , id(id_)
1461             , channelId(channelId_)
1462         {
1463         }
1464
1465         std::string method; // instanceRegistry_registerInstance,
1466         instanceRegistry_unregisterInstance or instanceRegistry_getList().
1467         uint64_t id{IRIS_UINT64_MAX}; // For instanceRegistry_registerInstance(): Original
1468         request id. For instanceRegistry_unregisterInstance(): params.aInstId.
1469         uint64_t channelId{IRIS_UINT64_MAX}; // For instanceRegistry_registerInstance() only:
1470         params.channelId.
1471     };
1472
1473     typedef std::map<uint64_t, OngoingInstanceRegistryCallEntry> OngoingInstanceRegistryCallMap;
1474
1475     OngoingInstanceRegistryCallMap ongoingInstanceRegistryCalls;
1476
1477     std::mutex ongoingInstanceRegistryCallsMutex;
1478
1479     unsigned verbose{0};
1480
1481     unsigned irisMessageLogLevel{0};
1482
1483     impl::IrisRpcAdapterTcp adapter{log};
1484
1485     std::unique_ptr<impl::IrisProcessEventsThread> socket_thread{nullptr};
1486
1487     Mode mode;
1488
1489     std::string component_name;
1490
1491     std::unique_ptr<impl::IrisPlugin<IrisClient>> plugin{nullptr};
1492
1493     std::string connectionStr{"(not connected)"};
1494
1495     uint64_t sleepOnDestructionMs{};
1496
1497 #ifndef _WIN32
1498     pid_t childPid{};
1499 #endif
1500
1501     int lastExitStatus{-1};
1502 };
1503
1504 namespace IRIS_END
1505
1506 #endif // #ifndef ARM_INCLUDE_IrisClient_h

```

## 9.7 IrisCommandLineParser.h File Reference

Generic command line parser.

```

#include <cstdint>
#include <map>
#include <string>
#include <vector>
#include <functional>
#include <exception>
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisErrorException.h"

```

### Classes

- class [iris::IrisCommandLineParser](#)
- struct [iris::IrisCommandLineParser::Option](#)

*Option container.*

## 9.7.1 Detailed Description

Generic command line parser.

### Copyright

Copyright (C) 2020-2022 Arm Limited. All rights reserved.

## 9.8 IrisCommandLineParser.h

[Go to the documentation of this file.](#)

```

1
2 #ifndef ARM_INCLUDE_IrisCommandLineParser_h
3 #define ARM_INCLUDE_IrisCommandLineParser_h
4
5 #include <stdint>
6 #include <map>
7 #include <string>
8 #include <vector>
9 #include <functional>
10 #include <exception>
11
12 #include "iris/detail/IrisCommon.h"
13 #include "iris/detail/IrisErrorException.h"
14
15 NAMESPACE_IRIS_START
16
17 #if 0
18 #include <iostream>
19 #include "iris/IrisCommandLineParser.h"
20
21 int main(int argc, const char* argv[])
22 {
23     // Declare command line options.
24     iris::IrisCommandLineParser options("mytool", "Usage: mytool [OPTIONS]\n", "0.0.1");
25     options.addOption('v', "verbose", "Be more verbose (may be specified multiple times)."); // Switch
26     option.
27     options.addOption(0, "port", "Specify local server port.", "PORT", "7999"); // Option with argument,
28     without a short option.
29
30     // Parse command line.
31     options.parseCommandLine(argc, argv);
32
33     // Use options.
34     if (options.getSwitch("verbose"))
35     {
36         std::cout << "Verbose level: " << options.getSwitch("verbose") << "\n";
37     }
38     std::cout << "Port: " << options.getInt("port") << "\n";
39     return 0;
40 }
41 #endif
42 class IrisCommandLineParser
43 {
44 public:
45     struct Option
46     {
47         // Public interface:
48
49         Option& setList(char sep = ',') { listSeparator = sep; return *this; }
50
51 private:
52         // Meta info:
53
54         char shortOption{};
55         std::string longOption;
56         std::string help;
57         std::string formalArgumentName;
58         std::string defaultValue;
59         char listSeparator{};
60
61         bool hasFormalArgument() const { return !formalArgumentName.empty(); }
62
63         // Actual values from command line:

```

```

98
102     std::string value;
103
105     bool isSpecified{};
106
108     void setValue(const std::string& v);
109
111     void unsetValue();
112
113     friend class IrisCommandLineParser;
114 };
115
117 IrisCommandLineParser(const std::string& programName_, const std::string& usageHeader_, const
std::string& versionStr_);
118
126 Option& addOption(char shortOption, const std::string& longOption, const std::string& help, const
std::string& formalArgumentName = std::string(), const std::string& defaultValue = std::string());
127
150 int parseCommandLine(int argc, const char** argv);
151 int parseCommandLine(int argc, char** argv) { return parseCommandLine(argc, const_cast<const
char**>(argv)); }
152
155 void noNonOptionArguments();
156
160 void pleaseSpecifyOneOf(const std::vector<std::string>& options, const std::vector<std::string>&
formalNonOptionArguments = std::vector<std::string>());
161
163 std::string getStr(const std::string& longOption) const;
164
167 int64_t getInt(const std::string& longOption) const;
168
171 uint64_t getUInt(const std::string& longOption) const;
172
175 double getDbl(const std::string& longOption) const;
176
178 uint64_t getSwitch(const std::string& longOption) const;
179
181 bool operator()(const std::string& longOption) const { return getSwitch(longOption) > 0; }
182
184 std::vector<std::string> getList(const std::string& longOption) const;
185
189 std::map<std::string, std::string> getMap(const std::string& longOption) const;
190
194 bool isSpecified(const std::string& longOption) const;
195
197 const std::vector<std::string>& getNonOptionArguments() const;
198
202 void clear();
203
208 int printMessage(const std::string& message, int error = 0, bool exit = false) const;
209
211 int printError(const std::string& message) const;
212
216 int printErrorAndExit(const std::string& message) const;
217
221 int printErrorAndExit(const IrisErrorException& e) const { return printErrorAndExit(e.errorMessage()
+ "\n"); }
222
226 int printErrorAndExit(const std::exception& e) const;
227
239 void setMessageFunc(const std::function<int(const std::string& message, int error, bool exit)>&
messageFunc);
240
244 static int defaultMessageFunc(const std::string& message, int error, bool exit);
245
249 std::string getHelpMessage() const;
250
254 void setValue(const std::string& longOption, const std::string& value, bool append = false);
255
258 void unsetValue(const std::string& longOption);
259
261 void setProgramName(const std::string& programName_, bool append = false);
262
263 private:
266 Option& getOption(const std::string& longOption);
267
269 const Option& getOption(const std::string& longOption) const;
270
272 std::string programName;
273
275 std::string usageHeader;
276
278 std::string versionStr;
279
281 std::vector<std::string> optionList;
282
285 std::map<std::string, Option> options;

```

```

286
288     std::vector<std::string> nonOptionArguments;
289
291     std::function<int(const std::string& message, int error, bool exit)> messageFunc;
292 };
293
294 NAMESPACE_IRIS_END
295
296 #endif // ARM_INCLUDE_IrisCommandLineParser_h

```

## 9.9 IrisElfDwarfArm.h File Reference

Constants for the register.canonicalRnScheme "ElfDwarf" for architecture Arm.

```

#include "iris/detail/IrisInterface.h"
#include "iris/detail/IrisCommon.h"

```

### Enumerations

- enum **ElfDwarfArm** : uint64\_t {
  - ARM\_R0** = 0x2800000000 , **ARM\_R1** = 0x2800000001 , **ARM\_R2** = 0x2800000002 , **ARM\_R3** = 0x2800000003 ,
  - ARM\_R4** = 0x2800000004 , **ARM\_R5** = 0x2800000005 , **ARM\_R6** = 0x2800000006 , **ARM\_R7** = 0x2800000007 ,
  - ARM\_R8** = 0x2800000008 , **ARM\_R9** = 0x2800000009 , **ARM\_R10** = 0x280000000a , **ARM\_R11** = 0x280000000b ,
  - ARM\_R12** = 0x280000000c , **ARM\_R13** = 0x280000000d , **ARM\_R14** = 0x280000000e , **ARM\_R15** = 0x280000000f ,
  - ARM\_SPSR** = 0x2800000080 , **ARM\_SPSR\_fiq** = 0x2800000081 , **ARM\_SPSR\_irq** = 0x2800000082 ,
  - ARM\_SPSR\_abt** = 0x2800000083 ,
  - ARM\_SPSR\_und** = 0x2800000084 , **ARM\_SPSR\_svc** = 0x2800000085 , **ARM\_R8\_fiq** = 0x2800000097 ,
  - ARM\_R9\_fiq** = 0x2800000098 ,
  - ARM\_R10\_fiq** = 0x2800000099 , **ARM\_R11\_fiq** = 0x280000009a , **ARM\_R12\_fiq** = 0x280000009b ,
  - ARM\_R13\_fiq** = 0x280000009c ,
  - ARM\_R14\_fiq** = 0x280000009d , **ARM\_R13\_irq** = 0x280000009e , **ARM\_R14\_irq** = 0x280000009f , **ARM\_R13\_abt** = 0x28000000a0 ,
  - ARM\_R14\_abt** = 0x28000000a1 , **ARM\_R13\_und** = 0x28000000a2 , **ARM\_R14\_und** = 0x28000000a3 ,
  - ARM\_R13\_svc** = 0x28000000a4 ,
  - ARM\_R14\_svc** = 0x28000000a5 , **ARM\_D0** = 0x2800000100 , **ARM\_D1** = 0x2800000101 , **ARM\_D2** = 0x2800000102 ,
  - ARM\_D3** = 0x2800000103 , **ARM\_D4** = 0x2800000104 , **ARM\_D5** = 0x2800000105 , **ARM\_D6** = 0x2800000106 ,
  - ARM\_D7** = 0x2800000107 , **ARM\_D8** = 0x2800000108 , **ARM\_D9** = 0x2800000109 , **ARM\_D10** = 0x280000010a ,
  - ARM\_D11** = 0x280000010b , **ARM\_D12** = 0x280000010c , **ARM\_D13** = 0x280000010d , **ARM\_D14** = 0x280000010e ,
  - ARM\_D15** = 0x280000010f , **ARM\_D16** = 0x2800000110 , **ARM\_D17** = 0x2800000111 , **ARM\_D18** = 0x2800000112 ,
  - ARM\_D19** = 0x2800000113 , **ARM\_D20** = 0x2800000114 , **ARM\_D21** = 0x2800000115 , **ARM\_D22** = 0x2800000116 ,
  - ARM\_D23** = 0x2800000117 , **ARM\_D24** = 0x2800000118 , **ARM\_D25** = 0x2800000119 , **ARM\_D26** = 0x280000011a ,
  - ARM\_D27** = 0x280000011b , **ARM\_D28** = 0x280000011c , **ARM\_D29** = 0x280000011d , **ARM\_D30** = 0x280000011e ,
  - ARM\_D31** = 0x280000011f , **AARCH64\_X0** = 0xb700000000 , **AARCH64\_X1** = 0xb700000001 ,
  - AARCH64\_X2** = 0xb700000002 ,
  - AARCH64\_X3** = 0xb700000003 , **AARCH64\_X4** = 0xb700000004 , **AARCH64\_X5** = 0xb700000005 ,
  - AARCH64\_X6** = 0xb700000006 ,
  - AARCH64\_X7** = 0xb700000007 , **AARCH64\_X8** = 0xb700000008 , **AARCH64\_X9** = 0xb700000009 ,
  - AARCH64\_X10** = 0xb70000000a ,

```

AARCH64_X11 = 0xb70000000b , AARCH64_X12 = 0xb70000000c , AARCH64_X13 = 0xb70000000d ,
AARCH64_X14 = 0xb70000000e ,
AARCH64_X15 = 0xb70000000f , AARCH64_X16 = 0xb700000010 , AARCH64_X17 = 0xb700000011 ,
AARCH64_X18 = 0xb700000012 ,
AARCH64_X19 = 0xb700000013 , AARCH64_X20 = 0xb700000014 , AARCH64_X21 = 0xb700000015 ,
AARCH64_X22 = 0xb700000016 ,
AARCH64_X23 = 0xb700000017 , AARCH64_X24 = 0xb700000018 , AARCH64_X25 = 0xb700000019 ,
AARCH64_X26 = 0xb70000001a ,
AARCH64_X27 = 0xb70000001b , AARCH64_X28 = 0xb70000001c , AARCH64_X29 = 0xb70000001d ,
AARCH64_X30 = 0xb70000001e ,
AARCH64_SP = 0xb70000001f , AARCH64_ELR = 0xb700000021 , AARCH64_V0 = 0xb700000040 ,
AARCH64_V1 = 0xb700000041 ,
AARCH64_V2 = 0xb700000042 , AARCH64_V3 = 0xb700000043 , AARCH64_V4 = 0xb700000044 ,
AARCH64_V5 = 0xb700000045 ,
AARCH64_V6 = 0xb700000046 , AARCH64_V7 = 0xb700000047 , AARCH64_V8 = 0xb700000048 ,
AARCH64_V9 = 0xb700000049 ,
AARCH64_V10 = 0xb70000004a , AARCH64_V11 = 0xb70000004b , AARCH64_V12 = 0xb70000004c ,
AARCH64_V13 = 0xb70000004d ,
AARCH64_V14 = 0xb70000004e , AARCH64_V15 = 0xb70000004f , AARCH64_V16 = 0xb700000050 ,
AARCH64_V17 = 0xb700000051 ,
AARCH64_V18 = 0xb700000052 , AARCH64_V19 = 0xb700000053 , AARCH64_V20 = 0xb700000054 ,
AARCH64_V21 = 0xb700000055 ,
AARCH64_V22 = 0xb700000056 , AARCH64_V23 = 0xb700000057 , AARCH64_V24 = 0xb700000058 ,
AARCH64_V25 = 0xb700000059 ,
AARCH64_V26 = 0xb70000005a , AARCH64_V27 = 0xb70000005b , AARCH64_V28 = 0xb70000005c ,
AARCH64_V29 = 0xb70000005d ,
AARCH64_V30 = 0xb70000005e , AARCH64_V31 = 0xb70000005f }

```

### 9.9.1 Detailed Description

Constants for the register.canonicalRnScheme "ElfDwarf" for architecture Arm.

Date

Copyright ARM Limited 2019. All Rights Reserved.

## 9.10 IrisElfDwarfArm.h

[Go to the documentation of this file.](#)

```

1
2
3 #ifndef ARM_INCLUDE_IrisElfDwarfArm_h
4 #define ARM_INCLUDE_IrisElfDwarfArm_h
5
6 #include "iris/detail/IrisInterface.h" // uint64_t
7 #include "iris/detail/IrisCommon.h" // namespace iris
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36

```

Constant	canonicalRn	Register	Architecture	ELF-Arch	DwarfReg
ARM_R0	= 0x2800000000	// R0	EM_ARM	40	0
ARM_R1	= 0x2800000001	// R1	EM_ARM	40	1
ARM_R2	= 0x2800000002	// R2	EM_ARM	40	2
ARM_R3	= 0x2800000003	// R3	EM_ARM	40	3
ARM_R4	= 0x2800000004	// R4	EM_ARM	40	4
ARM_R5	= 0x2800000005	// R5	EM_ARM	40	5
ARM_R6	= 0x2800000006	// R6	EM_ARM	40	6
ARM_R7	= 0x2800000007	// R7	EM_ARM	40	7
ARM_R8	= 0x2800000008	// R8	EM_ARM	40	8
ARM_R9	= 0x2800000009	// R9	EM_ARM	40	9
ARM_R10	= 0x280000000a	// R10	EM_ARM	40	10
ARM_R11	= 0x280000000b	// R11	EM_ARM	40	11
ARM_R12	= 0x280000000c	// R12	EM_ARM	40	12
ARM_R13	= 0x280000000d	// R13	EM_ARM	40	13



37	ARM_R14	= 0x280000000e, // R14	EM_ARM	40	14
38	ARM_R15	= 0x280000000f, // R15	EM_ARM	40	15
39	ARM_SPSR	= 0x2800000080, // SPSR	EM_ARM	40	128
40	ARM_SPSR_fiq	= 0x2800000081, // SPSR_fiq	EM_ARM	40	129
41	ARM_SPSR_irq	= 0x2800000082, // SPSR_irq	EM_ARM	40	130
42	ARM_SPSR_abt	= 0x2800000083, // SPSR_abt	EM_ARM	40	131
43	ARM_SPSR_und	= 0x2800000084, // SPSR_und	EM_ARM	40	132
44	ARM_SPSR_svc	= 0x2800000085, // SPSR_svc	EM_ARM	40	133
45	ARM_R8_fiq	= 0x2800000097, // R8_fiq	EM_ARM	40	151
46	ARM_R9_fiq	= 0x2800000098, // R9_fiq	EM_ARM	40	152
47	ARM_R10_fiq	= 0x2800000099, // R10_fiq	EM_ARM	40	153
48	ARM_R11_fiq	= 0x280000009a, // R11_fiq	EM_ARM	40	154
49	ARM_R12_fiq	= 0x280000009b, // R12_fiq	EM_ARM	40	155
50	ARM_R13_fiq	= 0x280000009c, // R13_fiq	EM_ARM	40	156
51	ARM_R14_fiq	= 0x280000009d, // R14_fiq	EM_ARM	40	157
52	ARM_R13_irq	= 0x280000009e, // R13_irq	EM_ARM	40	158
53	ARM_R14_irq	= 0x280000009f, // R14_irq	EM_ARM	40	159
54	ARM_R13_abt	= 0x28000000a0, // R13_abt	EM_ARM	40	160
55	ARM_R14_abt	= 0x28000000a1, // R14_abt	EM_ARM	40	161
56	ARM_R13_und	= 0x28000000a2, // R13_und	EM_ARM	40	162
57	ARM_R14_und	= 0x28000000a3, // R14_und	EM_ARM	40	163
58	ARM_R13_svc	= 0x28000000a4, // R13_svc	EM_ARM	40	164
59	ARM_R14_svc	= 0x28000000a5, // R14_svc	EM_ARM	40	165
60	ARM_D0	= 0x2800000100, // D0	EM_ARM	40	256
61	ARM_D1	= 0x2800000101, // D1	EM_ARM	40	257
62	ARM_D2	= 0x2800000102, // D2	EM_ARM	40	258
63	ARM_D3	= 0x2800000103, // D3	EM_ARM	40	259
64	ARM_D4	= 0x2800000104, // D4	EM_ARM	40	260
65	ARM_D5	= 0x2800000105, // D5	EM_ARM	40	261
66	ARM_D6	= 0x2800000106, // D6	EM_ARM	40	262
67	ARM_D7	= 0x2800000107, // D7	EM_ARM	40	263
68	ARM_D8	= 0x2800000108, // D8	EM_ARM	40	264
69	ARM_D9	= 0x2800000109, // D9	EM_ARM	40	265
70	ARM_D10	= 0x280000010a, // D10	EM_ARM	40	266
71	ARM_D11	= 0x280000010b, // D11	EM_ARM	40	267
72	ARM_D12	= 0x280000010c, // D12	EM_ARM	40	268
73	ARM_D13	= 0x280000010d, // D13	EM_ARM	40	269
74	ARM_D14	= 0x280000010e, // D14	EM_ARM	40	270
75	ARM_D15	= 0x280000010f, // D15	EM_ARM	40	271
76	ARM_D16	= 0x2800000110, // D16	EM_ARM	40	272
77	ARM_D17	= 0x2800000111, // D17	EM_ARM	40	273
78	ARM_D18	= 0x2800000112, // D18	EM_ARM	40	274
79	ARM_D19	= 0x2800000113, // D19	EM_ARM	40	275
80	ARM_D20	= 0x2800000114, // D20	EM_ARM	40	276
81	ARM_D21	= 0x2800000115, // D21	EM_ARM	40	277
82	ARM_D22	= 0x2800000116, // D22	EM_ARM	40	278
83	ARM_D23	= 0x2800000117, // D23	EM_ARM	40	279
84	ARM_D24	= 0x2800000118, // D24	EM_ARM	40	280
85	ARM_D25	= 0x2800000119, // D25	EM_ARM	40	281
86	ARM_D26	= 0x280000011a, // D26	EM_ARM	40	282
87	ARM_D27	= 0x280000011b, // D27	EM_ARM	40	283
88	ARM_D28	= 0x280000011c, // D28	EM_ARM	40	284
89	ARM_D29	= 0x280000011d, // D29	EM_ARM	40	285
90	ARM_D30	= 0x280000011e, // D30	EM_ARM	40	286
91	ARM_D31	= 0x280000011f, // D31	EM_ARM	40	287
92	AARCH64_X0	= 0xb700000000, // X0	EM_AARCH64	183	0
93	AARCH64_X1	= 0xb700000001, // X1	EM_AARCH64	183	1
94	AARCH64_X2	= 0xb700000002, // X2	EM_AARCH64	183	2
95	AARCH64_X3	= 0xb700000003, // X3	EM_AARCH64	183	3
96	AARCH64_X4	= 0xb700000004, // X4	EM_AARCH64	183	4
97	AARCH64_X5	= 0xb700000005, // X5	EM_AARCH64	183	5
98	AARCH64_X6	= 0xb700000006, // X6	EM_AARCH64	183	6
99	AARCH64_X7	= 0xb700000007, // X7	EM_AARCH64	183	7
100	AARCH64_X8	= 0xb700000008, // X8	EM_AARCH64	183	8
101	AARCH64_X9	= 0xb700000009, // X9	EM_AARCH64	183	9
102	AARCH64_X10	= 0xb70000000a, // X10	EM_AARCH64	183	10
103	AARCH64_X11	= 0xb70000000b, // X11	EM_AARCH64	183	11
104	AARCH64_X12	= 0xb70000000c, // X12	EM_AARCH64	183	12
105	AARCH64_X13	= 0xb70000000d, // X13	EM_AARCH64	183	13
106	AARCH64_X14	= 0xb70000000e, // X14	EM_AARCH64	183	14
107	AARCH64_X15	= 0xb70000000f, // X15	EM_AARCH64	183	15
108	AARCH64_X16	= 0xb700000010, // X16	EM_AARCH64	183	16
109	AARCH64_X17	= 0xb700000011, // X17	EM_AARCH64	183	17
110	AARCH64_X18	= 0xb700000012, // X18	EM_AARCH64	183	18
111	AARCH64_X19	= 0xb700000013, // X19	EM_AARCH64	183	19
112	AARCH64_X20	= 0xb700000014, // X20	EM_AARCH64	183	20
113	AARCH64_X21	= 0xb700000015, // X21	EM_AARCH64	183	21
114	AARCH64_X22	= 0xb700000016, // X22	EM_AARCH64	183	22
115	AARCH64_X23	= 0xb700000017, // X23	EM_AARCH64	183	23
116	AARCH64_X24	= 0xb700000018, // X24	EM_AARCH64	183	24
117	AARCH64_X25	= 0xb700000019, // X25	EM_AARCH64	183	25
118	AARCH64_X26	= 0xb70000001a, // X26	EM_AARCH64	183	26
119	AARCH64_X27	= 0xb70000001b, // X27	EM_AARCH64	183	27
120	AARCH64_X28	= 0xb70000001c, // X28	EM_AARCH64	183	28
121	AARCH64_X29	= 0xb70000001d, // X29	EM_AARCH64	183	29
122	AARCH64_X30	= 0xb70000001e, // X30	EM_AARCH64	183	30
123	AARCH64_SP	= 0xb70000001f, // SP	EM_AARCH64	183	31

```

124  AARCH64_ELR    = 0xb700000021, // ELR      EM_AARCH64    183    33
125  AARCH64_V0     = 0xb700000040, // V0      EM_AARCH64    183    64
126  AARCH64_V1     = 0xb700000041, // V1      EM_AARCH64    183    65
127  AARCH64_V2     = 0xb700000042, // V2      EM_AARCH64    183    66
128  AARCH64_V3     = 0xb700000043, // V3      EM_AARCH64    183    67
129  AARCH64_V4     = 0xb700000044, // V4      EM_AARCH64    183    68
130  AARCH64_V5     = 0xb700000045, // V5      EM_AARCH64    183    69
131  AARCH64_V6     = 0xb700000046, // V6      EM_AARCH64    183    70
132  AARCH64_V7     = 0xb700000047, // V7      EM_AARCH64    183    71
133  AARCH64_V8     = 0xb700000048, // V8      EM_AARCH64    183    72
134  AARCH64_V9     = 0xb700000049, // V9      EM_AARCH64    183    73
135  AARCH64_V10    = 0xb70000004a, // V10     EM_AARCH64    183    74
136  AARCH64_V11    = 0xb70000004b, // V11     EM_AARCH64    183    75
137  AARCH64_V12    = 0xb70000004c, // V12     EM_AARCH64    183    76
138  AARCH64_V13    = 0xb70000004d, // V13     EM_AARCH64    183    77
139  AARCH64_V14    = 0xb70000004e, // V14     EM_AARCH64    183    78
140  AARCH64_V15    = 0xb70000004f, // V15     EM_AARCH64    183    79
141  AARCH64_V16    = 0xb700000050, // V16     EM_AARCH64    183    80
142  AARCH64_V17    = 0xb700000051, // V17     EM_AARCH64    183    81
143  AARCH64_V18    = 0xb700000052, // V18     EM_AARCH64    183    82
144  AARCH64_V19    = 0xb700000053, // V19     EM_AARCH64    183    83
145  AARCH64_V20    = 0xb700000054, // V20     EM_AARCH64    183    84
146  AARCH64_V21    = 0xb700000055, // V21     EM_AARCH64    183    85
147  AARCH64_V22    = 0xb700000056, // V22     EM_AARCH64    183    86
148  AARCH64_V23    = 0xb700000057, // V23     EM_AARCH64    183    87
149  AARCH64_V24    = 0xb700000058, // V24     EM_AARCH64    183    88
150  AARCH64_V25    = 0xb700000059, // V25     EM_AARCH64    183    89
151  AARCH64_V26    = 0xb70000005a, // V26     EM_AARCH64    183    90
152  AARCH64_V27    = 0xb70000005b, // V27     EM_AARCH64    183    91
153  AARCH64_V28    = 0xb70000005c, // V28     EM_AARCH64    183    92
154  AARCH64_V29    = 0xb70000005d, // V29     EM_AARCH64    183    93
155  AARCH64_V30    = 0xb70000005e, // V30     EM_AARCH64    183    94
156  AARCH64_V31    = 0xb70000005f, // V31     EM_AARCH64    183    95
157 }; // enum ElfDwarfArm
158
159 } // namespace ElfDwarf
160
161 NAMESPACE_IRIS_END
162
163 #endif // ARM_INCLUDE_IrisElfDwarfArm_h
164

```

## 9.11 IrisEventEmitter.h File Reference

A utility class for emitting Iris events.

```
#include "iris/detail/IrisEventEmitterBase.h"
```

### Classes

- class `iris::IrisEventEmitter< ARGS >`  
A helper class for generating Iris events.

#### 9.11.1 Detailed Description

A utility class for emitting Iris events.

#### Copyright

Copyright (C) 2016 Arm Limited. All rights reserved.

## 9.12 IrisEventEmitter.h

[Go to the documentation of this file.](#)

```

1
8 #ifndef ARM_INCLUDE_IrisEventEmitter_h
9 #define ARM_INCLUDE_IrisEventEmitter_h
10
11 #include "iris/detail/IrisEventEmitterBase.h"
12
13 NAMESPACE_IRIS_START
14
35 template <typename... ARGS>
36 class IrisEventEmitter : public IrisEventEmitterBase

```

```

37 {
38 public:
40     IrisEventEmitter()
41         : IrisEventEmitterBase(sizeof...(ARGS))
42     {
43     }
44
45     void operator() (ARGS... args)
46     {
47         emitEvent(args...);
48     }
49 };
50
51 NAMESPACE_IRIS_END
52
53 #endif // ARM_INCLUDE_IrisEventEmitter_h

```

## 9.13 IrisGlobalInstance.h File Reference

Central instance which lives in the simulation engine and distributes all Iris messages.

```

#include "iris/IrisInstance.h"
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisFunctionDecoder.h"
#include "iris/detail/IrisInterface.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include "iris/detail/IrisReceivedRequest.h"
#include "iris/impl/IrisChannelRegistry.h"
#include "iris/impl/IrisPlugin.h"
#include "iris/impl/IrisServiceClient.h"
#include "iris/impl/IrisTcpServer.h"
#include <atomic>
#include <list>
#include <map>
#include <memory>
#include <mutex>
#include <string>
#include <thread>
#include <unordered_map>
#include <vector>

```

### Classes

- class [iris::IrisGlobalInstance](#)

### 9.13.1 Detailed Description

Central instance which lives in the simulation engine and distributes all Iris messages.

#### Date

Copyright ARM Limited 2014-2019 All Rights Reserved.

The IrisGlobalInstance lives in the simulation engine. It contains all central data structures like the instance registry. It is responsible for distributing Iris messages to all in-process instances and to the IrisTcpServer.

## 9.14 IrisGlobalInstance.h

[Go to the documentation of this file.](#)

```

1
10 #ifndef ARM_INCLUDE_IrisGlobalInstance_h
11 #define ARM_INCLUDE_IrisGlobalInstance_h
12
13 #include "iris/IrisInstance.h"

```

```

14 #include "iris/detail/IrisCommon.h"
15 #include "iris/detail/IrisFunctionDecoder.h"
16 #include "iris/detail/IrisInterface.h"
17 #include "iris/detail/IrisLogger.h"
18 #include "iris/detail/IrisObjects.h"
19 #include "iris/detail/IrisReceivedRequest.h"
20
21 #include "iris/impl/IrisChannelRegistry.h"
22 #include "iris/impl/IrisPlugin.h"
23 #include "iris/impl/IrisServiceClient.h"
24 #include "iris/impl/IrisTcpServer.h"
25
26 #include <atomic>
27 #include <list>
28 #include <map>
29 #include <memory>
30 #include <mutex>
31 #include <string>
32 #include <thread>
33 #include <unordered_map>
34 #include <vector>
35
36 namespace IRIS_START
37 {
38     class IrisGlobalInstance : public IrisInterface
39     , public IrisConnectionInterface
40     {
41     public:
42         IrisGlobalInstance();
43
44         ~IrisGlobalInstance();
45
46         uint64_t registerChannel(IrisC_CommunicationChannel* channel, const std::string& connection_info =
47             "");
48
49         void unregisterChannel(uint64_t channelId);
50
51         IrisInstance& getIrisInstance() { return irisInstance; }
52
53     public: // IrisConnectionInterface
54         virtual uint64_t registerIrisInterfaceChannel(IrisInterface* iris_interface) override;
55
56         virtual void unregisterIrisInterfaceChannel(uint64_t channelId) override
57         {
58             unregisterChannel(channelId);
59         }
60
61         virtual IrisErrorCode processAsyncMessages(bool waitForAMessage) override
62         {
63             return irisProxyInterface.load()->processAsyncMessagesInProxy(waitForAMessage);
64         }
65
66         virtual IrisInterface* getIrisInterface() override
67         {
68             return this;
69         }
70
71         virtual void setIrisProxyInterface(IrisProxyInterface* irisProxyInterface_) override
72         {
73             irisProxyInterface = irisProxyInterface_ ? irisProxyInterface_ : &defaultIrisProxyInterface;
74         }
75     public:
76         // IrisInterface implementation.
77
78         virtual void irisHandleMessage(const uint64_t* message) override;
79
80         // Set log level for logging messages.
81         void setLogLevel(unsigned level);
82
83     private:
84         // --- Functions implemented locally in the global instance (registered in the functionDecoder). ---
85
86         void impl_instanceRegistry_registerInstance(IrisReceivedRequest& request);
87
88         void impl_instanceRegistry_unregisterInstance(IrisReceivedRequest& request);
89
90         void impl_instanceRegistry_getList(IrisReceivedRequest& request);
91
92         void impl_instanceRegistry_getInstanceInfoByInstId(IrisReceivedRequest& request);
93
94         void impl_instanceRegistry_getInstanceInfoByName(IrisReceivedRequest& request);
95
96         void impl_perInstanceExecution_setStateAll(IrisReceivedRequest& request);
97
98         void impl_perInstanceExecution_getStateAll(IrisReceivedRequest& request);
99
100

```

```

124 void impl_tcpServer_start(IrisReceivedRequest& request);
125
127 void impl_tcpServer_stop(IrisReceivedRequest& request);
128
130 void impl_tcpServer_getPort(IrisReceivedRequest& request);
131
133 void impl_plugin_load(IrisReceivedRequest& request);
134
136 void impl_service_connect(IrisReceivedRequest& request);
137
139 void impl_service_disconnect(IrisReceivedRequest& request);
140
141 // --- Private helpers ---
142
144 struct InstanceRegistryEntry
145 {
146     std::string      instName;
147     uint64_t         channelId{IRIS_UINT64_MAX}; // If this is IRIS_UINT64_MAX this means this entry
is unused.
148     IrisInterface*   iris_interface{nullptr};
149     std::string      connection_info;
150
151     bool empty() const
152     {
153         return channelId == IRIS_UINT64_MAX;
154     }
155
157     void clear()
158     {
159         instName      = "";
160         channelId      = IRIS_UINT64_MAX;
161         iris_interface = nullptr;
162         connection_info = "";
163
164         assert(empty());
165     }
166 };
167
169 InstanceId registerInstance(std::string& instName,
170                             uint64_t      channelId,
171                             bool          uniquify,
172                             IrisInterface* iris_interface);
173
175 void unregisterInstanceAndGenerateEvent(InstanceRegistryEntry* entry,
176                                         InstanceId          aInstId,
177                                         uint64_t            time,
178                                         std::list<IrisRequest>& deferred_event_requests);
179
181 const InstanceRegistryEntry* findInstanceRegistryEntry(InstanceId instId) const
182 {
183     if (instId >= InstanceId(instanceRegistry.size()))
184         return nullptr;
185
186     if (instanceRegistry[instId].empty())
187         return nullptr;
188
189     return &instanceRegistry[instId];
190 }
191
193 InstanceId addNewInstance(const std::string& instName,
194                           uint64_t         channelId,
195                           IrisInterface*    iris_interface);
196
198 // Stop the Iris Server (if running)
199 void stopServer();
200
202 // stop the Iris Client (if running)
203 void stopClient();
204
206 void loadPlugin(const std::string& plugin_path);
207
209 IrisErrorCode createEventStream(EventStream*&, const EventSourceInfo&, const
std::vector<std::string>&);
210
212 uint64_t getTimeForEvents();
213
215 std::string getInstName(InstanceId instId) const;
216
218 // --- Private data ---
219
221 class Instance : public IrisInstance
222 {
223 public:
224     Instance()
225     : IrisInstance()
226     {
227     }
228 }
229

```

```

230         thisInstanceInfo.instName = "framework.GlobalInstance";
231         thisInstanceInfo.instId = IrisInstIdGlobalInstance;
232         setProperty("instName", getInstanceName());
233         setProperty("instId", getInstId());
234         // NOTE: This instance does not think it is registered.
235         //       This means it won't unregister itself when it is destroyed but that doesn't matter.
236         //       We will be cleaning up all that state anyway.
237     }
238
239     IrisInstanceEvent event_handler;
240 } irisInstance;
241
242 IrisEventRegistry instance_registry_changed_event_registry;
243
244 IrisEventRegistry shutdown_enter_event_registry;
245
246 IrisEventRegistry shutdown_leave_event_registry;
247
248 std::vector<InstanceRegistryEntry> instanceRegistry;
249
250 //
251 std::mutex instance_registry_mutex;
252
253 std::vector<InstanceId> freeInstIds;
254
255 typedef std::map<std::string, uint64_t> InstanceRegistryNameToIdMap;
256
257 InstanceRegistryNameToIdMap instanceRegistryNameToId;
258
259 unsigned logMessages;
260
261 IrisLogger log;
262
263 // TCP server. This won't start listening until startServer() is called.
264 impl::IrisTcpServer* tcp_server;
265
266 impl::IrisServiceClient* service_client;
267
268 // Create and manage communication channels
269 impl::IrisChannelRegistry channel_registry;
270
271 std::unordered_map<uint64_t, std::string> channel_connection_info;
272 std::mutex channel_connection_info_mutex;
273
274 // --- Load and manage plugins ---
275 using Plugin = impl::IrisPlugin<IrisGlobalInstance>;
276 std::unordered_map<std::string, std::unique_ptr<Plugin>> plugins;
277
278 std::mutex plugins_mutex;
279
280 std::mutex log_mutex;
281
282 class DefaultIrisProxyInterface : public IrisProxyInterface
283 {
284 public:
285     virtual void irisHandleMessageInProxy(IrisInterface* irisInterface, InstanceId instId,
286     const uint64_t* message) override;
287     virtual IrisErrorCode processAsyncMessagesInProxy(bool waitForAMessage) override;
288 } defaultIrisProxyInterface;
289
290 std::atomic<IrisProxyInterface*> irisProxyInterface{&defaultIrisProxyInterface};
291 };
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325

```

## 9.15 IrisInstance.h File Reference

Boilerplate code for an Iris instance, including clients and components.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisCppAdapter.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisFunctionDecoder.h"
#include "iris/detail/IrisObjects.h"
#include "iris/IrisInstanceEvent.h"
#include <cassert>
#include <mutex>
#include <functional>

```

```
#include "iris/IrisInstanceBuilder.h"
```

## Classes

- class [iris::IrisInstance](#)

## Macros

- **#define `irisRegisterEventBufferCallback`**(instancePtr, instanceType, functionName, description) register↵  
EventBufferCallback<instanceType, &instanceType::impl\_##functionName>(instancePtr, #functionName,  
description, #instanceType)  
*Register an event buffer callback function using an EventBufferCallbackDelegate.*
- **#define `irisRegisterEventCallback`**(instancePtr, instanceType, functionName, description) register↵  
EventCallback<instanceType, &instanceType::impl\_##functionName>(instancePtr, #functionName, description,  
#instanceType)  
*Register an event callback function using an EventCallbackDelegate Note: Use enableEvent() instead of  
[irisRegisterEventCallback\(\)](#).*
- **#define `irisRegisterFunction`**(instancePtr, instanceType, functionName, functionInfoJson) register↵  
Function(instancePtr, #functionName, &instanceType::impl\_##functionName, functionInfoJson, #instance↵  
Type)  
*Register an Iris function implementation. The function can be implemented in this class or in any other class. The  
helper macro is here to avoid repeating the function name. The 'impl\_' prefix limits namespace pollution.*

## Typedefs

- typedef IrisDelegate< const EventBufferCallbackData & > **`iris::EventBufferCallbackDelegate`**
- typedef IrisDelegate< uint64\_t, const IrisValueMap &, uint64\_t, uint64\_t, bool, std::string & >  
[iris::EventCallbackDelegate](#)  
*Event callback delegate (deprecated)*

### 9.15.1 Detailed Description

Boilerplate code for an Iris instance, including clients and components.

#### Copyright

Copyright (C) 2015-2023 Arm Limited. All rights reserved.

The IrisInstance class provides infrastructure that is:

- Necessary for all Iris instances.
- Useful for Iris components.
- Useful for Iris clients.

#### Note

Using this class to implement a correct Iris interface is optional. This class does not form an interface between instances. It just forms an interface between itself and the code of an instance.

This class is useful for, and used by, both components and clients.

### 9.15.2 Typedef Documentation

### 9.15.2.1 EventCallbackDelegate

```
typedef IrisDelegate<uint64_t, const IrisValueMap&, uint64_t, uint64_t, bool, std::string&>
iris::EventCallbackDelegate
```

Event callback delegate (deprecated)

Note: Use `enableEvent()` instead of `irisRegisterEventCallback()`.

Used to register a function that can receive event callbacks.

```
iris::IrisErrorCode ec_FOO(EventStreamId esId, const iris::IrisValueMap &fields, uint64_t time,
                          InstanceId sInstId, bool syncEc, std::string &errorMessageOut)
```

Example:

```
class MyEventCallback
{
public:
    iris::IrisErrorCode impl_ec_FOO(EventStreamId esId, const iris::IrisValueMap &fields, uint64_t time,
                                   InstanceId sInstId, bool syncEc, std::string &errorMessageOut)
    {
        ...
        return E_ok;
    }
};

MyEventCallback* my_event_callback_ptr;
iris_instance->irisRegisterEventCallback(my_event_callback_ptr, MyEventCallback, ec_FOO, "Handle event
FOO");
```

## 9.16 IrisInstance.h

[Go to the documentation of this file.](#)

```
1
19 #ifndef ARM_INCLUDE_IrisInstance_h
20 #define ARM_INCLUDE_IrisInstance_h
21
22 #include "iris/detail/IrisCommon.h"
23 #include "iris/detail/IrisCppAdapter.h"
24 #include "iris/detail/IrisDelegate.h"
25 #include "iris/detail/IrisFunctionDecoder.h"
26 #include "iris/detail/IrisObjects.h"
27 #include "iris/IrisInstanceEvent.h"
28
29 #include <cassert>
30 #include <mutex>
31 #include <functional>
32
33 namespace IRIS_START
34 {
35     typedef IrisDelegate<uint64_t, const IrisValueMap&, uint64_t, uint64_t, bool, std::string&>
36         EventCallbackDelegate;
37     typedef IrisDelegate<const EventBufferCallbackData&> EventBufferCallbackDelegate;
38
39     class IrisInstantiationContext;
40     class IrisInstanceBuilder;
41
42     class IrisInstance
43     {
44     public:
45         // --- Construction and destruction. ---
46
47         #define irisRegisterFunction(instancePtr, instanceType, functionName, functionInfoJson)
48             registerFunction(instancePtr, #functionName, &instanceType::impl_##functionName, functionInfoJson,
49                             #instanceType)
50
51         #define irisRegisterEventCallback(instancePtr, instanceType, functionName, description)
52             registerEventCallback<instanceType, &instanceType::impl_##functionName>(instancePtr, #functionName,
53             description, #instanceType)
54
55         #define irisRegisterEventBufferCallback(instancePtr, instanceType, functionName, description)
56             registerEventBufferCallback<instanceType, &instanceType::impl_##functionName>(instancePtr,
57             #functionName, description, #instanceType)
58
59         static const uint64_t UNQUIFY = (1 << 0);
60
61         static const uint64_t THROW_ON_ERROR = (1 << 1);
62
63         static const uint64_t DEFAULT_FLAGS = THROW_ON_ERROR;
64
65         IrisInstance(IrisConnectionInterface* connection_interface = nullptr,
66                     const std::string& instName = std::string(),
67                     uint64_t flags = DEFAULT_FLAGS);
68
69         IrisInstance(IrisInstantiationContext* context);
70
71         ~IrisInstance();
72     };
73 }
```



```

140
148 void setConnectionInterface(IrisConnectionInterface* connection_interface);
149
154 void processAsyncRequests();
155
161 IrisInterface* getRemoteIrisInterface()
162 {
163     return remoteIrisInterface;
164 }
165
176 void setThrowOnError(bool throw_on_error)
177 {
178     default_cppAdapter = throw_on_error ? &throw_cppAdapter : &nothrow_cppAdapter;
179 }
180
194 IrisErrorCode registerInstance(const std::string& instName, uint64_t flags = DEFAULT_FLAGS);
195
201 IrisErrorCode unregisterInstance();
202
221 template <class T>
222 void setProperty(const std::string& propertyName, const T& propertyValue)
223 {
224     propertyMap[propertyName].set(propertyValue);
225 }
226
233 const PropertyMap& getPropertyMap() const
234 {
235     return propertyMap;
236 }
237
238 // --- Interface for components. Provide functionality to clients. ---
239
252 template <class T>
253 void registerFunction(T* instance, const std::string& name, void
(T::*memberFunctionPtr)(IrisReceivedRequest&), const std::string& functionInfoJson, const
std::string& instanceTypeStr)
254 {
255     functionDecoder.registerFunction(instance, name, memberFunctionPtr, functionInfoJson,
instanceTypeStr);
256 }
257
261 void unregisterFunction(const std::string& name)
262 {
263     functionDecoder.unregisterFunction(name);
264 }
265
277 template <class T>
278 void registerEventCallback(T* instance, const std::string& name, const std::string& description,
279 void (T::*memberFunctionPtr)(IrisReceivedRequest&),
280 const std::string& instanceTypeStr)
281 {
282     std::string funcInfoJson = "{description:'" + description +
283     "','"
284     "args:{"
285     "  instId:{type:'NumberU64', description:'Target instance id.'},"
286     "  esId:{type:'NumberU64', description:'Event stream id.'},"
287     "  fields:{type:'Object', description:'Object which contains the names and values of event
source fields.'},"
288     "  time:{type:'NumberU64', description:'Simulation time timestamp of the event.'},"
289     "  sInstId:{type:'NumberU64', description:'Source instId: Instance which generated and sent
this event.'},"
290     "  syncEc:{type:'Boolean', description:'Synchronous callback behaviour.', optional:true},"
291     "},"
292     "retval:{type:'Null'}}";
293     functionDecoder.registerFunction(instance, name, memberFunctionPtr, funcInfoJson,
instanceTypeStr);
294 }
295
304 void registerEventCallback(EventCallbackDelegate delegate, const std::string& name,
305 const std::string& description, const std::string& dlgInstanceTypeStr)
306 {
307     eventCallbacks[name] = ECD(delegate);
308     registerEventCallback(this, name, description, &IrisInstance::impl_eventCallback,
dlgInstanceTypeStr);
309 }
310
319 template <typename T, IrisErrorCode (T::*METHOD)(uint64_t, const AttributeValueMap&, uint64_t,
uint64_t, bool, std::string&)>
320 void registerEventCallback(T* instance, const std::string& name, const std::string& description,
321 const std::string& dlgInstanceTypeStr)
322 {
323     registerEventCallback(EventCallbackDelegate::make<T, METHOD>(instance),
324 name, description, dlgInstanceTypeStr);
325 }
326
338 template <class T>
339 void registerEventBufferCallback(T* instance, const std::string& name, const std::string&

```

```

description,
340         void (T::*memberFunctionPtr) (IrisReceivedRequest&),
341         const std::string& instanceTypeStr)
342     {
343         std::string funcInfoJson = "{description:'" + description + "',"
344             "args:{"
345             "    instId:{type:'NumberU64', description:'Target instance id.'},"
346             "    sInstId:{type:'NumberU64', description:'Source instId: Instance which generated and sent
this event buffer data.'},"
347             "    evBufId:{type:'NumberU64', description:'Event buffer id.'},"
348             "    events:{type:'EventData[]', description:'Array of EventData objects which represent the
individual events in chronological order.'}"
349             "},"
350             "retval:{type:'Null'}}";
351         functionDecoder.registerFunction(instance, name, memberFunctionPtr, funcInfoJson,
instanceTypeStr);
352     }
353
354     void registerEventBufferCallback(EventBufferCallbackDelegate delegate, const std::string& name,
355         const std::string& description, const std::string&
356         dlgInstanceTypeStr)
357     {
358         eventBufferCallbacks[name] = EBCD(delegate);
359         registerEventBufferCallback(this, name, description, &IrisInstance::impl_eventBufferCallback,
360         dlgInstanceTypeStr);
361     }
362
363     template <typename T, IrisErrorCode (T::*METHOD) (const EventBufferCallbackData& data)>
364     void registerEventBufferCallback(T* instance, const std::string& name, const std::string&
365     description,
366         const std::string& dlgInstanceTypeStr)
367     {
368         registerEventBufferCallback(EventBufferCallbackDelegate::make<T, METHOD>(instance),
369             name, description, dlgInstanceTypeStr);
370     }
371
372     void unregisterEventCallback(const std::string& name);
373
374     void unregisterEventBufferCallback(const std::string& name);
375
376     using EventCallbackFunction = std::function<IrisErrorCode(EventStreamId, const IrisValueMap&,
377         uint64_t, InstanceId, bool, std::string&>;
378
379     void setCallback_IRIS_SIMULATION_TIME_EVENT(EventCallbackFunction f);
380
381     void setCallback_IRIS_SHUTDOWN_LEAVE(EventCallbackFunction f);
382
383     void addCallback_IRIS_INSTANCE_REGISTRY_CHANGED(EventCallbackFunction f);
384
385     void sendResponse(const uint64_t* response)
386     {
387         remoteIrisInterface->irisHandleMessage(response);
388     }
389
390     // --- Interface for clients. Access to other components. ---
391
392     IrisCppAdapter& irisCall() { return *default_cppAdapter; }
393
394     IrisCppAdapter& irisCallNoThrow() { return nothrow_cppAdapter; }
395
396     IrisCppAdapter& irisCallThrow() { return throw_cppAdapter; }
397
398     bool sendRequest(IrisRequest& req)
399     {
400         return irisCall().callAndPerhapsWaitForResponse(req);
401     }
402
403     // --- Misc functionality. ---
404
405     IrisInterface* getLocalIrisInterface() { return functionDecoder.getIrisInterface(); }
406
407     InstanceId getInstId() const { return thisInstanceInfo.instId; }
408
409     void setInstId(InstanceId instId) { thisInstanceInfo.instId = instId;
410     cppAdapter_request_manager.setInstId(instId); }
411
412     const std::string& getInstanceName() const { return thisInstanceInfo.instName; }
413
414     bool isRegistered() const { return cppAdapter_request_manager.isRegistered(); }
415
416     IrisInstanceBuilder* getBuilder();
417
418     bool isAdapterInitialized() const { return is_adapter_initialized; }
419
420     void setAdapterInitialized() { is_adapter_initialized = true; }
421
422     void setEventHandler(IrisInstanceEvent* handler);

```

```

540
551     void notifyStateChanged();
552
553     template<class T>
554     void publishCppInterface(const std::string& interfaceName, T *pointer, const std::string&
555                             jsonDescription)
556     {
557         // Ignore null pointers: instance_getCppInterface...() promises to always return non-null
558         // pointers.
559         // (If there is no interface, do not publish it.)
560         if (pointer == nullptr)
561             return;
562
563         std::string functionInfoJson =
564             "{"
565             "    \"description\": \"" + jsonDescription + "\"\n"
566             "    \"If this function is present it always returns a non-null pointer.\\n\"
567             \"The caller of this function must make sure that the caller and callee use the same C++
568             interface class layout and run in the same process. \"
569             \"This effectively means that they both must be compiled using the same compiler using the
570             same header files. \"
571             \"The returned pointer is only meaningful if caller and callee run in the same process.\\n\"
572             \"The meta-information provided alongside the returned pointer in CppInterfacePointer can
573             (and should) be used to do minimal compatibility checking between caller and callee, see
574             'CppInterfacePointer::isCompatibleWith()' in 'IrisObjects.h'.\\n\", \"
575             \"    \\\"args\\\": {\"
576             \"        \\\"instId\\\": {\"
577             \"            \\\"description\\\": \\\"Opaque number uniquely identifying the target instance.\\\", \"
578             \"            \\\"type\\\": \\\"NumberU64\\\"\"
579             \"        }\"
580             \"    }, \"
581             \"    \\\"errors\\\": {\"
582             \"        \\\"E_unknown_instance_id\\\"\"
583             \"    }, \"
584             \"    \\\"retval\\\": {\"
585             \"        \\\"description\\\": \\\"Pointer to the requested C++ interface (and associated
586             meta-information) of this instance. Use 'CppInterfacePointer::isCompatibleWith()' to do a minimal
587             compatibility check before using the pointer.\\\", \"
588             \"        \\\"type\\\": \\\"CppInterfacePointer\\\"\"
589             \"    }\"
590             \"}\";
591
592         registerFunction(this, \"instance_getCppInterface\" + interfaceName,
593             &IrisInstance::impl_instance_getCppInterface, functionInfoJson, \"IrisInstance\");
594         cppInterfaceRegistry[interfaceName].set(pointer);
595     }
596
597     void unpublishCppInterface(const std::string& interfaceName)
598     {
599         unregisterFunction(\"instance_getCppInterface\" + interfaceName);
600         cppInterfaceRegistry.erase(interfaceName);
601     }
602
603     // --- Blocking simulation time functions ---
604
605     void simulationTimeRun();
606
607     void simulationTimeStop();
608
609     void simulationTimeRunUntilStop(double timeoutInSeconds = 0.0);
610
611     bool simulationTimeWaitForStop(double timeoutInSeconds = 0.0);
612
613     bool simulationTimeIsRunning();
614
615     void simulationTimeDisableEvents();
616
617     void setPendingSyncStepResponse(RequestId requestId, EventBufferId evBufId);
618
619     bool isValidEvBufId(EventBufferId evBufId) const;
620
621     std::vector<EventStreamInfo> findEventSourcesAndFields(const std::string& spec, InstanceId
622     defaultInstId = IRIS_UINT64_MAX);
623
624     void findEventSourcesAndFields(const std::string& spec, std::vector<EventStreamInfo>&
625     eventStreamInfosOut, InstanceId defaultInstId = IRIS_UINT64_MAX);
626
627
628     void enableEvent(const std::string& eventSpec, std::function<void (const EventStreamInfo&
629     eventStreamInfo, IrisReceivedRequest& request)> callback);
630
631     void enableEvent(const std::string& eventSpec, std::function<void ()> callback);
632
633     void disableEvent(const std::string& eventSpec);
634
635     std::vector<InstanceInfo> findInstanceInfos(const std::string& instancePathFilter = \"all\");
636
637     std::vector<EventSourceInfo> findEventSources(const std::string& instancePathFilter = \"all\");
638

```

```

843     const InstanceInfo& getInstanceInfo(InstanceId instId);
844
845     InstanceInfo getInstanceInfo(const std::string& instancePathFilter);
846
847     const std::vector<InstanceInfo>& getInstanceList();
848
849     std::string getInstanceName(InstanceId instId);
850
851     InstanceId getInstanceId(const std::string& instName);
852
853     ResourceId getResourceId(InstanceId instId, const std::string& resourceSpec);
854
855     uint64_t resourceRead(InstanceId instId, const std::string& resourceSpec);
856
857     uint64_t resourceReadCrn(InstanceId instId, uint64_t canonicalRegisterNumber)
858     {
859         return resourceRead(instId, "crn:" + std::to_string(canonicalRegisterNumber));
860     }
861
862     std::string resourceReadStr(InstanceId instId, const std::string& resourceSpec);
863
864     void resourceWrite(InstanceId instId, const std::string& resourceSpec, uint64_t value);
865
866     void resourceWriteCrn(InstanceId instId, uint64_t canonicalRegisterNumber, uint64_t value)
867     {
868         resourceWrite(instId, "crn:" + std::to_string(canonicalRegisterNumber), value);
869     }
870
871     void resourceWriteStr(InstanceId instId, const std::string& resourceSpec, const std::string& value);
872
873     const std::vector<ResourceGroupInfo>& getResourceGroups(InstanceId instId);
874
875     const ResourceInfo& getResourceInfo(InstanceId instId, ResourceId resourceId);
876
877     const ResourceInfo& getResourceInfo(InstanceId instId, const std::string& resourceSpec);
878
879     const std::vector<ResourceInfo>& getResourceInfos(InstanceId instId);
880
881     MemorySpaceId getMemorySpaceId(InstanceId instId, uint64_t canonicalMsn);
882
883     MemorySpaceId getMemorySpaceId(InstanceId instId, const std::string& name);
884
885     const MemorySpaceInfo& getMemorySpaceInfo(InstanceId instId, uint64_t canonicalMsn);
886
887     const MemorySpaceInfo& getMemorySpaceInfo(InstanceId instId, const std::string& name);
888
889     const std::vector<MemorySpaceInfo>& getMemorySpaceInfos(InstanceId instId);
890
891     void clearCachedMetaInfo();
892
893 private:
894     void init(IrisConnectionInterface* connection_interface_ = nullptr,
895              const std::string& instName = std::string(),
896              uint64_t flags = DEFAULT_FLAGS);
897
898     struct InstanceMetaInfo
899     {
900         std::map<std::string, ResourceId> resourceSpecToResourceIdAll;
901         std::map<std::string, ResourceId> resourceSpecToResourceIdUsed;
902         std::vector<ResourceGroupInfo> groupInfos;
903         std::vector<ResourceInfo> resourceInfos;
904         std::map<ResourceId, uint64_t> resourceIdToIndex;
905         std::vector<MemorySpaceInfo> memorySpaceInfos;
906     };
907
908     InstanceMetaInfo& getInstanceMetaInfo(InstanceId instId);
909
910     IrisInstance::InstanceMetaInfo& getResourceMetaInfo(InstanceId instId);
911
912     IrisInstance::InstanceMetaInfo& getMemoryMetaInfo(InstanceId instId);
913
914     void expandWildcardsInEventStreamInfos(std::vector<EventStreamInfo>& eventStreamInfosInOut,
915     InstanceId defaultInstId = IRIS_UINT64_MAX, const std::string& instancePathFilter = "all");
916
917     void enableSimulationTimeEvents();
918
919     void enableShutdownLeaveEvents();
920
921     void enableInstanceRegistryChangedEvent();
922
923     void simulationTimeWaitForRunning();

```

```

1114     void simulationTimeClearGotRunning();
1115
1119     std::string lookupInstanceNameLocal(InstanceId instId);
1120
1121     // --- Iris function implementations ---
1122     void impl_instance_getProperties(IrisReceivedRequest& request);
1123
1124     void impl_instance_ping(IrisReceivedRequest& request);
1125
1126     void impl_instance_ping2(IrisReceivedRequest& request);
1127
1128     void impl_instance_getCppInterface(IrisReceivedRequest& request);
1129
1131     void impl_eventCallback(IrisReceivedRequest& request);
1132
1134     void impl_eventBufferCallback(IrisReceivedRequest& request);
1135
1137     void impl_enableEventCallback(IrisReceivedRequest &request);
1138
1140     IrisErrorCode impl_ec_IrisInstance_IRIS_SIMULATION_TIME_EVENT(EventStreamId esId, const
IrisValueMap& fields, uint64_t time,
1141                                                                    InstanceId sInstId, bool syncEc,
std::string& errorMessageOut);
1142
1144     IrisErrorCode impl_ec_IrisInstance_IRIS_SHUTDOWN_LEAVE(EventStreamId esId, const IrisValueMap&
fields, uint64_t time,
1145                                                                    InstanceId sInstId, bool syncEc,
std::string& errorMessageOut);
1146
1148     IrisErrorCode impl_ec_IrisInstance_IRIS_INSTANCE_REGISTRY_CHANGED(EventStreamId esId, const
IrisValueMap& fields, uint64_t time,
1149                                                                    InstanceId sInstId, bool syncEc,
std::string& errorMessageOut);
1150
1151     // --- Iris specific data and state ---
1152
1154     IrisFunctionDecoder functionDecoder{log, this};
1155
1157     IrisCppAdapter::RequestManager cppAdapter_request_manager{log};
1158
1160     IrisCppAdapter throw_cppAdapter{&cppAdapter_request_manager, /*throw_on_error=*/true};
1161
1163     IrisCppAdapter nothrow_cppAdapter{&cppAdapter_request_manager, /*throw_on_error=*/false};
1164
1166     IrisCppAdapter* default_cppAdapter{&throw_cppAdapter};
1167
1171     IrisConnectionInterface* connection_interface{nullptr};
1172
1175     IrisInterface* remoteIrisInterface{nullptr};
1176
1177 protected:
1179     InstanceInfo thisInstanceInfo{};
1180
1181 private:
1183     bool instance_getProperties_called{false};
1184
1185     bool registered{false};
1186
1187     bool is_adapter_initialized{false};
1188
1189     uint64_t channelId{IRIS_UINT64_MAX};
1190
1192     IrisLogger log;
1193
1194     // --- Instance specific data and state ---
1195
1197     PropertyMap propertyMap{};
1198
1200     struct ECD
1201     {
1202         // Work around symbol length limits in Visual Studio (warning C4503)
1203         EventCallbackDelegate dlg;
1204         ECD() {}
1205         ECD(EventCallbackDelegate dlg_)
1206             : dlg(dlg_)
1207         {
1208         }
1209     };
1210     typedef std::map<std::string, ECD> EventCallbackMap;
1211     EventCallbackMap eventCallbacks{};
1212
1214     struct EBCD
1215     {
1216         // Work around symbol length limits in Visual Studio (warning C4503)
1217         EventBufferCallbackDelegate dlg;
1218         EBCD() {}
1219         EBCD(EventBufferCallbackDelegate dlg_)

```

```

1220         : dlg(dlg_)
1221     {
1222     }
1223 };
1224 typedef std::map<std::string, EBCD> EventBufferCallbackMap;
1225 EventBufferCallbackMap eventBufferCallbacks{};
1226
1227 struct EnableEventCallbackInfo
1228 {
1229     EnableEventCallbackInfo() = default;
1230     EnableEventCallbackInfo(const EventStreamInfo& eventStreamInfo_, std::function<void (const
1231 EventStreamInfo& eventStreamInfo, IrisReceivedRequest& request)> callback_):
1232         eventStreamInfo(eventStreamInfo_),
1233         callback(callback_)
1234     {
1235     }
1236
1237     EventStreamInfo eventStreamInfo;
1238     std::function<void (const EventStreamInfo& eventStreamInfo, IrisReceivedRequest& request)>
1239 callback;
1240 };
1241 typedef std::map<std::string, EnableEventCallbackInfo> EnableEventCallbackMap;
1242 EnableEventCallbackMap enableEventCallbacks;
1243
1244 IrisInstanceBuilder* builder(nullptr);
1245
1246 IrisInstanceEvent *irisInstanceEvent{};
1247
1248 typedef std::map<std::string, CppInterfacePointer> CppInterfaceRegistryMap;
1249 CppInterfaceRegistryMap cppInterfaceRegistry{};
1250
1251 bool simulationTimeIsRunning_{};
1252
1253 bool simulationTimeGotRunningTrue{};
1254
1255 bool simulationTimeGotRunningFalse{};
1256
1257 std::mutex simulationTimeIsRunningMutex;
1258
1259 std::condition_variable simulationTimeIsRunningChanged;
1260
1261 EventStreamId simulationTimeEsId = IRIS_UINT64_MAX;
1262
1263 EventStreamId shutdownLeaveEsId = IRIS_UINT64_MAX;
1264
1265 EventStreamId instanceRegistryChangedEsId = IRIS_UINT64_MAX;
1266
1267 EventCallbackFunction simulationTimeCallbackFunction;
1268
1269 EventCallbackFunction shutdownLeaveCallbackFunction;
1270
1271 // List of callback functions for IRIS_INSTANCE_REGISTRY_CHANGED.
1272 std::vector<EventCallbackFunction> instanceRegistryChangedFunctions;
1273
1274 struct PendingSyncStepResponse
1275 {
1276     void set(RequestId requestId_, EventBufferId evBufId_)
1277     {
1278         requestId = requestId_;
1279         evBufId = evBufId_;
1280     }
1281
1282     bool isPending() const
1283     {
1284         return requestId != IRIS_UINT64_MAX;
1285     }
1286
1287     void clear()
1288     {
1289         requestId = IRIS_UINT64_MAX;
1290         evBufId = 0;
1291     }
1292
1293     RequestId requestId{IRIS_UINT64_MAX};
1294
1295     EventBufferId evBufId{};
1296 };
1297 PendingSyncStepResponse pendingSyncStepResponse;
1298
1299 std::vector<InstanceInfo> instanceInfos;
1300
1301 std::vector<uint64_t> instIdToIndex;
1302
1303 std::map<InstanceId, InstanceMetaInfo> instIdToMetaInfo;
1304
1305 bool globalInstanceHasNotifyStateChangedChecked{};

```

```

1335
1338     bool globalInstanceHasNotifyStateChanged{};
1339 };
1340
1341
1342 NAMESPACE_IRIS_END
1343
1344 #endif // #ifndef ARM_INCLUDE_IrisInstance_h
1345
1346 // Convenience #include.
1347 // (IrisInstanceBuilder needs the complete type of IrisInstance.)
1348 #include "iris/IrisInstanceBuilder.h"
1349

```

## 9.17 IrisInstanceBreakpoint.h File Reference

Breakpoint add-on to IrisInstance.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include <cstdio>

```

### Classes

- struct [iris::BreakpointHitInfo](#)
- class [iris::IrisInstanceBreakpoint](#)  
Breakpoint add-on for [IrisInstance](#).

### Typedefs

- typedef [IrisDelegate](#)< const [BreakpointInfo](#) & > [iris::BreakpointDeleteDelegate](#)  
Delete the breakpoint corresponding to the given information.
- typedef [IrisDelegate](#)< [BreakpointInfo](#) & > [iris::BreakpointSetDelegate](#)  
Set a breakpoint corresponding to the given information.
- typedef [IrisDelegate](#)< const [BreakpointHitInfo](#) & > [iris::HandleBreakpointHitDelegate](#)  
Handle a breakpoint hit corresponding to the given information.

### 9.17.1 Detailed Description

Breakpoint add-on to IrisInstance.

#### Copyright

Copyright (C) 2016-2020 Arm Limited. All rights reserved.

The IrisInstanceBreakpoint class:

- Implements all breakpoint-related Iris functions.
- Maintains and provides breakpoint information, for example type, address, and rscl.
- Converts between Iris breakpoint functions (breakpoint\*()) and various C++ access functions.

### 9.17.2 Typedef Documentation

### 9.17.2.1 BreakpointDeleteDelegate

```
typedef IrisDelegate<const BreakpointInfo&> iris::BreakpointDeleteDelegate
```

Delete the breakpoint corresponding to the given information.

```
IrisErrorCode deleteBpt(const BreakpointInfo &bptInfo)
```

The breakpoint is guaranteed to exist and to be valid.

Error: Return E\_\* error code if it failed to delete the breakpoint.

### 9.17.2.2 BreakpointSetDelegate

```
typedef IrisDelegate<BreakpointInfo&> iris::BreakpointSetDelegate
```

Set a breakpoint corresponding to the given information.

```
IrisErrorCode setBpt(BreakpointInfo &bptInfo)
```

The breakpoint information members are guaranteed to be valid. The BreakpointInfo is non-const as the metadata might need to be modified. For example, in some cases it might be useful to align the address and fix the size of a data breakpoint. It should never modify the bptId, which is uniquely set by this add-on.

Error: Return E\_\* error code if it failed to set the breakpoint.

### 9.17.2.3 HandleBreakpointHitDelegate

```
typedef IrisDelegate<const BreakpointHitInfo&> iris::HandleBreakpointHitDelegate
```

Handle a breakpoint hit corresponding to the given information.

```
IrisErrorCode handleBreakpointHit(const BreakpointHitInfo &bptInfo)
```

The breakpoint is guaranteed to exist and to be valid.

Error: Return E\_\* error code if there is some error in handling the breakpoint.

## 9.18 IrisInstanceBreakpoint.h

[Go to the documentation of this file.](#)

```
1
12 #ifndef ARM_INCLUDE_IrisInstanceBreakpoint_h
13 #define ARM_INCLUDE_IrisInstanceBreakpoint_h
14
15 #include "iris/detail/IrisCommon.h"
16 #include "iris/detail/IrisDelegate.h"
17 #include "iris/detail/IrisLogger.h"
18 #include "iris/detail/IrisObjects.h"
19
20 #include <cstdio>
21
22 namespace IRIS_START
23 {
24     class IrisInstance;
25     class IrisInstanceEvent;
26     class IrisEventRegistry;
27     class IrisReceivedRequest;
28
29     class EventStream;
30     struct EventSourceInfo;
31
32     struct BreakpointHitInfo
33     {
34         //Required for all breakpoint types
35         const BreakpointInfo& bptInfo;
36
37         //Register and memory breakpoint
38         const std::vector<uint64_t>& accessData;
39         bool isReadAccess;
40     };
41
42     typedef IrisDelegate<BreakpointInfo&> BreakpointSetDelegate;
43
44     typedef IrisDelegate<const BreakpointInfo&> BreakpointDeleteDelegate;
45
46     typedef IrisDelegate<const BreakpointHitInfo&> HandleBreakpointHitDelegate;
47
48     class IrisInstanceBreakpoint
49     {
50     public:
51         // --- Construction and destruction. ---
52         IrisInstanceBreakpoint(IrisInstance* irisInstance = nullptr);
53         ~IrisInstanceBreakpoint();
54
55         void attachTo(IrisInstance* irisInstance);
56     };
57 }
```



```

117
123     void setBreakpointSetDelegate(BreakpointSetDelegate delegate);
124
130     void setBreakpointDeleteDelegate(BreakpointDeleteDelegate delegate);
131
137     void setHandleBreakpointHitDelegate(HandleBreakpointHitDelegate delegate);
138
144     void setEventHandler(IrisInstanceEvent* handler);
145
157     void notifyBreakpointHit(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId pcSpaceId);
158
176     void notifyBreakpointHitData(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId
pcSpaceId,
177                                     uint64_t accessAddr, uint64_t accessSize,
178                                     const std::string& accessRw, const std::vector<uint64_t>& data);
179
195     void notifyBreakpointHitRegister(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId
pcSpaceId,
196                                     const std::string& accessRw, const std::vector<uint64_t>& data);
197
205     const BreakpointInfo* getBreakpointInfo(BreakpointId bptId) const;
206
216     void addCondition(const std::string& name, const std::string& type, const std::string& description,
217                     const std::vector<std::string> bpt_types = std::vector<std::string>());
218
225     void handleBreakpointHit(const BreakpointHitInfo& bptHitInfo);
226
227 private:
228     void impl_breakpoint_set(IrisReceivedRequest& request);
229
230     void impl_breakpoint_delete(IrisReceivedRequest& request);
231
232     void impl_breakpoint_getList(IrisReceivedRequest& request);
233
234     void impl_breakpoint_getAdditionalConditions(IrisReceivedRequest& request);
235
236     bool validateInterceptionParameters(IrisReceivedRequest& request, const InterceptionParams&
interceptionParams);
237
240     bool beginBreakpointHit(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId pcSpaceId);
241
243     IrisErrorCode createEventStream(EventStream*&, const EventSourceInfo&, const
std::vector<std::string>&);
244
246     IrisErrorCode deleteBreakpoint(BreakpointId bpt);
247
248     void register_ec_IRIS_INSTANCE_REGISTRY_CHANGED();
249     IrisErrorCode ec_IRIS_INSTANCE_REGISTRY_CHANGED(EventStreamId esId, const IrisValueMap& fields,
uint64_t time,
250                                                     InstanceId sInstId, bool syncEc, std::string&
errorMessageOut);
251
253
255     IrisInstance* irisInstance;
256
258     IrisEventRegistry* breakpoint_hit_registry;
259
262     std::vector<BreakpointInfo> bptInfos;
263
266     std::vector<uint64_t> freeBptIds;
267
269     std::map<uint64_t, BreakpointAction> bptActions;
270
272     std::vector<BreakpointConditionInfo> additional_conditions;
273
275     BreakpointSetDelegate bptSetDelegate;
276
278     BreakpointDeleteDelegate bptDeleteDelegate;
279
281     HandleBreakpointHitDelegate handleBreakpointHitDelegate;
282
284     IrisLogger log;
285
290     bool instance_registry_changed_registered{};
291 };
292
293 NAMESPACE_IRIS_END
294
295 #endif // #ifndef ARM_INCLUDE_IrisInstanceBreakpoint_h

```

## 9.19 IrisInstanceBuilder.h File Reference

A high level interface to build up functionality on an IrisInstance.

```
#include "iris/IrisEventEmitter.h"
#include "iris/IrisInstance.h"
#include "iris/IrisInstanceBreakpoint.h"
#include "iris/IrisInstanceDebuggableState.h"
#include "iris/IrisInstanceDisassembler.h"
#include "iris/IrisInstanceEvent.h"
#include "iris/IrisInstanceImage.h"
#include "iris/IrisInstanceMemory.h"
#include "iris/IrisInstancePerInstanceExecution.h"
#include "iris/IrisInstanceResource.h"
#include "iris/IrisInstanceSemihosting.h"
#include "iris/IrisInstanceCheckpoint.h"
#include "iris/IrisInstanceStep.h"
#include "iris/IrisInstanceTable.h"
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisElfDwarf.h"
#include <cassert>
```

## Classes

- class [iris::IrisInstanceBuilder::AddressTranslationBuilder](#)  
*Used to set metadata for an address translation.*
- class [iris::IrisInstanceBuilder::EventSourceBuilder](#)  
*Used to set metadata on an EventSource.*
- class [iris::IrisInstanceBuilder::FieldBuilder](#)  
*Used to set metadata on a register field resource.*
- class [iris::IrisInstanceBuilder](#)  
*Builder interface to populate an [IrisInstance](#) with registers, memory etc.*
- class [iris::IrisInstanceBuilder::MemorySpaceBuilder](#)  
*Used to set metadata for a memory space.*
- class [iris::IrisInstanceBuilder::ParameterBuilder](#)  
*Used to set metadata on a parameter.*
- class [iris::IrisInstanceBuilder::RegisterBuilder](#)  
*Used to set metadata on a register resource.*
- class [iris::IrisInstanceBuilder::SemihostingManager](#)  
*semihosting\_apis [IrisInstanceBuilder](#) semihosting APIs*
- class [iris::IrisInstanceBuilder::TableBuilder](#)  
*Used to set metadata for a table.*
- class [iris::IrisInstanceBuilder::TableColumnBuilder](#)  
*Used to set metadata for a table column.*

### 9.19.1 Detailed Description

A high level interface to build up functionality on an [IrisInstance](#).

Copyright

Copyright (C) 2016-2019 Arm Limited. All rights reserved.

## 9.20 IrisInstanceBuilder.h

[Go to the documentation of this file.](#)

```
1
8 #ifndef ARM_INCLUDE_IrisInstanceBuilder_h
9 #define ARM_INCLUDE_IrisInstanceBuilder_h
10
```

```

11 #include "iris/IrisEventEmitter.h"
12 #include "iris/IrisInstance.h"
13 #include "iris/IrisInstanceBreakpoint.h"
14 #include "iris/IrisInstanceDebuggableState.h"
15 #include "iris/IrisInstanceDisassembler.h"
16 #include "iris/IrisInstanceEvent.h"
17 #include "iris/IrisInstanceImage.h"
18 #include "iris/IrisInstanceMemory.h"
19 #include "iris/IrisInstancePerInstanceExecution.h"
20 #include "iris/IrisInstanceResource.h"
21 #include "iris/IrisInstanceSemihosting.h"
22 #include "iris/IrisInstanceCheckpoint.h"
23 #include "iris/IrisInstanceStep.h"
24 #include "iris/IrisInstanceTable.h"
25 #include "iris/detail/IrisCommon.h"
26 #include "iris/detail/IrisElfDwarf.h"
27
28 #include <cassert>
29
30 namespace IRIS_START
31 {
32     class IrisRegisterEventEmitterBase;
33
34     class IrisInstanceBuilder
35     {
36     private:
37         template <typename T, T* (IrisInstanceBuilder::*INIT_METHOD) ()>
38         class LazyAddOn
39         {
40         private:
41             IrisInstanceBuilder* parent;
42             T* add_on;
43
44         public:
45             LazyAddOn(IrisInstanceBuilder* parent_)
46                 : parent(parent_)
47                 , add_on(nullptr)
48             {
49             }
50
51             ~LazyAddOn()
52             {
53                 delete add_on;
54             }
55
56             T* operator->()
57             {
58                 if (add_on == nullptr)
59                 {
60                     init();
61                 }
62
63                 return add_on;
64             }
65
66             operator T*()
67             {
68                 if (add_on == nullptr)
69                 {
70                     init();
71                 }
72
73                 return add_on;
74             }
75
76             T* getPtr()
77             {
78                 return add_on;
79             }
80
81             void init()
82             {
83                 assert(add_on == nullptr);
84                 add_on = (parent->*INIT_METHOD)();
85             }
86         };
87
88         IrisInstance* iris_instance;
89 #define INTERNAL_LAZY(addon) \
90     addon* init##addon(); \
91     LazyAddOn<addon, &IrisInstanceBuilder::init##addon> \
92     INTERNAL_LAZY(IrisInstanceResource) \
93     inst_resource; \
94     INTERNAL_LAZY(IrisInstanceEvent) \
95     inst_event; \
96     INTERNAL_LAZY(IrisInstanceBreakpoint) \
97     inst_breakpoint; \
98     INTERNAL_LAZY(IrisInstanceMemory)

```

```

109     inst_memory;
110     INTERNAL_LAZY (IrisInstanceImage)
111     inst_image;
112     INTERNAL_LAZY (IrisInstanceImage_Callback)
113     inst_image_cb;
114     INTERNAL_LAZY (IrisInstanceStep)
115     inst_step;
116     INTERNAL_LAZY (IrisInstancePerInstanceExecution)
117     inst_per_inst_exec;
118     INTERNAL_LAZY (IrisInstanceTable)
119     inst_table;
120     INTERNAL_LAZY (IrisInstanceDisassembler)
121     inst_disass;
122     INTERNAL_LAZY (IrisInstanceDebuggableState)
123     inst_dbg_state;
124     INTERNAL_LAZY (IrisInstanceSemihosting)
125     inst_semihost;
126     INTERNAL_LAZY (IrisInstanceCheckpoint)
127     inst_checkpoint;
128 #undef INTERNAL_LAZY
129
130
131
132
133     ResourceReadDelegate default_reg_read_delegate;
134     ResourceWriteDelegate default_reg_write_delegate;
135
136
137     bool canonicalRnSchemeIsAlreadySet{};
138
139
140     struct RegisterEventInfo
141     {
142     {
143         IrisInstanceEvent::EventSourceInfoAndDelegate event_info;
144
145         typedef std::vector<uint64_t> RscIdList;
146         RscIdList rscId_list;
147         IrisRegisterEventEmitterBase* event_emitter;
148
149         RegisterEventInfo()
150             : event_emitter(nullptr)
151         {
152         }
153     };
154
155     std::vector<RegisterEventInfo*> register_read_event_info_list;
156     std::vector<RegisterEventInfo*> register_update_event_info_list;
157
158     RegisterEventInfo* active_register_read_event_info{};
159     RegisterEventInfo* active_register_update_event_info{};
160
161     RegisterEventInfo* find_register_event(const std::vector<RegisterEventInfo*>&
162     register_event_info_list,
163
164         const std::string& name);
165
166     RegisterEventInfo* initRegisterReadEventInfo(const std::string& name);
167     RegisterEventInfo* initRegisterUpdateEventInfo(const std::string& name);
168
169     void finalizeRegisterEvent(RegisterEventInfo* event_info, bool is_read);
170     void associateRegisterWithTraceEvents(ResourceId rscId);
171
172
173     IrisErrorCode setBreakpoint(BreakpointInfo& info);
174     IrisErrorCode deleteBreakpoint(const BreakpointInfo& info);
175
176     struct RegisterEventEmitterPair
177     {
178     {
179         IrisRegisterEventEmitterBase* read;
180         IrisRegisterEventEmitterBase* update;
181
182         RegisterEventEmitterPair()
183             : read(nullptr)
184             , update(nullptr)
185         {
186         }
187     };
188
189     typedef std::map<uint64_t, RegisterEventEmitterPair> RscIdEventEmitterMap;
190     RscIdEventEmitterMap register_event_emitter_map;
191
192     BreakpointSetDelegate user_setBreakpoint;
193     BreakpointDeleteDelegate user_deleteBreakpoint;
194
195 public:
196     IrisInstanceBuilder(IrisInstance* iris_instance);
197
198     /* No destructor: IrisInstanceBuilder objects live as long as the instance
199     * they belong to. Do not key anything to the destructor.
200     */
201
202

```

```

218 #define INTERNAL_RESOURCE_BUILDER_MIXIN(TYPE)
219
220
221
222     TYPE& setName(const std::string& name)
223     {
224         info->resourceInfo.name = name;
225         return *this;
226     }
227
228
229
230     TYPE& setCname(const std::string& cname)
231     {
232         info->resourceInfo.cname = cname;
233         return *this;
234     }
235
236
237
238     TYPE& setDescription(const std::string& description)
239     {
240         info->resourceInfo.description = description;
241         return *this;
242     }
243
244     /* [[deprecated("Inconsistently named function. Use setDescription() instead.")] ] */
245     TYPE& setDescr(const std::string& description)
246     {
247         return setDescription(description);
248     }
249
250
251
252     TYPE& setFormat(const std::string& format)
253     {
254         info->resourceInfo.format = format;
255         return *this;
256     }
257
258
259
260     TYPE& setBitWidth(uint64_t bitWidth)
261     {
262         info->resourceInfo.bitWidth = bitWidth;
263         return *this;
264     }
265
266
267
268     TYPE& setType(const std::string& type)
269     {
270         info->resourceInfo.type = type;

```

```

271         return *this;
272     }
273
274     \
275     \
276     TYPE& setRwMode(const std::string& rwMode)
277     {
278         \
279         info->resourceInfo.rwMode = rwMode;
280         return *this;
281     }
282
283     \
284     TYPE& setSubRscId(uint64_t subRscId)
285     {
286         \
287         info->resourceInfo.subRscId = subRscId;
288         return *this;
289     }
290
291     \
292     \
293     \
294     \
295     TYPE& addEnum(const std::string& symbol, const IrisValue& value, const std::string& description =
std::string())
296     {
297         \
298         info->resourceInfo.enums.push_back(EnumElementInfo(value, symbol, description));
299         return *this;
300     }
301
302     \
303     \
304     \
305     TYPE& addStringEnum(const std::string& stringValue, const std::string& description = std::string())
306     {
307         \
308         info->resourceInfo.enums.push_back(EnumElementInfo(IrisValue(stringValue), std::string(),
description));
309         return *this;
310     }
311
312     \
313     TYPE& setTag(const std::string& tag)
314     {
315         \
316         info->resourceInfo.tags[tag] = IrisValue(true);
317         return *this;
318     }
319
320     \
321     \
322     TYPE& setTag(const std::string& tag, const IrisValue& value)
323     {
324         \
325         info->resourceInfo.tags[tag] = value;
326         return *this;
327     }
328
329     \
330     \
331     \
332     \
333     \
334     \
335     \
336     \
337     \
338     \
339     \
340     \
341     \
342     \
343     \
344     \
345     \
346     \
347     \
348     \
349     \
350     \
351     \
352     \
353     \
354     \
355     \
356     \
357     \
358     \
359     \
360     \
361     \
362     \
363     \
364     \
365     \
366     \
367     \
368     \
369     \
370     \
371     \
372     \
373     \
374     \
375     \
376     \
377     \
378     \
379     \
380     \
381     \
382     \
383     \
384     \
385     \
386     \
387     \
388     \
389     \
390     \
391     \
392     \
393     \
394     \
395     \
396     \
397     \
398     \
399     \
400     \
401     \
402     \
403     \
404     \
405     \
406     \
407     \
408     \
409     \
410     \
411     \
412     \
413     \
414     \
415     \
416     \
417     \
418     \
419     \
420     \
421     \
422     \
423     \
424     \
425     \
426     \
427     \
428     \
429     \
430     \
431     \
432     \
433     \
434     \
435     \
436     \
437     \
438     \
439     \
440     \
441     \
442     \
443     \
444     \
445     \
446     \
447     \
448     \
449     \
450     \
451     \
452     \
453     \
454     \
455     \
456     \
457     \
458     \
459     \
460     \
461     \
462     \
463     \
464     \
465     \
466     \
467     \
468     \
469     \
470     \
471     \
472     \
473     \
474     \
475     \
476     \
477     \
478     \
479     \
480     \
481     \
482     \
483     \
484     \
485     \
486     \
487     \
488     \
489     \
490     \
491     \
492     \
493     \
494     \
495     \
496     \
497     \
498     \
499     \
500     \
501     \
502     \
503     \
504     \
505     \
506     \
507     \
508     \
509     \
510     \
511     \
512     \
513     \
514     \
515     \
516     \
517     \
518     \
519     \
520     \
521     \
522     \
523     \
524     \
525     \
526     \
527     \
528     \
529     \
530     \
531     \
532     \
533     \
534     \
535     \
536     \
537     \
538     \
539     \
540     \
541     \
542     \
543     \
544     \
545     \
546     \
547     \
548     \
549     \
550     \
551     \
552     \
553     \
554     \
555     \
556     \
557     \
558     \
559     \
560     \
561     \
562     \
563     \
564     \
565     \
566     \
567     \
568     \
569     \
570     \
571     \
572     \
573     \
574     \
575     \
576     \
577     \
578     \
579     \
580     \
581     \
582     \
583     \
584     \
585     \
586     \
587     \
588     \
589     \
590     \
591     \
592     \
593     \
594     \
595     \
596     \
597     \
598     \
599     \
600     \
601     \
602     \
603     \
604     \
605     \
606     \
607     \
608     \
609     \
610     \
611     \
612     \
613     \
614     \
615     \
616     \
617     \
618     \
619     \
620     \
621     \
622     \
623     \
624     \
625     \
626     \
627     \
628     \
629     \
630     \
631     \
632     \
633     \
634     \
635     \
636     \
637     \
638     \
639     \
640     \
641     \
642     \
643     \
644     \
645     \
646     \
647     \
648     \
649     \
650     \
651     \
652     \
653     \
654     \
655     \
656     \
657     \
658     \
659     \
660     \
661     \
662     \
663     \
664     \
665     \
666     \
667     \
668     \
669     \
670     \
671     \
672     \
673     \
674     \
675     \
676     \
677     \
678     \
679     \
680     \
681     \
682     \
683     \
684     \
685     \
686     \
687     \
688     \
689     \
690     \
691     \
692     \
693     \
694     \
695     \
696     \
697     \
698     \
699     \
700     \
701     \
702     \
703     \
704     \
705     \
706     \
707     \
708     \
709     \
710     \
711     \
712     \
713     \
714     \
715     \
716     \
717     \
718     \
719     \
720     \
721     \
722     \
723     \
724     \
725     \
726     \
727     \
728     \
729     \
730     \
731     \
732     \
733     \
734     \
735     \
736     \
737     \
738     \
739     \
740     \
741     \
742     \
743     \
744     \
745     \
746     \
747     \
748     \
749     \
750     \
751     \
752     \
753     \
754     \
755     \
756     \
757     \
758     \
759     \
760     \
761     \
762     \
763     \
764     \
765     \
766     \
767     \
768     \
769     \
770     \
771     \
772     \
773     \
774     \
775     \
776     \
777     \
778     \
779     \
780     \
781     \
782     \
783     \
784     \
785     \
786     \
787     \
788     \
789     \
790     \
791     \
792     \
793     \
794     \
795     \
796     \
797     \
798     \
799     \
800     \
801     \
802     \
803     \
804     \
805     \
806     \
807     \
808     \
809     \
810     \
811     \
812     \
813     \
814     \
815     \
816     \
817     \
818     \
819     \
820     \
821     \
822     \
823     \
824     \
825     \
826     \
827     \
828     \
829     \
830     \
831     \
832     \
833     \
834     \
835     \
836     \
837     \
838     \
839     \
840     \
841     \
842     \
843     \
844     \
845     \
846     \
847     \
848     \
849     \
850     \
851     \
852     \
853     \
854     \
855     \
856     \
857     \
858     \
859     \
860     \
861     \
862     \
863     \
864     \
865     \
866     \
867     \
868     \
869     \
870     \
871     \
872     \
873     \
874     \
875     \
876     \
877     \
878     \
879     \
880     \
881     \
882     \
883     \
884     \
885     \
886     \
887     \
888     \
889     \
890     \
891     \
892     \
893     \
894     \
895     \
896     \
897     \
898     \
899     \
900     \
901     \
902     \
903     \
904     \
905     \
906     \
907     \
908     \
909     \
910     \
911     \
912     \
913     \
914     \
915     \
916     \
917     \
918     \
919     \
920     \
921     \
922     \
923     \
924     \
925     \
926     \
927     \
928     \
929     \
930     \
931     \
932     \
933     \
934     \
935     \
936     \
937     \
938     \
939     \
940     \
941     \
942     \
943     \
944     \
945     \
946     \
947     \
948     \
949     \
950     \
951     \
952     \
953     \
954     \
955     \
956     \
957     \
958     \
959     \
960     \
961     \
962     \
963     \
964     \
965     \
966     \
967     \
968     \
969     \
970     \
971     \
972     \
973     \
974     \
975     \
976     \
977     \
978     \
979     \
980     \
981     \
982     \
983     \
984     \
985     \
986     \
987     \
988     \
989     \
990     \
991     \
992     \
993     \
994     \
995     \
996     \
997     \
998     \
999     \
1000    \

```

```

327         \
328         \
329         \
330         \
331         \
332     TYPE& setReadDelegate(ResourceReadDelegate readDelegate)
333     {
334         info->readDelegate = readDelegate;
335         return *this;
336     }
337     \
338     \
339     \
340     \
341     \
342     TYPE& setWriteDelegate(ResourceWriteDelegate writeDelegate)
343     {
344         info->writeDelegate = writeDelegate;
345         return *this;
346     }
347     \
348     \
349     \
350     \
351     \
352     \
353     \
354     \
355     template <typename T, IrisErrorCode (T::*METHOD)(const ResourceInfo&, ResourceReadResult&)>
356     TYPE& setReadDelegate(T* instance)
357     {
358         return setReadDelegate(ResourceReadDelegate::make<T, METHOD>(instance));
359     }
360     \
361     \
362     \
363     \
364     \
365     \
366     template <IrisErrorCode (*FUNC)(const ResourceInfo&, ResourceReadResult&)>
367     TYPE& setReadDelegate()
368     {
369         return setReadDelegate(ResourceReadDelegate::make<FUNC>());
370     }
371     \
372     \
373     \
374     \
375     \
376     \
377     \
378     \
379     template <typename T, IrisErrorCode (T::*METHOD)(const ResourceInfo&, const ResourceWriteValue&)>
380     TYPE& setWriteDelegate(T* instance)
381     {
382         return setWriteDelegate(ResourceWriteDelegate::make<T, METHOD>(instance));
383     }
384     \
385     \
386     \
387     \

```

```

388                                     \
389                                     \
390     template <IrisErrorCode (*FUNC)(const ResourceInfo&, const ResourceWriteValue&)>
391         TYPE& setWriteDelegate()
392     {
393         return setWriteDelegate(ResourceWriteDelegate::make<FUNC>());
394     }
395                                     \
396                                     \
397                                     \
398                                     \
399                                     \
400     TYPE& setParentRscId(ResourceId parentRscId)
401     {
402         info->resourceInfo.parentRscId = parentRscId;
403         return *this;
404     }
405                                     \
406                                     \
407     ResourceId getRscId() const
408     {
409         return info->resourceInfo.rscId;
410     }
411                                     \
412                                     \
413                                     \
414                                     \
415     TYPE& getRscId(ResourceId &rscIdOut)
416     {
417         rscIdOut = info->resourceInfo.rscId;
418         return *this;
419     }
420
421 #define INTERNAL_REGISTER_BUILDER_MIXIN(TYPE)
422                                     \
423                                     \
424                                     \
425     TYPE& setLsbOffset(uint64_t lsbOffset)
426     {
427         info->resourceInfo.registerInfo.lsbOffset = lsbOffset;
428         return *this;
429     }
430                                     \
431                                     \
432                                     \
433                                     \
434     TYPE& setCanonicalRn(uint64_t canonicalRn_)
435     {
436         info->resourceInfo.registerInfo.canonicalRn = canonicalRn_;
437         info->resourceInfo.registerInfo.hasCanonicalRn = true;
438         return *this;
439     }
440                                     \
441                                     \
442                                     \
443                                     \
444     TYPE& setCanonicalRnElfDwarf(uint16_t architecture, uint16_t dwarfRegNum)

```



```

445     {
446         if (!instance_builder->canonicalRnSchemeIsAlreadySet) /* Only set property if not already set.
447         */
448         {
449             if (getWithDefault(instance_builder->iris_instance->getPropertyMap(),
450                 "register.canonicalRnScheme", "").getAsString().empty()) \
451             {
452                 instance_builder->setPropertyCanonicalRnScheme("ElfDwarf");
453             }
454             instance_builder->canonicalRnSchemeIsAlreadySet = true;
455         }
456         return setCanonicalRn(makeCanonicalRnElfDwarf(architecture, dwarfRegNum));
457     }
458
459     \
460     \
461     TYPE& setWriteMask(uint64_t value)
462     {
463         info->resourceInfo.setVector(info->resourceInfo.registerInfo.writeMask, value);
464         return *this;
465     }
466
467     \
468     \
469     \
470     \
471     \
472     \
473     \
474     template<typename Container>
475     TYPE& setWriteMaskFromContainer(const Container& container)
476     {
477         info->resourceInfo.setVectorFromContainer(info->resourceInfo.registerInfo.writeMask, container);
478         return *this;
479     }
480
481     \
482     \
483     \
484     \
485     \
486     template<typename T>
487     TYPE& setWriteMask(std::initializer_list<T>&& t)
488     {
489         setWriteMaskFromContainer(std::forward<std::initializer_list<T>>(t));
490         return *this;
491     }
492
493     \
494     \
495     \
496     \
497     TYPE& setResetData(uint64_t value)
498     {
499         info->resourceInfo.setVector(info->resourceInfo.registerInfo.resetData, value);
500     }

```

```

500         return *this;
501     }
502     \
503     \
504     \
505     \
506     \
507     \
508     \
509     \
510     template<typename Container>
511     TYPE& setResetDataFromContainer(const Container& container)
512     {
513         info->resourceInfo.setVectorFromContainer(info->resourceInfo.registerInfo.resetData, container);
514         return *this;
515     }
516     \
517     \
518     \
519     \
520     \
521     \
522     template<typename T>
523     TYPE& setResetData(std::initializer_list<T>&& t)
524     {
525         setResetDataFromContainer(std::forward<std::initializer_list<T>>(t));
526         return *this;
527     }
528     \
529     \
530     \
531     \
532     TYPE& setResetString(const std::string& resetString)
533     {
534         info->resourceInfo.registerInfo.resetString = resetString;
535         return *this;
536     }
537     \
538     \
539     \
540     TYPE& setAddressOffset(uint64_t addressOffset)
541     {
542         info->resourceInfo.registerInfo.addressOffset = addressOffset;
543         info->resourceInfo.registerInfo.hasAddressOffset = true;
544         return *this;
545     }
546
547 #define INTERNAL_PARAMETER_BUILDER_MIXIN(TYPE)
548     \
549     \
550     \
551     \
552     \
553     TYPE& setDefaultData(uint64_t value)
554     {
555         info->resourceInfo.setVector(info->resourceInfo.parameterInfo.defaultData, value);
556         return *this;
557     }

```

```

558     \
559     \
560     \
561     \
562     \
563     \
564     \
565     \
566     template<typename Container>
567     TYPE& setDefaultDataFromContainer(const Container& container)
568     {
569         info->resourceInfo.setVectorFromContainer(info->resourceInfo.parameterInfo.defaultData,
570         container); \
571         return *this;
572     }
573     \
574     \
575     \
576     \
577     \
578     template<typename T>
579     TYPE& setDefaultData(std::initializer_list<T>&& t)
580     {
581         setDefaultDataFromContainer(std::forward<std::initializer_list<T>>(t));
582         return *this;
583     }
584     \
585     \
586     \
587     \
588     TYPE& setDefaultString(const std::string& defaultString)
589     {
590         info->resourceInfo.parameterInfo.defaultString = defaultString;
591         return *this;
592     }
593     \
594     \
595     \
596     \
597     TYPE& setInitOnly(bool initOnly = true)
598     {
599         info->resourceInfo.parameterInfo.initOnly = initOnly;
600         /* Implicitly set read-only to make clear that parameter cannot be modified at run-time. */
601         info->resourceInfo.rwMode = initOnly ? "r" : std::string(); /* =rw */
602         return *this;
603     }
604     \
605     \
606     /* but can still be accessed by resource_getResourceInfo() for clients that know the
607     */ \
608     /* resource name. */
609     \
610     TYPE& setHidden(bool hidden = true)
611     {
612         info->resourceInfo.isHidden = hidden;
613         return *this;
614     }

```

```

614 \
615 \
616 \
617 \
618 \
619 \ TYPE& setMax(uint64_t value)
620 {
621 \ info->resourceInfo.setVector(info->resourceInfo.parameterInfo.max, value);
622 \ return *this;
623 }
624 \
625 \
626 \
627 \
628 \
629 \
630 \
631 \
632 \ template<typename Container>
633 \ TYPE& setMaxFromContainer(const Container& container)
634 {
635 \ info->resourceInfo.setVectorFromContainer(info->resourceInfo.parameterInfo.max, container);
636 \ return *this;
637 }
638 \
639 \
640 \
641 \
642 \
643 \
644 \ template<typename T>
645 \ TYPE& setMax(std::initializer_list<T>&& t)
646 {
647 \ setMaxFromContainer(std::forward<std::initializer_list<T>>(t));
648 \ return *this;
649 }
650 \
651 \
652 \
653 \
654 \ TYPE& setMin(uint64_t value)
655 {
656 \
657 \ info->resourceInfo.setVector(info->resourceInfo.parameterInfo.min, value);
658 \ return *this;
659 }
660 \
661 \
662 \
663 \
664 \
665 \
666 \
667 \
668 \ template<typename Container>
669 \ TYPE& setMinFromContainer(const Container& container)
670 {
671 \ info->resourceInfo.setVectorFromContainer(info->resourceInfo.parameterInfo.min, container);
672 \ return *this;
673 }

```

```

673     }
674     \
675         \
676         \
677         \
678         \
679     \
680     template<typename T>
681     TYPE& setMin(std::initializer_list<T>&& t)
682     {
683     \
684         setMinFromContainer(std::forward<std::initializer_list<T>(t));
685     \
686         return *this;
687     }
688     \
689
690     class ParameterBuilder
691     {
692     private:
693         IrisInstanceResource::ResourceInfoAndAccess* info;
694     public:
695         ParameterBuilder(IrisInstanceResource::ResourceInfoAndAccess& info_)
696             : info(&info_)
697         {
698             info->resourceInfo.isParameter = true;
699         }
700
701         ParameterBuilder()
702             : info(nullptr)
703         {
704         }
705
706         INTERNAL_RESOURCE_BUILDER_MIXIN(ParameterBuilder)
707         INTERNAL_PARAMETER_BUILDER_MIXIN(ParameterBuilder)
708     };
709
710     class FieldBuilder;
711
712     class RegisterBuilder
713     {
714     private:
715         IrisInstanceResource::ResourceInfoAndAccess* info{};
716         IrisInstanceResource* inst_resource{};
717         IrisInstanceBuilder* instance_builder{};
718     public:
719         RegisterBuilder(IrisInstanceResource::ResourceInfoAndAccess& info_, IrisInstanceResource*
720 inst_resource_, IrisInstanceBuilder *instance_builder_)
721             : info(&info_)
722             , inst_resource(inst_resource_)
723             , instance_builder(instance_builder_)
724         {
725             info->resourceInfo.isRegister = true;
726         }
727
728         RegisterBuilder()
729         {
730         }
731
732         INTERNAL_RESOURCE_BUILDER_MIXIN(RegisterBuilder)
733         INTERNAL_REGISTER_BUILDER_MIXIN(RegisterBuilder)
734
735         FieldBuilder addField(const std::string& name, uint64_t lsbOffset, uint64_t bitWidth, const
736 std::string& description);
737
738         FieldBuilder addLogicalField(const std::string& name, uint64_t bitWidth, const std::string&
739 description);
740     };
741
742     class FieldBuilder
743     {
744     protected:
745         IrisInstanceResource::ResourceInfoAndAccess* info{};
746         RegisterBuilder* parent_reg{};
747         IrisInstanceBuilder* instance_builder{};
748     public:
749         FieldBuilder(IrisInstanceResource::ResourceInfoAndAccess& info_, RegisterBuilder* parent_reg_,
750 IrisInstanceBuilder *instance_builder_)
751             : info(&info_)
752             , parent_reg(parent_reg_)

```

```

780         , instance_builder(instance_builder_)
781     {
782     }
783
784     FieldBuilder()
785     {
786     }
787
788     INTERNAL_RESOURCE_BUILDER_MIXIN(FieldBuilder)
789     INTERNAL_REGISTER_BUILDER_MIXIN(FieldBuilder)
790
791     RegisterBuilder& parent()
792     {
793         return *parent_reg;
794     }
795
796     FieldBuilder addField(const std::string& name, uint64_t lsbOffset, uint64_t bitWidth, const
std::string& description)
797     {
798         return parent().addField(name, lsbOffset, bitWidth, description);
799     }
800
801     FieldBuilder addLogicalField(const std::string& name, uint64_t bitWidth, const std::string&
description)
802     {
803         return parent().addLogicalField(name, bitWidth, description);
804     }
805 };
806
807 #undef INTERNAL_RESOURCE_BUILDER_MIXIN
808 #undef INTERNAL_REGISTER_BUILDER_MIXIN
809 #undef INTERNAL_PARAMETER_BUILDER_MIXIN
810
811 void setDefaultResourceReadDelegate(ResourceReadDelegate delegate = ResourceReadDelegate())
812 {
813     default_reg_read_delegate = delegate;
814 }
815
816 template <typename T, IrisErrorCode (T::*METHOD)(const ResourceInfo&, ResourceReadResult&)>
void setDefaultResourceReadDelegate(T* instance)
817 {
818     setDefaultResourceReadDelegate(ResourceReadDelegate::make<T, METHOD>(instance));
819 }
820
821 template <IrisErrorCode (*FUNC)(const ResourceInfo&, ResourceReadResult&)>
void setDefaultResourceReadDelegate()
822 {
823     setDefaultResourceReadDelegate(ResourceReadDelegate::make<FUNC>());
824 }
825
826 void setDefaultResourceWriteDelegate(ResourceWriteDelegate delegate = ResourceWriteDelegate())
827 {
828     default_reg_write_delegate = delegate;
829 }
830
831 template <typename T, IrisErrorCode (T::*METHOD)(const ResourceInfo&, const ResourceWriteValue&)>
void setDefaultResourceWriteDelegate(T* instance)
832 {
833     setDefaultResourceWriteDelegate(ResourceWriteDelegate::make<T, METHOD>(instance));
834 }
835
836 template <IrisErrorCode (*FUNC)(const ResourceInfo&, const ResourceWriteValue&)>
void setDefaultResourceWriteDelegate()
837 {
838     setDefaultResourceWriteDelegate(ResourceWriteDelegate::make<*FUNC>());
839 }
840
841 template <typename T, IrisErrorCode (T::*READER)(const ResourceInfo&, ResourceReadResult&),
IrisErrorCode (T::*WRITER)(const ResourceInfo&, const ResourceWriteValue&)>
void setDefaultResourceDelegates(T* instance)
842 {
843     setDefaultResourceReadDelegate(ResourceReadDelegate::make<T, READER>(instance));
844     setDefaultResourceWriteDelegate(ResourceWriteDelegate::make<T, WRITER>(instance));
845 }
846
847 void beginResourceGroup(const std::string& name,
const std::string& description,
uint64_t subRscIdStart = IRIS_UINT64_MAX,
const std::string& cname = std::string());
848
849 ParameterBuilder addParameter(const std::string& name, uint64_t bitWidth, const std::string&
description);
850
851 ParameterBuilder addStringParameter(const std::string& name, const std::string& description);
852
853 RegisterBuilder addRegister(const std::string& name, uint64_t bitWidth, const std::string&
description,

```

```

1128             uint64_t addressOffset = IRIS_UINT64_MAX, uint64_t canonicalRn =
IRIS_UINT64_MAX);
1129
1148     RegisterBuilder addStringRegister(const std::string& name, const std::string& description);
1149
1170     RegisterBuilder addNoValueRegister(const std::string& name, const std::string& description, const
std::string& format);
1171
1190     ParameterBuilder enhanceParameter(ResourceId rscId)
1191     {
1192         return ParameterBuilder(*(inst_resource->getResourceInfo(rscId)));
1193     }
1194
1216     RegisterBuilder enhanceRegister(ResourceId rscId)
1217     {
1218         return RegisterBuilder(*(inst_resource->getResourceInfo(rscId)), inst_resource, this);
1219     }
1220
1243     void setPropertyCanonicalRnScheme(const std::string& canonicalRnScheme);
1244
1252     void setNextSubRscId(uint64_t nextSubRscId)
1253     {
1254         inst_resource->setNextSubRscId(nextSubRscId);
1255     }
1256
1266     void setTag(ResourceId rscId, const std::string& tag);
1267
1275     const ResourceInfo &getResourceInfo(ResourceId rscId)
1276     {
1277         return inst_resource->getResourceInfo(rscId)->resourceInfo;
1278     }
1279
1280
1294     class EventSourceBuilder
1295     {
1296     private:
1297         IrisInstanceEvent::EventSourceInfoAndDelegate& info;
1298
1299     public:
1300         EventSourceBuilder(IrisInstanceEvent::EventSourceInfoAndDelegate& info_)
1301             : info(info_)
1302         {
1303         }
1304
1310         EventSourceBuilder& setName(const std::string& name)
1311         {
1312             info.info.name = name;
1313             return *this;
1314         }
1315
1321         EventSourceBuilder& setDescription(const std::string& description)
1322         {
1323             info.info.description = description;
1324             return *this;
1325         }
1326
1332         EventSourceBuilder& setFormat(const std::string& format)
1333         {
1334             info.info.format = format;
1335             return *this;
1336         }
1337
1343         EventSourceBuilder& setCounter(bool counter = true)
1344         {
1345             info.info.counter = counter;
1346             return *this;
1347         }
1348
1356         EventSourceBuilder& setHidden(bool hidden = true)
1357         {
1358             info.info.isHidden = hidden;
1359             return *this;
1360         }
1361
1368         EventSourceBuilder& hasSideEffects(bool hasSideEffects_ = true)
1369         {
1370             info.info.hasSideEffects = hasSideEffects_;
1371             return *this;
1372         }
1373
1386         EventSourceBuilder& addField(const std::string& name, const std::string& type, uint64_t
sizeInBytes,
1387                                     const std::string& description)
1388         {
1389             info.info.addField(name, type, sizeInBytes, description);
1390             return *this;
1391         }

```

```

1392
1403     EventSourceBuilder& addEnumElement(uint64_t value, const std::string& symbol, const
std::string& description = "")
1404     {
1405         if (info.info.fields.size() > 0)
1406         {
1407             info.info.fields.back().addEnumElement(value, symbol, description);
1408             return *this;
1409         }
1410         else
1411         {
1412             throw IrisInternalError("EventSourceInfo has no fields to add an enum element to.");
1413         }
1414     }
1415
1425     EventSourceBuilder& setEventStreamCreateDelegate(EventStreamCreateDelegate delegate)
1426     {
1427         info.createEventStream = delegate;
1428         return *this;
1429     }
1430
1443     template <typename T,
1444               IrisErrorCode (T::*METHOD)(EventStream*&, const EventSourceInfo&, const
std::vector<std::string>&)>
1445     EventSourceBuilder& setEventStreamCreateDelegate(T* instance)
1446     {
1447         return setEventStreamCreateDelegate(EventStreamCreateDelegate::make<T, METHOD>(instance));
1448     }
1449
1463     template<typename T>
1464     EventSourceBuilder& addOption(const std::string& name, const std::string& type, const T&
defaultValue,
1465                                  bool optional, const std::string& description)
1466     {
1467         info.info.addOption(name, type, defaultValue, optional, description);
1468         return *this;
1469     }
1470 };
1471
1486     EventSourceBuilder addEventSource(const std::string& name, bool isHidden = false)
1487     {
1488         return EventSourceBuilder(inst_event->addEventSource(name, isHidden));
1489     }
1490
1502     EventSourceBuilder addEventSource(const std::string& name, IrisEventEmitterBase& event_emitter,
bool isHidden = false)
1503     {
1504         IrisInstanceEvent::EventSourceInfoAndDelegate& info = inst_event->addEventSource(name,
isHidden);
1505
1506         event_emitter.setIrisInstance(iris_instance);
1507         event_emitter.setEvSrcId(info.info.evSrcId);
1508         info.createEventStream = EventStreamCreateDelegate::make<IrisEventEmitterBase,
1509 &IrisEventEmitterBase::createEventStream>(&event_emitter);
1510
1511         return EventSourceBuilder(info);
1512     }
1513
1523     EventSourceBuilder enhanceEventSource(const std::string& name)
1524     {
1525         IrisInstanceEvent::EventSourceInfoAndDelegate& info = inst_event->enhanceEventSource(name);
1526         return EventSourceBuilder(info);
1527     }
1528
1534     void deleteEventSource(const std::string& name)
1535     {
1536         inst_event->deleteEventSource(name);
1537     }
1538
1545     bool hasEventSource(const std::string& name)
1546     {
1547         return inst_event->hasEventSource(name);
1548     }
1549
1575     EventSourceBuilder setRegisterReadEvent(const std::string& name, const std::string& description =
std::string());
1576
1602     EventSourceBuilder setRegisterReadEvent(const std::string& name, IrisRegisterEventEmitterBase&
event_emitter);
1603
1610     void finalizeRegisterReadEvent();
1611
1638     EventSourceBuilder setRegisterUpdateEvent(const std::string& name, const std::string& description =
std::string());
1639
1666     EventSourceBuilder setRegisterUpdateEvent(const std::string& name, IrisRegisterEventEmitterBase&

```



```

event_emitter);
1667
1674 void finalizeRegisterUpdateEvent();
1675
1682 void resetRegisterReadEvent();
1683
1690 void resetRegisterUpdateEvent();
1691
1723 void setDefaultEsCreateDelegate(EventStreamCreateDelegate delegate)
1724 {
1725     inst_event->setDefaultEsCreateDelegate(delegate);
1726 }
1727
1758 template <typename T, IrisErrorCode (T::*METHOD)(EventStream*&, const EventSourceInfo&, const
std::vector<std::string>&)>
1759 void setDefaultEsCreateDelegate(T* instance)
1760 {
1761     setDefaultEsCreateDelegate(EventStreamCreateDelegate::make<T, METHOD>(instance));
1762 }
1763
1786 template <IrisErrorCode (*FUNC)(EventStream*&, const EventSourceInfo&, const
std::vector<std::string>&)>
1787 void setDefaultEsCreateDelegate()
1788 {
1789     setDefaultEsCreateDelegate(EventStreamCreateDelegate::make<FUNC>());
1790 }
1791
1798 IrisInstanceEvent* getIrisInstanceEvent() { return inst_event; }
1799
1831 void setBreakpointSetDelegate(BreakpointSetDelegate delegate)
1832 {
1833     if (inst_breakpoint.getPtr() == nullptr)
1834     {
1835         // Ensure the underlying IrisInstanceBreakpoint object is initialised too.
1836         inst_breakpoint.init();
1837     }
1838     user_setBreakpoint = delegate;
1839 }
1840
1862 template <typename T, IrisErrorCode (T::*METHOD)(BreakpointInfo&)>
1863 void setBreakpointSetDelegate(T* instance)
1864 {
1865     setBreakpointSetDelegate(BreakpointSetDelegate::make<T, METHOD>(instance));
1866 }
1867
1881 template <IrisErrorCode (*FUNC)(BreakpointInfo&)>
1882 void setBreakpointSetDelegate()
1883 {
1884     setBreakpointSetDelegate(BreakpointSetDelegate::make<FUNC>());
1885 }
1886
1908 void setBreakpointDeleteDelegate(BreakpointDeleteDelegate delegate)
1909 {
1910     if (inst_breakpoint.getPtr() == nullptr)
1911     {
1912         // Ensure the underlying IrisInstanceBreakpoint object is initialised too.
1913         inst_breakpoint.init();
1914     }
1915     user_deleteBreakpoint = delegate;
1916 }
1917
1939 template <typename T, IrisErrorCode (T::*METHOD)(const BreakpointInfo&)>
1940 void setBreakpointDeleteDelegate(T* instance)
1941 {
1942     setBreakpointDeleteDelegate(BreakpointDeleteDelegate::make<T, METHOD>(instance));
1943 }
1944
1958 template <IrisErrorCode (*FUNC)(const BreakpointInfo&)>
1959 void setBreakpointDeleteDelegate()
1960 {
1961     setBreakpointDeleteDelegate(BreakpointDeleteDelegate::make<FUNC>());
1962 }
1963
1985 void setHandleBreakpointHitDelegate(HandleBreakpointHitDelegate delegate)
1986 {
1987     if (inst_breakpoint.getPtr() == nullptr)
1988     {
1989         // Ensure the underlying IrisInstanceBreakpoint object is initialised too.
1990         inst_breakpoint.init();
1991     }
1992     inst_breakpoint->setHandleBreakpointHitDelegate(delegate);
1993 }
1994
2017 template <typename T, IrisErrorCode (T::*METHOD)(const BreakpointHitInfo&)>
2018 void setHandleBreakpointHitDelegate(T* instance)
2019 {

```

```

2020     setHandleBreakpointHitDelegate(HandleBreakpointHitDelegate::make<T, METHOD>(instance));
2021 }
2022
2023 template <IrisErrorCode (*FUNC)(const BreakpointHitInfo&)>
2024 void setHandleBreakpointHitDelegate()
2025 {
2026     setHandleBreakpointHitDelegate(HandleBreakpointHitDelegate::make<FUNC>());
2027 }
2028
2029 void notifyBreakpointHit(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId pcSpaceId)
2030 {
2031     inst_breakpoint->notifyBreakpointHit(bptId, time, pc, pcSpaceId);
2032 }
2033
2034 void notifyBreakpointHitData(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId
pcSpaceId,
2035                             uint64_t accessAddr, uint64_t accessSize,
2036                             const std::string& accessRw, const std::vector<uint64_t>& data)
2037 {
2038     inst_breakpoint->notifyBreakpointHitData(bptId, time, pc, pcSpaceId, accessAddr, accessSize,
accessRw, data);
2039 }
2040
2041 void notifyBreakpointHitRegister(BreakpointId bptId, uint64_t time, uint64_t pc, MemorySpaceId
pcSpaceId,
2042                                 const std::string& accessRw, const std::vector<uint64_t>& data)
2043 {
2044     inst_breakpoint->notifyBreakpointHitRegister(bptId, time, pc, pcSpaceId, accessRw, data);
2045 }
2046
2047 const BreakpointInfo* getBreakpointInfo(BreakpointId bptId)
2048 {
2049     return inst_breakpoint->getBreakpointInfo(bptId);
2050 }
2051
2052 void addBreakpointCondition(const std::string& name, const std::string& type, const std::string&
description,
2053                             const std::vector<std::string> bpt_types = std::vector<std::string>())
2054 {
2055     inst_breakpoint->addCondition(name, type, description, bpt_types);
2056 }
2057
2058 class MemorySpaceBuilder
2059 {
2060 private:
2061     IrisInstanceMemory::SpaceInfoAndAccess& info;
2062 public:
2063     MemorySpaceBuilder(IrisInstanceMemory::SpaceInfoAndAccess& info_)
2064         : info(info_)
2065     {
2066     }
2067
2068     MemorySpaceBuilder& setName(const std::string& name)
2069     {
2070         info.spaceInfo.name = name;
2071         return *this;
2072     }
2073
2074     MemorySpaceBuilder& setDescription(const std::string& description)
2075     {
2076         info.spaceInfo.description = description;
2077         return *this;
2078     }
2079
2080     MemorySpaceBuilder& setMinAddr(uint64_t minAddr)
2081     {
2082         info.spaceInfo.minAddr = minAddr;
2083         return *this;
2084     }
2085
2086     MemorySpaceBuilder& setMaxAddr(uint64_t maxAddr)
2087     {
2088         info.spaceInfo.maxAddr = maxAddr;
2089         return *this;
2090     }
2091
2092     MemorySpaceBuilder& setCanonicalMsn(uint64_t canonicalMsn)
2093     {
2094         info.spaceInfo.canonicalMsn = canonicalMsn;
2095         return *this;
2096     }
2097
2098     MemorySpaceBuilder& setEndianness(const std::string& endianness)
2099     {
2100         info.spaceInfo.endianness = endianness;
2101         return *this;
2102     }
2103 }

```

```

2211     }
2212
2220     MemorySpaceBuilder& addAttribute(const std::string& name, AttributeInfo attrib)
2221     {
2222         info.spaceInfo.attrib[name] = attrib;
2223         return *this;
2224     }
2225
2233     MemorySpaceBuilder& setAttributeDefault(const std::string& name, IrisValue value)
2234     {
2235         info.spaceInfo.attribDefaults[name] = value;
2236         return *this;
2237     }
2238
2251     MemorySpaceBuilder& setSupportedByteWidths(uint64_t supportedByteWidths)
2252     {
2253         info.spaceInfo.supportedByteWidths = supportedByteWidths;
2254         return *this;
2255     }
2256
2267     MemorySpaceBuilder& setReadDelegate(MemoryReadDelegate delegate)
2268     {
2269         info.readDelegate = delegate;
2270         return *this;
2271     }
2272
2283     MemorySpaceBuilder& setWriteDelegate(MemoryWriteDelegate delegate)
2284     {
2285         info.writeDelegate = delegate;
2286         return *this;
2287     }
2288
2299     MemorySpaceBuilder& setSidebandDelegate(MemoryGetSidebandInfoDelegate delegate)
2300     {
2301         info.sidebandDelegate = delegate;
2302         return *this;
2303     }
2304
2318     template <typename T, IrisErrorCode (T::*METHOD)(const MemorySpaceInfo&, uint64_t, uint64_t,
uint64_t, const AttributeValueMap&, MemoryReadResult&)>
2319     MemorySpaceBuilder& setReadDelegate(T* instance)
2320     {
2321         return setReadDelegate(MemoryReadDelegate::make<T, METHOD>(instance));
2322     }
2323
2337     template <typename T, IrisErrorCode (T::*METHOD)(const MemorySpaceInfo&, uint64_t, uint64_t,
uint64_t, const AttributeValueMap&, const uint64_t*, MemoryWriteResult&)>
2338     MemorySpaceBuilder& setWriteDelegate(T* instance)
2339     {
2340         return setWriteDelegate(MemoryWriteDelegate::make<T, METHOD>(instance));
2341     }
2342
2356     template <typename T, IrisErrorCode (T::*METHOD)(const MemorySpaceInfo&, uint64_t, const
IrisValueMap&, const std::vector<std::string>&, IrisValueMap&)>
2357     MemorySpaceBuilder& setSidebandDelegate(T* instance)
2358     {
2359         return setSidebandDelegate(MemoryGetSidebandInfoDelegate::make<T, METHOD>(instance));
2360     }
2361
2372     template <IrisErrorCode (*FUNC)(const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t,
2373                                     const AttributeValueMap&, MemoryReadResult&)>
2374     MemorySpaceBuilder& setReadDelegate()
2375     {
2376         return setReadDelegate(MemoryReadDelegate::make<FUNC>());
2377     }
2378
2389     template <IrisErrorCode (*FUNC)(const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t,
2390                                     const AttributeValueMap&, const uint64_t*, MemoryWriteResult&)>
2391     MemorySpaceBuilder& setWriteDelegate()
2392     {
2393         return setWriteDelegate(MemoryWriteDelegate::make<FUNC>());
2394     }
2395
2406     template <IrisErrorCode (*FUNC)(const MemorySpaceInfo&, uint64_t, const IrisValueMap&,
2407                                     const std::vector<std::string>&, IrisValueMap&)>
2408     MemorySpaceBuilder& setSidebandDelegate()
2409     {
2410         return setSidebandDelegate(MemoryGetSidebandInfoDelegate::make<FUNC>());
2411     }
2412
2421     MemorySpaceId getSpaceId() const
2422     {
2423         return info.spaceInfo.spaceId;
2424     }
2425 };
2426
2430     class AddressTranslationBuilder

```

```

2431     {
2432     private:
2433         IrisInstanceMemory::AddressTranslationInfoAndAccess& info;
2434     public:
2435         AddressTranslationBuilder(IrisInstanceMemory::AddressTranslationInfoAndAccess& info_)
2436             : info(info_)
2437         {
2438         }
2439
2440         AddressTranslationBuilder& setTranslateDelegate(MemoryAddressTranslateDelegate delegate)
2441         {
2442             info.translateDelegate = delegate;
2443             return *this;
2444         }
2445
2446         template <typename T, IrisErrorCode (T::*METHOD)(uint64_t, uint64_t, uint64_t,
2447             MemoryAddressTranslationResult&)>
2448         AddressTranslationBuilder& setTranslateDelegate(T* instance)
2449         {
2450             return setTranslateDelegate(MemoryAddressTranslateDelegate::make<T, METHOD>(instance));
2451         }
2452
2453         template <IrisErrorCode (*FUNC)(uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult&)>
2454         AddressTranslationBuilder& setTranslateDelegate()
2455         {
2456             return setTranslateDelegate(MemoryAddressTranslateDelegate::make<FUNC>());
2457         }
2458     };
2459
2460     void setPropertyCanonicalMsnScheme(const std::string& canonicalMsnScheme);
2461
2462     void setDefaultMemoryReadDelegate(MemoryReadDelegate delegate = MemoryReadDelegate())
2463     {
2464         inst_memory->setDefaultReadDelegate(delegate);
2465     }
2466
2467     template <typename T, IrisErrorCode (T::*METHOD)(const MemorySpaceInfo&, uint64_t, uint64_t,
2468         uint64_t, const AttributeValueMap&, MemoryReadResult&)>
2469     void setDefaultMemoryReadDelegate(T* instance)
2470     {
2471         setDefaultMemoryReadDelegate(MemoryReadDelegate::make<T, METHOD>(instance));
2472     }
2473
2474     template <IrisErrorCode (*FUNC)(const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t,
2475         const AttributeValueMap&, MemoryReadResult&)>
2476     void setDefaultMemoryReadDelegate()
2477     {
2478         setDefaultMemoryReadDelegate(MemoryReadDelegate::make<FUNC>());
2479     }
2480
2481     void setDefaultMemoryWriteDelegate(MemoryWriteDelegate delegate = MemoryWriteDelegate())
2482     {
2483         inst_memory->setDefaultWriteDelegate(delegate);
2484     }
2485
2486     template <typename T, IrisErrorCode (T::*METHOD)(const MemorySpaceInfo&, uint64_t, uint64_t,
2487         uint64_t, const AttributeValueMap&, const uint64_t*, MemoryWriteResult&)>
2488     void setDefaultMemoryWriteDelegate(T* instance)
2489     {
2490         setDefaultMemoryWriteDelegate(MemoryWriteDelegate::make<T, METHOD>(instance));
2491     }
2492
2493     template <IrisErrorCode (*FUNC)(const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t,
2494         const AttributeValueMap&, const uint64_t*, MemoryWriteResult&)>
2495     void setDefaultMemoryWriteDelegate()
2496     {
2497         setDefaultMemoryWriteDelegate(MemoryWriteDelegate::make<FUNC>());
2498     }
2499
2500     MemorySpaceBuilder addMemorySpace(const std::string& name)
2501     {
2502         return MemorySpaceBuilder(inst_memory->addMemorySpace(name));
2503     }
2504
2505     void setDefaultAddressTranslateDelegate(MemoryAddressTranslateDelegate delegate =
2506         MemoryAddressTranslateDelegate())
2507     {
2508         inst_memory->setDefaultTranslateDelegate(delegate);
2509     }
2510
2511     template <typename T, IrisErrorCode (T::*METHOD)(uint64_t, uint64_t, uint64_t,
2512         MemoryAddressTranslationResult&)>
2513     void setDefaultAddressTranslateDelegate(T* instance)
2514     {
2515         setDefaultAddressTranslateDelegate(MemoryAddressTranslateDelegate::make<T, METHOD>(instance));
2516     }

```

```

2814
2834     template <IrisErrorCode (*FUNC) (uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult&)>
2835     void setDefaultAddressTranslateDelegate()
2836     {
2837         setDefaultAddressTranslateDelegate(MemoryAddressTranslateDelegate::make<FUNC>());
2838     }
2839
2856     AddressTranslationBuilder addAddressTranslation(MemorySpaceId inSpaceId, MemorySpaceId outSpaceId,
2857                                                     const std::string& description)
2858     {
2859         return AddressTranslationBuilder(inst_memory->addAddressTranslation(inSpaceId, outSpaceId,
2860 description));
2861     }
2862
2894     void setDefaultGetMemorySidebandInfoDelegate(MemoryGetSidebandInfoDelegate delegate)
2895     {
2896         inst_memory->setDefaultGetSidebandInfoDelegate(delegate);
2897     }
2898
2927     template <typename T, IrisErrorCode (T::*METHOD) (const MemorySpaceInfo&, uint64_t, const
IrisValueMap&, const std::vector<std::string>&, IrisValueMap&)>
2928     void setDefaultGetMemorySidebandInfoDelegate(T* instance)
2929     {
2930         setDefaultGetMemorySidebandInfoDelegate(MemoryGetSidebandInfoDelegate::make<T,
METHOD>(instance));
2931     }
2932
2953     template <IrisErrorCode (*FUNC) (const MemorySpaceInfo&, uint64_t, const IrisValueMap&,
2954                                     const std::vector<std::string>&, IrisValueMap&)>
2955     void setDefaultGetMemorySidebandInfoDelegate()
2956     {
2957         setDefaultGetMemorySidebandInfoDelegate(MemoryGetSidebandInfoDelegate::make<FUNC>());
2958     }
2959
2994     void setLoadImageFileDelegate(ImageLoadFileDelegate delegate = ImageLoadFileDelegate())
2995     {
2996         inst_image->setLoadImageFileDelegate(delegate);
2997     }
2998
3019     template <typename T, IrisErrorCode (T::*METHOD) (const std::string&)>
3020     void setLoadImageFileDelegate(T* instance)
3021     {
3022         setLoadImageFileDelegate(ImageLoadFileDelegate::make<T, METHOD>(instance));
3023     }
3024
3037     template <IrisErrorCode (*FUNC) (const std::string&)>
3038     void setLoadImageFileDelegate()
3039     {
3040         setLoadImageFileDelegate(ImageLoadFileDelegate::make<FUNC>());
3041     }
3042
3067     void setLoadImageDataDelegate(ImageLoadDataDelegate delegate = ImageLoadDataDelegate())
3068     {
3069         inst_image->setLoadImageDataDelegate(delegate);
3070     }
3071
3092     template <typename T, IrisErrorCode (T::*METHOD) (const std::vector<uint8_t>&)>
3093     void setLoadImageDataDelegate(T* instance)
3094     {
3095         setLoadImageDataDelegate(ImageLoadDataDelegate::make<T, METHOD>(instance));
3096     }
3097
3110     template <IrisErrorCode (*FUNC) (const std::vector<uint8_t>&)>
3111     void setLoadImageDataDelegate()
3112     {
3113         setLoadImageDataDelegate(ImageLoadDataDelegate::make<FUNC>());
3114     }
3115
3131     uint64_t openImage(const std::string& filename)
3132     {
3133         return inst_image_cb->openImage(filename);
3134     }
3135
3170     void setRemainingStepSetDelegate(RemainingStepSetDelegate delegate = RemainingStepSetDelegate())
3171     {
3172         inst_step->setRemainingStepSetDelegate(delegate);
3173     }
3174
3199     void setRemainingStepGetDelegate(RemainingStepGetDelegate delegate)
3200     {
3201         inst_step->setRemainingStepGetDelegate(delegate);
3202     }
3203
3224     template <typename T, IrisErrorCode (T::*METHOD) (uint64_t, const std::string&)>
3225     void setRemainingStepSetDelegate(T* instance)
3226     {
3227         setRemainingStepSetDelegate(RemainingStepSetDelegate::make<T, METHOD>(instance));

```

```

3228     }
3229
3230     template <typename T, IrisErrorCode (T::*METHOD)(uint64_t&, const std::string&)>
3231     void setRemainingStepGetDelegate(T* instance)
3232     {
3233         setRemainingStepGetDelegate(RemainingStepGetDelegate::make<T, METHOD>(instance));
3234     }
3235
3236     template <IrisErrorCode (*FUNC)(uint64_t&, const std::string&)>
3237     void setRemainingStepSetDelegate()
3238     {
3239         setRemainingStepSetDelegate(RemainingStepSetDelegate::make<FUNC>());
3240     }
3241
3242     template <IrisErrorCode (*FUNC)(uint64_t&, const std::string&)>
3243     void setRemainingStepGetDelegate()
3244     {
3245         setRemainingStepGetDelegate(RemainingStepGetDelegate::make<FUNC>());
3246     }
3247
3248     //
3249     void setStepCountGetDelegate(StepCountGetDelegate delegate = StepCountGetDelegate())
3250     {
3251         inst_step->setStepCountGetDelegate(delegate);
3252     }
3253
3254     template <typename T, IrisErrorCode (T::*METHOD)(uint64_t&, const std::string&)>
3255     void setStepCountGetDelegate(T* instance)
3256     {
3257         setStepCountGetDelegate(RemainingStepGetDelegate::make<T, METHOD>(instance));
3258     }
3259
3260     template <IrisErrorCode (*FUNC)(uint64_t&, const std::string&)>
3261     void setStepCountGetDelegate()
3262     {
3263         setStepCountGetDelegate(RemainingStepGetDelegate::make<FUNC>());
3264     }
3265
3266     /*
3267     * @brief exec_apis IrisInstanceBuilder per-instance execution APIs
3268     * @{
3269     */
3270
3271     void setExecutionStateSetDelegate(PerInstanceExecutionStateSetDelegate delegate =
3272     PerInstanceExecutionStateSetDelegate())
3273     {
3274         inst_per_inst_exec->setExecutionStateSetDelegate(delegate);
3275     }
3276
3277     template <typename T, IrisErrorCode (T::*METHOD)(bool)>
3278     void setExecutionStateSetDelegate(T* instance)
3279     {
3280         setExecutionStateSetDelegate(PerInstanceExecutionStateSetDelegate::make<T, METHOD>(instance));
3281     }
3282
3283     template <IrisErrorCode (*FUNC)(bool)>
3284     void setExecutionStateSetDelegate()
3285     {
3286         setExecutionStateSetDelegate(PerInstanceExecutionStateSetDelegate::make<FUNC>());
3287     }
3288
3289     void setExecutionStateGetDelegate(PerInstanceExecutionStateGetDelegate delegate)
3290     {
3291         inst_per_inst_exec->setExecutionStateGetDelegate(delegate);
3292     }
3293
3294     template <typename T, IrisErrorCode (T::*METHOD)(bool&)>
3295     void setExecutionStateGetDelegate(T* instance)
3296     {
3297         setExecutionStateGetDelegate(PerInstanceExecutionStateGetDelegate::make<T, METHOD>(instance));
3298     }
3299
3300     template <IrisErrorCode (*FUNC)(bool&)>
3301     void setExecutionStateGetDelegate()
3302     {
3303         setExecutionStateGetDelegate(PerInstanceExecutionStateGetDelegate::make<FUNC>());
3304     }
3305
3306     /*
3307     * @brief table_apis IrisInstanceBuilder table APIs
3308     * @{
3309     */
3310
3311     class TableColumnBuilder;
3312
3313     class TableBuilder
3314     {

```

```

3537     private:
3538         IrisInstanceTable::TableInfoAndAccess& info;
3539
3540     public:
3541         TableBuilder(IrisInstanceTable::TableInfoAndAccess& info_)
3542             : info(info_)
3543         {
3544         }
3545
3551         TableBuilder& setName(const std::string& name)
3552         {
3553             info.tableInfo.name = name;
3554             return *this;
3555         }
3556
3562         TableBuilder& setDescription(const std::string& description)
3563         {
3564             info.tableInfo.description = description;
3565             return *this;
3566         }
3567
3573         TableBuilder& setMinIndex(uint64_t minIndex)
3574         {
3575             info.tableInfo.minIndex = minIndex;
3576             return *this;
3577         }
3578
3584         TableBuilder& setMaxIndex(uint64_t maxIndex)
3585         {
3586             info.tableInfo.maxIndex = maxIndex;
3587             return *this;
3588         }
3589
3595         TableBuilder& setIndexFormatHint(const std::string& hint)
3596         {
3597             info.tableInfo.indexFormatHint = hint;
3598             return *this;
3599         }
3600
3606         TableBuilder& setFormatShort(const std::string& format)
3607         {
3608             info.tableInfo.formatShort = format;
3609             return *this;
3610         }
3611
3617         TableBuilder& setFormatLong(const std::string& format)
3618         {
3619             info.tableInfo.formatLong = format;
3620             return *this;
3621         }
3622
3632         TableBuilder& setReadDelegate(TableReadDelegate delegate)
3633         {
3634             info.readDelegate = delegate;
3635             return *this;
3636         }
3637
3647         TableBuilder& setWriteDelegate(TableWriteDelegate delegate)
3648         {
3649             info.writeDelegate = delegate;
3650             return *this;
3651         }
3652
3664         template <typename T, IrisErrorCode (T::*METHOD)(const TableInfo&, uint64_t, uint64_t,
TableReadResult&)>
3665         TableBuilder& setReadDelegate(T* instance)
3666         {
3667             return setReadDelegate(TableReadDelegate::make<T, METHOD>(instance));
3668         }
3669
3681         template <typename T, IrisErrorCode (T::*METHOD)(const TableInfo&, const TableRecords&,
TableWriteResult&)>
3682         TableBuilder& setWriteDelegate(T* instance)
3683         {
3684             return setWriteDelegate(TableWriteDelegate::make<T, METHOD>(instance));
3685         }
3686
3696         template <IrisErrorCode (*FUNC)(const TableInfo&, uint64_t, uint64_t, TableReadResult&)>
3697         TableBuilder& setReadDelegate()
3698         {
3699             return setReadDelegate(TableReadDelegate::make<FUNC>());
3700         }
3701
3711         template <IrisErrorCode (*FUNC)(const TableInfo&, const TableRecords&, TableWriteResult&)>
3712         TableBuilder& setWriteDelegate()
3713         {
3714             return setWriteDelegate(TableWriteDelegate::make<FUNC>());

```

```

3715     }
3716
3727     TableBuilder& addColumnInfo(const TableColumnInfo& columnInfo)
3728     {
3729         info.tableInfo.columns.push_back(columnInfo);
3730         return *this;
3731     }
3732
3744     TableColumnBuilder addColumn(const std::string& name);
3745 };
3746
3750 class TableColumnBuilder
3751 {
3752 private:
3753     TableBuilder&    parent;
3754     TableColumnInfo& info;
3755
3756 public:
3757     TableColumnBuilder(TableBuilder& parent_, TableColumnInfo& info_)
3758         : parent(parent_)
3759         , info(info_)
3760     {
3761     }
3762
3772     TableBuilder& addColumnInfo(const TableColumnInfo& columnInfo)
3773     {
3774         return parent.addColumnInfo(columnInfo);
3775     }
3776
3788     TableColumnBuilder addColumn(const std::string& name) { return parent.addColumn(name); }
3789
3798     TableBuilder& endColumn()
3799     {
3800         return parent;
3801     }
3802
3809     TableColumnBuilder& setName(const std::string& name)
3810     {
3811         info.name = name;
3812         return *this;
3813     }
3814
3821     TableColumnBuilder& setDescription(const std::string& description)
3822     {
3823         info.description = description;
3824         return *this;
3825     }
3826
3833     TableColumnBuilder& setFormat(const std::string& format)
3834     {
3835         info.format = format;
3836         return *this;
3837     }
3838
3845     TableColumnBuilder& setType(const std::string& type)
3846     {
3847         info.type = type;
3848         return *this;
3849     }
3850
3857     TableColumnBuilder& setBitWidth(uint64_t bitWidth)
3858     {
3859         info.bitWidth = bitWidth;
3860         return *this;
3861     }
3862
3869     TableColumnBuilder& setFormatShort(const std::string& format)
3870     {
3871         info.formatShort = format;
3872         return *this;
3873     }
3874
3881     TableColumnBuilder& setFormatLong(const std::string& format)
3882     {
3883         info.formatLong = format;
3884         return *this;
3885     }
3886
3893     TableColumnBuilder& setRwMode(const std::string& rwMode)
3894     {
3895         info.rwMode = rwMode;
3896         return *this;
3897     }
3898 };
3899
3922 TableBuilder addTable(const std::string& name)
3923 {

```



```

3924         return TableBuilder(inst_table->addTableInfo(name));
3925     }
3926
3927     void setDefaultTableReadDelegate(TableReadDelegate delegate = TableReadDelegate())
3928     {
3929         inst_table->setDefaultReadDelegate(delegate);
3930     }
3931
3932     void setDefaultTableWriteDelegate(TableWriteDelegate delegate = TableWriteDelegate())
3933     {
3934         inst_table->setDefaultWriteDelegate(delegate);
3935     }
3936
3937     template <typename T, IrisErrorCode (T::*METHOD)(const TableInfo&, uint64_t, uint64_t,
3938     TableReadResult&)>
3939     void setDefaultTableReadDelegate(T* instance)
3940     {
3941         setDefaultTableReadDelegate(TableReadDelegate::make<T, METHOD>(instance));
3942     }
3943
3944     template <typename T, IrisErrorCode (T::*METHOD)(const TableInfo&, const TableRecords&,
3945     TableWriteResult&)>
3946     void setDefaultTableWriteDelegate(T* instance)
3947     {
3948         setDefaultTableWriteDelegate(TableWriteDelegate::make<T, METHOD>(instance));
3949     }
3950
3951     template <IrisErrorCode (*FUNC)(const TableInfo&, uint64_t, uint64_t, TableReadResult&)>
3952     void setDefaultTableReadDelegate()
3953     {
3954         setDefaultTableReadDelegate(TableReadDelegate::make<FUNC>());
3955     }
3956
3957     template <IrisErrorCode (*FUNC)(const TableInfo&, const TableRecords&, TableWriteResult&)>
3958     void setDefaultTableWriteDelegate()
3959     {
3960         setDefaultTableWriteDelegate(TableWriteDelegate::make<FUNC>());
3961     }
3962
3963     void setCurrentDisassemblyModeDelegate(GetCurrentDisassemblyModeDelegate delegate)
3964     {
3965         inst_disass->setGetCurrentModeDelegate(delegate);
3966     }
3967
3968     template <typename T, IrisErrorCode (T::*METHOD)(std::string&)>
3969     void setGetCurrentDisassemblyModeDelegate(T* instance)
3970     {
3971         setGetCurrentDisassemblyModeDelegate(GetCurrentDisassemblyModeDelegate::make<T,
3972     METHOD>(instance));
3973     }
3974
3975     void setGetDisassemblyDelegate(GetDisassemblyDelegate delegate)
3976     {
3977         inst_disass->setGetDisassemblyDelegate(delegate);
3978     }
3979
3980     template <typename T, IrisErrorCode (T::*METHOD)(uint64_t, const std::string&, MemoryReadResult&,
3981     uint64_t, uint64_t, std::vector<DisassemblyLine>&)>
3982     void setGetDisassemblyDelegate(T* instance)
3983     {
3984         setGetDisassemblyDelegate(GetDisassemblyDelegate::make<T, METHOD>(instance));
3985     }
3986
3987     template <IrisErrorCode (*FUNC)(uint64_t, const std::string&, MemoryReadResult&,
3988     uint64_t, uint64_t, std::vector<DisassemblyLine>&)>
3989     void setGetDisassemblyDelegate()
3990     {
3991         setGetDisassemblyDelegate(GetDisassemblyDelegate::make<FUNC>());
3992     }
3993
3994     void setDisassembleOpcodeDelegate(DisassembleOpcodeDelegate delegate)
3995     {
3996         inst_disass->setDisassembleOpcodeDelegate(delegate);
3997     }
3998
3999     template <typename T, IrisErrorCode (T::*METHOD)(const std::vector<uint64_t>&, uint64_t, const
4000     std::string&, DisassembleContext&, DisassemblyLine&)>
4001     void setDisassembleOpcodeDelegate(T* instance)
4002     {
4003         setDisassembleOpcodeDelegate(DisassembleOpcodeDelegate::make<T, METHOD>(instance));
4004     }
4005
4006     template <IrisErrorCode (*FUNC)(const std::vector<uint64_t>&, uint64_t, const std::string&,
4007     DisassembleContext&, DisassemblyLine&)>
4008     void setDisassembleOpcodeDelegate()
4009     {
4010         setDisassembleOpcodeDelegate(DisassembleOpcodeDelegate::make<FUNC>());
4011     }

```

```

4169     }
4170
4171     void addDisassemblyMode(const std::string& name, const std::string& description)
4172     {
4173         inst_disass->addDisassemblyMode(name, description);
4174     }
4175
4176     void setDbgStateSetRequestDelegate(DebuggableStateSetRequestDelegate delegate =
4210 DebuggableStateSetRequestDelegate())
4211     {
4212         inst_dbg_state->setSetRequestDelegate(delegate);
4213     }
4214
4215     template <typename T, IrisErrorCode (T::*METHOD)(bool)>
4235     void setDbgStateSetRequestDelegate(T* instance)
4236     {
4237         setDbgStateSetRequestDelegate(DebuggableStateSetRequestDelegate::make<T, METHOD>(instance));
4238     }
4239
4240     template <IrisErrorCode (*FUNC)(bool)>
4253     void setDbgStateSetRequestDelegate()
4254     {
4255         setDbgStateSetRequestDelegate(DebuggableStateSetRequestDelegate::make<FUNC>());
4256     }
4257
4258     void setDbgStateGetAcknowledgeDelegate(DebuggableStateGetAcknowledgeDelegate delegate =
4283 DebuggableStateGetAcknowledgeDelegate())
4284     {
4285         inst_dbg_state->setGetAcknowledgeDelegate(delegate);
4286     }
4287
4288     template <typename T, IrisErrorCode (T::*METHOD)(bool&)>
4308     void setDbgStateGetAcknowledgeDelegate(T* instance)
4309     {
4310         setDbgStateGetAcknowledgeDelegate(DebuggableStateGetAcknowledgeDelegate::make<T,
4311 METHOD>(instance));
4312     }
4313
4314     template <IrisErrorCode (*FUNC)(bool&)>
4326     void setDbgStateGetAcknowledgeDelegate()
4327     {
4328         setDbgStateGetAcknowledgeDelegate(DebuggableStateGetAcknowledgeDelegate::make<FUNC>());
4329     }
4330
4331     template <typename T, IrisErrorCode (T::*SET_REQUEST)(bool), IrisErrorCode
4359 (T::*GET_ACKNOWLEDGE)(bool&)>
4360     void setDbgStateDelegates(T* instance)
4361     {
4362         setDbgStateSetRequestDelegate<T, SET_REQUEST>(instance);
4363         setDbgStateGetAcknowledgeDelegate<T, GET_ACKNOWLEDGE>(instance);
4364     }
4365
4366     void setCheckpointSaveDelegate(CheckpointSaveDelegate delegate = CheckpointSaveDelegate())
4367     {
4368         inst_checkpoint->setCheckpointSaveDelegate(delegate);
4369     }
4370
4371     template <typename T, IrisErrorCode (T::*METHOD)(const std::string&)>
4372     void setCheckpointSaveDelegate(T* instance)
4373     {
4374         setCheckpointSaveDelegate(CheckpointSaveDelegate::make<T, METHOD>(instance));
4375     }
4376
4377     void setCheckpointRestoreDelegate(CheckpointRestoreDelegate delegate = CheckpointRestoreDelegate())
4378     {
4379         inst_checkpoint->setCheckpointRestoreDelegate(delegate);
4380     }
4381
4382     template <typename T, IrisErrorCode (T::*METHOD)(const std::string&)>
4383     void setCheckpointRestoreDelegate(T* instance)
4384     {
4385         setCheckpointRestoreDelegate(CheckpointRestoreDelegate::make<T, METHOD>(instance));
4386     }
4387
4388     class SemihostingManager
4401     {
4402     private:
4403         IrisInstanceSemihosting* inst_semihost;
4404
4405     public:
4406         SemihostingManager(IrisInstanceSemihosting* inst_semihost_)
4407             : inst_semihost(inst_semihost_)
4408         {
4409         }
4410
4411         ~SemihostingManager()
4412         {
4413         }

```

```

4414         // Interrupt any requests that are currently blocked
4415         unblock();
4416     }
4417
4422     void enableExtensions()
4423     {
4424         inst_semihost->enableExtensions();
4425     }
4426
4441     std::vector<uint8_t> readData(uint64_t fDes, size_t max_size = 0, uint64_t flags =
semihost::DEFAULT)
4442     {
4443         return inst_semihost->readData(fDes, max_size, flags);
4444     }
4445
4446     /*
4447     * @brief Write data for a given file descriptor
4448     *
4449     * @param fDes      File descriptor to write to. Usually semihost::STDOUT or
semihost::STDERR.
4450     * @param data      Buffer containing the data to write.
4451     * @param size      Size of the data buffer in bytes.
4452     * @return          Returns false if no client is registered for IRIS_SEMIHOSTING_OUTPUT
events.
4453     */
4454     bool writeData(uint64_t fDes, const uint8_t* data, size_t size)
4455     {
4456         return inst_semihost->writeData(fDes, data, size);
4457     }
4458
4459     /*
4460     * @brief Write data for a given file descriptor
4461     *
4462     * @param fDes      File descriptor to write to. Usually semihost::STDOUT or
semihost::STDERR.
4463     * @param data      Buffer containing the data to write.
4464     * @return          Returns false if no client is registered for IRIS_SEMIHOSTING_OUTPUT
events.
4465     */
4466     bool writeData(uint64_t fDes, const std::vector<uint8_t>& data)
4467     {
4468         return writeData(fDes, &data.front(), data.size());
4469     }
4470
4485     std::pair<bool, uint64_t> semihostedCall(uint64_t operation, uint64_t parameter)
4486     {
4487         return inst_semihost->semihostedCall(operation, parameter);
4488     }
4489
4490     /*
4491     * @brief Request premature exit from any blocking requests that are currently blocked.
4492     */
4493     void unblock()
4494     {
4495         return inst_semihost->unblock();
4496     }
4497 };
4498
4506     SemihostingManager enableSemihostingAndGetManager()
4507     {
4508         inst_semihost.init();
4509         return SemihostingManager(inst_semihost);
4510     }
4511 };
4512
4516     inline IrisInstanceBuilder::TableColumnBuilder IrisInstanceBuilder::TableBuilder::addColumn(const
std::string& name)
4517     {
4518     {
4519         // Add a new column with default info
4520         info.tableInfo.columns.resize(info.tableInfo.columns.size() + 1);
4521         TableColumnInfo& col = info.tableInfo.columns.back();
4522
4523         col.name = name;
4524
4525         return TableColumnBuilder(*this, col);
4526     }
4527
4528     NAMESPACE_IRIS_END
4529
4530 #endif // ARM_INCLUDE_IrisInstanceBuilder_h

```

## 9.21 IrisInstanceCheckpoint.h File Reference

Checkpoint add-on to IrisInstance.

```
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
```

### Classes

- class [iris::IrisInstanceCheckpoint](#)  
*Checkpoint add-on for [IrisInstance](#).*

### Typedefs

- typedef [IrisDelegate](#)< const std::string & > [iris::CheckpointRestoreDelegate](#)  
*Restore the checkpoint corresponding to the given information.*
- typedef [IrisDelegate](#)< const std::string & > [iris::CheckpointSaveDelegate](#)  
*Save a checkpoint corresponding to the given information.*

#### 9.21.1 Detailed Description

Checkpoint add-on to IrisInstance.

Date

Copyright ARM Limited 2019 All Rights Reserved.

#### 9.21.2 Typedef Documentation

##### 9.21.2.1 CheckpointRestoreDelegate

```
typedef IrisDelegate<const std::string&> iris::CheckpointRestoreDelegate
```

Restore the checkpoint corresponding to the given information.

```
IrisErrorCode checkpoint_restore(const std::string & checkpoint_dir)
```

Error: Return E\_\* error code if it failed to restore the checkpoint.

##### 9.21.2.2 CheckpointSaveDelegate

```
typedef IrisDelegate<const std::string&> iris::CheckpointSaveDelegate
```

Save a checkpoint corresponding to the given information.

```
IrisErrorCode checkpoint_save(const std::string & checkpoint_dir)
```

Error: Return E\_\* error code if it failed to save the checkpoint.

## 9.22 IrisInstanceCheckpoint.h

[Go to the documentation of this file.](#)

```
1
2
3
4
5
6
7 #ifndef ARM_INCLUDE_IrisInstanceCheckpoint_h
8 #define ARM_INCLUDE_IrisInstanceCheckpoint_h
9
10 #include "iris/detail/IrisCommon.h"
11 #include "iris/detail/IrisDelegate.h"
12
13 namespace iris_start
14 {
15     class IrisInstance;
16     class IrisReceivedRequest;
17
18     typedef IrisDelegate<const std::string&> CheckpointSaveDelegate;
19
20     typedef IrisDelegate<const std::string&> CheckpointRestoreDelegate;
21
22 }
```

```

41 class IrisInstanceCheckpoint
42 {
43
44 public:
45     IrisInstanceCheckpoint(IrisInstance* iris_instance = nullptr);
46
47     void attachTo(IrisInstance* iris_instance_);
48
49     void setCheckpointSaveDelegate(CheckpointSaveDelegate delegate);
50
51     void setCheckpointRestoreDelegate(CheckpointRestoreDelegate delegate);
52
53 private:
54     void impl_checkpoint_save(IrisReceivedRequest& request);
55
56     void impl_checkpoint_restore(IrisReceivedRequest& request);
57
58     IrisInstance* iris_instance;
59
60     CheckpointSaveDelegate save_delegate;
61
62     CheckpointRestoreDelegate restore_delegate;
63 };
64
65 #endif // #ifndef ARM_INCLUDE_IrisInstanceCheckpoint_h

```

## 9.23 IrisInstanceDebuggableState.h File Reference

IrisInstance add-on to implement debuggableState functions.

```
#include "iris/detail/IrisCommon.h"
```

```
#include "iris/detail/IrisDelegate.h"
```

### Classes

- class [iris::IrisInstanceDebuggableState](#)  
*Debuggable-state add-on for [IrisInstance](#).*

### Typedefs

- typedef IrisDelegate< bool & > [iris::DebuggableStateGetAcknowledgeDelegate](#)  
*Interface to stop the simulation time progress.*
- typedef IrisDelegate< bool > [iris::DebuggableStateSetRequestDelegate](#)  
*Delegate to set the debuggable-state-request flag.*

#### 9.23.1 Detailed Description

IrisInstance add-on to implement debuggableState functions.

#### Copyright

Copyright (C) 2017 Arm Limited. All rights reserved.

#### 9.23.2 Typedef Documentation

##### 9.23.2.1 DebuggableStateGetAcknowledgeDelegate

```
typedef IrisDelegate<bool&> iris::DebuggableStateGetAcknowledgeDelegate
```

Interface to stop the simulation time progress.

```
IrisErrorCode getAcknowledge(bool &acknowledge_out);
```

### 9.23.2.2 DebuggableStateSetRequestDelegate

typedef IrisDelegate<bool> [iris::DebuggableStateSetRequestDelegate](#)

Delegate to set the debuggable-state-request flag.

IrisErrorCode setRequest(bool request);

## 9.24 IrisInstanceDebuggableState.h

[Go to the documentation of this file.](#)

```

1
2
3
4
5
6
7
8 #ifndef ARM_INCLUDE_IrisInstanceDebuggableState_h
9 #define ARM_INCLUDE_IrisInstanceDebuggableState_h
10
11 #include "iris/detail/IrisCommon.h"
12 #include "iris/detail/IrisDelegate.h"
13
14 NAMESPACE_IRIS_START
15
16
17
18
19
20
21
22 typedef IrisDelegate<bool> DebuggableStateSetRequestDelegate;
23
24
25
26
27
28
29
30 typedef IrisDelegate<bool&> DebuggableStateGetAcknowledgeDelegate;
31
32
33
34
35
36
37
38 class IrisInstance;
39 class IrisReceivedRequest;
40
41 class IrisInstanceDebuggableState
42 {
43 private:
44     IrisInstance* iris_instance;
45
46     DebuggableStateSetRequestDelegate setRequest;
47     DebuggableStateGetAcknowledgeDelegate getAcknowledge;
48
49 public:
50     IrisInstanceDebuggableState(IrisInstance* iris_instance = nullptr);
51
52     void attachTo(IrisInstance* irisInstance);
53
54
55     void setSetRequestDelegate(DebuggableStateSetRequestDelegate delegate)
56     {
57         setRequest = delegate;
58     }
59
60     void setGetAcknowledgeDelegate(DebuggableStateGetAcknowledgeDelegate delegate)
61     {
62         getAcknowledge = delegate;
63     }
64
65 private:
66     void impl_debuggableState_setRequest(IrisReceivedRequest& request);
67
68     void impl_debuggableState_getAcknowledge(IrisReceivedRequest& request);
69 };
70
71 NAMESPACE_IRIS_END
72
73 #endif // ARM_INCLUDE_IrisInstanceSimulationTime_h

```

## 9.25 IrisInstanceDisassembler.h File Reference

Disassembler add-on to IrisInstance.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include <cstdio>

```

### Classes

- class [iris::IrisInstanceDisassembler](#)  
Disassembler add-on for [IrisInstance](#).

## Typedefs

- typedef IrisDelegate< const std::vector< uint64\_t > &, uint64\_t, const std::string &, DisassembleContext &, DisassemblyLine & > [iris::DisassembleOpcodeDelegate](#)  
*Get the disassembly for an individual opcode.*
- typedef IrisDelegate< std::string & > [iris::GetCurrentDisassemblyModeDelegate](#)  
*Get the current disassembly mode.*
- typedef IrisDelegate< uint64\_t, const std::string &, MemoryReadResult &, uint64\_t, uint64\_t, std::vector< DisassemblyLine > & > [iris::GetDisassemblyDelegate](#)  
*Get the disassembly of a chunk of memory.*

### 9.25.1 Detailed Description

Disassembler add-on to IrisInstance.

#### Copyright

Copyright (C) 2016 Arm Limited. All rights reserved.

The IrisInstanceDisassembler class implements all disassembly-related Iris functions.

## 9.26 IrisInstanceDisassembler.h

[Go to the documentation of this file.](#)

```

1
2 #ifndef ARM_INCLUDE_IrisInstanceDisassembler_h
3 #define ARM_INCLUDE_IrisInstanceDisassembler_h
4
5 #include "iris/detail/IrisCommon.h"
6 #include "iris/detail/IrisDelegate.h"
7 #include "iris/detail/IrisLogger.h"
8 #include "iris/detail/IrisObjects.h"
9
10 #include <cstdio>
11
12 namespace IRIS_START
13 {
14     class IrisInstance;
15     class IrisReceivedRequest;
16
17     typedef IrisDelegate<std::string&> GetCurrentDisassemblyModeDelegate;
18
19     typedef IrisDelegate<uint64_t, const std::string&, MemoryReadResult&,
20         uint64_t, uint64_t, std::vector<DisassemblyLine>&>
21         GetDisassemblyDelegate;
22
23     typedef IrisDelegate<const std::vector<uint64_t>&, uint64_t, const std::string&,
24         DisassembleContext&, DisassemblyLine&>
25         DisassembleOpcodeDelegate;
26
27     /*
28     * @}
29     */
30
31     class IrisInstanceDisassembler
32     {
33     public:
34         IrisInstanceDisassembler(IrisInstance* irisInstance = nullptr);
35
36         void attachTo(IrisInstance* irisInstance);
37
38         void setGetCurrentModeDelegate(GetCurrentDisassemblyModeDelegate delegate)
39         {
40             getCurrentMode = delegate;
41         }
42
43         void setGetDisassemblyDelegate(GetDisassemblyDelegate delegate)
44         {
45             getDisassembly = delegate;
46         }
47
48         void setDisassembleOpcodeDelegate(DisassembleOpcodeDelegate delegate)
49         {
50             disassembleOpcode = delegate;
51         }
52     }
53
54 #endif

```

```

152     void addDisassemblyMode(const std::string& name, const std::string& description);
153
154 private:
155     void impl_disassembler_getModes(IrisReceivedRequest& request);
156
157     void impl_disassembler_getCurrentMode(IrisReceivedRequest& request);
158
159     void impl_disassembler_getDisassembly(IrisReceivedRequest& request);
160
161     void impl_disassembler_disassembleOpcode(IrisReceivedRequest& request);
162
163     void checkDisassemblyMode(std::string& mode, bool& isValidMode);
164
165
166
167
168     IrisInstance* irisInstance;
169
170     GetCurrentDisassemblyModeDelegate getCurrentMode;
171
172     GetDisassemblyDelegate getDisassembly;
173
174     DisassembleOpcodeDelegate disassembleOpcode;
175
176     std::vector<DisassemblyMode> disassemblyModes;
177     IrisLogger log;
178 };
179
180 namespace IRIS_END
181
182 #endif // #ifndef ARM_INCLUDE_IrisInstanceDisassembler_h

```

## 9.27 IrisInstanceEvent.h File Reference

Event add-on to IrisInstance.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include "iris/detail/IrisRequest.h"
#include <cstdio>
#include <set>

```

### Classes

- struct [iris::IrisInstanceEvent::EventSourceInfoAndDelegate](#)  
*Contains the metadata and delegates for a single EventSource.*
- class [iris::EventStream](#)  
*Base class for event streams.*
- class [iris::IrisEventRegistry](#)  
*Class to register Iris event streams for an event.*
- class [iris::IrisEventStream](#)  
*Event stream class for Iris-specific events.*
- class [iris::IrisInstanceEvent](#)  
*Event add-on for [IrisInstance](#).*
- struct [iris::IrisInstanceEvent::ProxyEventInfo](#)  
*Contains information for a single proxy EventSource.*

### Typedefs

- typedef [IrisDelegate< EventStream \\*&, const EventSourceInfo &, const std::vector< std::string > & >](#)  
[iris::EventStreamCreateDelegate](#)  
*Delegate to create an [EventStream](#).*



### 9.27.1 Detailed Description

Event add-on to IrisInstance.

#### Copyright

Copyright (C) 2016-2021 Arm Limited. All rights reserved.

The IrisInstanceEvent class:

- Implements all event-related Iris functions.
- Maintains and provides event source metadata.
- Converts between Iris event functions (event\*()) and various C++ access functions.

### 9.27.2 Typedef Documentation

#### 9.27.2.1 EventStreamCreateDelegate

```
typedef IrisDelegate<EventStream*&, const EventSourceInfo&, const std::vector<std::string>&>
iris::EventStreamCreateDelegate
```

Delegate to create an EventStream.

```
IrisErrorCode create(EventStream *evStream, const EventSourceInfo &srcInfo, const std::vector<std::string>
&fields)
```

Create a new event stream with the specified fields for an event source.

The new event stream is maintained and destroyed in the event add-on.

Error: Return E\_\* error code, for example E\_unknown\_event\_field, if the event stream could not be created.

## 9.28 IrisInstanceEvent.h

[Go to the documentation of this file.](#)

```
1
12 #ifndef ARM_INCLUDE_IrisInstanceEvent_h
13 #define ARM_INCLUDE_IrisInstanceEvent_h
14
15 #include "iris/detail/IrisCommon.h"
16 #include "iris/detail/IrisDelegate.h"
17 #include "iris/detail/IrisLogger.h"
18 #include "iris/detail/IrisObjects.h"
19 #include "iris/detail/IrisRequest.h"
20
21 #include <cstdio>
22 #include <set>
23
24 namespace IRIS_START
25
26 class IrisInstance;
27 class IrisReceivedRequest;
28
29 class EventStream;
30 class IrisEventRegistry;
31
44 typedef IrisDelegate<EventStream*&, const EventSourceInfo&, const std::vector<std::string>&>
    EventStreamCreateDelegate;
45
63 class IrisInstanceEvent
64 {
65 public:
66
67     /* ! What is a proxy event source?
68        - The event source in actual does not belong to this Iris instance, but instead belongs to another
        Iris instance (target).
69        - The event source is registered as a proxy in this Iris instance using Iris interface -
        event_registerProxyEventSource()
70        - This Iris instance acts as a proxy for those registered events.
71        - All interface calls (for example, eventStream_create) on the proxy event source are forwarded to
        the target instance.
72        - Similarly, all the created event streams in this Iris instance for the proxy event source are
        tagged as proxyForOtherInstance
73        - All the interface calls (for example, eventStream_enable) on such proxy event streams are
        forwarded to the target instance.
```

```

74     - Finally, the proxy event source can be deregistered using Iris interface -
event_unregisterProxyEventSource()
75     */
76
80     struct ProxyEventInfo
81     {
82         InstanceId targetInstId{}; //target Iris instance Id
83         EventSourceId targetEvSrcId{}; //event source ID in target Iris instance
84         std::vector<EventStreamId> evStreamIds; //list of created event stream IDs
85         //Important note: When we create an event stream, we use the same esID for both - this and target
Iris instance
86     };
87
91     struct EventSourceInfoAndDelegate
92     {
93         EventSourceInfo info;
94         EventStreamCreateDelegate createEventStream;
95
96         bool isValid{true}; //deleteEventSource() sets isValid to false
97         bool isProxy{false};
98         ProxyEventInfo proxyEventInfo; //contains proper values only if isProxy=true
99     };
100
106     IrisInstanceEvent(IrisInstance* irisInstance = nullptr);
107     ~IrisInstanceEvent();
108
116     void attachTo(IrisInstance* irisInstance);
117
125     void setDefaultEsCreateDelegate(EventStreamCreateDelegate delegate);
126
139     EventSourceInfoAndDelegate& addEventSource(const std::string& name, bool isHidden = false);
140
148     uint64_t addEventSource(const EventSourceInfoAndDelegate& info);
149
158     EventSourceInfoAndDelegate& enhanceEventSource(const std::string& name);
159
165     void deleteEventSource(const std::string& eventName);
166
173     bool hasEventSource(const std::string& eventName);
174
182     const uint64_t *eventBufferGetSyncStepResponse(EventBufferId evBufId, RequestId requestId);
183
192     void eventBufferClear(EventBufferId evBufId);
193
201     bool isValidEvBufId(EventBufferId evBufId) const;
202
203 private:
204     // --- Iris function implementations ---
205
206     void impl_event_getEventSources(IrisReceivedRequest& request);
207
208     void impl_event_getEventSource(IrisReceivedRequest& request);
209
210     void impl_eventStream_create(IrisReceivedRequest& request);
211
212     void impl_eventStream_destroy(IrisReceivedRequest& request);
213
214     void impl_eventStream_enable(IrisReceivedRequest& request);
215
216     void impl_eventStream_disable(IrisReceivedRequest& request);
217
218     void impl_eventStream_getCounter(IrisReceivedRequest& request);
219
220     void impl_eventStream_setTraceRanges(IrisReceivedRequest& request);
221
222     void impl_eventStream_getState(IrisReceivedRequest& request);
223
224     void impl_eventStream_flush(IrisReceivedRequest& request);
225
226     void impl_eventStream_setOptions(IrisReceivedRequest& request);
227
228     void impl_eventStream_action(IrisReceivedRequest& request);
229
230     void impl_eventBuffer_create(IrisReceivedRequest& request);
231
232     void impl_eventBuffer_flush(IrisReceivedRequest& request);
233
234     void impl_eventBuffer_destroy(IrisReceivedRequest& request);
235
236     void impl_ec_eventBuffer(IrisReceivedRequest& request);
237
238     void register_ec_IRIS_INSTANCE_REGISTRY_CHANGED();
239     IrisErrorCode ec_IRIS_INSTANCE_REGISTRY_CHANGED(EventStreamId esId, const IrisValueMap& fields,
uint64_t time,
240                                                     InstanceId sInstId, bool syncEc, std::string&
errorMessageOut);
241

```

```

243
244 void impl_event_registerProxyEventSource(IrisReceivedRequest& request);
245
246 void impl_event_unregisterProxyEventSource(IrisReceivedRequest& request);
247
248 void impl_eventStream_create_proxy(IrisReceivedRequest& request);
249
250 IrisErrorCode impl_eventStream_destroy_target(IrisReceivedRequest& request, EventStream* evStream);
251
252 void impl_eventStream_enable_proxy(IrisReceivedRequest& request, EventStream* evStream);
253
254 void impl_eventStream_disable_proxy(IrisReceivedRequest& request, EventStream* evStream);
255
256 void impl_eventStream_getCounter_proxy(IrisReceivedRequest& request, EventStream* evStream);
257
258 void impl_eventStream_setTraceRanges_proxy(IrisReceivedRequest& request, EventStream* evStream);
259
260 void impl_eventStream_getState_proxy(IrisReceivedRequest& request, EventStream* evStream);
261
262 void impl_eventStream_flush_proxy(IrisReceivedRequest& request, EventStream* evStream);
263
264 void impl_eventStream_setOptions_proxy(IrisReceivedRequest& request, EventStream* evStream);
265
266 void impl_eventStream_action_proxy(IrisReceivedRequest& request, EventStream* evStream);
267
268 ProxyEventInfo& getProxyEventInfo(EventStream* evStream);
269
270 InstanceId getTargetInstId(EventStream* evStream);
271
272
273
274 EventStream* getEventStream(EventStreamId esId);
275
276 struct EventBufferStreamInfo;
277 struct EventBuffer;
278
279 const EventBufferStreamInfo* getEventBufferStreamInfo(InstanceId sInstId, EventStreamId esId) const;
280
281 EventBuffer* getEventBuffer(EventBufferId evBufId) const;
282
283 void eventBufferSend(EventBuffer *eventBuffer, bool flush);
284
285 void eventBufferDestroy(EventBufferId evBufId);
286
287 //Find a free event stream ID where a new EventStream can be added
288 //The returned ID is greater than or equal to 'minEsId'
289 EventStreamId findFreeEventStreamId(EventStreamId minEsId);
290
291
292
293 IrisInstance* irisInstance;
294
295 std::vector<EventSourceInfoAndDelegate> eventSources;
296
297 std::map<std::string, uint64_t> srcNameToId;
298
299 std::vector<EventStream*> eventStreams;
300
301 std::vector<EventStreamId> freeEsIds;
302
303 EventStreamCreateDelegate defaultEsCreateDelegate;
304
305 IrisLogger log;
306
307 bool instance_registry_changed_registered{};
308
309 struct EventStreamOriginInfo
310 {
311     EventStreamId esId;
312     InstanceId sInstId;
313 };
314
315 struct EventBuffer
316 {
317     EventBuffer(const std::string& mode, uint64_t bufferSize, const std::string& ebcFunc, InstanceId
318 ebcInstId, bool syncEbc, EventBufferId evBufId, IrisInstanceEvent *parent);
319
320     ~EventBuffer();
321
322     void clear();
323
324     const uint64_t* getResponse(RequestId requestId);
325
326     void getRequest(bool flush);
327
328     void addEventData(EventStreamInfoId esInfoId, uint64_t time, const uint64_t *fieldsU64Json);
329
330     void dropOldEvents(uint64_t targetBufferSizeU64);
331

```

```

362         std::string mode;
363
364         uint64_t bufferSizeU64{};
365
366         std::string ebcFunc;
367
368         InstanceId ebcInstId{IRIS_UINT64_MAX};
369
370         bool syncEbc{};
371
372         std::vector<EventStreamOriginInfo> eventStreams;
373
374         IrisU64JsonWriter writer;
375
376         uint64_t numEvents{};
377
378         size_t eventDataStartPos{};
379
380         IrisU64JsonWriter responseHeader;
381         size_t responseStartPos{};
382         size_t responseObjectPos{};
383         size_t responseArrayPos{};
384
385         IrisU64JsonWriter requestHeader;
386         size_t requestStartPos{};
387         size_t requestParamsPos{};
388         size_t requestReasonPos{};
389         size_t requestArrayPos{};
390
391         const uint64_t reasonSend = 0x200000646E657304; // == "send"
392         const uint64_t reasonFlush = 0x20006873756C6605; // == "flush"
393
394         IrisInstanceEvent *parent{};
395     };
396     friend struct EventBuffer;
397
398     std::vector<EventBuffer*> eventBuffers;
399
400     std::vector<EventBufferId> freeEventBufferIds;
401
402     struct EventBufferStreamInfo
403     {
404         EventBuffer* eventBuffer{};
405         EventStreamInfoId esInfoId{};
406     };
407
408     std::vector<std::vector<EventBufferStreamInfo>> eventCallbackInfoToEventBufferStreamInfo;
409 };
410
411 class EventStream
412 {
413 public:
414     EventStream()
415         : enabled(false)
416         , req(nullptr)
417         , internal_req(nullptr)
418         , counter(false)
419         , isWaiting(false)
420         , selfReleaseAfterWaiting(false)
421     {
422     }
423
424     virtual ~EventStream() {}
425
426     void selfRelease()
427     {
428         // Disable the event stream if it is still enabled.
429         if (isEnabled())
430         {
431             disable();
432         }
433
434         // The request to destroy this event stream is nested and processed in the delegate to
435         // wait for the response, so it is not multi-threaded and no need to protect the variables.
436         if (!isWaiting)
437         {
438             delete this;
439             return;
440         }
441
442         // It is waiting for the response of the current request.
443         // Cancel the wait and release this object later (after the end of the wait).
444         req->cancel();
445         selfReleaseAfterWaiting = true;
446     }
447
448     virtual IrisErrorCode enable() = 0;

```

```

529
540     virtual IrisErrorCode disable() = 0;
541
551     virtual IrisErrorCode getState(IrisValueMap& fields)
552     {
553         (void) fields;
554         return E_not_supported_for_event_source;
555     }
556
566     virtual IrisErrorCode flush(RequestId requestId)
567     {
568         (void)requestId;
569         return E_not_supported_for_event_source;
570     }
571
589     virtual IrisErrorCode setOptions(const AttributeValueMap& options, bool eventStreamCreate,
std::string& errorMessageOut)
590     {
591         (void)options;
592         (void)eventStreamCreate;
593         (void)errorMessageOut;
594
595         // Event streams which do not support options happily accept an empty options map.
596         return options.empty() ? E_ok : E_not_supported_for_event_source;
597     }
598
609     virtual IrisErrorCode action(const BreakpointAction& action_)
610     {
611         (void)action_;
612         return E_not_supported_for_event_source;
613     }
614
615     // Temporary: Keep PVMODELLIB happy. TODO: Remove.
616     virtual IrisErrorCode insertTrigger()
617     {
618         return E_not_supported_for_event_source;
619     }
620
621
622     // --- Functions for basic properties ---
623
639     void setProperties(IrisInstance* irisInstance, const EventSourceInfo* srcInfo,
640                     InstanceId ecInstId, const std::string& ecFunc, EventStreamId esId,
641                     bool syncEc);
642
648     bool isEnabled() const
649     {
650         return enabled;
651     }
652
658     EventStreamId getEsId() const
659     {
660         return esId;
661     }
662
668     const EventSourceInfo* getEventSourceInfo() const
669     {
670         return srcInfo;
671     }
672
679     InstanceId getEcInstId() const
680     {
681         return ecInstId;
682     }
683
684     // --- Functions for the counter mode ---
685
692     void setCounter(uint64_t startVal, const EventCounterMode& counterMode);
693
699     bool isCounter() const
700     {
701         return counter;
702     }
703
708     void setProxyForOtherInstance()
709     {
710         isProxyForOtherInstance = true;
711     }
712
718     bool isProxyForOtherInstance() const
719     {
720         return isProxyForOtherInstance;
721     }
722
728     void setProxiedByInstanceId(InstanceId instId)
729     {
730         proxiedByInstanceId = instId;

```

```

731     }
732
733     bool IsProxiedByOtherInstance() const
734     {
735         return proxiedByInstanceId != IRIS_UINT64_MAX;
736     }
737
738     InstanceId getProxiedByInstanceId() const
739     {
740         return proxiedByInstanceId;
741     }
742
743     uint64_t getCountVal() const
744     {
745         return curVal;
746     }
747
748     // --- Functions for event stream with ranges
749
750     IrisErrorCode setRanges(const std::string& aspect, const std::vector<uint64_t>& ranges);
751
752     bool checkRangePc(uint64_t pc) const
753     {
754         return ranges.empty() || (aspect != ":pc") || checkRangesHelper(pc, ranges);
755     }
756
757     // --- Functions to emit the event callback ---
758     // Usage (example):
759     //     emitEventBegin(time, pc); // Start to emit the callback.
760     //     addField(...);           // Add field value.
761     //     addField(...);           // Add field value.
762     //     ...
763     //     emitEventEnd();           // Emit the callback.
764
765     void emitEventBegin(IrisRequest& req, uint64_t time, uint64_t pc = IRIS_UINT64_MAX);
766
767     void emitEventBegin(uint64_t time, uint64_t pc = IRIS_UINT64_MAX);
768
769     void addField(const IrisU64StringConstant& field, uint64_t value)
770     {
771         addFieldRangeHelper(field, value);
772     }
773
774     void addField(const IrisU64StringConstant& field, int64_t value)
775     {
776         addFieldRangeHelper(field, value);
777     }
778
779     void addField(const IrisU64StringConstant& field, bool value)
780     {
781         addFieldRangeHelper(field, value);
782     }
783
784     template <class T>
785     void addField(const IrisU64StringConstant& field, const T& value)
786     {
787         fieldObj.member(field, value);
788     }
789
790     void addField(const IrisU64StringConstant& field, const uint8_t *data, size_t sizeInBytes)
791     {
792         fieldObj.member(field, data, sizeInBytes);
793     }
794
795     void addFieldSlow(const std::string& field, uint64_t value)
796     {
797         addFieldSlowRangeHelper(field, value);
798     }
799
800     void addFieldSlow(const std::string& field, int64_t value)
801     {
802         addFieldSlowRangeHelper(field, value);
803     }
804
805     void addFieldSlow(const std::string& field, bool value)
806     {
807         addFieldSlowRangeHelper(field, value);
808     }
809
810     template <class T>
811     void addFieldSlow(const std::string& field, const T& value)
812     {
813         fieldObj.memberSlow(field, value);
814     }
815
816     void addFieldSlow(const std::string& field, const uint8_t *data, size_t sizeInBytes)
817     {

```

```

952         fieldObj.memberSlow(field, data, sizeInBytes);
953     }
954
955     void emitEventEnd(bool send = true);
956
957 private:
958
959     bool counterTrigger();
960
961     bool checkRanges() const
962     {
963         return !aspectFound || checkRangesHelper(curAspectValue, ranges);
964     }
965
966     static bool checkRangesHelper(uint64_t value, const std::vector<uint64_t>& ranges);
967
968     template <typename T>
969     void addFieldRangeHelper(const IrisU64StringConstant& field, T value)
970     {
971         if (!aspect.empty() && aspect == toString(field))
972         {
973             aspectFound = true;
974             curAspectValue = static_cast<uint64_t>(value);
975         }
976
977         fieldObj.member(field, value);
978     }
979
980     template <typename T>
981     void addFieldSlowRangeHelper(const std::string& field, T value)
982     {
983         if (aspect == field)
984         {
985             aspectFound = true;
986             curAspectValue = static_cast<uint64_t>(value);
987         }
988
989         fieldObj.memberSlow(field, value);
990     }
991
992 protected:
993
994     IrisInstance* irisInstance;
995
996     const EventSourceInfo* srcInfo;
997
998     InstanceId ecInstId;
999
1000     std::string ecFunc;
1001
1002     EventStreamId esId;
1003
1004     bool syncEc;
1005
1006     bool enabled;
1007
1008     IrisRequest* req;
1009     IrisRequest* internal_req;
1010     IrisU64JsonWriter::Object fieldObj;
1011
1012     bool counter;
1013
1014     uint64_t startVal;
1015     uint64_t curVal;
1016
1017     EventCounterMode counterMode;
1018
1019     std::string aspect;
1020     std::vector<uint64_t> ranges;
1021
1022     bool aspectFound;
1023
1024     uint64_t curAspectValue;
1025
1026     bool isProxyForOtherInstance{false};
1027
1028     InstanceId proxiedByInstanceId{IRIS_UINT64_MAX};
1029
1030 private:
1031     bool isWaiting;
1032
1033     bool selfReleaseAfterWaiting;
1034 };
1035
1036 class IrisEventStream : public EventStream

```

```

1081 {
1082 public:
1083     IrisEventStream(IrisEventRegistry* registry_);
1084
1085     virtual IrisErrorCode enable() IRIS_OVERRIDE;
1086
1087     virtual IrisErrorCode disable() IRIS_OVERRIDE;
1088
1089 private:
1090     IrisEventRegistry* registry;
1091 };
1092
1093 class IrisEventRegistry
1094 {
1095 public:
1096     bool empty() const
1097     {
1098         return esSet.empty();
1099     }
1100
1101     bool registerEventStream(EventStream* evStream);
1102
1103     bool unregisterEventStream(EventStream* evStream);
1104
1105     // --- Functions to emit the callback of all registered event streams ---
1106     // Usage (example):
1107     //     emitEventBegin(time, pc);    // Start to emit the callback.
1108     //     addField(...);              // Add field value.
1109     //     addField(...);              // Add field value.
1110     //     ...
1111     //     emitEventEnd();              // Emit the callback.
1112
1113     void emitEventBegin(uint64_t time, uint64_t pc = IRIS_UINT64_MAX) const;
1114
1115     template <class T>
1116     void addField(const IrisU64StringConstant& field, const T& value) const
1117     {
1118         for (std::set<EventStream*>::const_iterator i = esSet.begin(), e = esSet.end(); i != e; i++)
1119             (*i)->addField(field, value);
1120     }
1121
1122     template <class T>
1123     void addFieldSlow(const std::string& field, const T& value) const
1124     {
1125         for (std::set<EventStream*>::const_iterator i = esSet.begin(), e = esSet.end(); i != e; i++)
1126             (*i)->addFieldSlow(field, value);
1127     }
1128
1129     template <class T, typename F>
1130     void forEach(F && func) const
1131     {
1132         for (std::set<EventStream*>::const_iterator i = esSet.begin(), e = esSet.end(); i != e; i++)
1133         {
1134             T* t = static_cast<T*>(*i);
1135             func(*t);
1136         }
1137     }
1138
1139     void emitEventEnd() const;
1140
1141     typedef std::set<EventStream*>::const_iterator iterator;
1142
1143     iterator begin() const
1144     {
1145         return esSet.begin();
1146     }
1147
1148     iterator end() const
1149     {
1150         return esSet.end();
1151     }
1152
1153     ~IrisEventRegistry()
1154     {
1155         // Disable any remaining event streams.
1156         // Calling disable() on an EventStream will cause esSet to be modified so we need to loop
1157         without
1158         // using iterators which become invalidated.
1159         while (!esSet.empty())
1160         {
1161             (*esSet.begin())->disable();
1162         }
1163     }
1164
1165 private:
1166     // All registered event streams
1167     std::set<EventStream*> esSet;

```



```

1250 };
1251
1252 NAMESPACE_IRIS_END
1253
1254 #endif // #ifndef ARM_INCLUDE_IrisInstanceBreakpoint_h

```

## 9.29 IrisInstanceFactoryBuilder.h File Reference

A helper class to build instantiation parameter metadata.

```

#include "iris/IrisParameterBuilder.h"
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisObjects.h"
#include <string>
#include <vector>

```

### Classes

- class [iris::IrisInstanceFactoryBuilder](#)  
*A builder class to construct instantiation parameter metadata.*

### 9.29.1 Detailed Description

A helper class to build instantiation parameter metadata.

#### Copyright

Copyright (C) 2017 Arm Limited. All rights reserved.

## 9.30 IrisInstanceFactoryBuilder.h

[Go to the documentation of this file.](#)

```

1
7 #ifndef ARM_INCLUDE_IrisInstanceFactoryBuilder_h
8 #define ARM_INCLUDE_IrisInstanceFactoryBuilder_h
9
10 #include "iris/IrisParameterBuilder.h"
11 #include "iris/detail/IrisCommon.h"
12 #include "iris/detail/IrisObjects.h"
13
14 #include <string>
15 #include <vector>
16
17 NAMESPACE_IRIS_START
18
22 class IrisInstanceFactoryBuilder
23 {
24 private:
26     std::vector<ResourceInfo> parameters;
27
29     std::vector<ResourceInfo> hidden_parameters;
30
32     std::string parameter_prefix;
33
34     ResourceInfo& addParameterInternal(const std::string& name, uint64_t bitWidth, const std::string&
description,
35                                     const std::string& type, bool hidden)
36     {
37         std::vector<ResourceInfo>& param_list = hidden ? hidden_parameters : parameters;
38         param_list.resize(parameters.size() + 1);
39         ResourceInfo& info = param_list.back();
40
41         info.name      = name;
42         info.bitWidth  = bitWidth;
43         info.description = description;
44         info.type      = type;
45
46         return info;
47     }
48
49 public:
55     IrisInstanceFactoryBuilder(const std::string& prefix)

```

```

56         : parameter_prefix(prefix)
57     {
58     }
59
60     IrisParameterBuilder addParameter(const std::string& name, uint64_t bitWidth, const std::string&
description)
61     {
62         return IrisParameterBuilder(addParameterInternal(parameter_prefix + name, bitWidth, description,
63         "" /*numeric*/, false));
64     }
65
66     IrisParameterBuilder addHiddenParameter(const std::string& name, uint64_t bitWidth, const
std::string& description)
67     {
68         return IrisParameterBuilder(addParameterInternal(parameter_prefix + name, bitWidth, description,
69         "" /*numeric*/, true));
70     }
71
72     IrisParameterBuilder addStringParameter(const std::string& name, const std::string& description)
73     {
74         return IrisParameterBuilder(addParameterInternal(parameter_prefix + name, 0, description,
75         "string", false));
76     }
77
78     IrisParameterBuilder addHiddenStringParameter(const std::string& name, const std::string&
description)
79     {
80         return IrisParameterBuilder(addParameterInternal(parameter_prefix + name, 0, description,
81         "string", true));
82     }
83
84     IrisParameterBuilder addBooleanParameter(const std::string& name, const std::string& description)
85     {
86         ResourceInfo& info = addParameterInternal(parameter_prefix + name, 1, description, "numeric",
87         false);
88
89         // Be explicit about the range even though there are only two possible values anyway.
90         info.parameterInfo.min.push_back(0);
91         info.parameterInfo.max.push_back(1);
92
93         // Add enum strings for the values
94         info.enums.push_back(EnumElementInfo(IrisValue(0), "false", ""));
95         info.enums.push_back(EnumElementInfo(IrisValue(1), "true", ""));
96
97         return IrisParameterBuilder(info);
98     }
99
100    IrisParameterBuilder addHiddenBooleanParameter(const std::string& name, const std::string&
description)
101    {
102        ResourceInfo& info = addParameterInternal(parameter_prefix + name, 1, description, "numeric",
103        true);
104
105        // Be explicit about the range even though there are only two possible values anyway.
106        info.parameterInfo.min.push_back(0);
107        info.parameterInfo.max.push_back(1);
108
109        // Add enum strings for the values
110        info.enums.push_back(EnumElementInfo(IrisValue(0), "false", ""));
111        info.enums.push_back(EnumElementInfo(IrisValue(1), "true", ""));
112
113        return IrisParameterBuilder(info);
114    }
115
116    const std::vector<ResourceInfo>& getParameterInfo() const
117    {
118        return parameters;
119    }
120
121    const std::vector<ResourceInfo>& getHiddenParameterInfo() const
122    {
123        return hidden_parameters;
124    }
125 };
126
127 namespace IRIS_END
128
129 #endif // ARM_INCLUDE_IrisInstanceFactoryBuilder_h

```

## 9.31 IrisInstanceImage.h File Reference

Image-loading add-on to IrisInstance and image-loading callback add-on to the caller.

```
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include <cstdio>
```

## Classes

- class [iris::IrisInstancelImage](#)  
*Image loading add-on for [IrisInstance](#).*
- class [iris::IrisInstancelImage\\_Callback](#)  
*Image loading add-on for [IrisInstance](#) clients implementing `image_loadDataRead()`.*

## Typedefs

- typedef `IrisDelegate< const std::vector< uint8_t > & > iris::ImageLoadDataDelegate`  
*Delegate to load an image from the given data.*
- typedef `IrisDelegate< const std::string & > iris::ImageLoadFileDelegate`  
*Delegate function to load an image from the given file.*

### 9.31.1 Detailed Description

Image-loading add-on to `IrisInstance` and image-loading callback add-on to the caller.

#### Copyright

Copyright (C) 2016-2022 Arm Limited. All rights reserved.

The `IrisInstancelImage` class:

- Implements all image-loading Iris functions.
- Maintains and provides image metadata, for example `path`, `instanceSideFile`, `rawAddr`.
- Converts between Iris image-loading functions (`image_load*()`) and various C++ access functions.

### 9.31.2 Typedef Documentation

#### 9.31.2.1 ImageLoadDataDelegate

```
typedef IrisDelegate<const std::vector<uint8_t>&> iris::ImageLoadDataDelegate
```

Delegate to load an image from the given data.

```
IrisErrorCode loadImage(const std::vector<uint8_t> &data)
```

Typical implementations try to load the data with the supported formats.

Errors:

- If the image format is unknown, `E_unknown_image_format` is returned.
- If the image format is known but the image could not be loaded, `E_image_format_error` is returned.

### 9.31.2.2 ImageLoadFileDelegate

typedef IrisDelegate<const std::string&> iris::ImageLoadFileDelegate

Delegate function to load an image from the given file.

The path can be absolute or relative to the current working directory.

IrisErrorCode loadImage(const std::string &path)

Typical implementations try to load the file with the supported formats.

Errors:

- If the file specified by path could not be opened, E\_error\_opening\_file is returned.
- If the file could be opened but could not be read, E\_io\_error is returned.
- If the image format is unknown, E\_unknown\_image\_format is returned.
- If the image format is known but the image could not be loaded, E\_image\_format\_error is returned.

## 9.32 IrisInstanceImage.h

[Go to the documentation of this file.](#)

```

1
13 #ifndef ARM_INCLUDE_IrisInstanceImage_h
14 #define ARM_INCLUDE_IrisInstanceImage_h
15
16 #include "iris/detail/IrisCommon.h"
17 #include "iris/detail/IrisDelegate.h"
18 #include "iris/detail/IrisLogger.h"
19 #include "iris/detail/IrisObjects.h"
20
21 #include <cstdio>
22
23 NAMESPACE_IRIS_START
24
25 class IrisInstance;
26 class IrisReceivedRequest;
27
44 typedef IrisDelegate<const std::string&> ImageLoadFileDelegate;
45
59 typedef IrisDelegate<const std::vector<uint8_t>&> ImageLoadDataDelegate;
60
77 class IrisInstanceImage
78 {
79
80 public:
86     IrisInstanceImage(IrisInstance* irisInstance = 0);
87
93     void attachTo(IrisInstance* irisInstance);
94
100     void setLoadImageFileDelegate(ImageLoadFileDelegate delegate);
101
107     void setLoadImageDataDelegate(ImageLoadDataDelegate delegate);
108
116     static IrisErrorCode readFileData(const std::string& fileName, std::vector<uint8_t>& data);
117
118 private:
120     void loadImageFromData(IrisReceivedRequest& request, const ImageReadResult& imageData);
121
123
125     void impl_image_loadFile(IrisReceivedRequest& request);
126
128     void impl_image_loadData(IrisReceivedRequest& request);
129
131     void impl_image_loadDataPull(IrisReceivedRequest& request);
132
133     void impl_image_getMetaInfoList(IrisReceivedRequest& request);
134
135     void impl_image_clearMetaInfoList(IrisReceivedRequest& request);
136
138     void writeRawDataToMemory(IrisReceivedRequest& request, const std::vector<uint8_t>& data, uint64_t
rawAddr, MemorySpaceId rawSpaceId);
139
141     IrisErrorCode pullData(InstanceId callerId, uint64_t tag, ImageReadResult& result);
142
144
146     IrisInstance* irisInstance;
147
151     typedef std::vector<ImageMetaInfo> ImageMetaInfoList;
152     ImageMetaInfoList metaInfos;
153
155     IrisLogger log;

```

```

156
157     ImageLoadFileDelegate loadFileDelegate;
158     ImageLoadDataDelegate loadDataDelegate;
159 };
160
161 class IrisInstanceImage_Callback
162 {
163 public:
164     IrisInstanceImage_Callback(IrisInstance* irisInstance = 0);
165
166     ~IrisInstanceImage_Callback();
167
168     void attachTo(IrisInstance* irisInstance);
169
170     uint64_t openImage(const std::string& fileName);
171
172 protected:
173     void impl_image_loadDataRead(IrisReceivedRequest& request);
174
175 private:
176     IrisErrorCode readImageData(uint64_t tag, uint64_t position, uint64_t size, bool end,
177                                ImageReadResult& result);
178
179     IrisInstance* irisInstance;
180
181     IrisLogger log;
182
183     typedef std::vector<FILE*> ImageList;
184     ImageList images;
185 };
186
187 namespace IRIS
188 {
189     #endif // #ifndef ARM_INCLUDE_IrisInstanceImage_h

```

## 9.33 IrisInstanceMemory.h File Reference

Memory add-on to IrisInstance.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"

```

### Classes

- struct [iris::IrisInstanceMemory::AddressTranslationInfoAndAccess](#)  
*Contains static address translation information.*
- class [iris::IrisInstanceMemory](#)  
*Memory add-on for [IrisInstance](#).*
- struct [iris::IrisInstanceMemory::SpaceInfoAndAccess](#)  
*Entry in 'spaceInfos'.*

### Typedefs

- typedef [IrisDelegate< uint64\\_t, uint64\\_t, uint64\\_t, MemoryAddressTranslationResult & >](#) [iris::MemoryAddressTranslateDelegate](#)  
*Delegate to translate an address.*
- typedef [IrisDelegate< const MemorySpaceInfo &, uint64\\_t, const IrisValueMap &, const std::vector< std::string > &, IrisValueMap & >](#) [iris::MemoryGetSidebandInfoDelegate](#)
- typedef [IrisDelegate< const MemorySpaceInfo &, uint64\\_t, uint64\\_t, uint64\\_t, const AttributeValueMap &, MemoryReadResult & >](#) [iris::MemoryReadDelegate](#)  
*Delegate to read memory data.*
- typedef [IrisDelegate< const MemorySpaceInfo &, uint64\\_t, uint64\\_t, uint64\\_t, const AttributeValueMap &, const uint64\\_t \\*, MemoryWriteResult & >](#) [iris::MemoryWriteDelegate](#)  
*Delegate to write memory data.*

### 9.33.1 Detailed Description

Memory add-on to IrisInstance.

#### Copyright

Copyright (C) 2015 Arm Limited. All rights reserved.

The IrisInstanceMemory class:

- Implements all memory-related Iris functions.
- Feeds memory-related properties (memory.\*) to instance\_getProperties() of the associated IrisInstance.
- Provides infrastructure that is useful for Iris clients.
- Maintains and provides memory meta information (memory spaces, address translations, sideband information).
- Converts between Iris memory access functions (memory\_read()) and various C++ access functions.

### 9.33.2 Typedef Documentation

#### 9.33.2.1 MemoryAddressTranslateDelegate

```
typedef IrisDelegate<uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult&> iris::MemoryAddressTransl
```

Delegate to translate an address.

```
IrisErrorCode translate(MemorySpaceId inSpaceId, uint64_t address,
                      MemorySpaceId outSpaceId, MemoryAddressTranslationResult &result)
```

inSpaceId, address, and outSpaceId are guaranteed to be valid.

Typical implementations inspect the inSpaceId and outSpaceId to determine how to translate the address.

Return addresses are appended to result.address, which is a vector<uint64\_t>:

- If this array is empty then 'address' is not mapped in 'outSpaceId'.
- If the array contains exactly one element then the mapping is unique.
- If it contains multiple addresses then 'address' is accessible in the same way under all of these addresses in 'outSpaceId'.

Error: Return E\_\* error code for translation errors.

#### 9.33.2.2 MemoryGetSidebandInfoDelegate

```
typedef IrisDelegate<const MemorySpaceInfo&, uint64_t, const IrisValueMap&, const std::vector<std::string>&,
                    IrisValueMap&> iris::MemoryGetSidebandInfoDelegate
```

@ Delegate to get memory sideband information.

```
IrisErrorCode getSidebandInfo(const MemorySpaceInfo &spaceInfo, uint64_t address,
                             const IrisValueMap &attrib,
                             const std::vector<std::string> &request,
                             IrisValueMap &result)
```

Returns sideband information for a range of addresses in a given memory space.

#### 9.33.2.3 MemoryReadDelegate

```
typedef IrisDelegate<const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t, const AttributeValueMap&,
                    MemoryReadResult&> iris::MemoryReadDelegate
```

Delegate to read memory data.

```
IrisErrorCode read(const MemorySpaceInfo &spaceInfo, uint64_t address, uint64_t byteWidth,
                  uint64_t count, const AttributeValueMap &attrib, MemoryReadResult &result)
```

spaceInfo, address, byteWidth, and count are guaranteed to be valid.

Typical implementations inspect the spaceId, address, byteWidth, and count to determine which memory elements should be read. Then they append the read elements to result.data, which is a vector<uint64\_t>:

- Data elements are read from ascending addresses, packed into uint64\_ts such that the lowest address is in the lowest bits.
- Elements of byteWidth  $\geq 2$  are read with the endianness of the memory space inside each element, but elements are stored with the lowest bits inside each uint64\_t (for byteWidth  $< 8$ ) and with the lowest bits first in sequences of uint64\_t (for byteWidth  $> 8$ ).

Error: Return E\_\* error code for read errors. It appends the address that could not be read to result.error.

#### 9.33.2.4 MemoryWriteDelegate

```
typedef IrisDelegate<const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t, const Attribute↵
ValueMap&, const uint64_t*, MemoryWriteResult&> iris::MemoryWriteDelegate
Delegate to write memory data.
IrisErrorCode write(const MemorySpaceInfo &spaceInfo, uint64_t address, uint64_t byteWidth,
                    uint64_t count, const AttributeValueMap &attrib, const uint64_t *data, MemoryWriteResult
                    &result)
```

See also

MemoryReadDelegate data contains the data elements to be written in the same format as MemoryRead↵  
Result.data for reads.

## 9.34 IrisInstanceMemory.h

[Go to the documentation of this file.](#)

```
1
14 #ifndef ARM_INCLUDE_IrisInstanceMemory_h
15 #define ARM_INCLUDE_IrisInstanceMemory_h
16
17 #include "iris/detail/IrisCommon.h"
18 #include "iris/detail/IrisDelegate.h"
19 #include "iris/detail/IrisLogger.h"
20 #include "iris/detail/IrisObjects.h"
21
22 namespace IRIS_START
23
24 class IrisInstance;
25 class IrisReceivedRequest;
26
27 typedef IrisDelegate<const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t,
28                     const AttributeValueMap&, MemoryReadResult&>
29     MemoryReadDelegate;
30
31 typedef IrisDelegate<const MemorySpaceInfo&, uint64_t, uint64_t, uint64_t,
32                     const AttributeValueMap&, const uint64_t*, MemoryWriteResult&>
33     MemoryWriteDelegate;
34
35 typedef IrisDelegate<uint64_t, uint64_t, uint64_t, MemoryAddressTranslationResult&>
36     MemoryAddressTranslateDelegate;
37
38 typedef IrisDelegate<const MemorySpaceInfo&, uint64_t, const IrisValueMap&,
39                     const std::vector<std::string>&, IrisValueMap&>
40     MemoryGetSidebandInfoDelegate;
41
42 class IrisInstanceMemory
43 {
44 public:
45     struct SpaceInfoAndAccess
46     {
47         MemorySpaceInfo    spaceInfo;
48         MemoryReadDelegate readDelegate;    // May be empty. In this case
49         defaultReadDelegate is used.
50         MemoryWriteDelegate writeDelegate;  // May be empty. In this case
51         defaultWriteDelegate is used.
52         MemoryGetSidebandInfoDelegate sidebandDelegate; // May be empty. In this case sidebandDelegate
53         is used.
54     };
55
56     struct AddressTranslationInfoAndAccess
57     {
58         AddressTranslationInfoAndAccess (MemorySpaceId inSpaceId, MemorySpaceId outSpaceId, const
59         std::string& description)
60             : translationInfo(inSpaceId, outSpaceId, description)
61         {
62         }
63     };
64
65     MemorySupportedAddressTranslationResult translationInfo;
```

```

156     MemoryAddressTranslateDelegate    translateDelegate;
157 };
158
165 IrisInstanceMemory(IrisInstance* irisInstance = 0);
166
172 void attachTo(IrisInstance* irisInstance);
173
179 void setDefaultReadDelegate(MemoryReadDelegate delegate = MemoryReadDelegate())
180 {
181     memReadDelegate = delegate;
182 }
183
189 void setDefaultWriteDelegate(MemoryWriteDelegate delegate = MemoryWriteDelegate())
190 {
191     memWriteDelegate = delegate;
192 }
193
201 SpaceInfoAndAccess& addMemorySpace(const std::string& name);
202
213 AddressTranslationInfoAndAccess& addAddressTranslation(MemorySpaceId inSpaceId, MemorySpaceId
outSpaceId,
214                                                         const std::string& description);
215
221 void setDefaultTranslateDelegate(MemoryAddressTranslateDelegate delegate =
MemoryAddressTranslateDelegate())
222 {
223     translateDelegate = delegate;
224 }
225
231 void setDefaultGetSidebandInfoDelegate(MemoryGetSidebandInfoDelegate delegate =
MemoryGetSidebandInfoDelegate())
232 {
233     if (delegate.empty())
234     {
235         delegate = MemoryGetSidebandInfoDelegate::make<IrisInstanceMemory,
&IrisInstanceMemory::getDefaultSidebandInfo>(this);
236     }
237     sidebandDelegate = delegate;
238 }
239
240 private:
241
244 void impl_memory_getMemorySpaces(IrisReceivedRequest& request);
245
246 void impl_memory_read(IrisReceivedRequest& request);
247
248 void impl_memory_write(IrisReceivedRequest& request);
249
250 void impl_memory_translateAddress(IrisReceivedRequest& request);
251
252 void impl_memory_getUsefulAddressTranslations(IrisReceivedRequest& request);
253
254 void impl_memory_getSidebandInfo(IrisReceivedRequest& request);
255
258 IrisErrorCode getDefaultSidebandInfo(const MemorySpaceInfo& spaceInfo, uint64_t address,
259                                     const IrisValueMap& attrib,
260                                     const std::vector<std::string>& request,
261                                     IrisValueMap& result);
262 // --- state ---
263
265 IrisInstance* irisInstance;
266
268 typedef std::vector<SpaceInfoAndAccess> SpaceInfoList;
269 SpaceInfoList spaceInfos;
270
272 typedef std::vector<AddressTranslationInfoAndAccess> SupportedTranslations;
273 SupportedTranslations supportedTranslations;
274
276 MemoryReadDelegate memReadDelegate;
277 MemoryWriteDelegate memWriteDelegate;
278 MemoryAddressTranslateDelegate translateDelegate;
279
282 MemoryGetSidebandInfoDelegate sidebandDelegate;
283
285 IrisLogger log;
286 };
287
288 namespace IRIS_END
289
290 #endif // #ifndef ARM_INCLUDE_IrisInstanceMemory_h

```



## 9.35 IrisInstancePerInstanceExecution.h File Reference

Per-instance execution control add-on to IrisInstance.

```
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include <cstdio>
```

### Classes

- class [iris::IrisInstancePerInstanceExecution](#)  
*Per-instance execution control add-on for [IrisInstance](#).*

### Typedefs

- typedef IrisDelegate< bool & > [iris::PerInstanceExecutionStateGetDelegate](#)  
*Get the execution state.*
- typedef IrisDelegate< bool > [iris::PerInstanceExecutionStateSetDelegate](#)  
*Delegate to set the execution state.*

### 9.35.1 Detailed Description

Per-instance execution control add-on to IrisInstance.

#### Copyright

Copyright (C) 2016 Arm Limited. All rights reserved.

Implements all per-instance execution control-related Iris functions.

### 9.35.2 Typedef Documentation

#### 9.35.2.1 PerInstanceExecutionStateGetDelegate

```
typedef IrisDelegate<bool&> iris::PerInstanceExecutionStateGetDelegate
```

Get the execution state.

*enabled* should be set to true if execution is enabled and false otherwise.

```
IrisErrorCode getState(bool &enabled)
```

Return E\_ok on success, otherwise return the error code.

#### 9.35.2.2 PerInstanceExecutionStateSetDelegate

```
typedef IrisDelegate<bool> iris::PerInstanceExecutionStateSetDelegate
```

Delegate to set the execution state.

Enable or disable the execution of instructions (or processing of work items).

```
IrisErrorCode setState(bool enable)
```

Return E\_ok on success, otherwise return the error code.

## 9.36 IrisInstancePerInstanceExecution.h

[Go to the documentation of this file.](#)

```
1
9 #ifndef ARM_INCLUDE_IrisInstancePerInstanceExecution_h
10 #define ARM_INCLUDE_IrisInstancePerInstanceExecution_h
11
12 #include "iris/detail/IrisCommon.h"
13 #include "iris/detail/IrisDelegate.h"
```

```

14 #include "iris/detail/IrisLogger.h"
15 #include "iris/detail/IrisObjects.h"
16
17 #include <cstdio>
18
19 NAMESPACE_IRIS_START
20
21 class IrisInstance;
22 class IrisReceivedRequest;
23
24 typedef IrisDelegate<bool> PerInstanceExecutionStateSetDelegate;
25
26 typedef IrisDelegate<bool&> PerInstanceExecutionStateGetDelegate;
27
28 class IrisInstancePerInstanceExecution
29 {
30 public:
31     IrisInstancePerInstanceExecution(IrisInstance* irisInstance = nullptr);
32
33     void attachTo(IrisInstance* irisInstance);
34
35     void setExecutionStateSetDelegate(PerInstanceExecutionStateSetDelegate delegate);
36
37     void setExecutionStateGetDelegate(PerInstanceExecutionStateGetDelegate delegate);
38
39 private:
40     void impl_perInstanceExecution_setState(IrisReceivedRequest& request);
41
42     void impl_perInstanceExecution_getState(IrisReceivedRequest& request);
43
44     IrisInstance* irisInstance;
45
46     PerInstanceExecutionStateSetDelegate execStateSet;
47     PerInstanceExecutionStateGetDelegate execStateGet;
48
49     IrisLogger log;
50 };
51
52 NAMESPACE_IRIS_END
53
54 #endif // #ifndef ARM_INCLUDE_IrisInstancePerInstanceExecution_h

```

## 9.37 IrisInstanceResource.h File Reference

Resource add-on to IrisInstance.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include <cassert>

```

### Classes

- class [iris::IrisInstanceResource](#)  
*Resource add-on for [IrisInstance](#).*
- struct [iris::IrisInstanceResource::ResourceInfoAndAccess](#)  
*Entry in 'resourceInfos'.*
- struct [iris::ResourceWriteValue](#)

### Typedefs

- typedef IrisDelegate< const ResourceInfo &, ResourceReadResult & > [iris::ResourceReadDelegate](#)  
*Delegate to read resources.*
- typedef IrisDelegate< const ResourceInfo &, const ResourceWriteValue & > [iris::ResourceWriteDelegate](#)  
*Delegate to write resources.*

## Functions

- `uint64_t iris::resourceReadBitField` (`uint64_t` parentValue, `const ResourceInfo &resourceInfo`)
- `template<class T >`  
`void iris::resourceWriteBitField` (`T &parentValue`, `uint64_t` fieldValue, `const ResourceInfo &resourceInfo`)

### 9.37.1 Detailed Description

Resource add-on to `IrisInstance`.

#### Copyright

Copyright (C) 2015-2019 Arm Limited. All rights reserved.

The `IrisInstanceResource` class:

- Implements all resource-related Iris functions.
- Feeds resource-related properties (`resource.*`) to `instance_getProperties()` of the associated `IrisInstance`.
- Provides infrastructure that is useful for Iris clients.
- Maintains and provides resource meta information (name, bitwidth).
- Converts between Iris resource-access functions (`resource_read()`) and various C++ access functions.

### 9.37.2 Typedef Documentation

#### 9.37.2.1 ResourceReadDelegate

```
typedef IrisDelegate<const ResourceInfo&, ResourceReadResult&> iris::ResourceReadDelegate
```

Delegate to read resources.

```
IrisErrorCode read(const ResourceInfo &resourceInfo, ResourceReadResult &result)
```

`resourceInfo.rsclId` is guaranteed to be valid.

Typical implementations inspect the `rsclId`, `canonicalRn`, `addressOffset`, or even the name or `cname` value to determine which resource should be read and then append the read data to `result`:

- Return data (no undefined bits):
  - Append data to `result.data`, which is a `vector<uint64_t>`. Append one `uint64_t` if resource is  $\leq 64$  bits.
  - Append multiple `uint64_t` for wider resources, least significant `uint64_t` first.
- Return data with undefined bits:
  - Same as above, but in addition, append a mask which contains 1 bit for all undefined bits to `result.← undefinedBits` (same format and length as `result.data`) and set all undefined bits to 0 in `result.data`.

Error: If the resource could not be read, return `E_*` error code, for example `E_error_reading_write_only_resource`, `E_error_reading_resource`, or `E_not_implemented`, and leave `result` unchanged.

#### 9.37.2.2 ResourceWriteDelegate

```
typedef IrisDelegate<const ResourceInfo&, const ResourceWriteValue&> iris::ResourceWriteDelegate
```

Delegate to write resources.

```
IrisErrorCode write(const ResourceInfo &resourceInfo, const ResourceWriteValue &value)
```

`resourceInfo.rsclId` is guaranteed to be valid.

Typical implementations inspect the `rsclId`, `canonicalRn`, `addressOffset`, or even the name or `cname` value to determine which resource should be written.

`data` contains the data for all resources to be written in the same format as `ResourceReadResult.data` for reads. The number of elements in the data array is `resourceInfo.getDataSizeInU64Chunks()`. `data` is only evaluated for string resources.

### 9.37.3 Function Documentation

#### 9.37.3.1 resourceReadBitField()

```
uint64_t iris::resourceReadBitField (
    uint64_t parentValue,
    const ResourceInfo & resourceInfo ) [inline]
```

Helper for ResourceReadDelegates to read a bit field of a parent register according to the lsbOffset and bitWidth in resourceInfo. This helps reducing redundancy in the debug interface implementation.

#### 9.37.3.2 resourceWriteBitField()

```
template<class T >
void iris::resourceWriteBitField (
    T & parentValue,
    uint64_t fieldValue,
    const ResourceInfo & resourceInfo ) [inline]
```

Helper for ResourceWriteDelegates to write a bit field of a parent register according to the lsbOffset and bitWidth in resourceInfo. This helps reducing redundancy in the debug interface implementation.

## 9.38 IrisInstanceResource.h

[Go to the documentation of this file.](#)

```
1
14 #ifndef ARM_INCLUDE_IrisInstanceResource_h
15 #define ARM_INCLUDE_IrisInstanceResource_h
16
17 #include "iris/detail/IrisCommon.h"
18 #include "iris/detail/IrisDelegate.h"
19 #include "iris/detail/IrisLogger.h"
20 #include "iris/detail/IrisObjects.h"
21
22 #include <cassert>
23
24 NAMESPACE_IRIS_START
25
26 class IrisInstance;
27 class IrisReceivedRequest;
28
32 inline uint64_t resourceReadBitField(uint64_t parentValue, const ResourceInfo& resourceInfo)
33 {
34     return (resourceInfo.registerInfo.lsbOffset < 64) ?
35         ((parentValue » resourceInfo.registerInfo.lsbOffset) & maskWidthLsb(resourceInfo.bitWidth, 0))
36         : 0;
37 }
38
39
43 template<class T>
44 inline void resourceWriteBitField(T& parentValue, uint64_t fieldValue, const ResourceInfo& resourceInfo)
45 {
46     T mask = T(maskWidthLsb(resourceInfo.bitWidth, resourceInfo.registerInfo.lsbOffset));
47     parentValue &= ~mask;
48     parentValue |= (resourceInfo.registerInfo.lsbOffset < 64) ?
49         ((fieldValue « resourceInfo.registerInfo.lsbOffset) & mask)
50         : 0;
51 }
52
53
58 struct ResourceWriteValue
59 {
60     const uint64_t* data{};
61     const std::string* str{};
62 };
63
64
65
89 typedef IrisDelegate<const ResourceInfo&, ResourceReadResult&> ResourceReadDelegate;
90
106 typedef IrisDelegate<const ResourceInfo&, const ResourceWriteValue&> ResourceWriteDelegate;
107
120 class IrisInstanceResource
121 {
122 public:
128     struct ResourceInfoAndAccess
```

```

129     {
130         ResourceInfo      resourceInfo;
131         ResourceReadDelegate readDelegate; // May be invalid. In this case defaultReadDelegate is
used.
132         ResourceWriteDelegate writeDelegate; // May be invalid. In this case defaultWriteDelegate is
used.
133     };
134
141     IrisInstanceResource(IrisInstance* irisInstance = 0);
142
148     void attachTo(IrisInstance* irisInstance);
149
163     ResourceInfoAndAccess& addResource(const std::string& type,
164                                       const std::string& name,
165                                       const std::string& description);
166
179     void beginResourceGroup(const std::string& name,
180                             const std::string& description,
181                             uint64_t          startSubRscId = IRIS_UINT64_MAX,
182                             const std::string& cname         = std::string());
183
193     void setNextSubRscId(ResourceId nextSubRscId_)
194     {
195         nextSubRscId = nextSubRscId_;
196     }
197
206     void setTag(ResourceId rscId, const std::string& tag);
207
216     ResourceInfoAndAccess* getResourceInfo(ResourceId rscId);
217
238     static void calcHierarchicalNames(std::vector<ResourceInfo>& resourceInfos);
239
254     static void makeNamesHierarchical(std::vector<ResourceInfo>& resourceInfos);
255
256 protected:
257     // --- Iris function implementations ---
258
259     void impl_resource_getList(IrisReceivedRequest& request);
260
261     void impl_resource_getListOfResourceGroups(IrisReceivedRequest& request);
262
263     void impl_resource_getResourceInfo(IrisReceivedRequest& request);
264
265     void impl_resource_read(IrisReceivedRequest& request);
266
267     void impl_resource_write(IrisReceivedRequest& request);
268
269 private:
270
276     static void calcHierarchicalNamesInternal(std::vector<ResourceInfo>& resourceInfos, const
std::map<ResourceId, size_t>& rscIdToIndex, std::vector<bool>& done, size_t index);
277
278     // --- State ---
279
281     IrisInstance* irisInstance;
282
284     IrisLogger log;
285
288     typedef std::vector<ResourceInfoAndAccess> ResourceInfoList;
289     ResourceInfoList resourceInfos;
290
292     typedef std::vector<ResourceGroupInfo> GroupInfoList;
293     GroupInfoList groupInfos;
294
296     typedef std::map<std::string, size_t> GroupNameToIndex;
297     GroupNameToIndex groupNameToIndex;
298
300     ResourceGroupInfo* currentAddGroup;
301
303     uint64_t nextSubRscId{IRIS_UINT64_MAX};
304 };
305
306 namespace IRIS_END
307
308 #endif // #ifndef ARM_INCLUDE_IrisInstanceResource_source

```

## 9.39 IrisInstanceSemihosting.h File Reference

IrisInstance add-on to implement semihosting functionality.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"

```

```
#include "iris/IrisInstanceEvent.h"
#include <mutex>
#include <queue>
```

## Classes

- class [iris::IrisInstanceSemihosting](#)

### 9.39.1 Detailed Description

IrisInstance add-on to implement semihosting functionality.

#### Copyright

Copyright (C) 2017 Arm Limited. All rights reserved.

## 9.40 IrisInstanceSemihosting.h

[Go to the documentation of this file.](#)

```
1
2
3 #ifndef ARM_INCLUDE_IrisInstanceSemihosting_h
4 #define ARM_INCLUDE_IrisInstanceSemihosting_h
5
6 #include "iris/detail/IrisCommon.h"
7 #include "iris/detail/IrisLogger.h"
8 #include "iris/detail/IrisObjects.h"
9
10 #include "iris/IrisInstanceEvent.h"
11
12 #include <mutex>
13 #include <queue>
14
15 NAMESPACE_IRIS_START
16
17 class IrisInstance;
18 class IrisInstanceEvent;
19 class IrisReceivedRequest;
20
21 namespace semihost
22 {
23     static const uint64_t COOKED = (0 << 0);
24     static const uint64_t RAW = (1 << 0);
25     static const uint64_t BLOCK = (0 << 1);
26     static const uint64_t NONBLOCK = (1 << 1);
27     static const uint64_t EMIT_EVENT = (0 << 2);
28     static const uint64_t NO_EVENT = (1 << 2);
29     static const uint64_t DEFAULT = COOKED | BLOCK | EMIT_EVENT;
30     static const uint64_t STDIN = 0;
31     static const uint64_t STDOUT = 1;
32     static const uint64_t STDERR = 2;
33 } // namespace semihost
34
35 class IrisInstanceSemihosting
36 {
37 private:
38     IrisInstance* iris_instance{nullptr};
39     IrisInstanceEvent* inst_event{nullptr};
40     std::map<uint64_t, unsigned> evSrcId_map{};
41     std::vector<IrisEventRegistry> event_registries{};
42     struct InputBuffer
43     {
44         std::queue<uint8_t> buffer;
```

```

114     bool empty_write{false};
115 };
116 std::map<uint64_t, InputBuffer> buffered_input_data{};
117
118 std::mutex buffer_mutex{};
119
120 std::mutex extension_mutex{};
121
122 uint64_t extension_retval{0};
123
124 IrisLogger log{};
125
126 std::atomic<bool> unblock_requested{false};
127
128 enum ExtensionState
129 {
130     XS_DISABLED,           // Semihosting extensions are not supported
131     XS_DORMANT,            // No ongoing semihosting extension call in progress
132     XS_WAITING_FOR_REPLY,  // Event has been emitted, waiting for a reply for a client
133     XS_RETURNED,          // A client instance has called semihosting_return()
134     XS_NOT_IMPLEMENTED    // A client instance has called semihosting_notImplemented()
135 } extension_state{XS_DISABLED};
136
137 public:
138     IrisInstanceSemihosting(IrisInstance* iris_instance = nullptr, IrisInstanceEvent* inst_event =
139         nullptr);
140
141     ~IrisInstanceSemihosting();
142
143     void attachTo(IrisInstance* iris_instance);
144
145     void setEventHandler(IrisInstanceEvent* handler);
146
147     std::vector<uint8_t> readData(uint64_t fDes, uint64_t max_size = 0, uint64_t flags =
148         semihost::DEFAULT);
149
150     /*
151     * @brief Write data for a given file descriptor
152     *
153     * @param fDes      File descriptor to write to. Usually semihost::STDOUT or semihost::STDERR.
154     * @param data      Buffer containing the data to write.
155     * @param size      Size of the data buffer in bytes.
156     * @return          Returns false if no client is registered for IRIS_SEMIHOSTING_OUTPUT events.
157     */
158     bool writeData(uint64_t fDes, const uint8_t* data, uint64_t size);
159
160     void enableExtensions();
161
162     std::pair<bool, uint64_t> semihostedCall(uint64_t operation, uint64_t parameter);
163
164     void unblock();
165
166 private:
167     void impl_semihosting_provideInputData(IrisReceivedRequest& request);
168
169     void impl_semihosting_return(IrisReceivedRequest& request);
170
171     void impl_semihosting_notImplemented(IrisReceivedRequest& request);
172
173     IrisErrorCode createEventStream(EventStream* stream_out, const EventSourceInfo& info,
174         const std::vector<std::string>& requested_fields);
175
176     void notifyCall(uint64_t operation, uint64_t parameter);
177
178     class SemihostingEventStream;
179
180     IrisErrorCode enableEventStream(EventStream* stream, unsigned event_type);
181     IrisErrorCode disableEventStream(EventStream* stream, unsigned event_type);
182 };
183
184 namespace iris_end
185 {
186     #endif // ARM_INCLUDE_IrisInstanceSemihosting_h

```

## 9.41 IrisInstanceSimulation.h File Reference

IrisInstance add-on to implement simulation\_\* functions.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"

```

```
#include "iris/IrisInstantiationContext.h"
#include <map>
#include <mutex>
#include <string>
#include <vector>
```

## Classes

- class [iris::IrisInstanceSimulation](#)  
*An [IrisInstance](#) add-on that adds simulation functions for the SimulationEngine instance.*
- class [iris::IrisSimulationResetContext](#)  
*Provides context to a reset delegate call.*

## Typedefs

- typedef IrisDelegate< std::vector< ResourceInfo > & > [iris::SimulationGetParameterInfoDelegate](#)  
*Delegate to get a list of parameter information.*
- typedef IrisDelegate< InstantiationResult & > [iris::SimulationInstantiateDelegate](#)  
*Delegate to instantiate the simulation.*
- typedef IrisDelegate [iris::SimulationRequestShutdownDelegate](#)  
*Delegate to request that the simulation be shut down.*
- typedef IrisDelegate< const IrisSimulationResetContext & > [iris::SimulationResetDelegate](#)  
*Delegate to reset the simulation.*
- typedef IrisDelegate< const InstantiationParameterValue & > [iris::SimulationSetParameterValueDelegate](#)  
*Delegate to set the value of an instantiation parameter.*

## Enumerations

- enum [iris::IrisSimulationPhase](#) {  
IRIS\_SIM\_PHASE\_INITIAL\_PLUGIN\_LOADING\_COMPLETE , IRIS\_SIM\_PHASE\_INSTANTIATE\_ENTER , IRIS\_SIM\_PHASE\_INSTANTIATE\_LEAVE ,  
IRIS\_SIM\_PHASE\_INIT\_ENTER , IRIS\_SIM\_PHASE\_INIT\_LEAVE , IRIS\_SIM\_PHASE\_BEFORE\_END\_OF\_ELABORATION ,  
IRIS\_SIM\_PHASE\_END\_OF\_ELABORATION , IRIS\_SIM\_PHASE\_INITIAL\_RESET\_ENTER , IRIS\_SIM\_PHASE\_INITIAL\_RESET\_LEAVE ,  
IRIS\_SIM\_PHASE\_START\_OF\_SIMULATION , IRIS\_SIM\_PHASE\_RESET\_ENTER , IRIS\_SIM\_PHASE\_RESET\_LEAVE ,  
IRIS\_SIM\_PHASE\_END\_OF\_SIMULATION , IRIS\_SIM\_PHASE\_TERMINATE\_ENTER , IRIS\_SIM\_PHASE\_TERMINATE\_LEAVE ,  
IRIS\_SIM\_PHASE\_NUM }  
*List of IRIS\_SIMULATION\_PHASE events.*

### 9.41.1 Detailed Description

IrisInstance add-on to implement simulation\_\* functions.

Copyright

Copyright (C) 2017 Arm Limited. All rights reserved.

### 9.41.2 Typedef Documentation



### 9.41.2.1 SimulationGetParameterInfoDelegate

```
typedef IrisDelegate<std::vector<ResourceInfo>&> iris::SimulationGetParameterInfoDelegate
Delegate to get a list of parameter information.
IrisErrorCode getInstantiationParameterInfo(std::vector<ResourceInfo> &parameters_out)
```

### 9.41.2.2 SimulationInstantiateDelegate

```
typedef IrisDelegate<InstantiationResult&> iris::SimulationInstantiateDelegate
Delegate to instantiate the simulation.
IrisErrorCode instantiate(InstantiationResult &result_out)
```

### 9.41.2.3 SimulationRequestShutdownDelegate

```
typedef IrisDelegate iris::SimulationRequestShutdownDelegate
Delegate to request that the simulation be shut down.
IrisErrorCode requestShutdown()
```

### 9.41.2.4 SimulationResetDelegate

```
typedef IrisDelegate<const IrisSimulationResetContext&> iris::SimulationResetDelegate
Delegate to reset the simulation.
IrisErrorCode reset(const IrisSimulationResetContext &)
```

### 9.41.2.5 SimulationSetParameterValueDelegate

```
typedef IrisDelegate<const InstantiationParameterValue&> iris::SimulationSetParameterValueDelegate
Delegate to set the value of an instantiation parameter.
IrisErrorCode setInstantiationParameterValue(const InstantiationParameterValue &value)
```

## 9.42 IrisInstanceSimulation.h

[Go to the documentation of this file.](#)

```
1
2 #ifndef ARM_INCLUDE_IrisInstanceSimulation_h
3 #define ARM_INCLUDE_IrisInstanceSimulation_h
4
5 #include "iris/detail/IrisCommon.h"
6 #include "iris/detail/IrisDelegate.h"
7 #include "iris/detail/IrisLogger.h"
8 #include "iris/detail/IrisObjects.h"
9
10 #include "iris/IrisInstantiationContext.h"
11
12 #include <map>
13 #include <mutex>
14 #include <string>
15 #include <vector>
16
17 NAMESPACE_IRIS_START
18
19 class IrisInstance;
20 class IrisReceivedRequest;
21 class IrisInstanceEvent;
22 class IrisEventRegistry;
23
24 class EventStream;
25
26 typedef IrisDelegate<InstantiationResult&> SimulationInstantiateDelegate;
27
28 class IrisSimulationResetContext
29 {
30 private:
31     static const uint64_t ALLOW_PARTIAL = (1 << 0);
32     uint64_t flags;
33     bool getFlag(uint64_t mask) const
```

```

55     {
56         return (flags & mask) != 0;
57     }
58
59     void setFlag(uint64_t mask, bool value)
60     {
61         flags &= ~mask;
62         flags |= (value ? mask : 0);
63     }
64
65 public:
66     IrisSimulationResetContext()
67         : flags(0)
68     {
69     }
70
71     bool getAllowPartialReset() const
72     {
73         return getFlag(ALLOW_PARTIAL);
74     }
75
76     // Set/clear the allowPartialReset flag.
77     void setAllowPartialReset(bool value = true)
78     {
79         setFlag(ALLOW_PARTIAL, value);
80     }
81 };
82
83 typedef IrisDelegate<const IrisSimulationResetContext&> SimulationResetDelegate;
84
85 typedef IrisDelegate<> SimulationRequestShutdownDelegate;
86
87 typedef IrisDelegate<std::vector<ResourceInfo>&> SimulationGetParameterInfoDelegate;
88
89 typedef IrisDelegate<const InstantiationParameterValue&> SimulationSetParameterValueDelegate;
90
91 enum IrisSimulationPhase
92 {
93     IRIS_SIM_PHASE_INITIAL_PLUGIN_LOADING_COMPLETE,
94     IRIS_SIM_PHASE_INSTANTIATE_ENTER,
95     IRIS_SIM_PHASE_INSTANTIATE,
96     IRIS_SIM_PHASE_INSTANTIATE_LEAVE,
97     IRIS_SIM_PHASE_INIT_ENTER,
98     IRIS_SIM_PHASE_INIT,
99     IRIS_SIM_PHASE_INIT_LEAVE,
100    IRIS_SIM_PHASE_BEFORE_END_OF_ELABORATION,
101    IRIS_SIM_PHASE_END_OF_ELABORATION,
102    IRIS_SIM_PHASE_INITIAL_RESET_ENTER,
103    IRIS_SIM_PHASE_INITIAL_RESET,
104    IRIS_SIM_PHASE_INITIAL_RESET_LEAVE,
105    IRIS_SIM_PHASE_START_OF_SIMULATION,
106    IRIS_SIM_PHASE_RESET_ENTER,
107    IRIS_SIM_PHASE_RESET,
108    IRIS_SIM_PHASE_RESET_LEAVE,
109    IRIS_SIM_PHASE_END_OF_SIMULATION,
110    IRIS_SIM_PHASE_TERMINATE_ENTER,
111    IRIS_SIM_PHASE_TERMINATE,
112    IRIS_SIM_PHASE_TERMINATE_LEAVE,
113    IRIS_SIM_PHASE_NUM
114 };
115
116 static const size_t IrisSimulationPhase_total = IRIS_SIM_PHASE_NUM;
117
118 class IrisInstanceSimulation
119 {
120 private:
121     IrisInstance* iris_instance;
122
123     IrisConnectionInterface* connection_interface;
124
125     SimulationInstantiateDelegate instantiate;
126
127     SimulationResetDelegate reset;
128
129     SimulationRequestShutdownDelegate requestShutdown;
130
131     SimulationGetParameterInfoDelegate getParameterInfo;
132
133     SimulationSetParameterValueDelegate setParameterValue;
134
135     enum
136     {
137         CACHE_DISABLED,
138         CACHE_EMPTY,
139         CACHE_SET
140     } parameter_info_cache_state;
141
142     std::vector<ResourceInfo> cached_parameter_info;

```

```

183
184     std::mutex mutex;
185
186
187     std::vector<IrisEventRegistry*> simulation_phase_event_registries;
188
189
190     std::map<uint64_t, IrisSimulationPhase> evSrcId_to_phase;
191
192
193     IrisLogger log;
194
195
196     bool simulation_has_been_initialised;
197
198
199     std::vector<uint64_t> requests_waiting_for_instantiation;
200
201
202     unsigned logLevel{};
203
204
205 public:
206     IrisInstanceSimulation(IrisInstance* iris_instance = nullptr,
207                            IrisConnectionInterface* connection_interface = nullptr);
208     ~IrisInstanceSimulation();
209
210     void attachTo(IrisInstance* iris_instance);
211
212     void setConnectionInterface(IrisConnectionInterface* connection_interface_)
213     {
214         connection_interface = connection_interface_;
215     }
216
217     void setInstantiateDelegate(SimulationInstantiateDelegate delegate)
218     {
219         instantiate = delegate;
220     }
221
222     template <typename T, IrisErrorCode (T::*METHOD)(InstantiationResult&)>
223     void setInstantiateDelegate(T* instance)
224     {
225         setInstantiateDelegate(SimulationInstantiateDelegate::make<T, METHOD>(instance));
226     }
227
228     template <IrisErrorCode (*FUNC)(InstantiationResult&)>
229     void setInstantiateDelegate()
230     {
231         setInstantiateDelegate(SimulationInstantiateDelegate::make<FUNC>());
232     }
233
234     void setResetDelegate(SimulationResetDelegate delegate)
235     {
236         reset = delegate;
237     }
238
239     template <typename T, IrisErrorCode (T::*METHOD)(const IrisSimulationResetContext&)>
240     void setResetDelegate(T* instance)
241     {
242         setResetDelegate(SimulationResetDelegate::make<T, METHOD>(instance));
243     }
244
245     template <IrisErrorCode (*FUNC)(const IrisSimulationResetContext&)>
246     void setResetDelegate()
247     {
248         setResetDelegate(SimulationResetDelegate::make<FUNC>());
249     }
250
251     void setRequestShutdownDelegate(SimulationRequestShutdownDelegate delegate)
252     {
253         requestShutdown = delegate;
254     }
255
256     template <typename T, IrisErrorCode (T::*METHOD)()>
257     void setRequestShutdownDelegate(T* instance)
258     {
259         setRequestShutdownDelegate(SimulationRequestShutdownDelegate::make<T, METHOD>(instance));
260     }
261
262     template <IrisErrorCode (*FUNC)()>
263     void setRequestShutdownDelegate()
264     {
265         setRequestShutdownDelegate(SimulationRequestShutdownDelegate::make<FUNC>());
266     }
267
268     void setGetParameterInfoDelegate(SimulationGetParameterInfoDelegate delegate, bool cache_result =
269 true)
270     {
271         getParameterInfo = delegate;
272         parameter_info_cache_state = cache_result ? CACHE_EMPTY : CACHE_DISABLED;
273         cached_parameter_info.clear();
274     }
275
276     template <typename T, IrisErrorCode (T::*METHOD)(std::vector<ResourceInfo>&)>

```

```

381 void setGetParameterInfoDelegate(T* instance, bool cache_result = true)
382 {
383     typedef SimulationGetParameterInfoDelegate D;
384     setGetParameterInfoDelegate(D::make<T, METHOD>(instance), cache_result);
385 }
386
398 template <IrisErrorCode (*FUNC)(std::vector<ResourceInfo>&)>
399 void setGetParameterInfoDelegate(bool cache_result = true)
400 {
401     typedef SimulationGetParameterInfoDelegate D;
402     setGetParameterInfoDelegate(D::make<FUNC>(), cache_result);
403 }
404
411 void setSetParameterValueDelegate(SimulationSetParameterValueDelegate delegate)
412 {
413     setParameterValue = delegate;
414 }
415
425 template <typename T, IrisErrorCode (T::METHOD)(const InstantiationParameterValue&)>
426 void setSetParameterValueDelegate(T* instance)
427 {
428     setSetParameterValueDelegate(SimulationSetParameterValueDelegate::make<T, METHOD>(instance));
429 }
430
438 template <IrisErrorCode (*FUNC)(const InstantiationParameterValue&)>
439 void setSetParameterValueDelegate()
440 {
441     setSetParameterValueDelegate(SimulationSetParameterValueDelegate::make<FUNC>());
442 }
443
452 void enterPostInstantiationPhase();
453
459 void setEventHandler(IrisInstanceEvent* handler);
460
467 void notifySimPhase(uint64_t time, IrisSimulationPhase phase);
468
480 void registerSimEventsOnGlobalInstance();
481
487 static std::string getSimulationPhaseName(IrisSimulationPhase phase);
488
494 static std::string getSimulationPhaseDescription(IrisSimulationPhase phase);
495
501 void setLogLevel(unsigned logLevel_) { logLevel = logLevel_; }
502
503 private:
505 void impl_simulation_getInstantiationParameterInfo(IrisReceivedRequest& request);
506
508 void impl_simulation_setInstantiationParameterValues(IrisReceivedRequest& request);
509
511 void impl_simulation_instantiate(IrisReceivedRequest& request);
512
514 void impl_simulation_reset(IrisReceivedRequest& request);
515
517 void impl_simulation_requestShutdown(IrisReceivedRequest& request);
518
520 void impl_simulation_waitForInstantiation(IrisReceivedRequest& request);
521
523 IrisErrorCode createEventStream(EventStream* event_stream_out, const EventSourceInfo& info,
524                               const std::vector<std::string>& fields);
525 };
526
527 namespace IRIS_END
528
529 #endif // ARM_INCLUDE_IrisInstanceSimulation_h

```

## 9.43 IrisInstanceSimulationTime.h File Reference

IrisInstance add-on to implement simulationTime functions.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include <string>
#include <vector>
#include <functional>

```

### Classes

- class [iris::IrisInstanceSimulationTime](#)

Simulation time add-on for [IrisInstance](#).

## Typedefs

- typedef IrisDelegate< uint64\_t &, uint64\_t &, bool & > [iris::SimulationTimeGetDelegate](#)  
Delegate to get the simulation time.
- typedef IrisDelegate [iris::SimulationTimeRunDelegate](#)  
Delegate to resume the simulation time progress.
- typedef IrisDelegate [iris::SimulationTimeStopDelegate](#)  
Delegate to stop the simulation time progress.

## Enumerations

- enum [iris::TIME\\_EVENT\\_REASON](#) {  
[iris::TIME\\_EVENT\\_NO\\_REASON](#) = 0 , [iris::TIME\\_EVENT\\_UNKNOWN](#) = (1 << 0) , [iris::TIME\\_EVENT\\_STOP](#) = (1 << 1) , [iris::TIME\\_EVENT\\_BREAKPOINT](#) = (1 << 2) ,  
[iris::TIME\\_EVENT\\_EVENT\\_COUNTER\\_OVERFLOW](#) = (1 << 3) , [iris::TIME\\_EVENT\\_STEPPING\\_COMPLETED](#) = (1 << 4) , [iris::TIME\\_EVENT\\_REACHED\\_DEBUGGABLE\\_STATE](#) = (1 << 5) , [iris::TIME\\_EVENT\\_EVENT](#) = (1 << 6) ,  
[iris::TIME\\_EVENT\\_STATE\\_CHANGED](#) = (1 << 7) }  
The reasons why the simulation time stopped. Bit masks.

### 9.43.1 Detailed Description

IrisInstance add-on to implement simulationTime functions.

#### Copyright

Copyright (C) 2017-2023 Arm Limited. All rights reserved.

### 9.43.2 Typedef Documentation

#### 9.43.2.1 SimulationTimeGetDelegate

```
typedef IrisDelegate<uint64_t&, uint64_t&, bool&> iris::SimulationTimeGetDelegate
```

Delegate to get the simulation time.

```
IrisErrorCode getTime(uint64_t &ticks, uint64_t &tickHz, bool &running);
```

#### 9.43.2.2 SimulationTimeRunDelegate

```
typedef IrisDelegate iris::SimulationTimeRunDelegate
```

Delegate to resume the simulation time progress.

```
IrisErrorCode run();
```

#### 9.43.2.3 SimulationTimeStopDelegate

```
typedef IrisDelegate iris::SimulationTimeStopDelegate
```

Delegate to stop the simulation time progress.

```
IrisErrorCode stop();
```

### 9.43.3 Enumeration Type Documentation

## 9.43.3.1 TIME\_EVENT\_REASON

enum `iris::TIME_EVENT_REASON`

The reasons why the simulation time stopped. Bit masks.

Note that Fast Models only ever emits `TIME_EVENT_UNKNOWN`.

## Enumerator

<code>TIME_EVENT_NO_REASON</code>	Do not emit a REASON field.
<code>TIME_EVENT_UNKNOWN</code>	Simulation stopped for any reason.
<code>TIME_EVENT_STOP</code>	<code>simulationTime_stop()</code> was called.
<code>TIME_EVENT_BREAKPOINT</code>	Breakpoint was hit.
<code>TIME_EVENT_EVENT_COUNTER_OVERFLOW</code>	<code>EventCounterMode.overflowStopSim</code> .
<code>TIME_EVENT_STEPPING_COMPLETED</code>	<code>step_setup()</code> and then <code>simulationTime_run()</code> .
<code>TIME_EVENT_REACHED_DEBUGGABLE_STATE</code>	<code>simulationTime_runUntilDebuggableState()</code> .
<code>TIME_EVENT_EVENT</code>	<code>eventStream_create(stop=true)</code> .
<code>TIME_EVENT_STATE_CHANGED</code>	State of any component changed.

## 9.44 IrisInstanceSimulationTime.h

[Go to the documentation of this file.](#)

```

1
2
3
4
5
6
7
8 #ifndef ARM_INCLUDE_IrisInstanceSimulationTime_h
9 #define ARM_INCLUDE_IrisInstanceSimulationTime_h
10
11 #include "iris/detail/IrisCommon.h"
12 #include "iris/detail/IrisDelegate.h"
13
14 #include <string>
15 #include <vector>
16 #include <functional>
17
18 NAMESPACE_IRIS_START
19
20
21
22
23
24 typedef IrisDelegate<> SimulationTimeRunDelegate;
25
26
27
28
29
30 typedef IrisDelegate<> SimulationTimeStopDelegate;
31
32
33
34
35
36 typedef IrisDelegate<uint64_t&, uint64_t&, bool&> SimulationTimeGetDelegate;
37
38
39
40
41
42
43 enum TIME_EVENT_REASON
44 {
45     TIME_EVENT_NO_REASON = 0,
46     TIME_EVENT_UNKNOWN = (1 << 0),
47     TIME_EVENT_STOP = (1 << 1),
48     TIME_EVENT_BREAKPOINT = (1 << 2),
49     TIME_EVENT_EVENT_COUNTER_OVERFLOW = (1 << 3),
50     TIME_EVENT_STEPPING_COMPLETED = (1 << 4),
51     TIME_EVENT_REACHED_DEBUGGABLE_STATE = (1 << 5),
52     TIME_EVENT_EVENT = (1 << 6),
53     TIME_EVENT_STATE_CHANGED = (1 << 7),
54 };
55
56 class IrisInstance;
57 class IrisInstanceEvent;
58 class IrisEventRegistry;
59 class IrisReceivedRequest;
60
61 class EventStream;
62 struct EventSourceInfo;
63
64
65
66
67 class IrisInstanceSimulationTime
68 {
69 private:
70     IrisInstance* iris_instance;
71
72     IrisEventRegistry* simulation_time_event_registry;
73
74     SimulationTimeRunDelegate run_delegate;
75     SimulationTimeStopDelegate stop_delegate;
76     SimulationTimeGetDelegate get_time_delegate;
77     std::function<void()> notify_state_changed_delegate;
78
79
80

```

```

81
82 public:
83     IrisInstanceSimulationTime(IrisInstance* iris_instance = nullptr, IrisInstanceEvent* inst_event =
84         nullptr);
85     ~IrisInstanceSimulationTime();
86
87     void attachTo(IrisInstance* irisInstance);
88
89     void setEventHandler(IrisInstanceEvent* handler);
90
91     void setSimTimeRunDelegate(SimulationTimeRunDelegate delegate)
92     {
93         run_delegate = delegate;
94     }
95
96     template <typename T, IrisErrorCode (T::*METHOD)()>
97     void setSimTimeRunDelegate(T* instance)
98     {
99         setSimTimeRunDelegate(SimulationTimeRunDelegate::make<T, METHOD>(instance));
100     }
101
102     template <IrisErrorCode (*FUNC)()>
103     void setSimTimeRunDelegate()
104     {
105         setSimTimeRunDelegate(SimulationTimeRunDelegate::make<FUNC>());
106     }
107
108     void setSimTimeStopDelegate(SimulationTimeStopDelegate delegate)
109     {
110         stop_delegate = delegate;
111     }
112
113     template <typename T, IrisErrorCode (T::*METHOD)()>
114     void setSimTimeStopDelegate(T* instance)
115     {
116         setSimTimeStopDelegate(SimulationTimeStopDelegate::make<T, METHOD>(instance));
117     }
118
119     template <IrisErrorCode (*FUNC)()>
120     void setSimTimeStopDelegate()
121     {
122         setSimTimeStopDelegate(SimulationTimeStopDelegate::make<FUNC>());
123     }
124
125     void setSimTimeGetDelegate(SimulationTimeGetDelegate delegate)
126     {
127         get_time_delegate = delegate;
128     }
129
130     template <typename T, IrisErrorCode (T::*METHOD)(uint64_t&, uint64_t&, bool&)>
131     void setSimTimeGetDelegate(T* instance)
132     {
133         setSimTimeGetDelegate(SimulationTimeGetDelegate::make<T, METHOD>(instance));
134     }
135
136     template <IrisErrorCode (*FUNC)(uint64_t&, uint64_t&, bool&)>
137     void setSimTimeGetDelegate()
138     {
139         setSimTimeGetDelegate(SimulationTimeGetDelegate::make<FUNC>());
140     }
141
142     void setSimTimeNotifyStateChanged(std::function<void()> func)
143     {
144         notify_state_changed_delegate = func;
145     }
146
147     void notifySimulationTimeEvent(uint64_t reason = TIME_EVENT_UNKNOWN);
148
149     void registerSimTimeEventsOnGlobalInstance();
150
151 private:
152     void impl_simulationTime_run(IrisReceivedRequest& request);
153     void impl_simulationTime_stop(IrisReceivedRequest& request);
154     void impl_simulationTime_get(IrisReceivedRequest& request);
155     void impl_simulationTime_notifyStateChanged(IrisReceivedRequest& request);
156
157     IrisErrorCode createEventStream(EventStream*&, const EventSourceInfo&, const
158         std::vector<std::string>&);
159 };
160
161 NAMESPACE_IRIS_END
162
163 #endif // ARM_INCLUDE_IrisInstanceSimulationTime_h

```

## 9.45 IrisInstanceStep.h File Reference

Stepping-related add-on to an IrisInstance.

```
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisLogger.h"
#include "iris/detail/IrisObjects.h"
#include <cstdio>
```

### Classes

- class [iris::IrisInstanceStep](#)  
*Step add-on for [IrisInstance](#).*

### Typedefs

- typedef IrisDelegate< uint64\_t &, const std::string & > [iris::RemainingStepGetDelegate](#)  
*Delegate to get the value of the currently remaining steps.*
- typedef IrisDelegate< uint64\_t, const std::string & > [iris::RemainingStepSetDelegate](#)  
*Delegate to set the remaining steps measured in the specified unit.*
- typedef IrisDelegate< uint64\_t &, const std::string & > [iris::StepCountGetDelegate](#)  
*Delegate to get the value of the step count.*

### 9.45.1 Detailed Description

Stepping-related add-on to an IrisInstance.

#### Copyright

Copyright (C) 2016 Arm Limited. All rights reserved.

The IrisInstanceStep class implements all stepping-related Iris functions.

### 9.45.2 Typedef Documentation

#### 9.45.2.1 RemainingStepGetDelegate

```
typedef IrisDelegate<uint64_t&, const std::string&> iris::RemainingStepGetDelegate
```

Delegate to get the value of the currently remaining steps.

```
IrisErrorCode getRemainingSteps(uint64_t &steps, const std::string &unit)
```

Error: Return E\_\* error code if it failed to get the remaining steps.

#### 9.45.2.2 RemainingStepSetDelegate

```
typedef IrisDelegate<uint64_t, const std::string&> iris::RemainingStepSetDelegate
```

Delegate to set the remaining steps measured in the specified unit.

```
IrisErrorCode setRemainingSteps(uint64_t steps, const std::string &unit)
```

Error: Return E\_\* error code if it failed to set the steps.

#### 9.45.2.3 StepCountGetDelegate

```
typedef IrisDelegate<uint64_t&, const std::string&> iris::StepCountGetDelegate
```

Delegate to get the value of the step count.

```
IrisErrorCode getStepCount(uint64_t &count, const std::string &unit)
```

Error: Return E\_\* error code if it failed to get the step count.



## 9.46 IrisInstanceStep.h

[Go to the documentation of this file.](#)

```

1
9 #ifndef ARM_INCLUDE_IrisInstanceStep_h
10 #define ARM_INCLUDE_IrisInstanceStep_h
11
12 #include "iris/detail/IrisCommon.h"
13 #include "iris/detail/IrisDelegate.h"
14 #include "iris/detail/IrisLogger.h"
15 #include "iris/detail/IrisObjects.h"
16
17 #include <cstdio>
18
19 NAMESPACE_IRIS_START
20
21 class IrisInstance;
22 class IrisReceivedRequest;
23
24 typedef IrisDelegate<uint64_t, const std::string&> RemainingStepSetDelegate;
25
26 typedef IrisDelegate<uint64_t&, const std::string&> RemainingStepGetDelegate;
27
28 typedef IrisDelegate<uint64_t&, const std::string&> StepCountGetDelegate;
29
30 class IrisInstanceStep
31 {
32 public:
33     IrisInstanceStep(IrisInstance* irisInstance = nullptr);
34
35     void attachTo(IrisInstance* irisInstance);
36
37     void setRemainingStepSetDelegate(RemainingStepSetDelegate delegate);
38
39     void setRemainingStepGetDelegate(RemainingStepGetDelegate delegate);
40
41     void setStepCountGetDelegate(StepCountGetDelegate delegate);
42
43 private:
44     void impl_step_setup(IrisReceivedRequest& request);
45
46     void impl_step_getRemainingSteps(IrisReceivedRequest& request);
47
48     void impl_step_getStepCounterValue(IrisReceivedRequest& request);
49
50     void impl_step_syncStep(IrisReceivedRequest& request);
51
52     void impl_step_syncStepSetup(IrisReceivedRequest& request);
53
54     IrisInstance* irisInstance;
55
56     RemainingStepSetDelegate stepSetDel;
57     RemainingStepGetDelegate stepGetDel;
58
59     StepCountGetDelegate stepCountGetDel;
60
61     IrisLogger log;
62
63     EventBufferId evBufId{IRIS_UINT64_MAX};
64 };
65
66 NAMESPACE_IRIS_END
67
68 #endif // #ifndef ARM_INCLUDE_IrisInstanceStep_h

```

## 9.47 IrisInstanceTable.h File Reference

Table add-on to IrisInstance.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisDelegate.h"
#include "iris/detail/IrisObjects.h"

```

### Classes

- class [iris::IrisInstanceTable](#)

Table add-on for [IrisInstance](#).

- struct [iris::IrisInstanceTable::TableInfoAndAccess](#)  
*Entry in 'tableInfos'.*

## Typedefs

- typedef IrisDelegate< const TableInfo &, uint64\_t, uint64\_t, TableReadResult & > [iris::TableReadDelegate](#)  
*Delegate to read table data.*
- typedef IrisDelegate< const TableInfo &, const TableRecords &, TableWriteResult & > [iris::TableWriteDelegate](#)  
*Delegate to write table data.*

## 9.47.1 Detailed Description

Table add-on to IrisInstance.

### Copyright

Copyright (C) 2016 Arm Limited. All rights reserved.

The IrisInstanceTable class implements all table-related Iris functions.

## 9.47.2 Typedef Documentation

### 9.47.2.1 TableReadDelegate

typedef IrisDelegate<const TableInfo&, uint64\_t, uint64\_t, TableReadResult&> [iris::TableReadDelegate](#)  
 Delegate to read table data.  
 IrisErrorCode read(const TableInfo &tableInfo, uint64\_t index, uint64\_t count, TableReadResult &result)  
 tableInfo, index, and count are guaranteed to be valid. count is non-zero.  
 TableReadResult holds the read results and any errors from reading table cell values.

### 9.47.2.2 TableWriteDelegate

typedef IrisDelegate<const TableInfo&, const TableRecords&, TableWriteResult&> [iris::TableWriteDelegate](#)  
 Delegate to write table data.  
 IrisErrorCode write(const TableInfo &tableInfo, const TableRecords &records, TableWriteResult &result)  
 records is guaranteed to be non-empty.  
 TableWriteResult holds any errors from writing table cell values.

## 9.48 IrisInstanceTable.h

[Go to the documentation of this file.](#)

```

1
9 #ifndef ARM_INCLUDE_IrisInstanceTable_h
10 #define ARM_INCLUDE_IrisInstanceTable_h
11
12 #include "iris/detail/IrisCommon.h"
13 #include "iris/detail/IrisDelegate.h"
14 #include "iris/detail/IrisObjects.h"
15
16 NAMESPACE_IRIS_START
17
18 class IrisInstance;
19 class IrisReceivedRequest;
20
31 typedef IrisDelegate<const TableInfo&, uint64_t, uint64_t, TableReadResult&> TableReadDelegate;
32
43 typedef IrisDelegate<const TableInfo&, const TableRecords&, TableWriteResult&> TableWriteDelegate;
44
50 class IrisInstanceTable
51 {
52 public:
53     struct TableInfoAndAccess
54     {
55         TableInfo      tableInfo;
56         TableReadDelegate readDelegate;

```

```

62     TableWriteDelegate writeDelegate;
63 };
64
70     IrisInstanceTable(IrisInstance* irisInstance = nullptr);
71
79     void attachTo(IrisInstance* irisInstance);
80
88     TableInfoAndAccess& addTableInfo(const std::string& name);
89
96     void setDefaultReadDelegate(TableReadDelegate delegate = TableReadDelegate())
97     {
98         defaultReadDelegate = delegate;
99     }
100
107     void setDefaultWriteDelegate(TableWriteDelegate delegate = TableWriteDelegate())
108     {
109         defaultWriteDelegate = delegate;
110     }
111
112 private:
113     void impl_table_getList(IrisReceivedRequest& request);
114
115     void impl_table_read(IrisReceivedRequest& request);
116
117     void impl_table_write(IrisReceivedRequest& request);
118
120
122     IrisInstance* irisInstance;
123
125     typedef std::vector<TableInfoAndAccess> TableInfoAndAccessList;
126     TableInfoAndAccessList tableInfos;
127
129     TableReadDelegate defaultReadDelegate;
130     TableWriteDelegate defaultWriteDelegate;
131 };
132
133 namespace IRIS_END
134
135 #endif // #ifndef ARM_INCLUDE_IrisInstanceTable_h

```

## 9.49 IrisInstantiationContext.h File Reference

Helper class used to instantiate Iris instances from generic factories.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisObjects.h"
#include "iris/detail/IrisUtils.h"
#include <string>
#include <vector>

```

### Classes

- class [iris::IrisInstantiationContext](#)  
*Provides context when instantiating an Iris instance from a factory.*

### 9.49.1 Detailed Description

Helper class used to instantiate Iris instances from generic factories.

#### Copyright

Copyright (C) 2017-2023 Arm Limited. All rights reserved.

## 9.50 IrisInstantiationContext.h

[Go to the documentation of this file.](#)

```

1
7 #ifndef ARM_INCLUDE_IrisInstantiationContext_h
8 #define ARM_INCLUDE_IrisInstantiationContext_h
9
10 #include "iris/detail/IrisCommon.h"
11 #include "iris/detail/IrisObjects.h"

```

```

12 #include "iris/detail/IrisUtils.h"
13
14 #include <string>
15 #include <vector>
16
17 NAMESPACE_IRIS_START
18
22 class IrisInstantiationContext
23 {
24 private:
25     IrisConnectionInterface* connection_interface;
26
29     InstantiationResult& result;
30
33     IrisValueMap params;
34
39     std::string prefix;
40
42     std::string component_name;
43
44     uint64_t instance_flags;
45
47     std::vector<IrisInstantiationContext*> children;
48
49     void errorInternal(const std::string& severity,
50                       const std::string& code,
51                       const std::string& parameterName,
52                       const char* format,
53                       va_list args);
54
57     void processParameters(const std::vector<ResourceInfo>& param_info_,
58                           const std::vector<InstantiationParameterValue>& param_values_);
59
61     IrisInstantiationContext(const IrisInstantiationContext* parent, const std::string& instance_name);
62
63 public:
64     IrisInstantiationContext(IrisConnectionInterface* connection_interface_,
65                             InstantiationResult& result_,
66                             const std::vector<ResourceInfo>& param_info_,
67                             const std::vector<InstantiationParameterValue>& param_values_,
68                             const std::string& prefix_,
69                             const std::string& component_name_,
70                             uint64_t instance_flags_);
71
72     ~IrisInstantiationContext();
73
85     IrisInstantiationContext* getSubcomponentContext(const std::string& child_name);
86
96     template <typename T>
97     void getParameter(const std::string& name, T& value)
98     {
99         getParameter(name).get(value);
100     }
101
111     const IrisValue& getParameter(const std::string& name)
112     {
113         IrisValueMap::const_iterator it = params.find(name);
114         if (it == params.end())
115         {
116             throw IrisInternalError("getParameter(" + name + "): Unknown parameter");
117         }
118         return it->second;
119     }
120
127     std::string getStringParameter(const std::string& name)
128     {
129         return getParameter(name).getAsString();
130     }
131
138     uint64_t getU64Parameter(const std::string& name)
139     {
140         return getParameter(name).getAsU64();
141     }
142
149     int64_t getS64Parameter(const std::string& name)
150     {
151         return getParameter(name).getAsS64();
152     }
153
160     bool getBoolParameter(const std::string& name)
161     {
162         return getParameter(name).getAsBool();
163     }
164
174     void getParameter(const std::string& name, std::vector<uint64_t>& value);
175
182     uint64_t getRecommendedInstanceFlags() const

```

```

183     {
184         return instance_flags;
185     }
186
193     std::string getInstanceName() const
194     {
195         return prefix + "." + component_name;
196     }
197
203     IrisConnectionInterface* getConnectionInterface() const
204     {
205         return connection_interface;
206     }
207
218     void warning(const std::string& code, const char* format, ...) INTERNAL_IRIS_PRINTF(3, 4);
219
231     void parameterWarning(const std::string& code, const std::string& parameterName, const char* format,
232         ...) INTERNAL_IRIS_PRINTF(4, 5);
242     void error(const std::string& code, const char* format, ...) INTERNAL_IRIS_PRINTF(3, 4);
243
255     void parameterError(const std::string& code, const std::string& parameterName, const char* format,
256         ...) INTERNAL_IRIS_PRINTF(4, 5);
257 };
258
259 #endif // ARM_INCLUDE_IrisInstantiationContext_h

```

## 9.51 IrisParameterBuilder.h File Reference

Helper class to construct instantiation parameters.

```

#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisObjects.h"
#include <string>
#include <vector>

```

### Classes

- class [iris::IrisParameterBuilder](#)

*Helper class to construct instantiation parameters.*

### 9.51.1 Detailed Description

Helper class to construct instantiation parameters.

#### Copyright

Copyright (C) 2017 Arm Limited. All rights reserved.

## 9.52 IrisParameterBuilder.h

[Go to the documentation of this file.](#)

```

1
7 #ifndef ARM_INCLUDE_IrisParameterBuilder_h
8 #define ARM_INCLUDE_IrisParameterBuilder_h
9
10 #include "iris/detail/IrisCommon.h"
11 #include "iris/detail/IrisObjects.h"
12
13 #include <string>
14 #include <vector>
15
16 namespace IRIS_START
17 {
21 class IrisParameterBuilder
22 {
23 private:
24     ResourceInfo& info;
25
26     IrisParameterBuilder& setValueExtend(std::vector<uint64_t>& arr, uint64_t value, uint64_t extension)
27     {
28         arr.resize(info.getDataSizeInU64Chunks(), extension);

```

```

29         arr[0] = value;
30
31         return *this;
32     }
33
34     IrisParameterBuilder& setValueExtend(std::vector<uint64_t>& arr, const std::vector<uint64_t>& value,
uint64_t extension)
35     {
36         size_t param_size = info.getDataSizeInU64Chunks();
37         if (param_size < value.size())
38         {
39             throw IrisInternalError("Invalid parameter configuration");
40         }
41         arr = value;
42         arr.resize(info.getDataSizeInU64Chunks(), extension);
43
44         return *this;
45     }
46
47     IrisParameterBuilder& setValueSignExtend(std::vector<uint64_t>& arr, int64_t value)
48     {
49         return setValueExtend(arr, static_cast<uint64_t>(value), (value < 0) ? IRIS_UINT64_MAX : 0);
50     }
51
52     IrisParameterBuilder& setValueZeroExtend(std::vector<uint64_t>& arr, uint64_t value)
53     {
54         return setValueExtend(arr, value, 0);
55     }
56
57     IrisParameterBuilder& setValueSignExtend(std::vector<uint64_t>& arr, const std::vector<uint64_t>&
value)
58     {
59         return setValueExtend(arr, value, (static_cast<int64_t>(value.back()) < 0) ? IRIS_UINT64_MAX :
0);
60     }
61
62     IrisParameterBuilder& setValueZeroExtend(std::vector<uint64_t>& arr, const std::vector<uint64_t>&
value)
63     {
64         return setValueExtend(arr, value, 0);
65     }
66
67     IrisParameterBuilder& setValueDouble(std::vector<uint64_t>& arr, double value)
68     {
69         arr.resize(1);
70         *static_cast<double*>((void*) (&arr[0])) = value;
71
72         return *this;
73     }
74
75 public:
76     IrisParameterBuilder(ResourceInfo& info_)
77     : info(info_)
78     {
79         info.isParameter = true;
80     }
81
82     IrisParameterBuilder& setName(const std::string& name)
83     {
84         info.name = name;
85         return *this;
86     }
87
88     IrisParameterBuilder& setDescr(const std::string& description)
89     {
90         info.description = description;
91         return *this;
92     }
93
94     IrisParameterBuilder& setFormat(const std::string& format)
95     {
96         info.format = format;
97         return *this;
98     }
99
100     IrisParameterBuilder& setBitWidth(uint64_t bitWidth)
101     {
102         info.bitWidth = bitWidth;
103         return *this;
104     }
105
106     IrisParameterBuilder& setRwMode(const std::string& rwMode)
107     {
108         info.rwMode = rwMode;
109         return *this;
110     }
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140

```

```

146     IrisParameterBuilder& setSubRscId(uint64_t subRscId)
147     {
148         info.subRscId = subRscId;
149         return *this;
150     }
151
152
153
154
155
156
157     IrisParameterBuilder& setTopology(bool value = true)
158     {
159         info.parameterInfo.topology = value;
160         return *this;
161     }
162
163
164
165
166
167
168     IrisParameterBuilder& setInitOnly(bool value = true)
169     {
170         info.parameterInfo.initOnly = value;
171         return *this;
172     }
173
174
175
176
177
178
179     IrisParameterBuilder& setMin(uint64_t min)
180     {
181         return setValueZeroExtend(info.parameterInfo.min, min);
182     }
183
184
185
186
187
188
189     IrisParameterBuilder& setMax(uint64_t max)
190     {
191         return setValueZeroExtend(info.parameterInfo.max, max);
192     }
193
194
195
196
197
198
199
200     IrisParameterBuilder& setRange(uint64_t min, uint64_t max)
201     {
202         return setMin(min).setMax(max);
203     }
204
205
206
207
208
209
210
211
212
213     IrisParameterBuilder& setMin(const std::vector<uint64_t>& min)
214     {
215         return setValueZeroExtend(info.parameterInfo.min, min);
216     }
217
218
219
220
221
222
223
224
225
226     IrisParameterBuilder& setMax(const std::vector<uint64_t>& max)
227     {
228         return setValueZeroExtend(info.parameterInfo.max, max);
229     }
230
231
232
233
234
235
236
237
238
239     IrisParameterBuilder& setRange(const std::vector<uint64_t>& min, const std::vector<uint64_t>& max)
240     {
241         return setMin(min).setMax(max);
242     }
243
244
245
246
247
248
249
250
251
252
253     IrisParameterBuilder& setMinSigned(int64_t min)
254     {
255         return setValueSignExtend(info.parameterInfo.min, min)
256             .setType("numericSigned");
257     }
258
259
260
261
262
263
264
265
266
267     IrisParameterBuilder& setMaxSigned(int64_t max)
268     {
269         return setValueSignExtend(info.parameterInfo.max, max)
270             .setType("numericSigned");
271     }
272
273
274
275
276
277
278
279
280
281
282     IrisParameterBuilder& setRangeSigned(int64_t min, int64_t max)
283     {
284         return setValueSignExtend(info.parameterInfo.min, min)
285             .setValueSignExtend(info.parameterInfo.max, max)
286             .setType("numericSigned");
287     }
288
289
290
291
292
293
294
295
296
297
298     IrisParameterBuilder& setMinSigned(const std::vector<uint64_t>& min)
299     {
300         return setValueSignExtend(info.parameterInfo.min, min)
301             .setType("numericSigned");
302     }
303
304
305
306
307
308
309
310
311
312
313     IrisParameterBuilder& setMaxSigned(const std::vector<uint64_t>& max)
314     {
315         return setValueSignExtend(info.parameterInfo.max, max)
316             .setType("numericSigned");
317     }
318
319
320
321
322
323
324
325
326
327
328
329     IrisParameterBuilder& setRangeSigned(const std::vector<uint64_t>& min, const std::vector<uint64_t>&
max)
330     {
331         return setValueSignExtend(info.parameterInfo.min, min)
332             .setValueSignExtend(info.parameterInfo.max, max)
333             .setType("numericSigned");
334     }
335

```

```

344     IrisParameterBuilder& setMinFloat(double min)
345     {
346         return setValueDouble(info.parameterInfo.min, min)
347             .setType("numericFp");
348     }
349
350     IrisParameterBuilder& setMaxFloat(double max)
351     {
352         return setValueDouble(info.parameterInfo.max, max)
353             .setType("numericFp");
354     }
355
356     IrisParameterBuilder& setRangeFloat(double min, double max)
357     {
358         return setValueDouble(info.parameterInfo.min, min)
359             .setValueDouble(info.parameterInfo.max, max)
360             .setType("numericFp");
361     }
362
363     IrisParameterBuilder& addEnum(const std::string& symbol, const IrisValue& value, const std::string&
description = std::string())
364     {
365         info.enums.push_back(EnumElementInfo(value, symbol, description));
366         return *this;
367     }
368
369     IrisParameterBuilder& addStringEnum(const std::string& value, const std::string& description =
std::string())
370     {
371         info.enums.push_back(EnumElementInfo(IrisValue(value), std::string(), description));
372         return *this;
373     }
374
375     IrisParameterBuilder& setTag(const std::string& tag)
376     {
377         info.tags[tag] = IrisValue(true);
378         return *this;
379     }
380
381     IrisParameterBuilder& setHidden(bool hidden)
382     {
383         info.isHidden = hidden;
384         return *this;
385     }
386
387     IrisParameterBuilder& setTag(const std::string& tag, const IrisValue& value)
388     {
389         info.tags[tag] = value;
390         return *this;
391     }
392
393     IrisParameterBuilder& setDefault(const std::string& value)
394     {
395         info.parameterInfo.defaultString = value;
396         return *this;
397     }
398
399     IrisParameterBuilder& setDefault(uint64_t value)
400     {
401         return setValueZeroExtend(info.parameterInfo.defaultData, value);
402     }
403
404     IrisParameterBuilder& setDefault(const std::vector<uint64_t>& value)
405     {
406         return setValueZeroExtend(info.parameterInfo.defaultData, value);
407     }
408
409     IrisParameterBuilder& setDefaultSigned(int64_t value)
410     {
411         return setValueSignExtend(info.parameterInfo.defaultData, value);
412     }
413
414     IrisParameterBuilder& setDefaultSigned(const std::vector<uint64_t>& value)
415     {
416         return setValueSignExtend(info.parameterInfo.defaultData, value);
417     }
418
419     IrisParameterBuilder& setDefaultFloat(double value)
420     {
421         return setValueDouble(info.parameterInfo.defaultData, value);
422     }
423
424     IrisParameterBuilder& setType(const std::string& type)
425     {
426         if ((info.bitWidth != 32) && (info.bitWidth != 64) && (type == "numericFp"))
427         {
428             throw IrisInternalError(
429

```



```

530             "Invalid parameter configuration."
531             " NumericFp parameters must have a bitWidth of 32 or 64");
532         }
533
534         info.type = type;
535         return *this;
536     }
537 };
538
539 NAMESPACE_IRIS_END
540
541 #endif // ARM_INCLUDE_IrisParameterBuilder_h

```

## 9.53 IrisPluginFactory.h File Reference

A generic plug-in factory for instantiating plug-in instances.

```

#include "iris/IrisCConnection.h"
#include "iris/IrisInstance.h"
#include "iris/IrisInstanceFactoryBuilder.h"
#include "iris/IrisInstantiationContext.h"
#include "iris/detail/IrisCommon.h"
#include "iris/detail/IrisFunctionInfo.h"
#include "iris/detail/IrisObjects.h"
#include "iris/detail/IrisU64JsonReader.h"
#include "iris/detail/IrisU64JsonWriter.h"
#include <mutex>
#include <string>
#include <vector>

```

### Classes

- class [iris::IrisNonFactoryPlugin< PLUGIN\\_CLASS >](#)  
*Wrapper to instantiate a non-factory plugin.*
- class [iris::IrisPluginFactory< PLUGIN\\_CLASS >](#)
- class [iris::IrisPluginFactoryBuilder](#)  
*Set meta data for instantiating a plug-in instance.*

### Macros

- #define [IRIS\\_NON\\_FACTORY\\_PLUGIN](#)(PluginClassName)  
*Create plugin entry point for non-factory plugins (i.e. plugins which do not have parameters and which are always instantiated just once).*
- #define [IRIS\\_PLUGIN\\_FACTORY](#)(PluginClassName)  
*Create plugin entry point for plugins which have a factory (i.e. plugins which have parameters and/or plugins which are potentially instantiated multiple times).*

#### 9.53.1 Detailed Description

A generic plug-in factory for instantiating plug-in instances.

#### Copyright

Copyright (C) 2017-2023 Arm Limited. All rights reserved.

#### 9.53.2 Macro Definition Documentation

## 9.53.2.1 IRIS\_NON\_FACTORY\_PLUGIN

```
#define IRIS_NON_FACTORY_PLUGIN(
    PluginClassName )
```

**Value:**

```
extern "C" IRIS_EXPORT int64_t irisInitPlugin(IrisC_Funcions* functions)
{
    return ::iris::IrisNonFactoryPlugin<PluginClassName>::initPlugin(functions, #PluginClassName);
}
```

Create plugin entry point for non-factory plugins (i.e. plugins which do not have parameters and which are always instantiated just once).

**Parameters**

<i>PluginClassName</i>	Class name of the plugin.
------------------------	---------------------------

## 9.53.2.2 IRIS\_PLUGIN\_FACTORY

```
#define IRIS_PLUGIN_FACTORY(
    PluginClassName )
```

**Value:**

```
extern "C" IRIS_EXPORT int64_t irisInitPlugin(IrisC_Funcions* functions)
{
    return ::iris::IrisPluginFactory<PluginClassName>::initPlugin(functions, #PluginClassName);
}
```

Create plugin entry point for plugins which have a factory (i.e. plugins which have parameters and/or plugins which are potentially instantiated multiple times).

**Parameters**

<i>PluginClassName</i>	Objects of this type are instantiated for each plug-in instance created.
------------------------	--

## 9.54 IrisPluginFactory.h

[Go to the documentation of this file.](#)

```
1
2
3
4
5
6
7 #ifndef ARM_INCLUDE_IrisPluginFactory_h
8 #define ARM_INCLUDE_IrisPluginFactory_h
9
10 #include "iris/IrisCConnection.h"
11 #include "iris/IrisInstance.h"
12 #include "iris/IrisInstanceFactoryBuilder.h"
13 #include "iris/IrisInstantiationContext.h"
14 #include "iris/detail/IrisCommon.h"
15 #include "iris/detail/IrisFunctionInfo.h"
16 #include "iris/detail/IrisObjects.h"
17 #include "iris/detail/IrisU64JsonReader.h"
18 #include "iris/detail/IrisU64JsonWriter.h"
19
20 #include <mutex>
21 #include <string>
22 #include <vector>
23
24 namespace IRIS_START
25 {
26     // Iris plugins
27     // =====
28     //
29     // This header supports declaring two different kind of plugins by using one of two macros:
30     //
31     // 1. Factory plugins:
32     //
33     // IRIS_PLUGIN_FACTORY(PluginClassName)
34     //
35     // where PluginClassName is the class of the plugin, not the factory. The factory is instantiated
36     // automatically by the macro.
37     //
38     // This declares a plugin which has a plugin factory. This type of plugin must be used
```

```

38 // for plugins which have parameters and for plugins where it makes sense to instantiate them multiple
    times.
39 // If unsure, use this type.
40 // PluginClassName must have this constructor and a static buildPluginFactory() function to declare the
    parameters:
41 //
42 // PluginClassName(iris::IrisInstantiationContext& context) { ... initialize plugin ... }
43 // static void buildPluginFactory(iris::IrisPluginFactoryBuilder& b) { ... declare parameters ... }
44 //
45 // 2. Non-factory plugins:
46 //
47 // IRIS_NON_FACTORY_PLUGIN(PluginClassName)
48 //
49 // where PluginClassName is the class of the plugin.
50 //
51 // This declares a plugin which is automatically instantiated exactly once when the DSO is loaded.
52 // The plugin cannot have parameters and cannot be instantiated multiple times. A non-factory plugin
53 // plays the same role as the factory instance of factory plugins.
54 //
55 // PluginClassName must have this constructor:
56 //
57 // PluginClassName(iris::IrisInstantiationContext& context) { ... initialize plugin ... }
58 //
59 // Both types of plugins have identical entry points (irisInitPlugin()), and the plugin loader treats
    them the same way.
60 // After loading a plugin DSO, the plugin loader calls irisInitPlugin() which creates a single plugin
    instance.
61 // This is either a plugin factory, indicated by the fact that this instance has the functions
    plugin_getInstantiationParameterInfo()
62 // and plugin_instantiate(), or a non-factory plugin, when these plugin_*() functions are not present. In
    the latter case the
63 // plugin loader is now done. For factory-plugins the plugin loader now instantiates all desired plugins
    by calling plugin_instantiate()
64 // with the respective parameter values.
65
66 class IrisPluginFactoryBuilder : public IrisInstanceFactoryBuilder
67 {
68 private:
69     std::string plugin_name;
70
71     std::string instance_name_prefix;
72
73     std::string default_instance_name;
74
75 public:
76     IrisPluginFactoryBuilder(const std::string& name)
77         : IrisInstanceFactoryBuilder(*parameter_prefix+/"")
78         , plugin_name(name)
79         , instance_name_prefix("client.plugin")
80     {
81     }
82
83     void setPluginName(const std::string& name)
84     {
85         plugin_name = name;
86     }
87
88     const std::string& getPluginName() const
89     {
90         return plugin_name;
91     }
92
93     void setInstanceNamePrefix(const std::string& prefix)
94     {
95         instance_name_prefix = prefix;
96     }
97
98     const std::string& getInstanceNamePrefix() const
99     {
100         return instance_name_prefix;
101     }
102
103     void setDefaultInstanceName(const std::string& name)
104     {
105         default_instance_name = name;
106     }
107
108     const std::string& getDefaultInstanceName() const
109     {
110         if (default_instance_name.empty())
111         {
112             return getPluginName();
113         }
114         else
115         {
116             return default_instance_name;
117         }
118     }
119
120

```

```

165     }
166 };
167
168 template <class PLUGIN_CLASS>
169 class IrisPluginFactory
170 {
171 private:
172     IrisCConnection connection_interface;
173
174     IrisInstance factory_instance;
175
176     std::vector<PLUGIN_CLASS*> plugin_instances;
177
178     std::mutex plugin_instances_mutex;
179
180     IrisPluginFactoryBuilder builder;
181
182     void impl_plugin_getInstantiationParameterInfo(IrisReceivedRequest& req)
183     {
184         factory_instance.sendResponse(req.generateOkResponse(builder.getParameterInfo()));
185     }
186
187     void impl_plugin_instantiate(IrisReceivedRequest& req)
188     {
189         InstantiationResult result;
190         result.success = true; // Assume we will succeed until proven otherwise
191
192         uint64_t instance_flags = IrisInstance::DEFAULT_FLAGS;
193
194         std::string instName;
195
196         if (!req.getOptionalArg(ISTR("instName"), instName))
197         {
198             instName = builder.getDefaultInstanceName();
199             instance_flags |= IrisInstance::UNIQUEIFY;
200         }
201
202         std::vector<InstantiationParameterValue> param_values;
203         req.getOptionalArg(ISTR("paramValues"), param_values);
204
205         // Build the full parameter info list
206         const std::vector<ResourceInfo>& param_info = builder.getParameterInfo();
207         const std::vector<ResourceInfo>& hidden_param_info = builder.getHiddenParameterInfo();
208
209         std::vector<ResourceInfo> all_param_info;
210         all_param_info.insert(all_param_info.end(), param_info.begin(), param_info.end());
211         all_param_info.insert(all_param_info.end(), hidden_param_info.begin(), hidden_param_info.end());
212
213         IrisInstantiationContext init_context(&connection_interface, result,
214                                             all_param_info, param_values,
215                                             builder.getInstanceNamePrefix(),
216                                             instName, instance_flags);
217
218         // Parameters have been validated. If they all passed we can instantiate the plugin.
219
220         if (result.success)
221         {
222             try
223             {
224                 std::lock_guard<std::mutex> lock(plugin_instances_mutex);
225
226                 plugin_instances.push_back(new PLUGIN_CLASS(init_context));
227
228                 if (!result.success)
229                 {
230                     // The plugin instance set an error in its constructor so destroy it.
231                     delete plugin_instances.back();
232                     plugin_instances.pop_back();
233                 }
234             }
235             catch (IrisErrorException& e)
236             {
237                 result.success = false;
238                 result.errors.resize(result.errors.size() + 1);
239
240                 InstantiationError& error = result.errors.back();
241                 error.severity = "error";
242                 error.code = "error_general_error";
243                 error.message = e.getMessage();
244             }
245             catch (...)
246             {
247                 result.success = false;
248                 result.errors.resize(result.errors.size() + 1);
249
250                 InstantiationError& error = result.errors.back();
251                 error.severity = "error";

```

```

258         error.code           = "error_general_error";
259         error.message        = "Internal error while instantiating plugin";
260     }
261 }
262
263     factory_instance.sendResponse(req.generateOkResponse(result));
264 }
265
266 public:
267     IrisPluginFactory(IrisC_Functions* iris_c_functions, const std::string& plugin_name)
268         : connection_interface(iris_c_functions)
269         , factory_instance(&connection_interface)
270         , builder(plugin_name)
271     {
272         PLUGIN_CLASS::buildPluginFactory(builder);
273
274         typedef IrisPluginFactory<PLUGIN_CLASS> Self;
275
276         factory_instance.irisRegisterFunction(this, Self, plugin_getInstantiationParameterInfo,
277                                             function_info::plugin_getInstantiationParameterInfo);
278
279         factory_instance.irisRegisterFunction(this, Self, plugin_instantiate,
280                                             "{description:'Instantiate an instance of the " +
281                                             builder.getPluginName() +
282                                             " plugin', "
283                                             "args:{
284                                             "   instName:{type:'String', description:'Used to
285                                             construct the instance name for the new instance."
286                                             "   Instance name will be \"
287                                             + builder.getInstanceNamePrefix() +
288                                             "<instName>\", "
289                                             "defval:\"
290                                             + builder.getDefaultInstanceName() +
291                                             "\", optional:true}, "
292                                             "   paramValues:{type:'Array',
293                                             description:'Instantiation parameter values'}"
294                                             "}, "
295                                             "retval:{type:'InstantiationResult',
296                                             description:'Indicates success of and errors/warnings'
297                                             " that occurred during plugin instantiation.'}}");
298
299         // Register factory instance
300         uint64_t flags = IrisInstance::DEFAULT_FLAGS
301             | IrisInstance::UNIQUEIFY;
302
303         std::string factory_instName = "framework.plugin." + builder.getPluginName() + "Factory";
304         factory_instance.registerInstance(factory_instName, flags);
305         factory_instance.setProperty("componentType", "IrisPluginFactory");
306
307         IrisLogger log("IrisPluginFactory");
308     }
309
310 ~IrisPluginFactory()
311 {
312     {
313         std::lock_guard<std::mutex> lock(plugin_instances_mutex);
314
315         // Clean up plugin instances
316         typename std::vector<PLUGIN_CLASS*>::iterator it;
317         for (it = plugin_instances.begin(); it != plugin_instances.end(); ++it)
318         {
319             delete *it;
320         }
321     }
322 }
323
324 // Unregister factory instance. Call this when unloading a plugin before simulation termination.
325 IrisErrorCode unregisterInstance()
326 {
327     return factory_instance.unregisterInstance();
328 }
329
330 // Implementation of the plugin entry point.
331 // This will initialize an IrisPluginFactory the first time it is called.
332 static int64_t initPlugin(IrisC_Functions* functions, const std::string& plugin_name)
333 {
334     static IrisPluginFactory<PLUGIN_CLASS>* factory = nullptr;
335
336     if (factory == nullptr)
337     {
338         factory = new IrisPluginFactory<PLUGIN_CLASS>(functions, plugin_name);
339         return E_ok;
340     }
341     else
342     {
343         return E_plugin_already_loaded;
344     }
345 }

```

```

341     }
342 };
343
344 #define IRIS_PLUGIN_FACTORY(PluginClassName) \
345     extern "C" IRIS_EXPORT int64_t irisInitPlugin(IrisC_Functions* functions) \
346     { \
347         return ::iris::IrisPluginFactory<PluginClassName>::initPlugin(functions, #PluginClassName); \
348     } \
349
350 // --- Non-factory plugin support. ---
351 // Non-factory plugins are plugins which instantiate themselves directly in the entry point function.
352 // There is no factory instance. The singleton instance is the plugin rather than used to instantiate
353 // the plugins.
354 // They cannot receive parameters and cannot be instantiated multiple times.
355 // These are usually very simple singleton plugins.
356
357 template<class PLUGIN_CLASS>
358 class IrisNonFactoryPlugin
359 {
360 public:
361     IrisNonFactoryPlugin(IrisC_Functions* functions, const std::string& pluginName)
362         : connectionInterface(functions)
363         , instantiationContext(&connectionInterface, instantiationResult,
364             std::vector<iris::ResourceInfo>(), std::vector<iris::InstantiationParameterValue>(), "client.plugin",
365             pluginName, iris::IrisInstance::DEFAULT_FLAGS | iris::IrisInstance::UNIQUEIFY)
366         , plugin(instantiationContext)
367     {
368     }
369
370     // Implementation of the plugin entry point.
371     // This will instantiate a new plugin.
372     static int64_t initPlugin(IrisC_Functions* functions, const std::string& pluginName)
373     {
374         new IrisNonFactoryPlugin<PLUGIN_CLASS>(functions, pluginName);
375         return E_ok;
376     }
377
378 private:
379     iris::IrisCConnection connectionInterface;
380     iris::IrisInstantiationContext instantiationContext;
381     PLUGIN_CLASS plugin;
382     iris::InstantiationResult instantiationResult;
383 };
384
385 #define IRIS_NON_FACTORY_PLUGIN(PluginClassName) \
386     extern "C" IRIS_EXPORT int64_t irisInitPlugin(IrisC_Functions* functions) \
387     { \
388         return ::iris::IrisNonFactoryPlugin<PluginClassName>::initPlugin(functions, #PluginClassName); \
389     } \
390
391 namespace IRIS_END
392
393 #endif // ARM_INCLUDE_IrisPluginFactory_h

```

## 9.55 IrisRegisterEventEmitter.h File Reference

Utility classes for emitting register read and register update events.

```
#include "iris/detail/IrisCommon.h"
```

```
#include "iris/detail/IrisRegisterEventEmitterBase.h"
```

### Classes

- class `iris::IrisRegisterReadEventEmitter< REG_T, ARGS >`  
An *EventEmitter* class for register read events.
- class `iris::IrisRegisterUpdateEventEmitter< REG_T, ARGS >`  
An *EventEmitter* class for register update events.

### 9.55.1 Detailed Description

Utility classes for emitting register read and register update events.

## Copyright

Copyright (C) 2016 Arm Limited. All rights reserved.

## 9.56 IrisRegisterEventEmitter.h

[Go to the documentation of this file.](#)

```

1
2 #ifndef ARM_INCLUDE_IrisRegisterEventEmitter_h
3 #define ARM_INCLUDE_IrisRegisterEventEmitter_h
4
5 #include "iris/detail/IrisCommon.h"
6 #include "iris/detail/IrisRegisterEventEmitterBase.h"
7
8 NAMESPACE_IRIS_START
9
10 template <typename REG_T, typename... ARGS>
11 class IrisRegisterReadEventEmitter : public IrisRegisterEventEmitterBase
12 {
13 public:
14     IrisRegisterReadEventEmitter()
15         : IrisRegisterEventEmitterBase(sizeof...(ARGS) + 3)
16     {
17     }
18
19     void operator()(ResourceId rscId, bool debug, REG_T value, ARGS... args)
20     {
21         // Emit event
22         emitEvent(rscId, debug, value, args...);
23
24         // Check if this event indicates a breakpoint was hit
25         if (!debug)
26         {
27             checkBreakpointHit(rscId, value, /*is_read=*/true);
28         }
29     }
30 };
31
32 template <typename REG_T, typename... ARGS>
33 class IrisRegisterUpdateEventEmitter : public IrisRegisterEventEmitterBase
34 {
35 public:
36     IrisRegisterUpdateEventEmitter()
37         : IrisRegisterEventEmitterBase(sizeof...(ARGS) + 4)
38     {
39     }
40
41     void operator()(ResourceId rscId, bool debug, REG_T old_value, REG_T new_value, ARGS... args)
42     {
43         // Emit event
44         emitEvent(rscId, debug, old_value, new_value, args...);
45
46         // Check if this event indicates a breakpoint was hit
47         if (!debug)
48         {
49             checkBreakpointHit(rscId, new_value, /*is_read=*/false);
50         }
51     }
52 };
53
54 NAMESPACE_IRIS_END
55 #endif // ARM_INCLUDE_IrisRegisterEventEmitter_h

```

## 9.57 IrisTcpClient.h File Reference

IrisTcpClient Type alias for IrisClient.

```
#include "iris/IrisClient.h"
```

### Typedefs

- using **iris::IrisTcpClient** = IrisClient  
*Alias for backward compatibility.*

### 9.57.1 Detailed Description

IrisTcpClient Type alias for IrisClient.

Date

Copyright ARM Limited 2022 All Rights Reserved.

## 9.58 IrisTcpClient.h

[Go to the documentation of this file.](#)

```
1
7 #ifndef ARM_INCLUDE_IrisTcpClient_h
8 #define ARM_INCLUDE_IrisTcpClient_h
9
10 #include "iris/IrisClient.h"
11
12 namespace IRIS_START
13
14 using IrisTcpClient = IrisClient;
15
16
17 namespace IRIS_END
18
19 #endif // #ifndef ARM_INCLUDE_IrisTcpClient_h
```



